

MB-662

LPX- size Intel FC-370 Pentium III
CPU Card with LCD, LAN, Audio,
4 COMs & SSD.

Copyright Notice

This document is copyrighted, 2000. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, nor for any infringements upon the rights of third parties which may result from its use.

The material in this document is for information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, AAEON, assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

AAEON reserves the right to make changes in the product design without notice to its users.

Acknowledgements

AMD is a trademark of Advanced Micro Devices, Inc.

AMI is a trademark of American Megatrends, Inc.

Award is a trademark of Award Software International, Inc.

IBM, PC/AT, PS/2, and VGA are trademarks of International Business Machines Corporation.

Intel and Pentium III are trademarks of Intel Corporation.

Microsoft Windows® is a registered trademark of Microsoft Corp.

SMC is a trademark of Standard Microsystems Corporation.

RTL is a trademark of Realtek Semi-Conductor Co., Ltd.

A Message to the Customer

AAEON Customer Services

Each and every AAEON product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new AAEON equipment is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name AAEON has come to be known.

Your satisfaction is our primary concern. Here is a guide to AAEON's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical Support

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally more detailed than the ones we can give over the phone.

So please consult this manual first. If you still cannot find the answer, gather all the information or questions that apply to your problem, and with the product close at hand, call your dealer. Our dealers are well trained and ready to give you the support you need to get the most from your AAEON products. In fact, most problems reported are minor and are able to be easily solved over the phone.

In addition, free technical support is available from AAEON engineers every business day. We are always ready to give advice on application requirements or specific information on the installation and operation of any of our products.

Product Warranty

AAEON warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of shipment.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by AAEON, or which have been subject to misuse, abuse, accident or improper installation. AAEON assumes no liability under the terms of this warranty as a consequence of such events.

Because of AAEON's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an AAEON product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time, and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU type and speed, AAEON products used, other hardware and software used, etc.) Note anything abnormal and list any on-screen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return material authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

C&T is a trademark of Chips and Technologies, Inc.
UMC is a trademark of United Microelectronics Corporation.
ITE is a trademark of Integrated Technology Express, Inc.
SiS is a trademark of Silicon Integrated Systems Corp.
VIA is a trademark of VIA Technology, Inc.
Intel is a trademark of Intel

All other product names or trademarks are properties of their respective owners.

Packing list

Before you begin installing your card, please make sure that the following materials have been shipped:

- 1 MB-662 LPX- size Single Board Computer Card
- 1 Quick Installation Guide
- 1 Support CD contains the followings:
 - User's Manual (this manual in PDF file)
 - Ethernet, Audio, VGA drivers and utilities
- 1 hard disk drive (IDE) interface cable (44-pin, pitch 2.0mm)
- 1 floppy disk drive interface cable (34-pin, pitch 2.0mm)
- 1 IDE cable (40-pin, pitch 2.54mm)
- 1 parallel port (26-25-pin, pitch 2.0mm) and serial port (10-9 pin, pitch 2.0mm) adapter kit.
- 1 bag of screws and miscellaneous parts

If any of these items are missing or damaged, contact your distributor or sales representative immediately.

Notice

Dear Customer,

Thank you for purchasing the MB-662 board. This user's manual is designed to help you to get the most out of the MB-662, please read it thoroughly before you install and use the board. The product that you have purchased comes with an two-year limited warranty, but AAEON will not be responsible for misuse of the product. Therefore, we strongly urge you to first read the manual before using the product.

To receive the latest version of the user manual, please visit our Web site at:

<http://www.aaeon.com>

Contents

Chapter 1: General Information	1
Introduction	2
Features	3
Specifications	4
Board layout	7
Board dimensions	8
Chapter 2: Installation	9
Setting Jumpers	10
CPU installing and upgrading.....	11
Installing DRAM (DIMMs)	13
Locating Jumpers and Connectors	14
List of Jumpers	15
List of Connectors	16
Clear CMOS (JP1)	17
LCD Panel Voltage Setting (JP6).....	17
LCD Clock Signal Selection (JP7)	18
Ethernet Tx/Rx/Link LED Connector (JP8)	18
COM4 RS-232/422/485 Selection (JP10)	19
Speaker/Buzzer (JP12)	19
System Status LED Pin Header (JP13)	20
DOC Address Selection (JP15)	21
IR Touch Screen Power Pin Header (JP16)	22
100/66 MHz Frequency Selection (JP17)	22
Keyboard Lock (JP18)	22
ATX Power Connector (CN2)	23
Display Connectors (CN3,12)	23
VGA Display Connector (CN3).....	24
LCD Display Connector (CN12)	25
USB Connector (CN6)	26
Floppy Drive Connector (CN7, 9)	27

IrDA Connector (CN8)	28
Floppy Drive Connector (CN9)	29
Parallel Port 1 & 2 (CN10, 21)	29
Keyboard and Mouse Connector (CN11)	31
CPU and System Fan Power Connector (CN13, 24)	31
RJ-45 Ethernet Connector (CN14)	32
IDE hard drive connector (CN16 & 17)	33
Serial Port COM1 (CN22)	36
LCD Inverter Backlight Power Connector (CN25)	36
Digital I/O Connector (CN29)	37
Serial Port COM2 Connectors(CN30)	37
Serial Port COM3 Connectors(CN32).....	38
Serial Port COM4 Connectors(CN31).....	38
Joystick/MIDI Port (CN33)	39
Audio Connector for CD_In (CN34).....	39
Phone Jack for Line_Out (CN35).....	40
Phone Jack for MIC (CN36).....	40
Phone Jack for Line_In (CN37).....	41
Chapter 3: Award BIOS Setup.....	42
Starting setup.....	43
Setup keys.....	44
Getting help	45
In case of problem	45
Main setup menu	46
Standard CMOS setup	48
BIOS features setup	54
CHIPSET features setup	59
Power management setup	64
PNP/PCI configuration setup	69
Load BIOS defaults/Load setup defaults	71
Integrated peripherals setup.....	72

Supervisor/User password setting	76
IDE HDD auto detection	78
Save & exit setup	79
Chapter 4: Flat Panel/CRT controller Display Drivers	
and Utilities	80
Software drives	81
Hardware configuration	81
Necessary prerequisites	82
Before you begin	82
Windows 95	83
Driver installation	83
Windows 3.1	91
OS/2.....	92
Windows 3.51.....	94
Windows 98.....	95
Windows NT 4.0	96
Driver installation	96
Chapter 5: Ethernet Software configuration	
.....	97
Windows 98 Driver Installation.....	98
Ethernet software configuration	99
Chapter 6: Audio Software configuration.....	
Audio Software configuration.....	101
Windows 98.....	101
Windows NT 4.0.....	104
Appendix A: Programming the Watchdog Timer.....	
Programming the watchdog timer	106
Watchdog timer	106
Configuration register	107