

SERVICE MANUAL

notebook



Notebook Computer
5600D
Service Manual

Notice

The company reserves the right to revise this publication or to change its contents without notice. Information contained herein is for reference only and does not constitute a commitment on the part of the manufacturer or any subsequent vendor. They assume no responsibility or liability for any errors or inaccuracies that may appear in this publication nor are they in anyway responsible for any loss or damage resulting from the use (or misuse) of this publication.

This publication and any accompanying software may not, in whole or in part, be reproduced, translated, transmitted or reduced to any machine readable form without prior consent from the vendor, manufacturer or creators of this publication, except for copies kept by the user for backup purposes.

Brand and product names mentioned in this publication may or may not be copyrights and/or registered trademarks of their respective companies. They are mentioned for identification purposes only and are not intended as an endorsement of that product or its manufacturer.

Version 1.0
November 2002

Trademarks

Intel® and **Pentium®** are registered trademarks of Intel Corporation.

Windows® is a registered trademark of Microsoft Corporation.

Other brand and product names are trademarks and/or registered trademarks of their respective companies.

About this Manual

This manual is intended for service personnel who have completed sufficient training to undertake the maintenance and inspection of personal computers.

It is organized to allow you to look up basic information for servicing and/or upgrading components of the computer.

The following information is included:

Chapter 1, Introduction, provides general information about the location of system elements and their specifications.

Chapter 2, Disassembly, provides step-by-step instructions for disassembling parts and subsystems and how to upgrade elements of the system.

Appendix A, Part Lists

Appendix B, Schematic Diagrams

Preface

Related Documents

You may also need to consult the following manual for additional information:

User's Manual on CD

This describes the computer's features and the procedures for operating the computer and its ROM-based setup program. It also describes the installation and operation of the utility programs provided with the computer.

Contents

| | |
|---|------------|
| Introduction | 1-1 |
| Overview | 1-1 |
| System Specifications | 1-2 |
| Processor | 1-2 |
| Core Logic | 1-2 |
| Structure | 1-2 |
| Security | 1-2 |
| Memory | 1-2 |
| BIOS | 1-2 |
| LCD | 1-2 |
| Display | 1-3 |
| Storage | 1-3 |
| Audio | 1-3 |
| PC Card | 1-3 |
| Interface | 1-4 |
| Communication | 1-4 |
| Power Management | 1-4 |
| Power | 1-5 |
| Indicators | 1-5 |
| Environmental Spec | 1-5 |
| Physical Dimensions | 1-5 |
| Weight | 1-5 |
| Optional | 1-5 |
| External Locator - Top Views | 1-6 |
| Front View | 1-7 |
| External Locator - Right & Rear Views | 1-8 |
| External Locator - Bottom View | 1-9 |
| Mainboard Overview - Top | 1-10 |
| Key Parts | 1-10 |

| | |
|-----------------------------------|------|
| Mainboard Overview - Bottom | 1-11 |
| Key Parts | 1-11 |
| Mainboard Overview - Top | 1-12 |
| Cable Connectors | 1-12 |
| Mainboard Overview - Bottom | 1-13 |
| Cable Connectors | 1-13 |

Disassembly 2-1

| | |
|--|-----|
| Overview | 2-1 |
| Maintenance Tools | 2-2 |
| Connections | 2-2 |
| Maintenance Precautions | 2-3 |
| Cleaning | 2-3 |
| Disassembly Steps | 2-4 |
| To remove the Battery: | 2-4 |
| To remove the Bay One Device: | 2-4 |
| To remove the Hard Disk Drive: | 2-4 |
| To remove the Bay Two Device: | 2-4 |
| To remove the Keyboard: | 2-4 |
| To remove the System Memory: | 2-4 |
| To remove the CPU: | 2-4 |
| To remove the Modem: | 2-4 |
| To remove the Wireless LAN Module: | 2-4 |
| To remove the Palm Rest: | 2-4 |
| To remove the Bottom Case: | 2-4 |
| To remove the Audio “DJ” Module: | 2-5 |
| To remove the HDD Converter Board: | 2-5 |
| To remove the Mainboard: | 2-5 |
| To remove the DC/DC Board: | 2-5 |
| To remove the Click Board: | 2-5 |
| To remove the TouchPad: | 2-6 |
| To remove the LED Board: | 2-6 |

| | |
|---|------|
| To remove the Speakers: | 2-6 |
| To remove the Inverter: | 2-6 |
| To remove the LCD panel: | 2-6 |
| Removing the Battery | 2-7 |
| Removing the Bay One Device | 2-8 |
| Removing the Hard Disk Drive Assembly | 2-9 |
| Removing the Bay Two Device | 2-10 |
| Removing the Keyboard | 2-11 |
| Removing the System Memory | 2-12 |
| Removing the CPU | 2-13 |
| Removing the Modem | 2-15 |
| Removing the Wireless LAN Module | 2-15 |
| Removing the Palm Rest | 2-16 |
| Removing the Bottom Case | 2-17 |
| Removing the Audio "DJ" Module | 2-19 |
| Removing the HDD Converter Board | 2-20 |
| Removing the Mainboard | 2-21 |
| Removing the DC/DC Board | 2-23 |
| Removing the Click Board | 2-24 |
| Removing the TouchPad | 2-24 |
| Removing the LED Board | 2-25 |
| Removing the Speakers | 2-25 |
| Removing the Inverter | 2-26 |
| Removing the LCD Panel | 2-27 |

Part Lists A-1

| | |
|---------------------------------------|-----|
| Part List Illustration Location | A-2 |
| Top (5600D) | A-3 |
| Bottom (5600D) | A-4 |
| LCD 15" (5600D) | A-5 |
| Battery (5600D) | A-6 |
| Second Battery (5600D) | A-7 |

Preface

| | |
|---------------------------------|------|
| TEAC CD-ROM Drive (5600D) | A-8 |
| KME CD-RW Drive (5600D) | A-9 |
| Combo Drive (5600D) | A-10 |
| DVD-ROM Drive (5600D) | A-11 |
| Audio DJ (5600D) | A-12 |
| Floppy Disk Drive (5600D) | A-13 |
| Top (5620D) | A-14 |
| Bottom (5620D) | A-15 |
| LCD 15" (5620D) | A-16 |
| Battery (5620D) | A-17 |
| Second Battery (5620D) | A-18 |
| TEAC CD-ROM Drive (5620D) | A-19 |
| KME CD-RW Drive (5620D) | A-20 |
| Combo Drive (5620D) | A-21 |
| DVD-ROM Drive (5620D) | A-22 |
| Audio DJ (5620D) | A-23 |
| Floppy Disk Drive (5620D) | A-24 |
| Top (5800D) | A-25 |
| Bottom (5800D) | A-26 |
| LCD 15" (5800D) | A-27 |
| Battery (5800D) | A-28 |
| Second Battery (5800D) | A-29 |
| TEAC CD-ROM Drive (5800D) | A-30 |
| KME CD-RW Drive (5800D) | A-31 |
| Combo Drive (5800D) | A-32 |
| DVD-ROM Drive (5800D) | A-33 |
| Audio DJ (5800D) | A-34 |
| Floppy Disk Drive (5800D) | A-35 |
| Top (5820D) | A-36 |
| Bottom (5820D) | A-37 |
| LCD 15" (5820D) | A-38 |
| Battery (5820D) | A-39 |

| | |
|---------------------------------|------|
| Second Battery (5820D) | A-40 |
| TEAC CD-ROM Drive (5820D) | A-41 |
| KME CD-RW Drive (5820D) | A-42 |
| Combo Drive (5820D) | A-43 |
| DVD-ROM Drive (5820D) | A-44 |
| Audio "DJ" (5820D) | A-45 |
| Floppy Disk Drive (5820D) | A-46 |

Schematic DiagramsB-1

| | |
|-----------------------------------|------|
| System Block Diagram | B-2 |
| CPU (Northwood) 1 of 2 | B-3 |
| CPU (Northwood) 2 of 2 | B-4 |
| MCH845 Power & Ground | B-5 |
| MCH845 Memory Interface | B-6 |
| Clock Generator | B-7 |
| DDRAM | B-8 |
| DDR Termination | B-9 |
| Mobility P7 | B-10 |
| Mobility Mem A; Term; LVDS | B-11 |
| Mobility Mem B; CRT; TV Out | B-12 |
| ICH3 (1 of 3) | B-13 |
| ICH3 (2 of 3) | B-14 |
| ICH3 (3 of 3) | B-15 |
| HDD/CDROM/FDD | B-16 |
| Mini PCI; MDC Modem | B-17 |
| LAN RTL8139CL | B-18 |
| TI1394 TSB43AB22 | B-19 |
| NS-PC87393; IR; ROM | B-20 |
| H8 | B-21 |
| KBC Conn; Fan Conn | B-22 |
| ACIN; PWR Button | B-23 |
| AC'97 AD1886 | B-24 |

Preface

| | |
|----------------------|------|
| PCI 1410 | B-25 |
| PCMCIA Socket | B-26 |
| CPU Core Power | B-27 |
| D/D Conn | B-28 |
| +3V; +5V | B-29 |
| USB 2.0 | B-30 |

1: Introduction

Overview

This manual covers the information you need to service or upgrade the 5600D/5620D/5800D/5820D notebook computer. Information about operating the computer (e.g. getting started, and the *Setup* utility) is in the *User's Manual*. Information about drivers (e.g. VGA & audio) is also found in *User's Manual*. That manual is shipped with the computer.

Operating systems (e.g. *DOS*, *Windows 9x*, *Windows NT 4.0*, *Windows 2000*, *Windows XP*, *OS/2 Warp*, *UNIX*, etc.) have their own manuals as do application software (e.g. word processing and database programs). If you have questions about those programs, you should consult those manuals.

The 5600D/5620D/5800D/5820D notebook is designed to be upgradeable. See “***Disassembly***” on page 2 - 1 for a detailed description of the upgrade procedures for each specific component. Please note the warning and safety information indicated by the “” symbol.

The balance of this chapter reviews the computer's technical specifications and features.

Introduction

System Specifications

Processor

- Intel Pentium 4 Processor - (478-pin) FC-PGA2 package
(μ0.13) 0.13 Micron Process Technology - 2.0/2.2/2.26/2.4/2.5/2.53/2.6/2.66/2.8 GHz
- Intel Celeron Processor - (478-pin) uPGA package
(μ0.13) 0.13 Micron Process Technology - 1.7/1.8 GHz

Core Logic

- Intel® 845E

Structure

- All-in-one
- Compliant to PC99 standard

Security

- Security (Kensington® type) Lock Slot

Memory

- Two 200Pin SODIMM sockets, DDR200/266 MHz DDR devices
- Expandable memory up to 1024 MB, depends on 128/256/512MB SODIMM Modules

BIOS

- One 512KB Flash ROM
- Phoenix BIOS

LCD

- 14.1" XGA 1024x768/ SXGA+ 1400x1050, 15.0" XGA 1024X768, 15.0" SXGA+ 1400x1050, 15.0" UXGA 1600x1200, 15.0" QXGA 2048x1536

Display

- ATI Mobility Radeon 9000 high performance chip
- Support AGP™ 4X
- Integrated 128-bit 2D / 3D Graphics Accelerator
 - Advanced HW Acceleration for DVD Playback
 - Fully DirectX 8.1 with Hardware
- External memory up to 32/64 MB DDR SGRAM on board
- Dual-view Display Monitor
- Support resolution up to 2048x1536

Storage

- 3.5" 3-mode FDD, and secondary battery bay one only
- DVD-ROM 12.7mm (h), OR CD-ROM 12.7mm (h), OR CD-RW 12.7mm (h), OR Combination DVD-ROM / CD-RW 12.7mm (h) drive for all bays
- Easy changeable 2.5" 9.5 mm (h) HDD
- Support Master mode IDE, support PIO mode 4 / ATA-33/66/100 (Ultra DMA)

Audio

- AC'97 2.1 Compliant Interface
- 3D stereo enhanced sound system
- Compatible Sound-Blaster PRO™
- S/PDIF Digital output (5.1 CH)
- Built in microphone
- Audio DJ
- Built in 2 speakers 1 watt 36F, 8O

PC Card

- One PCMCIA 3.3V/5V sockets, one type II
- Supports CardBus

Introduction

Interface

- Built in TouchPad (Scroll functionality included)
- Four USB ports
- One IEEE 1394 port
- One S-Video jack for TV output
- One parallel port (LPT1), support ECP/EPP
- Infrared file transfer, IrDA 1.1 FIR/SIR/ASKIR
- External CRT monitor
- One PS/2 port support mouse and keyboard (through Y cable)
- One headphone-out jack
- One microphone-in jack
- One RJ-11 jack for MDC Modem
- One RJ-45 jack for LAN
- DC-in jack
- Built-in 3 instant keys, www, email, and Player

Communication

- Infrared transfer: 115.2K bps SIR/ 4M bps FIR, 1cm ~ 1M operating distance, IrDA 1.1 compliant
- 10/100Mb Ethernet LAN built-in
- 802.11b Wireless LAN mini-PCI interface (option)
- 56K MDC Modem with V.90 & V.92 compliant

Power Management

- Supports ACPI v1.0b
- Supports suspend to RAM (S3)
- Supports suspend to disk (S4)
- Modem resume from system suspend
- Cover switch

Power

- Full Range AC adapter - AC in 100~240V, 50~60Hz DC Output 20V, 6.0A. 120W
- Main battery smart Li-Ion 59W (removable)
- Second battery smart Li-Ion 50W (removable)

Indicators

- LED indicator (HDD, Suspend/Power on/ AC-In, Battery Charging/Battery full, E-mail, Num Lock, Caps Lock, Scroll Lock)

Environmental Spec

- | | |
|-------------------------------|--------------------------|
| • Temperature | Relative Humidity |
| • Operating: 5°C~35°C | Operating: 20% ~ 80% |
| • Non-Operating: -20°C ~ 60°C | Non-Operating: 10% ~ 90% |

Physical Dimensions

- 329 (w) x 290 (d) x 44 (h) mm

Weight

- 3.4 ~ 3.7 kg without battery

Optional



- Secondary battery pack
- DVD-ROM Drive
- CD-RW Drive
- DVD-ROM and CD-RW Combo Drive
- Software DVD Player
- Wireless LAN module

Introduction

Figure 1 - 1
Top Views

1. LCD
2. LED Power & E-Mail Indicators
3. Close Cover Switch
4. Speakers
5. Hot-Key buttons
6. LED Status Indicators
7. Power Button
8. Keyboard
9. TouchPad and Buttons
10. Palm Rest (Removable)
11. LCD Latch

External Locator - Top Views





Model A

 **Model Differences**

This manual refers to the two notebook models pictured on this page.

The models vary slightly in external design. Photographs used throughout this manual are of Model A.



Model B

Front View



Figure 1 - 2
Front View

1. LCD Latch
2. Audio "DJ" CD Player Control Panel On/Off Switch
3. Previous Track
4. Next Track
5. LCD
6. Play Pause
7. Stop
8. Volume Down
9. Volume Up
10. Built-In Microphone




Figure 1 - 3
Left Side View

1. DC-In Jack
2. Vent
3. PC Card Slot
4. PC Card Eject Button

Introduction

External Locator - Right & Rear Views

Figure 1 - 4
Right Side View

1. Device Bay One
2. Device Bay Two
3. Infrared Transceiver




Figure 1 - 5
Rear View

1. Security Lock
2. Microphone-In Jack
3. Headphone-Out Jack
4. S/PDIF Out Port
5. Mini - IEEE 1394 Port
6. 4 USB Ports
7. RJ-11 Phone Jack
8. RJ-45 LAN Jack
9. S-Video Connector
10. External Monitor (CRT) Port
11. Parallel Port
12. PS/2 Type Port
13. Vents



External Locator - Bottom View

Figure 1 - 6
Bottom View




1. Vent/Fan Outlets
2. Device Bay One
3. Device Bay One Release Latch
4. Device Bay Two
5. Battery
6. Battery Release Latch

Introduction

Figure 1 - 7
Mainboard
Overview - Top
Key Parts

1. 2 * SO-DIMM sockets
2. AC'97 Codec
3. TI 1394 Controller
4. Flash BIOS ROM
5. Audio DJ Controller
6. CMOS Battery
7. On-Board Video Memory

Mainboard Overview - Top Key Parts



Mainboard Overview - Bottom

Key Parts




Figure 1 - 8
Mainboard
Overview - Bottom
Key Parts

1. CPU Socket (no CPU installed)
2. VGA Chip - ATI M7-P
3. LAN Controller - RTL8139
4. Clock Generator
5. PCI Bus1410 Controller
6. Super IO NS87393
7. Southbridge Intel ICH3 421 EBGA
8. Northbridge Intel MCH 845-MP Brookdale 593 FCBGA
9. H8 Keyboard Controller
10. Audio AMP TI-TPA0132
11. On-Board Video Memory


Introduction

Figure 1 - 9
Mainboard
Overview - Top
Cable Connectors

1. JINTKB1 (Keyboard Connector)
2. JTP1 (TouchPad Connector)
3. JMDC1 (Modem Connector)
4. JSPK1 (Speaker Connector)
5. JLED1 (LED Connector)
6. JLCD1 (LCD Connector)
7. JBAT1 (CMOS Battery Connector)
8. JINV1 (Inverter Connector)
9. JLAN1 (LAN Connector)
10. JMINPCI1 (Wireless LAN Connector)
11. JFAN3 (Fan Connector)
12. JMIC1 (Microphone Connector)

Mainboard Overview - Top

Cable Connectors



Mainboard Overview - Bottom

Cable Connectors




Figure 1 - 10
Mainboard
Overview - Bottom
Cable Connectors

1. JHDD1 (Hard Disk Connector)
2. JFAN1 (Fan Connector)
3. JFAN2 (Fan Connector)
4. PCMCIA Connector
5. JCD1 (Bay One Device Connector)
6. JDD1 (DC/DC Board Connector)
7. JDD2 (DC/DC Board Connector)

Introduction

2: Disassembly

Overview

This chapter provides step-by-step instructions for disassembling parts and subsystems. When it comes to reassembly, reverse the procedures (unless otherwise indicated).

We suggest you completely review any procedure before you take the computer apart.

Procedures such as upgrading/replacing the RAM, CD device and hard disk are included in the User's Manual but are repeated here for your convenience.

To make the disassembly process easier each section may have a box in the page margin. Information contained under the figure # will give a synopsis of the sequence of procedures involved in the disassembly procedure. A box with a  lists the relevant parts you will have after the disassembly process is complete. **Note:** The parts listed will be for the disassembly procedure listed ONLY, and not any previous disassembly step(s) required. Refer to the part list for the previous disassembly procedure. The amount of screws you should be left with will be listed here also.

A box with a  will provide any possible helpful information. A box with a  contains warnings.

An example of these types of boxes are shown in the sidebar.



Disassembly

NOTE: All disassembly procedures assume that the system is turned **OFF**, and disconnected from any power supply (the battery is removed too).

Maintenance Tools

The following tools are recommended when working on the notebook PC:

- M3 Philips-head screwdriver
- M2.5 Philips-head screwdriver (magnetized)
- M2 Philips-head screwdriver
- Small flat-head screwdriver
- Pair of needle-nose pliers
- Anti-static wrist-strap

Connections

Connections within the computer are one of four types:

Locking collar sockets for ribbon connectors

To release these connectors, use a small flat-head screwdriver to gently pry the locking collar away from its base. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.

Pressure sockets for multi-wire connectors

To release this connector type, grasp it at its head and gently rock it from side to side as you pull it out. Do not pull on the wires themselves. When replacing the connection, do not try to force it. The socket only fits one way.

Pressure sockets for ribbon connectors

To release these connectors, use a small pair of needle-nose pliers to gently lift the connector away from its socket. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.

Board-to-board or multi-pin sockets

To separate the boards, gently rock them from side to side as you pull them apart. If the connection is very tight, use a small flat-head screwdriver - use just enough force to start.

Maintenance Precautions

The following precautions are a reminder. To avoid personal injury or damage to the computer while performing a removal and/or replacement job, take the following precautions:

1. **Don't drop it.** Perform your repairs and/or upgrades on a stable surface. If the computer falls, the case and other components could be damaged.
2. **Don't overheat it.** Note the proximity of any heating elements. Keep the computer out of direct sunlight.
3. **Avoid interference.** Note the proximity of any high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage components and/or data. You should also monitor the position of magnetized tools (i.e. screwdrivers).
4. **Keep it dry.** This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.
5. **Be careful with power.** Avoid accidental shocks, discharges or explosions.
 - Before removing or servicing any part from the computer, turn the computer off and detach any power supplies.
 - When you want to unplug the power cord or any cable/wire, be sure to disconnect it by the plug head. Do not pull on the wire.
6. **Peripherals** – Turn off and detach any peripherals. **Beware of static discharge.** ICs, such as the CPU and main support chips, are vulnerable to static electricity. Before handling any part in the computer, discharge any static electricity inside the computer. When handling a printed circuit board, do not use gloves or other materials which allow static electricity buildup. We suggest that you use an anti-static wrist strap instead.
7. **Beware of corrosion.** As you perform your job, avoid touching any connector leads. Even the cleanest hands produce oils which can attract corrosive elements.
8. **Keep your work environment clean.** Tobacco smoke, dust or other air-born particulate matter is often attracted to charged surfaces, reducing performance.
9. **Keep track of the components.** When removing or replacing any part, be careful not to leave small parts, such as screws, loose inside the computer.

Cleaning

Do not apply cleaner directly to the computer, use a soft clean cloth.

Do not use volatile (petroleum distillates) or abrasive cleaners on any part of the computer.



Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines). It is advisable to also remove your battery in order to prevent accidentally turning the machine on.

Disassembly

Disassembly Steps

The following table lists the disassembly steps, and on which page to find the related information. PLEASE PERFORM THE DISASSEMBLY STEPS IN THE ORDER INDICATED.

To remove the Battery:

1. Remove the battery [page 2 - 7](#)

To remove the Bay One Device:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)

To remove the Hard Disk Drive:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)

To remove the Bay Two Device:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay Two device [page 2 - 10](#)

To remove the Keyboard:

1. Remove the battery [page 2 - 7](#)
2. Remove the keyboard [page 2 - 11](#)

To remove the System Memory:

1. Remove the battery [page 2 - 7](#)
2. Remove the keyboard [page 2 - 11](#)
3. Remove the memory [page 2 - 12](#)

To remove the CPU:

1. Remove the battery [page 2 - 7](#)
2. Remove the CPU [page 2 - 13](#)

To remove the Modem:

1. Remove the battery [page 2 - 7](#)
2. Remove the keyboard [page 2 - 11](#)
3. Remove the modem [page 2 - 15](#)

To remove the Wireless LAN Module:

1. Remove the battery [page 2 - 7](#)
2. Remove the keyboard [page 2 - 11](#)
3. Remove the Wireless LAN module [page 2 - 15](#)

To remove the Palm Rest:

1. Remove the Palm Rest [page 2 - 16](#)

To remove the Bottom Case:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)

To remove the Audio “DJ” Module:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)
9. Remove the Audio “DJ” module [page 2 - 19](#)

To remove the HDD Converter Board:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)
9. Remove the Audio “DJ” module [page 2 - 19](#)
10. Remove the HDD converter board [page 2 - 20](#)

To remove the Mainboard:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)

9. Remove the Audio “DJ” module [page 2 - 19](#)
10. Remove the HDD converter board [page 2 - 20](#)
11. Remove the mainboard [page 2 - 21](#)

To remove the DC/DC Board:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)
9. Remove the Audio “DJ” module [page 2 - 19](#)
10. Remove the HDD converter board [page 2 - 20](#)
11. Remove the mainboard [page 2 - 21](#)
12. Remove the DC/DC board [page 2 - 23](#)

To remove the Click Board:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)
9. Remove the Click Board [page 2 - 24](#)

Disassembly

To remove the TouchPad:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)
9. Remove the TouchPad [page 2 - 24](#)

To remove the LED Board:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)
9. Remove the LED board [page 2 - 25](#)

To remove the Speakers:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)
9. Remove the speakers [page 2 - 25](#)

To remove the Inverter:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)
9. Remove the inverter [page 2 - 26](#)

To remove the LCD panel:

1. Remove the battery [page 2 - 7](#)
2. Remove the Bay One device [page 2 - 8](#)
3. Remove the hard disk drive assembly [page 2 - 9](#)
4. Remove the Bay Two device [page 2 - 10](#)
5. Remove the keyboard [page 2 - 11](#)
6. Remove the CPU [page 2 - 13](#)
7. Remove the Palm Rest [page 2 - 16](#)
8. Remove the bottom case [page 2 - 17](#)
9. Remove the LCD Panel [page 2 - 27](#)

Removing the Battery

1. With the computer shut down and on a level surface, raise the LCD cover.
2. Turn the computer over and locate the battery release latch **1** (*Figure 2 - 1a*).
3. Slide the battery release latch towards the unlock symbol.
4. The battery **2** will pop-up and can be lifted out of the computer.




Figure 2 - 1
Battery Removal
Sequence

- a. Slide the battery release latch to the unlock position.
- b. The battery will pop-up.
- c. Remove the battery.

Disassembly

Figure 2 - 2 Bay One Device Removal Sequence

- a. Slide the release latch to the unlock position and hold it in position.
- b. Partially slide the device out partially.
- c. Lift the device up and out of the computer.



2. Bay One Device

Removing the Bay One Device

1. Turn the computer OFF.
2. Place the computer on a clean, stable surface and turn it over.
3. Locate the release latch **1** (*Figure 2 - 2a*) for the Bay One device.
4. Slide the release latch towards the unlock symbol and hold it in position.
5. With the release latch held in position, slide the device out slightly, then lift it up out of the computer.





Figure 2 - 3
Hard Disk
Removal
Sequence

Removing the Hard Disk Drive Assembly

1. Turn the computer OFF and turn it over.
2. Remove the device in Bay One (see “[Removing the Bay One Device” on page 2 - 8](#)).
3. Remove screw ① ([Figure 2 - 3a](#)).
4. Slide the HDD assembly forward, then lift it up out of the computer.
5. Remove screws ② - ⑤ ([Figure 2 - 3e](#)) from the assembly, and slide the hard disk ⑦ out of the case ⑥.



- a. Remove the HDD assembly screw.
- b. Slide the HDD assembly in the direction of the arrow.
- c. Lift the HDD assembly up.
- d. Lift the HDD assembly out of the computer.
- e. Remove the screws and separate the HDD from the case.

 6. HDD case
7. HDD
• 5 Screws

Disassembly


Figure 2 - 4

Bay Two Device Removal Sequence

- a. Remove the screw from point **1**.
- b. Apply pressure to point **2** to slide the device out of the bay.

Removing the Bay Two Device

1. Turn **OFF** the computer.
2. Turn the computer over.
3. Remove screw **1** (*Figure 2 - 4a*)
4. Apply gentle but firm pressure at point **2** (*Figure 2 - 4b*), and slide the device out of the computer.



3. Bay Two device
• 1 Screw

Removing the Keyboard

1. Turn **OFF** the computer.
2. Press the two keyboard latches at the top of the keyboard to elevate the keyboard from its normal position as in **Figure 2 - 5a** (you may need to use a small screwdriver to do this).
3. Carefully lift the keyboard up and out, being careful not to bend the keyboard ribbon cable **③** (**Figure 2 - 5b**).
4. Disconnect the keyboard ribbon cable from the locking collar socket **③** (**Figure 2 - 5b**).







Figure 2 - 5
Keyboard
Removal
Sequence

- a. Press the two latches to release the keyboard.
- b. Lift the keyboard out and disconnect the cable from the locking collar.



Disassembly

Figure 2 - 6

Memory Removal Sequence

- a. Remove the screws from the shielding plate.
- b. Remove the shielding plate.
- c. Pull the latch(es) on the memory sockets to release the module(s).
- d. When the module pops up, lift it out.



1. Shielding plate
8. Memory module(s)
• 2 Screws




Contact Warning

Be careful not to touch the metal pins on the module's connecting edge. Even the cleanest hands have oils which can attract particles, and degrade the module's performance.


Removing the System Memory

1. Remove the keyboard (see [page 2 - 11](#)).
2. Remove screws **2** and **3** ([Figure 2 - 6a](#)) from the shielding plate, and lift the plate up **1** off the computer.
3. Locate the memory sockets **4** and **5** ([Figure 2 - 6c](#)), and gently pull latches **6** and **7** ([Figure 2 - 6c](#)) on the memory socket toward the sides of the computer as indicated in [Figure 2 - 6c](#).
4. The module **8** ([Figure 2 - 6d](#)) will pop-up, and you can remove it.
5. Insert a new module holding it at about a 30° angle and fit the connectors firmly into the memory slot.




Removing the CPU

1. Turn **OFF** the computer and turn it over.
2. Remove the screws **① - ⑤** (*Figure 2 - 7a*) from the CPU cover, and remove the CPU cover **⑥**.



3. Remove the five screws from the heat sink in order **① - ⑤** as indicated (*Figure 2 - 8*).



Caution

The heat sink, and CPU area in general, contains parts which are subject to high temperatures - Please allow the area time to cool before removing these parts).

Figure 2 - 7
**Processor
Removal
Sequence**

- a. Remove the five screws and the CPU cover.
- b. Remove the CPU cover.

Figure 2 - 8
**Processor
Removal
Sequence
(cont'd)**

Remove the five screws from the heat sink in **the order indicated**.



Reassembly Screw Order

When inserting a new or replacement CPU, make sure you insert the screws in the same order indicated in *Figure 2 - 8*.



- 6. CPU cover
- 10 Screws

Disassembly


Figure 2 - 9

Processor Removal Sequence (cont'd)


- Slide the heat sink forward slightly, and prise the unit upwards.
- Release the fan cables.
- Unlock the cpu and remove it.

- Use a screwdriver to apply pressure at point ② (*Figure 2 - 9a*) in order to carefully slide the heat sink ① forward slightly, and prise the unit upwards.
- Release the fan cables from points ③ - ④ (*Figure 2 - 9b*), and remove the heat sink.
- Unlock the processor by raising lever ⑤ (*Figure 2 - 9c*) to the fully vertical position, and carefully lift the processor ⑥ off the socket.


a.



b.



c.



1. Heat sink
6. CPU

Removing the Modem

1. Remove the keyboard ([see page 2 - 11](#)).
2. Remove screws **1** - **2** and carefully lift the modem **3** up off the mainboard ([Figure 2 - 10](#)).
3. Disconnect the modem cable **4** from the modem module.



Removing the Wireless LAN Module

1. Remove the keyboard ([see page 2 - 11](#)).
2. Gently pull latches **1** & **2** in the direction of the arrows ([Figure 2 - 11](#)) and the module will pop-up.
3. Carefully remove the wireless LAN module **5**, and disconnect the cables at points **3** & **4**.




Figure 2 - 10
Modem Removal
Sequence

Remove the screws, lift the modem off the mainboard, and disconnect the cable.

3. Modem
- 2 Screws

Figure 2 - 11
Wireless LAN
Module Removal
Sequence

Pull the latches, lift the module off the mainboard, and disconnect the cables.

5. Wireless LAN module

Disassembly

Figure 2 - 12

Palm Rest Removal Sequence

Apply gentle upward pressure with your fingers close to the area indicated, and lift the palm rest up.

Removing the Palm Rest


1. With the computer shut down and on a level surface, raise the LCD cover.
2. Remove the palm rest by applying gentle upward pressure with your fingers close to the area around the **left Alt** key, and the **right Ctrl** key (*Figure 2 - 12*).
3. To replace the palm rest **①**, slide it back in to place, and then apply slight downward pressure to points **②** and **③** in order to snap it gently back down.



1. Palm Rest


Removing the Bottom Case

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)) and palm rest ([page 2 - 16](#)).
2. Turn the computer over and remove screws **1** - **15** ([Figure 2 - 13](#)).



**Figure 2 - 13
Bottom Case
Removal
Sequence**

Remove the 15 screws from the bottom of the case.




Disassembly

Figure 2 - 14

Bottom Case Removal Sequence (cont'd)

Remove the six screws from the rear of the computer.

- Turn the computer around and remove screws ① - ⑥ (*Figure 2 - 14*) from the rear of the computer.




- Disconnect the inverter cable ①, touchpad cable ②, LED cable ③, LCD cable ④, Wireless LAN module ⑤ (if included) speaker cable ⑥ (*Figure 2 - 15*).
- Carefully lift the LCD and top case assembly ⑦ off the bottom case assembly ⑧.

Figure 2 - 15

Bottom Case Removal Sequence (cont'd)

- Remove the cables connected to the mainboard.
- Lift the LCD and top case off the bottom case.



- 7. LCD & Top Case
- 8. Bottom Case
- 6 Screws




b.



Removing the Audio "DJ" Module

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)) and bottom case ([page 2 - 17](#)).
2. When the top and bottom case assemblies are separated the Audio "DJ" module will be visible.
3. Disconnect the microphone cable **1**, the Audio "DJ" cable **2**, then carefully remove the Audio "DJ" module **3** ([Figure 2 - 16b](#)).
4. Remove screws **4** - **7** from the back of the Audio "DJ" board in order to separate the board **8** from the module **3** and power button **9** ([Figure 2 - 16c](#)).



*Figure 2 - 16
Audio "DJ"
Module Removal
Sequence*

- a. Disconnect the microphone and Audio "DJ" cables.
- b. Remove the module.
- c. Remove the 4 screws to separate the board, module and power button.



Disassembly

Figure 2 - 17


HDD Converter Board Removal Sequence

- a. Remove screws **①** - **⑥**.
- b. Remove the shielding plate, cover and HDD converter board.


Removing the HDD Converter Board

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)) bottom case ([page 2 - 17](#)) and Audio “DJ” module ([page 2 - 19](#)).
2. Remove screws **①** - **⑥** from the PCMCIA shielding plate and HDD converter board ([Figure 2 - 17](#)).
3. Carefully lift the PCMCIA shielding plate **⑦**, cover **⑧** and HDD converter board **⑨** away from the mainboard (be careful not to bend the pins in the HDD converter board when removing and inserting it).

a.




b.



- 7. PCMCIA Shielding Plate
- 8. Cover
- 9. HDD converter board
- 6 Screws

Removing the Mainboard

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)) bottom case ([page 2 - 17](#)), Audio "DJ" module ([page 2 - 19](#)) and HDD converter board ([page 2 - 20](#)).
2. Remove screws ① - ④ from the rear of the computer ([Figure 2 - 18a](#)).
3. Remove screws ⑤ - ⑬ (screws ⑫ & ⑬ hold the modem in place and will only need removed if you haven't already removed the modem module) from the mainboard ([Figure 2 - 18b](#)).
4. Disconnect the battery cable ⑭, fan cable ⑮ and LAN cable ⑯ ([Figure 2 - 18b](#)).



**Figure 2 - 18
Mainboard
Removal
Sequence**

- a. Remove screws 1 - 4.
- b. Remove screws 5 - 13, and disconnect cables 14 - 16.



- 13 Screws

2. Disassembly


Disassembly

Figure 2 - 19

Mainboard Removal Sequence (cont'd)

- a. Lift the mainboard assembly out of the bottom case.
- b. Separate the LAN and modem ports/cables.

5. Lift the mainboard **1** and DC/DC board **5** out of the bottom case **2** (*Figure 2 - 19a*).
6. If required, separate the LAN and modem ports and cables **3** from the bottom case.




1. Mainboard
2. Bottom case
3. LAN & modem ports/cables and modem
4. Bracket
5. DC/DC board




Removing the DC/DC Board

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)), bottom case ([page 2 - 17](#)), Audio "DJ" module ([page 2 - 19](#)), HDD converter board ([page 2 - 20](#)) and mainboard ([page 2 - 21](#)).
2. Turn the mainboard over and remove screws **1** - **2** ([Figure 2 - 20a](#)).
3. Carefully separate the DC/DC board **3** from the mainboard **4** ([Figure 2 - 20b](#)).

a.



b.



**Figure 2 - 20
DC/DC Board
Removal
Sequence**

a. Remove screws **1** - **2**.

b. Separate the mainboard from the DC/DC board.



3. DC/DC board
4. Mainboard

Disassembly

Figure 2 - 21
**Click Board
Removal
Sequence**

- a. Remove the screws and disconnect the cable.
- b. Lift the click board off the top case assembly.


6. Click board
• 4 Screws


Figure 2 - 22
**TouchPad
Removal
Sequence**

- a. Remove the screws and disconnect the cable.
- b. Lift the TouchPad and bracket off the top case assembly.


6. TouchPad
7. Bracket
• 4 Screws


Removing the Click Board

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)) and bottom case ([page 2 - 17](#)).
2. Turn the top case assembly over and remove screws **1** - **4**, and disconnect cable **5** ([Figure 2 - 21a](#)).
3. Lift the click board **6** off the top case assembly ([Figure 2 - 21b](#)).



Removing the TouchPad

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)) and bottom case ([page 2 - 17](#)).
2. Turn the top case assembly over and remove screws **1** - **4**, and disconnect cable **5** ([Figure 2 - 22a](#)).
3. Lift the TouchPad **6** and bracket **7** off the top case assembly ([Figure 2 - 22b](#)).



Removing the LED Board

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)) and bottom case ([page 2 - 17](#)).
2. Turn the top case assembly over and remove screws **1** - **5** from the LED board ([Figure 2 - 23a](#)).
3. Lift the LED board **6** off the top case assembly ([Figure 2 - 23b](#)).




Figure 2 - 23
LED Board
Removal
Sequence

- a. Remove the screws.
- b. Lift the LED board off the top case assembly.

- 
6. LED board
• 5 Screws

Removing the Speakers

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)), bottom case ([page 2 - 17](#)) and LED board (above).
2. Remove screws **1** - **4** from the speakers ([Figure 2 - 24a](#)).
3. Carefully lift the speakers **5** off the top case assembly ([Figure 2 - 24b](#)).




Figure 2 - 24
Speakers
Removal
Sequence

- a. Remove the screws.
- b. Lift the speakers off the top case assembly.

- 
5. Speakers
• 4 Screws


Disassembly

Figure 2 - 25 LCD Removal Sequence

- a. Remove the screws.
- b. Unsnap the LCD front panel from the back.
- c. Remove the screw from the inverter.
- d. Disconnect the cables and remove the inverter.

Removing the Inverter

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)) and bottom case ([page 2 - 17](#)).
2. Remove the rubber covers and screws **1** - **6** from the LCD ([Figure 2 - 25a](#)).
3. Run your finger around the middle of the frame to carefully unsnap the LCD front panel module **7** from the back ([Figure 2 - 25b](#)).
4. Remove screw **8** from the inverter, and disconnect cables **9** & **10** from the rear of the inverter ([Figure 2 - 25c](#)).
5. Lift the inverter **11** off the LCD assembly ([Figure 2 - 25d](#)).



7. LCD Front Panel
11. Inverter
• 7 Screws

Removing the LCD Panel

1. Remove the battery ([page 2 - 7](#)), bay one device ([page 2 - 8](#)), hard disk assembly ([page 2 - 9](#)), bay two device ([page 2 - 10](#)), keyboard ([page 2 - 11](#)) CPU ([page 2 - 13](#)), palm rest ([page 2 - 16](#)), bottom case ([page 2 - 17](#)) and inverter ([page 2 - 26](#)).
2. Remove screws **1** - **8** and lift the LCD panel **9** off the top assembly ([**Figure 2 - 26a**](#)).
3. Remove screws **10** - **17** to separate the LCD panel from the brackets **18** ([**Figure 2 - 25b**](#)).




Figure 2 - 26
LCD Removal
Sequence

- a. Remove the screws.
- b. Lift the panel off the assembly and remove the screws to release the brackets.


9. LCD Panel
18. 2 * Brackets
• 16 Screws

2. Disassembly

Disassembly

Appendix A: Part Lists

This appendix breaks down the notebook PC's construction into a series of illustrations. The component part numbers are indicated in the tables opposite the drawings.

Note: This section indicates the *manufacturer's* part numbers. Your organization may use a different system, so be sure to cross-check any relevant documentation.

Note: Some assemblies may have parts in common (especially screws). However, the part lists DO NOT indicate the total number of duplicated parts used.

Note: Be sure to check any update notices. The parts shown in these illustrations are appropriate for the system at the time of publication. Over the product life, some parts may be improved or re-configured, resulting in *new* part numbers.


Part Lists**Part List Illustration Location**

The following table indicates where to find the appropriate part list illustration.

*Table 1 - 1***Part List Illustration Location**

| Part | 5600D | 5620D | 5800D | 5820D |
|----------------|--------------------|--------------------|--------------------|--------------------|
| Top | <i>page A - 3</i> | <i>page A - 14</i> | <i>page A - 25</i> | <i>page A - 36</i> |
| Bottom | <i>page A - 4</i> | <i>page A - 15</i> | <i>page A - 26</i> | <i>page A - 37</i> |
| LCD 15" | <i>page A - 5</i> | <i>page A - 16</i> | <i>page A - 27</i> | <i>page A - 38</i> |
| Battery | <i>page A - 6</i> | <i>page A - 17</i> | <i>page A - 28</i> | <i>page A - 39</i> |
| Second Battery | <i>page A - 7</i> | <i>page A - 18</i> | <i>page A - 29</i> | <i>page A - 40</i> |
| TEAC CD-ROM | <i>page A - 8</i> | <i>page A - 19</i> | <i>page A - 30</i> | <i>page A - 41</i> |
| KME CD-RW | <i>page A - 9</i> | <i>page A - 20</i> | <i>page A - 31</i> | <i>page A - 42</i> |
| Combo | <i>page A - 10</i> | <i>page A - 21</i> | <i>page A - 32</i> | <i>page A - 43</i> |
| DVD-ROM | <i>page A - 11</i> | <i>page A - 22</i> | <i>page A - 33</i> | <i>page A - 44</i> |
| Audio DJ | <i>page A - 12</i> | <i>page A - 23</i> | <i>page A - 34</i> | <i>page A - 45</i> |
| FDD | <i>page A - 13</i> | <i>page A - 24</i> | <i>page A - 35</i> | <i>page A - 46</i> |

Top (5600D)




| ITEM | PART | NAME | PART NO | REMARK |
|------|----------------------------------|------|--------------|--------|
| 1 | KEYBOARD | | 80-56P08-7G0 | |
| 2 | SCREW M2.5*6L P BZ ICT NY | | 35-06125-6RA | |
| 3 | SHIELDING FOR KEYBOARD | | 33-56P07-010 | |
| 4 | HINGE (RIGHT) | | 33-56P01-070 | |
| 5 | FIXED BRACKET FOR CABLE | | 33-56P03-060 | |
| 6 | SPEAKER W/CABLE | | 23-53610-281 | |
| 7 | SCREW M2*5L P NI ICT NY W/WASHER | | 35-01020-2RE | |
| 8 | TOP CASE MODULE | | 39-56P02-010 | |
| 9 | M3*0.5P*4L K1 NI ICT NY | | 35-BI130-4R0 | |
| 10 | HINGE (LEFT) | | 33-56P01-080 | |
| 11 | LED BOARD | | 77-56P04-D0X | |
| 12 | FFC CABLE FOR LED&HOTKEY | | 43-56P02-020 | |
| 13 | SCREW M2*3L K1 NI ICT NY | | 35-BI120-3RA | |
| 14 | TOUCH PAD SYNAPTICS TM41PDG351-1 | | 49-42002-010 | |
| 15 | TOUCH PAD BRACKET | | 33-56P02-050 | |
| 16 | FFC CABLE FOR TOUCH PAD | | 43-56P02-010 | |
| 17 | FFC CABLE FOR CLICK | | 43-56P03-010 | |
| 18 | CLICK BOARD | | 77-56002-D0X | |
| 19 | PALMREST | | 42-56P72-030 | |
| 20 | SCREW M2*4L K1 NI ICT NY | | 35-BI120-4R0 | |


Figure 1 - 1
Top (5600D)

Part Lists

Bottom (5600D)

Figure 1 - 2
Bottom(5600D)

| ITEM | PART NO | NAME | PART NO | REMARK |
|------|--|----------------|---------|-------------------------------------|
| 1 | SCREW M2*3L K1 BK/D ICT NY | 35-B1120-3RA | | |
| 2 | MDC MODEM+TEL CABLE MODULE | 76-32200-100 | | |
| 3 | MAIN BOARD | 77-56D00-D06-M | | |
| 4 | SCREW M2.5*6L P BZ ICT NY | 35-06125-6RA | | |
| 5 | CPU HEATSINK MODULE | 31-56P0N-101 | | |
| 6 | SCREW | 35-41025-175 | | |
| 7 | WIRE CABLE FOR LAN AND MODEM | 43-56POU-010 | | |
| 8 | SCREW M2*4L F NI ICT NY | 35-21120-4RA | | |
| 9 | SCREW M2*2.5 P NI ICT NY W/WASHER | 35-01020-2RE | | |
| 10 | FAN 25*25*6.5T 5V 0.09A CON | 23-A2514-050 | | |
| 11 | SCREW M2.5*4 K1 BK/D ICT NY | 35-B4125-4RA | | |
| 12 | CPU COVER & SHIELDING PLATE MODULE P4 | 42-56P7S-102 | | |
| 13 | BATTERY S LI 4.0AH FOR SMP/SAMSUNG | 87-56P8S-4D3 | | Reference Ass'y No 099-56P0N-000 |
| 13 | BATTERY S LI 4.0AH FOR GLW/LG | 87-56P8S-4E3 | | Reference Ass'y No 099-56P0N-000 |
| 13 | BATTERY S LI 3.4AH FOR SMP/PANASONIC | 87-56P8S-4C1 | | Reference Ass'y No 099-56P0N-000 |
| 14 | PRODUCT LABEL(TUV) 5600D | 45-56103-010 | | |
| 15 | NON DJ KEL KNOB (FOR BATH/CD/DVD MINI SUM) | 42-56P78-A00 | | Reference Ass'y No 099-56P0N-101 |
| 16 | BOTTOM CASE-SHELDING PLATE MODULE | 39-56P03-012 | | |
| 17 | RUBBER PAD H=7mm (BACK) | 47-56P23-020 | | |
| 18 | FDD ASS'Y 5600P | 79-56P2J-010 | | Reference Ass'y No 099-56P0N-000 |
| 18 | CD-ROM ASS'Y 5600P | 79-56P2Z-010 | | Reference Ass'y No 099-56P0N-000 |
| 18 | DVD ROM ASS'Y 5600P | 79-56P2V-020 | | Reference Ass'y No 099-56P0N-000 |
| 19 | DC/DC BOARD | 77-56P0C-DOX | | |
| 20 | HEX H=16MM M=M2.5 | 34-56P03-010 | | |
| 21 | COSMETIC COVER (METAL) | 33-56P03-030 | | |
| 22 | HDD CONVERTER BOARD | 77-5600N-DOX | | |
| 23 | W/D HDD ASS'Y 5600P | 79-56P2I-010 | | |
| 24 | CD-RW ASS'Y 5600P | 79-56P2V-010 | | Reference Ass'y No 099-56P0N-000 |
| 24 | COMBO ASS'Y 5600P | 79-56P2X-010 | | Reference Ass'y No 099-56P0N-000 |
| 25 | HEATSINK FOR PCMCIA | 31-56P0N-020 | | |
| 26 | EMI GASKET(L18*W9*H3.5MM) | 47-00190-181 | | |
| 27 | FFC CABLE FOR AUDIO DJ MODULE | 43-56P0B-010 | | |


LCD 15" (5600D)

| ITEM | PART NAME | PART NO | REMARK |
|------|--|----------------|--------|
| 1 | RUBBER FOR LCD (MIDDLE) | 47-56P21-030 | |
| 2 | RUBBER FOR LCD (TOP) | 47-56P32-010 | |
| 3 | SCREW M2*6L P NI ICT NY | 35-01120-6RA | |
| 4 | LCD FRONT PANEL MODULE(15.1") | 39-56P01-013 | |
| 5 | LCD 15.0" SXGA TFT 101 SANYO 2048x1536 7.2mm | 50-L6272-E01 | |
| 6 | LCD BRACKET (LEFT SANYO-CPT 15.1") | 33-56P01-040 | |
| 7 | SCREW M2*3L KI NI ICT NY | 35-BI120-3RA | |
| 8 | SCREW M3*0.5P*4L KI NI ICT NY | 35-BI130-4R0 | |
| 9 | SCREW M3*0.5*7L KI NI ICT NY | 35-BI130-7R0 | |
| 10 | SPRING FOR HOOK (Φ3.7*15*0.3φ) | 38-21P30-011 | |
| 11 | HOOK KNOB | 42-56P81-011 | |
| 12 | 24GHZ DIPOLE ANTENNA Ø13.8MM L(RIGHT-LEFT) | 23-712R4-002 | |
| 13 | BACK PANEL MODULE | 39-56P01-024 | |
| 14 | NAMEPLATE BASE | 42-56P03-010 | |
| 15 | NAME PLATE "NOTEBOOK" | 45-42001-010 | |
| 16 | WIRE CABLE FOR INVERTER | 43-56P0R-011 | |
| 17 | INVERTER BOARD | 77-4200R-D02-1 | |
| 18 | LCD COAXIAL CABLE FOR IBM SXGA | 43-56P01-070 | |
| 19 | LCD BRACKET(RIGHT SANYO-CPT 15.1") | 33-56P01-030 | |
| 20 | RUBBER FOR LCD (BOTTOM) | 47-56P33-010 | |

Figure 1 - 3
LCD 15" 5600D

Battery (5600D)

Figure 1 - 4
Battery (5600D)



| ITEM | PART NAME | PART NO | REMARK |
|------|--------------------------------|--------------|--------|
| 1 | BATTERY TOP CASE | 42-56P7M-010 | |
| 2 | BATTERY BOTTOM CASE | 42-56P7M-020 | |
| 3 | SCREW M2*25L P NI IGT W/WASHER | 35-01020-2RE | |
| 4 | SPRING | 38-5600M-010 | |
| 5 | BATTERY LOCK | 42-56P8M-010 | |
| 6 | RUBBER PAN H=4mm | 47-56P23-040 | |
| 7 | BATTERY LABEL | 87-56P8S-4D3 | |
| 7 | BATTERY LABEL | 87-56P8S-4E3 | |

Second Battery (5600D)





Figure 1 - 5
Second Battery
(5600D)

| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------|--------------|--------|
| 1 | SECOND BATTERY TOP COVER | 42-56P7M-031 | |
| 2 | SECOND BATTERY BOTTOM CASE | 42-56P7M-041 | |
| 3 | RUBBER PAN H=4mm | 47-56P23-040 | |
| 4 | BATTERY LABEL | 87-56P8S-4C1 | |
| 4 | BATTERY LABEL | 87-56P8S-4E1 | |

TEAC CD-ROM Drive (5600D)

Figure 1 - 6
CD-ROM TEAC
(5600D)



| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------|--------------|-------------|
| 1 | SCREW M2*5L K1 BK/D TAP | 35-B4920-5R0 | |
| 2 | CD-ROM BEZEL MODULE FOR TEAC | 42-56P7Z-100 | |
| 3 | CD-ROM 5 1/4" 24X 12.7mm | 85-6070X-706 | CD-224E-B20 |
| 4 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 5 | CD & DVD ROM CASE | 42-5607Z-010 | |

KME CD-RW Drive (5600D)






Figure 1 - 7
CD-RW KME
(5600D)

| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------------|--------------|-----------------|
| 1 | SCREW M1.7*3.5L K BZ TAP | 35-86717-3R5 | |
| 2 | CD-RW BEZEL MODULE KME(5600 COLOR) | 42-56P7W-100 | |
| 3 | CD-R/W 5 1/4" 8X 12.7mm | 85-8078X-K00 | UJDA330CL-Z KME |
| 4 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 5 | CD-RW BRACKET 5600P | 33-56P0W-010 | |
| 6 | CD-RW CONVERTER BOARD | 77-5600Z-D0X | |
| 7 | SCREW M2*5L K NI NY(d=3.5 t=0.8) | 35-81120-SR0 | |
| 8 | CD RW CASE+RUBBER PAD MODULE | 42-56P7W-110 | |

Combo Drive (5600D)

Figure 1 - 8
Combo (5600D)



| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------------|--------------|-----------------|
| 1 | SAMSUNG COMBO BEZEL MODULE | 42-56P7X-100 | |
| 2 | CD-RW/DVD 5 1/4" 8X 12.7mm | 85-9078X-S00 | SN-308B SAMSUNG |
| 3 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 4 | CD-RW BRACKET 5600P | 33-56P0W-010 | |
| 5 | CD-RW CONVERTER BOARD | 77-5600Z-D0X | |
| 6 | SCREW M2*5L K NI NY(d=3.5 t=0.8) | 35-81120-5R0 | |
| 7 | CD RW CASE+RUBBER PAD MODULE | 42-56P7W-110 | |

DVD-ROM Drive (5600D)





Figure 1 - 9
DVD (5600D)

| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------|--------------|----------|
| 1-1 | SAMSUNG DVD BEZEL MODULE | 42-56P7V-200 | |
| 1-2 | TOSHIBA DVD BEZEL MODULE | 42-56P7V-100 | |
| 2-1 | DVD 5 1/4" 8X 12.7mm SAMSUNG | 85-7078X-S00 | SN-608 |
| 2-2 | DVD 5 1/4" 8X 12.7mm TOSHIBA | 85-7078X-T02 | SD-C2502 |
| 3 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 4 | CD & DVD ROM CASE | 42-56P7Z-010 | |

Audio DJ (5600D)

Figure 1 - 10
Audio DJ (5600D)



| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------------|--------------|--------|
| 1 | SCREW M2*3L K1 NI ICT NY | 35-B1120-3RA | |
| 2 | WIRE CABLE FOR MICROPHONE ASSEMBLY | 43-5600T-010 | |
| 3 | AUDIO DJ BOARD | 77-5600Y-D0X | |
| 4 | POWER BUTTON FOR AUDIO DJ | 42-56P82-010 | |
| 5 | AUDIO MODULE | 42-56278-100 | |

Floppy Disk Drive (5600D)






Figure 1 - 11
Floppy Disk Drive
(5600D)

| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------------|--------------|---------------|
| 1 | 3.5" FDD 12.7mm Y-E DATA | 85-11700-Y01 | YD-702J-6637J |
| 2 | FDD BRACKET 5600P | 33-56P0J-010 | |
| 3 | SCREW M2.5*4L K1 BK/D ICT NY | 35-B4125-4RA | |
| 4 | FDD CASE+RUBBER PAD MODULE | 42-56P7J-100 | |
| 5 | FPC CABLE MODULE FOR FDD ADAPTOR | 43-5600J-010 | |
| 6 | SCREW M2*4L K BZ ICT NY | 35-86120-4RA | |


Part Lists**Top (5620D)**

*Figure 1 - 12
Top (5620D)*



| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------------|--------------|--------|
| 1 | KEYBOARD | 80-56P08-7G0 | |
| 2 | SCREW M2.5*6L P BZ ICT NY | 35-06125-6RA | |
| 3 | SHIELDING FOR KEYBOARD | 33-56P07-010 | |
| 4 | HINGE (RIGHT) | 33-56P01-070 | |
| 5 | FIXED BRACKET FOR CABLE | 33-56P03-060 | |
| 6 | SPEAKER W/CABLE | 23-53610-281 | |
| 7 | SCREW M2*5L P NI ICT NY W/WASHER | 35-01020-2RE | |
| 8 | TOP CASE MODULE | 39-56202-010 | |
| 9 | M3*0.5P*4L KI NI ICT NY | 35-B1130-4R0 | |
| 10 | HINGE (LEFT) | 33-56P01-080 | |
| 11 | LED BOARD | 77-56P04-D0X | |
| 12 | FFC CABLE FOR LED&HOTKEY | 43-56P02-020 | |
| 13 | SCREW M2*3L K1 NI ICT NY | 35-B1120-3RA | |
| 14 | TOUCH PAD SYNAPTICS TM14PG035I-I | 49-42002-010 | |
| 15 | TOUCH PAD BRACKET | 33-56P02-050 | |
| 16 | FFC CABLE FOR TOUCH PAD | 43-56P02-010 | |
| 17 | FFC CABLE FOR CLICK | 43-56P03-010 | |
| 18 | CLICK BOARD | 77-56002-D0X | |
| 19 | PALMREST | 42-56272-030 | |
| 20 | SCREW M2*4L KI NI ICT NY | 35-B1120-4R0 | |

Bottom (5620D)




| ITEM | PART NO | NAME | PART NO | REMARK |
|------|--|----------------|-------------------------------------|--------|
| 1 | SCREW M2*3L K1 NI ICT NY | 35-B1120-3RA | | |
| 2 | MDC MODEM+TEL CABLE MODULE | 76-32200-100 | | |
| 3 | MAIN BOARD | 77-56200-106-M | | |
| 4 | SCREW M2.5*6L P BZ ICT NY | 35-06125-6RA | | |
| 5 | CPU HEATSINK MODULE | 31-56P0N-101 | | |
| 6 | SCREW | 35-41025-175 | | |
| 7 | WIRE CABLE FOR LAN AND MODEM | 43-56P0U-010 | | |
| 8 | SCREW M2*4L F NI ICT NY | 35-21120-4RA | | |
| 9 | SCREW M2*2.5 P NI ICT NY W/WASHER | 35-01020-2RE | | |
| 10 | FAN 25*25*6.5T 5V 0.09A CDH | 23-A2514-050 | | |
| 11 | SCREW M2.5*4L K1 BK/D ICT NY | 35-B4125-4RA | | |
| 12 | CPU COVER + SHIELDING PLATE-RUBBER PAD MODULE | 42-5627S-100 | | |
| 13 | BATTERY S LI 4.0AH FDR SMP-SAMSUNG | 87-5628S-4D3 | Reference Assy No 099-56205-0601 | |
| 13 | BATTERY S LI 4.0AH FOR GLW/LG | 87-5628S-4E3 | Reference Assy No 099-56205-0602 | |
| 13 | BATTERY S LI 3.4AH FOR SMP/PANASONIC | 87-5628S-4C1 | Reference Assy No 099-56205-0631 | |
| 14 | PRODUCT LABEL TUVO 56200 | 45-562D3-010 | | |
| 15 | ANODIZED ALUMINUM POWER BUTTON FOR V-DISK MODULE 56200 | 42-5627B-8A00 | Reference Assy No 099-56205-1101 | |
| 16 | BOTTOM CASE-SHIELDING PLATE MODULE | 39-56203-012 | | |
| 17 | RUBBER PAD H=7mm (BACK) | 47-56223-020 | | |
| 18 | FDD ASSY 5600P | 79-5622J-010 | Reference Assy No 099-56205-0401 | |
| 18 | CD-RW ASSY 5600P | 79-5622Z-010 | Reference Assy No 099-56205-0402 | |
| 18 | DVD ROM ASSY 5600P | 79-5622V-020 | Reference Assy No 099-56205-0701 | |
| 19 | DC/DC BOARD | 77-56P0C-00X | | |
| 20 | HEX H=16MM M=M2.5 F=M2.5 | 34-56P03-010 | | |
| 21 | COSMETIC COVER (METAL) | 33-56P03-030 | | |
| 22 | HDD CONVERTER BOARD | 77-5600N-DOX | | |
| 23 | W/D HDD ASSY 5600P | 79-56P21-010 | | |
| 24 | CD-RW ASSY 5600P | 79-5622W-010 | Reference Assy No 099-56205-0401 | |
| 24 | COMBO ASSY 5600P | 79-5622X-010 | Reference Assy No 099-56205-0201 | |
| 25 | HEATSINK FOR PCMCIA | 31-56P0N-020 | | |
| 26 | EMI GASKET(L19*W9*H3.5MM) | 47-00190-181 | | |
| 27 | FFC CABLE FOR AUDIO DJ MODULE | 43-56P08-010 | | |

Figure 1 - 13
Bottom (5620D)

LCD 15" (5620D)

*Figure 1 - 14
LCD 15" (5620D)*



| ITEM | PART NAME | PART NO | REMARK |
|------|--|----------------|--------|
| 1 | RUBBER FOR LCD (MIDDLE) | 47-56221-030 | |
| 2 | RUBBER FOR LCD (TOP) | 47-56232-010 | |
| 3 | SCREW M2*6L P NI ICT NY | 35-01120-6RA | |
| 4 | LCD FRONT PANEL MODULE(15.1") | 39-56201-013 | |
| 5 | LCD 15.0" QXGA TFT IDT IADION 2048x1536 72mm | 50-L6270-E01 | |
| 6 | LCD BRACKET (LEFT SANYO-CPT 15.1") | 33-56P01-040 | |
| 7 | SCREW M2*3L KI NI ICT NY | 35-BI120-3RA | |
| 8 | SCREW M3*0.5P*4L KI NI ICT NY | 35-BI130-4R0 | |
| 9 | SCREW M3*0.5*7L KI NI ICT NY | 35-BI130-7R0 | |
| 10 | SPRING FOR HOOK (Φ3.7*15*0.3d) | 38-21P30-011 | |
| 11 | HOOK KNOB | 42-56P81-011 | |
| 12 | 2-AUG DIPOLE ANTENNA OD:13MM L:RIGHT+LEFT | 23-712R4-002 | |
| 13 | BACK PANEL MODULE | 39-56201-024 | |
| 14 | NAMEPLATE BASE | 42-56203-010 | |
| 15 | NAME PLATE "NOTEBOOK" | 45-18N01-010 | |
| 16 | WIRE CABLE FOR INVERTER | 43-56P0R-011 | |
| 17 | INVERTER BOARD | 77-4200R-D02-1 | |
| 18 | LCD COAXIAL CABLE FOR IBM QXGA | 43-56P01-070 | |
| 19 | LCD BRACKET(RIGHT SANYO-CPT 15.1") | 33-56P01-030 | |
| 20 | RUBBER FOR LCD (BOTTOM) | 47-56233-010 | |

Battery (5620D)






Figure 1 - 15
Battery (5620D)

| ITEM | PART NAME | PART NO | REMARK |
|------|---------------------------------|--------------|--------|
| 1 | BATTERY TOP CASE | 42-5627M-010 | |
| 2 | BATTERY BOTTOM CASE | 42-5627M-020 | |
| 3 | SCREW M2*2.5L P NI IGT W/WASHER | 35-01020-2RE | |
| 4 | SPRING | 38-5600M-010 | |
| 5 | BATTERY LOCK | 42-58P8M-010 | |
| 6 | RUBBER PAN H=4mm | 47-56223-040 | |
| 7 | BATTERY LABEL | 87-5628S-4D3 | |
| 7 | BATTERY LABEL | 87-5628S-4E3 | |

Second Battery (5620D)

Figure 1 - 16
Second Battery
(5620D)



| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------|--------------|--------|
| 1 | SECOND BATTERY TOP COVER | 42-5627M-030 | |
| 2 | SECOND BATTERY BOTTOM CASE | 42-5627M-040 | |
| 3 | RUBBER PAN H=4mm | 47-56223-030 | |
| 4 | BATTERY LABEL | 87-5628S-4C1 | |
| 4 | BATTERY LABEL | 87-5628S-4E1 | |

TEAC CD-ROM Drive (5620D)






Figure 1 - 17
TEAC CD-ROM
Drive
(5620D)

| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------|--------------|-------------|
| 1 | SCREW M2*5L K1 BK/D TAP | 35-B4920-5R0 | |
| 2 | CD-ROM BEZEL MODULE FOR TEAC | 42-5627Z-100 | |
| 3 | CD-ROM 5 1/4" 24X 12.7mm | 85-6070X-706 | CD-224E-B20 |
| 4 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 5 | CD & DVD ROM CASE | 42-5627Z-010 | |

KME CD-RW Drive (5620D)

Figure 1 - 18
KME CD-RW Drive
(5620D)



| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------------|--------------|-----------------|
| 1 | SCREW M1.7*3.5L K BZ TAP | 35-86717-3R5 | |
| 2 | CD-RW BEZEL MODULE KME<5600 COLOR> | 42-5627W-100 | |
| 3 | CD-RW 5 1/4" 8X 12.7mm | 85-8078X-K00 | UJDA330CL-Z KME |
| 4 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 5 | CD-RW BRACKET 5600P | 33-56P0W-010 | |
| 6 | CD-RW CONVERTER BOARD | 77-5600Z-D0X | |
| 7 | SCREW M2*5L K NI NY(d=3.5 t=0.8) | 35-81120-5R0 | |
| 8 | CD RW CASE+RUBBER PAD MODULE | 42-5627W-110 | |

Combo Drive (5620D)






Figure 1 - 19
Combo Drive
(5620D)

| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------------|--------------|-----------------|
| 1 | SAMSUNG COMBO BEZEL MODULE | 42-5620X-100 | |
| 2 | CD-RW/DVD 5 1/4" 8X 12.7mm | 85-907BX-S00 | SN-308B SAMSUNG |
| 3 | SCREW M2*25L K NI ICT NY | 35-81120-2R5 | |
| 4 | CD-RW BRACKET 5600P | 33-56P0W-010 | |
| 5 | CD-RW CONVERTER BOARD | 77-5600Z-D0X | |
| 6 | SCREW M2*5L K NI NY(d=3.5 t=0.8) | 35-81120-5R0 | |
| 7 | CD RW CASE+RUBBER PAD MODULE | 42-5627W-110 | |

DVD-ROM Drive (5620D)

Figure 1 - 20
DVD-ROM Drive
(5620D)



| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------|--------------|----------|
| 1-1 | SAMSUNG DVD BEZEL MODULE | 42-5627V-200 | |
| 1-2 | TOSHIBA DVD BEZEL MODULE | 42-5627V-100 | |
| 2-1 | DVD 5 1/4" 8X 12.7mm SAMSUNG | 85-7078X-S00 | SN-608 |
| 2-2 | DVD 5 1/4" 8X 12.7mm TOSHIBA | 85-7078X-T02 | SD-C2502 |
| 3 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 4 | CD & DVD ROM CASE | 42-5627Z-010 | |

Audio DJ (5620D)






Figure 1 - 21
Audio DJ
(5620D)

| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------------|--------------|--------|
| 1 | SCREW M2*3L K1 NI ICT NY | 35-B1120-3RA | |
| 2 | WIRE CABLE FOR MICROPHONE ASSEMBLY | 43-5600T-010 | |
| 3 | AUDIO DJ BOARD | 77-5600Y-D0X | |
| 4 | POWER BUTTON FOR AUDIO DJ | 42-56P82-010 | |
| 5 | AUDIO MODULE | 42-56278-100 | |

Floppy Disk Drive (5620D)

Figure 1 - 22
Floppy Disk Drive
(5620D)



| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------------|--------------|---------------|
| 1 | 3.5" FDD 12.7MM Y-E DATA | 85-11700-Y01 | YD-702J-6637J |
| 2 | FDD BRACKET 5600P | 33-56P0J-010 | |
| 3 | SCREW M2.5*4L K1 BK/D ICT NY | 35-B4125-4RA | |
| 4 | FDD CASE+RUBBER PAD MODULE | 42-5627J-100 | |
| 5 | FPC CABLE MODULE FOR FDD ADAPTOR | 43-5600J-010 | |
| 6 | SCREW M2*4L K1 NI ICT NY | 35-B1120-4RA | |

Top (5800D)





Figure 1 - 23
Top (5800D)

| ITEM | PART NAME | PART NO | REMARK |
|------|---------------------------------|--------------|--------|
| 1 | KEYBOARD | 80-56P08-7G0 | |
| 2 | SCREW M2*6L P BZ ICT NY | 35-06125-6RA | |
| 3 | SHIELDING FOR KEYBOARD | 33-56P07-010 | |
| 4 | HINGE (RIGHT) | 33-56P01-070 | |
| 5 | FIXED BRACKET FOR CABLE | 33-56P03-060 | |
| 6 | SPEAKER W/CABLE | 23-53610-281 | |
| 7 | SCREW M2*5L P NI ICT NY ✓WASHER | 35-01020-2RE | |
| 8 | TOP CASE MODULE | 39-58P02-010 | |
| 9 | M3*0.5P*4L KI NI ICT NY | 35-B1130-4R0 | |
| 10 | HINGE (LEFT) | 33-56P01-080 | |
| 11 | LED BOARD | 77-56P04-0DX | |
| 12 | FFC CABLE FOR LED&HOTKEY | 43-56P02-020 | |
| 13 | SCREW M2*3L KI NI ICT NY | 35-B1120-3RA | |
| 14 | TOUCH PAD SYNAPTICS T44PDG3S1-I | 49-42002-010 | |
| 15 | TOUCH PAD BRACKET | 33-58P02-050 | |
| 16 | FFC CABLE FOR TOUCH PAD | 43-56P02-010 | |
| 17 | FFC CABLE FOR CLICK | 43-56P03-010 | |
| 18 | CLICK BOARD | 77-58002-0DX | |
| 19 | TRANSPARENTE COVER | 42-58P72-030 | |
| 20 | SCREW M2*4L KI NI ICT NY | 35-B1120-4R0 | |

Part Lists


Bottom (5800D)

Figure 1 - 24
Bottom (5800D)



| ITEM | PART NAME | PART NO | REMARK |
|------|---|----------------|---------------------------------------|
| 1 | SCREW M2x3L K1 NI ICT NY | 35-B1120-3RA | |
| 2 | MDC MODEM+TEL+CABLE MODULE | 76-32200-100 | |
| 3 | MAIN BOARD | 77-56D00-D06-M | |
| 4 | SCREW M2.5x6L P BZ ICT NY | 35-06125-6RA | |
| 5 | CPU HEATSINK MODULE | 31-56P0N-101 | |
| 6 | SCREW | 35-41025-175 | |
| 7 | WIRE CABLE FOR LAN AND MODEM | 43-56POU-010 | |
| 8 | SCREW M2x4L F NI ICT NY | 35-21120-4RA | |
| 9 | SCREW M2x5L P NI ICT W/WASHER | 35-01020-2RE | |
| 10 | FAN 25x25x6.5T 5V 0.09A CDN | 23-A2514-050 | |
| 11 | SCREW M2.5x4L K1 BK/D ICT NY | 35-B4125-4RA | |
| 12 | CPU COVER & SHIELDING PLATE MODULE | 42-58P7S-100 | |
| 13 | BATTERY S LI 3400 mAh FOR SMP/PANASONIC | 87-58PBS-403 | Reference Ass'y No: (99-58PBS-165) |
| 13 | BATTERY S LI 3400 mAh FOR SMP/PANASONIC | 87-58PBS-4C1 | Reference Ass'y No: (99-58PBS-165) |
| 14 | PRODUCT LABEL(TUV) 5800D | 45-58D03-010 | |
| 15 | ANTI-XRAY FILTER FOR CD-ROM DRIVE 5800D | 42-58P78-400 | Reference Ass'y No: (99-58P78-110) |
| 16 | BOTTOM CASE-SHIELDING PLATE MODULE | 39-58P03-012 | |
| 17 | RUBBER PAD H=7mm (BACK) | 47-56223-020 | |
| 18 | FDD ASSY' 5600P | 79-58P2J-010 | Reference Ass'y No: (99-58P05-140) |
| 18 | CD-ROM ASSY' 5600P | 79-58P2Z-010 | Reference Ass'y No: (99-58P05-140) |
| 18 | DVD/RDM ASSY' 5600P | 79-58P2V-020 | Reference Ass'y No: (99-58P05-070) |
| 19 | DC/DC BOARD | 77-56P0C-BOX | |
| 20 | HEX H=16MM M=M2.5 F=M2.5 | 34-56P03-010 | |
| 21 | COSMETIC COVER (METAL) | 33-56P03-030 | |
| 22 | HDMI CONVERTER BOARD | 77-5600N-DOX | |
| 23 | W/D HDD ASSY' 5600P | 79-56P21-010 | |
| 24 | CD-RW ASSY' 5600P | 79-58P2W-010 | Reference Ass'y No: (99-58P05-160) |
| 24 | COMBO ASSY' 5600P | 79-58P2X-010 | Reference Ass'y No: (99-58P05-160) |
| 25 | HEATSINK FDD PCMCIA | 31-56P0N-020 | |
| 26 | EMI GASKET(LB#W#W#H#SMM#) | 47-00190-181 | |
| 27 | FFC CABLE FOR AUDIO DJ MODULE | 43-56P08-010 | |

LCD 15" (5800D)




| ITEM | PART NAME | PART NO | REMARK |
|------|---|----------------|--------|
| 1 | RUBBER FOR LCD (MIDDLE) | 47-56221-030 | |
| 2 | RUBBER FOR LCD (TOP) | 47-56232-010 | |
| 3 | SCREW M2*6L P NI ICT NY | 35-01120-6RA | |
| 4 | LCD FRONT PANEL MODULE(15.1") | 39-58P01-013 | |
| 5 | LCD 15" SXGA TFT 1D IDAC10N 2048x1536 7.2mm | 50-L6272-E01 | |
| 6 | LCD BRACKET LEFT SANYO-CPT 15.1" | 33-56P01-040 | |
| 7 | SCREW M2*3L KI NI ICT NY | 35-B1120-3RA | |
| 8 | SCREW M3*0.5P*4L KI NI ICT NY | 35-B1130-4R0 | |
| 9 | SCREW M3*0.5*7L KI NI ICT NY | 35-B1130-7R0 | |
| 10 | SPRING FOR HOOK (Ø3.7*15*0.3d) | 38-21P30-011 | |
| 11 | HOOK KNOB | 42-58P81-011 | |
| 12 | 24GHZ DIPOLE ANTENNA ØD13MM L=RIGHT+LEFT | 23-712R4-002 | |
| 13 | BACK PANEL MODULE | 39-58P01-024 | |
| 14 | NAMEPLATE BASE | 42-58P03-010 | |
| 15 | LCD BACK COVER LABEL | 43-4200R-010 | |
| 16 | WIRE CABLE FOR INVERTER | 43-56P0R-011 | |
| 17 | INVERTER BOARD | 77-4200R-D02-1 | |
| 18 | LCD COAXIAL CABLE FOR IBM SXGA | 43-56P01-070 | |
| 19 | LCD BRACKET(RIGHT SANYO-CPT 15.1") | 33-56P01-030 | |
| 20 | RUBBER FOR LCD (BOTTOM) | 47-56233-010 | |

Figure 1 - 25
LCD 15"
(5800D)

Part Lists**Battery (5800D)**

Figure 1 - 26
Battery (5800D)



| ITEM | PART NAME | PART NO | REMARK |
|------|--------------------------------|--------------|--------|
| 1 | BATTERY TOP CASE | 42-58P7M-010 | |
| 2 | BATTERY BOTTOM CASE | 42-58P7M-020 | |
| 3 | SCREW M2*2SL P NI ICT W/WASHER | 35-01020-2RE | |
| 4 | SPRING | 38-5600M-010 | |
| 5 | BATTERY LOCK KNOB | 42-58P8M-010 | |
| 6 | RUBBER PAN H=4mm | 47-56223-040 | |
| 7 | BATTERY LABEL | 87-58P8S-4D3 | |

Second Battery (5800D)






Figure 1 - 27
Second Battery
(5800D)

| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------|--------------|--------|
| 1 | SECOND BATTERY TOP COVER | 42-58P7M-031 | |
| 2 | SECOND BATTERY BOTTOM CASE | 42-58P7M-041 | |
| 3 | RUBBER PAN H=4mm | 47-56223-040 | |
| 4 | BATTERY LABEL | 87-58P8S-4C1 | |

TEAC CD-ROM Drive (5800D)

Figure 1 - 28
TEAC CD_ROM
Drive
(5800D)



| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------|--------------|-------------|
| 1 | SCREW M2*5L K1 BK/D TAP | 35-B4920-5R0 | |
| 2 | CD-ROM BEZEL MODULE FOR TEAC | 42-58P7Z-100 | |
| 3 | CD-ROM 5 1/4" 24X 12.7mm | 85-6070X-706 | CD-224E-B20 |
| 4 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 5 | CD & DVD ROM CASE | 42-58P7Z-010 | |

KME CD-RW Drive (5800D)






Figure 1 - 29
**KME CD-RW Drive
(5800D)**

| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------------|--------------|-----------------|
| 1 | SCREW M1.7*3.5L K BZ TAP | 35-86717-3R5 | |
| 2 | CD-RW BEZEL MODULE KME(5600 COLOR) | 42-58P7W-100 | |
| 3 | CD-R/W 5 1/4" 8X 12.7mm | 85-8078X-K00 | UJDA330CL-Z KME |
| 4 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 5 | CD-RW BRACKET 5600P | 33-56P0W-010 | |
| 6 | CD-RW CONVERTER BOARD | 77-5600Z-DOX | |
| 7 | SCREW M2*5L K NI NY(d=3.5 t=0.8) | 35-81120-5R0 | |
| 8 | CD RW CASE MODULE | 42-58P7W-110 | |

Combo Drive (5800D)

Figure 1 - 30
Combo Drive
(5800D)



| ITEM | PART NAME | PART NO | REMARK |
|------|---------------------------------|--------------|-----------------|
| 1 | SAMSUNG COMBO BEZEL MODULE | 42-58P7X-100 | |
| 2 | CD-RW/DVD 5 1/4" 8X 12.7mm | 85-9078X-S00 | SN-308B SAMSUNG |
| 3 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 4 | CD-RW BRACKET 5600P | 33-56P0W-010 | |
| 5 | CD-RW CONVERTER BOARD | 77-5600Z-D0X | |
| 6 | SCREW M2*5L K NI NY(d=35 t=0.8) | 35-81120-5R0 | |
| 7 | CD RW CASE MODULE | 42-58P7W-110 | |

DVD-ROM Drive (5800D)





Figure 1 - 31
DVD-ROM Drive
(5800D)

| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------|--------------|----------|
| 1-1 | SAMSUNG DVD BEZEL MODULE | 42-58P7V-200 | |
| 1-2 | TOSHIBA DVD BEZEL MODULE | 42-58P7V-100 | |
| 2-1 | DVD 5 1/4" 8X 12.7mm SAMSUNG | 85-7078X-S00 | SN-608 |
| 2-2 | DVD 5 1/4" 8X 12.7mm TOSHIBA | 85-7078X-T02 | SD-C2502 |
| 3 | SCREW M2*25L K NI ICT NY | 35-81120-2R5 | |
| 4 | CD & DVD ROM CASE | 42-58P7Z-010 | |

Audio DJ (5800D)

Figure 1 - 32
Audio DJ
(5800D)



Floppy Disk Drive (5800D)






Figure 1 - 33
Floppy Disk Drive
(5800D)

| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------------|--------------|---------------|
| 1 | 3.5" FDD 12.7mm Y-E DATA | 85-11700-Y01 | YD-702J-6637J |
| 2 | FDD BRACKET 5600P | 33-56P0J-010 | |
| 3 | SCREW M2.5*4L K1 BK/D ICT NY | 35-B4125-4RA | |
| 4 | FDD CASE MODULE | 42-58P7J-100 | |
| 5 | FPC CABLE MODULE FOR FDD ADAPTOR | 43-5600J-010 | |
| 6 | SCREW M2*4L K1 NI ICT NY | 35-B1120-4RA | |

Part Lists


Top (5820D)

Figure 1 - 34
Top
(5820D)



| ITEM | PART NAME | PART NO | REMARK |
|------|-----------------------------------|--------------|--------|
| 1 | KEYBOARD | 80-56P08-7G0 | |
| 2 | SCREW M2.5*6L P BZ ICT NY | 35-06125-6RA | |
| 3 | SHIELDING FOR KEYBOARD | 33-56P07-010 | |
| 4 | HINGE (RIGHT) | 33-56P01-070 | |
| 5 | FIXED BRACKET FOR CABLE | 33-56P03-060 | |
| 6 | SPEAKER W/CABLE | 23-53610-281 | |
| 7 | SCREW M2*5L P NI ICT NY W/WASHER | 35-01020-2RE | |
| 8 | TOP CASE MODULE | 39-58202-010 | |
| 9 | M3*0.5P*4L KI NI ICT NY | 35-B1130-4R0 | |
| 10 | HINGE (LEFT) | 33-56P01-080 | |
| 11 | LED BOARD | 77-56P04-D0X | |
| 12 | FFC CABLE FOR LED&HOTKEY | 43-56P02-020 | |
| 13 | SCREW M2*3L KI NI ICT NY | 35-B1120-3RA | |
| 14 | TOUCH PAD SYNTACTICS TM4IPDG351-1 | 49-42002-010 | |
| 15 | TOUCH PAD BRACKET | 33-56P02-050 | |
| 16 | FFC CABLE FOR TOUCH PAD | 43-56P02-010 | |
| 17 | FFC CABLE FOR CLICK | 43-56P03-010 | |
| 18 | CLICK BOARD | 77-58002-D0X | |
| 19 | PALMREST | 42-58272-030 | |

Bottom (5820D)




| ITEM | PART NAME | PART NO | REMARK |
|------|--|----------------|---------------------------------------|
| 1 | SCREW M2.5*3L K1 NI ICT NY | 35-B1120-3RA | |
| 2 | MDC MODEM+TEL CABLE MODULE | 76-32200-100 | |
| 3 | MAIN BOARD | 77-56000-D06-M | |
| 4 | SCREW M2.5*6L P BZ ICT NY | 35-06125-6RA | |
| 5 | CPU HEATSINK MODULE | 31-56P0N-101 | |
| 6 | SCREW | 35-41025-175 | |
| 7 | WIRE CABLE FOR LAN AND MODEM | 43-56POU-010 | |
| 8 | SCREW M2.5*4L F NI ICT NY | 35-21120-4RA | |
| 9 | SCREW M2.5L P NI ICT NY w/VASHER | 35-01020-2RE | |
| 10 | FAN 25W2565T 5V 0.09A CDN | 23-A2514-050 | |
| 11 | SCREW M2.5*4L K1 BK/D ICT NY | 35-84125-4RA | |
| 12 | CPU COVER & SHIELDING PLATE MODULE PA | 42-56P7S-100 | |
| 13 | BATTERY S LI 4.0AH FOR SMP/SAMSUNG | 87-58P8S-4D3 | Reference Ass'y No. (99-58P0S-060) |
| 14 | BATTERY S LI 3.4AH FOR SMP/PANASONIC | 87-58P8S-4C1 | |
| 15 | PRODUCT LABEL(UV) 5880D | 45-582D3-010 | |
| 16 | ANODIZED ALUMINUM PLATE FOR HOLE 38X38 | 42-58278-A00 | Reference Ass'y No. (99-58P0S-115) |
| 17 | BOTTOM CASE+SHIELDING PLATE MODULE | 39-56P03-012 | |
| 18 | RUBBER PAD H=7mm (BACK) | 47-56P23-020 | |
| 19 | FDD ASS'Y 5600P | 79-56P2J-010 | Reference Ass'y No. (99-56P0S-040) |
| 20 | CD-RDM ASS'Y 5600P | 79-56P2Z-010 | Reference Ass'y No. (99-56P0S-050) |
| 21 | DVD RDM ASS'Y 5600P | 79-56P2V-020 | Reference Ass'y No. (99-56P0S-070) |
| 22 | DC/DC BOARD | 77-56POC-DOX | |
| 23 | HEX H=16MM M=M2.5 F=M2.5 | 34-56P03-010 | |
| 24 | COSMETIC COVER (METAL) | 33-56P03-030 | |
| 25 | HDD CONVERTER BOARD | 77-5600N-DOX | |
| 26 | W/D HDD ASS'Y 5600P | 79-56P2I-010 | |
| 27 | CD-RW ASS'Y 5600P | 79-56P2W-010 | Reference Ass'y No. (99-56P0S-080) |
| 28 | COMBO ASS'Y 5600P | 79-56P2X-010 | Reference Ass'y No. (99-56P0S-090) |
| 29 | HEATSINK FOR PCMCIA | 31-56P0N-020 | |
| 30 | EMI GASKET(L18*w9*h3.5MM) | 47-00190-181 | |
| 31 | FFC CABLE FOR AUDIO DJ MODULE | 43-56P0B-010 | |

Figure 1 - 35
Bottom
(5820D)

Part Lists

LCD 15" (5820D)

Figure 1 - 36
LCD 15"
(5820D)



| ITEM | PART NAME | PART NO | REMARK |
|------|--|----------------|--------|
| 1 | RUBBER FOR LCD (MIDDLE) | 47-56P21-030 | |
| 2 | RUBBER FOR LCD (TOP) | 47-56P32-010 | |
| 3 | SCREW M2*6L P NI ICT NY | 35-01120-6RA | |
| 4 | LCD FRONT PANEL MODULE(15.1") | 39-56P01-013 | |
| 5 | LCD 15" QXGA TFT 1024x768 264K 15.1" | 50-L6272-E01 | |
| 6 | LCD BRACKET (LEFT SANYO-CPT 15.1") | 33-56P01-040 | |
| 7 | SCREW M2*3L KI NI ICT NY | 35-B1120-3RA | |
| 8 | SCREW M3*0.5*4L KI NI ICT NY | 35-B1130-4R0 | |
| 9 | SCREW M3*0.5*7L KI NI ICT NY | 35-B1130-7R0 | |
| 10 | SPRING FOR HOOK (Φ3.7*15*0.3φ) | 38-2IP30-011 | |
| 11 | HOOK KNOB | 42-56P81-011 | |
| 12 | 2.4GHZ DIPOLE ANTENNA DD:12MM L-RIGHT+LEFT | 23-712R4-002 | |
| 13 | BACK PANEL MODULE | 39-58201-024 | |
| 14 | NAMEPLATE BASE | 42-58203-010 | |
| 15 | NAME PLATE "NOTEBOOK" | 45-42001-010 | |
| 16 | WIRE CABLE FOR INVERTER | 43-56P0R-011 | |
| 17 | INVERTER BOARD | 77-4200R-D02-1 | |
| 18 | LCD CABLE CABLE FOR IBM QXGA | 43-56P01-070 | |
| 19 | LCD BRACKET(RIGHT SANYO-CPT 15.1") | 33-56P01-030 | |
| 20 | RUBBER FOR LCD (BOTTOM) | 47-56P33-010 | |

Battery (5820D)





Figure 1 - 37
Battery (5820D)

| ITEM | PART NAME | PART NO | REMARK |
|------|---------------------------------|--------------|--------|
| 1 | BATTERY TOP CASE | 42-56P7M-010 | |
| 2 | BATTERY BOTTOM CASE | 42-56P7M-020 | |
| 3 | SCREW M2*2.5L P NI ICT W/WASHER | 35-01020-2RE | |
| 4 | SPRING | 38-5600M-010 | |
| 5 | BATTERY LOCK | 42-56P8M-010 | |
| 6 | RUBBER PAD H=4mm | 47-56P23-040 | |
| 7 | BATTERY LABEL | 87-56PBS-4D3 | |
| 7 | BATTERY LABEL | 87-56PBS-4E3 | |

Second Battery (5820D)

Figure 1 - 38
Second Battery
(5820D)



| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------|--------------|--------|
| 1 | SECOND BATTERY TOP COVER | 42-56P7M-031 | |
| 2 | SECOND BATTERY BOTTOM CASE | 42-56P7M-041 | |
| 3 | RUBBER PAN H=4mm | 47-56P23-040 | |
| 4 | BATTERY LABEL | 87-56P8S-4C1 | |
| 4 | BATTERY LABEL | 87-56P8S-4E1 | |

TEAC CD-ROM Drive (5820D)





Figure 1 - 39
CD-ROM TEAC
(5820D)

| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------|--------------|-------------|
| 1 | SCREW M2*5L K1 BK/D TAP | 35-B4920-5R0 | |
| 2 | CD-ROM BEZEL MODULE FOR TEAC | 42-56P7Z-100 | |
| 3 | CD-ROM 5 1/4" 24X 12.7mm | 85-6070X-706 | CD-224E-B20 |
| 4 | SCREW M2*25L K NI ICT NY | 35-81120-2R5 | |
| 5 | CD & DVD ROM CASE | 42-5607Z-010 | |

KME CD-RW Drive (5820D)

Figure 1 - 40
CD-RW KME
(5820D)



| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------------|--------------|-----------------|
| 1 | SCREW M1.7*3.5L K BZ TAP | 35-86717-3R5 | |
| 2 | CD-RW BEZEL MODULE KME(5600 COLOR) | 42-56P7W-100 | |
| 3 | CD-R/W 5 1/4" 8X 12.7mm | 85-8078X-K00 | UJDA330CL-Z KME |
| 4 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 5 | CD-RW BRACKET 5600P | 33-56P0W-010 | |
| 6 | CD-RW CONVERTER BOARD | 77-5600Z-D0X | |
| 7 | SCREW M2*5L K NI NY(d=3.5 t=0.8) | 35-81120-5R0 | |
| 8 | CD RW CASE+RUBBER PAD MODULE | 42-56P7W-110 | |

Combo Drive (5820D)






Figure 1 - 41
Combo (5820D)

| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------------|--------------|-----------------|
| 1 | SAMSUNG COMBO BEZEL MODULE | 42-56P7X-100 | |
| 2 | CD-RW/DVD 5 1/4" 8X 12.7mm | 85-9078X-S00 | SN-30BB SAMSUNG |
| 3 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 4 | CD-RW BRACKET 5600P | 33-56P0W-010 | |
| 5 | CD-RW CONVERTER BOARD | 77-5600Z-D0X | |
| 6 | SCREW M2*5L K NI NY(d=3.5 t=0.8) | 35-81120-5R0 | |
| 7 | CD RW CASE+RUBBER PAD MODULE | 42-56P7W-110 | |

DVD-ROM Drive (5820D)

Figure 1 - 42
DVD (5820D)



| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------|--------------|----------|
| 1-1 | SAMSUNG DVD BEZEL MODULE | 42-56P7V-200 | |
| 1-2 | TOSHIBA DVD BEZEL MODULE | 42-56P7V-100 | |
| 2-1 | DVD 5 1/4" 8X 12.7mm SAMSUNG | 85-7078X-S00 | SN-608 |
| 2-2 | DVD 5 1/4" 8X 12.7mm TOSHIBA | 85-7078X-T02 | SD-C2502 |
| 3 | SCREW M2*2.5L K NI ICT NY | 35-81120-2R5 | |
| 4 | CD & DVD ROM CASE | 42-56P7Z-010 | |

Audio “DJ” (5820D)







Figure 1 - 43
Audio “DJ”
(5820D)

| ITEM | PART NAME | PART NO | REMARK |
|------|------------------------------------|--------------|--------|
| 1 | SCREW M2*3L K1 NI ICT NY | 35-B1120-3RA | |
| 2 | WIRE CABLE FOR MICROPHONE ASSEMBLY | 43-5600T-010 | |
| 3 | AUDIO DJ BOARD | 77-5600Y-D0X | |
| 4 | POWER BUTTON FOR AUDIO DJ | 42-58282-010 | |
| 5 | AUDIO DJ MODULE | 42-58278-100 | |

Figure 1 - 44
Floppy Disk Drive
(5820D)



| ITEM | PART NAME | PART NO | REMARK |
|------|----------------------------------|--------------|---------------|
| 1 | 3.5" FDD 12.7mm Y-E DATA | 85-11700-Y01 | YD-702J-6637J |
| 2 | FDD BRACKET 5600P | 33-56P0J-010 | |
| 3 | SCREW M2*4L K1 BK/D ICT NY | 35-B4125-4RA | |
| 4 | FDD CASE+RUBBER PAD MODULE | 42-56P7J-100 | |
| 5 | FPC CABLE MODULE FOR FDD ADAPTOR | 43-5600J-010 | |
| 6 | SCREW M2*4L K BZ ICT NY | 35-86120-4RA | |

Table 1
**Schematic
Diagrams**


Appendix B:Schematic Diagrams

This appendix has circuit diagrams of the systems PCB's. The following table indicates where to find the appropriate schematic diagram.

| Diagram - Page | Diagram - Page |
|--|--|
| <i>System Block Diagram - Page B - 2</i> | <i>Mini PCI; MDC Modem - Page B - 17</i> |
| <i>CPU (Northwood) 1 of 2 - Page B - 3</i> | <i>LAN RTL8139CL - Page B - 18</i> |
| <i>CPU (Northwood) 2 of 2 - Page B - 4</i> | <i>TII394 TSB43AB22 - Page B - 19</i> |
| <i>MCH845 Power & Ground - Page B - 5</i> | <i>NS-PC87393; IR; ROM - Page B - 20</i> |
| <i>MCH845 Memory Interface - Page B - 6</i> | <i>H8 - Page B - 21</i> |
| <i>Clock Generator - Page B - 7</i> | <i>KBC Conn; Fan Conn - Page B - 22</i> |
| <i>DDRAM - Page B - 8</i> | <i>ACIN; PWR Button - Page B - 23</i> |
| <i>DDR Termination - Page B - 9</i> | <i>AC'97 AD1886 - Page B - 24</i> |
| <i>Mobility P7 - Page B - 10</i> | <i>PCI 1410 - Page B - 25</i> |
| <i>Mobility Mem A; Term; LVDS - Page B - 11</i> | <i>PCMCIA Socket - Page B - 26</i> |
| <i>Mobility Mem B; CRT; TV Out - Page B - 12</i> | <i>CPU Core Power - Page B - 27</i> |
| <i>ICH3 (1 of 3) - Page B - 13</i> | <i>D/D Conn - Page B - 28</i> |
| <i>ICH3 (2 of 3) - Page B - 14</i> | <i>+3V; +5V - Page B - 29</i> |
| <i>ICH3 (3 of 3) - Page B - 15</i> | <i>USB 2.0 - Page B - 30</i> |
| <i>HDD/CDROM/FDD - Page B - 16</i> | |

System Block Diagram

**Sheet 1 of 29
System Block
Diagram**




Schematic Diagrams

Schematic Diagrams


CPU (Northwood) 2 of 2

Sheet 3 of 29
CPU 2 of 2



B - 4 CPU (Northwood) 2 of 2 (71-56P00-D05)

MCH845 Power & Ground




Sheet 4 of 29
MCH845
Power & Ground


Schematic Diagrams

MCH845 Memory Interface

Sheet 5 of 29
MCH845
Memory Interface



Clock Generator




Sheet 6 of 29
Clock Generator

Schematic Diagrams

Schematic Diagrams

DDRAM

Sheet 7 of 29



B - 8 DDRAM (71-56P00-D05)


Schematic Diagrams

Schematic Diagrams

Mobility P7


Sheet 9 of 29

Mobility P7




B - 10 Mobility P7 (71-56P00-D05)

Mobility Mem A; Term; LVDS




Schematic Diagrams

Mobility Mem B; CRT; TV Out



B - 12 Mobility Mem B; CRT; TV Out (71-56P00-D05)

ICH3 (1 of 3)




Sheet 12 of 29
ICH3
1 of 3

Schematic Diagrams

ICH3 (2 of 3)

Schematic Diagrams


Sheet 13 of 29
ICH3
2 of 3




B - 14 ICH3 (2 of 3) (71-56P00-D05)

Schematic Diagrams

ICH3 (3 of 3)



Sheet 14 of 29
ICH3
3 of 3




Schematic Diagrams

HDD/CDROM/FDD


Schematic Diagrams

Sheet 15 of 29
HDD/CDROM/FDD



B - 16 HDD/CDROM/FDD (71-56P00-D05)

Mini PCI; MDC Modem




Sheet 16 of 29
Mini PCI;
MDC Modem

Schematic Diagrams

Schematic Diagrams


LAN RTL8139CL

Sheet 17 of 29
LAN RTL8139CL



Schematic Diagrams

TI1394 TSB43AB22




Sheet 18 of 29
TI1394 TSB43AB22

Schematic Diagrams

Schematic Diagrams


NS-PC87393; IR; ROM



B - 20 NS-PC87393; IR; ROM (71-56P00-D05)

Schematic Diagrams

H8



Sheet 20 of 29
H8


Schematic Diagrams

Schematic Diagrams

KBC Conn; Fan Conn


Schematic Diagrams

Sheet 21 of 29
KBC Conn;
Fan Conn



B - 22 KBC Conn; Fan Conn (71-56P00-D05)

ACIN; PWR Button




Schematic Diagrams

Schematic Diagrams


AC'97 AD1886

Sheet 23 of 29
AC'97 AD1886



Schematic Diagrams

PCI 1410




Sheet 24 of 29
PCI 1410


Schematic Diagrams

PCMCIA Socket

Sheet 25 of 29
PCMCIA Socket



CPU Core Power




Sheet 26 of 29
CPU Core Power

Schematic Diagrams

Schematic Diagrams


D/D Conn



B - 28 D/D Conn (71-56P00-D05)

Schematic Diagrams

+3V; +5V



Sheet 28 of 29
+3V; +5V

Schematic Diagrams

USB 2.0

VIA TECHNOLOGIES ASSUMES NO RESPONSIBILITY FOR ANY ERRORS IN DRAWING THESE SCHEMATICS.
THESE SCHEMATICS ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE.
COPYRIGHT 2001 VIA TECHNOLOGIES INCORPORATED.

Sheet 29 of 29
USB 2.0

