
Tigercat Pentium II *System Board Manual*

MICRONICS

Document Number: 06-00305-01, Rev. 2A

July 1997

45365 Northport Loop West, Fremont, CA. 94538-6417

Copyright Notices

Copyright © 1997 Micronics Computers, Inc. The information contained in the Tigercat PCI/ISA/AGP Pentium II system board manual has been carefully checked and is believed to be accurate. Micronics assumes no responsibility for any inaccuracies that may be contained in this document. Micronics makes no commitments to update or to keep the information in this manual at a current level when changes are made to the product.

Micronics reserves the right to make improvements to this document and/or product at any time and without notice. All Rights Reserved. No part of this document may be photocopied, reproduced, translated, or reduced to any medium or machine form without prior, written consent from Micronics.

Portions of the Manual

Portions of this manual were copied (with permission) from Phoenix Technologies, Ltd. All rights reserved.

Trademarks

IBM is a registered trademark of International Business Machines. Microsoft and Windows are registered trademarks of Microsoft Corporation. Intel, PCI and AGP are registered trademarks of Intel Corporation. All other product names mentioned herein are used for identification purposes only and may be the trademarks of their respective companies.

Table of Contents

Introduction	5
Features	6
Software Compatibility	7
Before You Begin	8
Chapter 1 - Quick Installation	9
Installing the Tigercat	9
Chapter 2 - Configuring the Tigercat	11
Static Electricity	11
Environment Considerations	11
Tigercat System Board	12
Tigercat Back Panel Connections	12
Jumper Settings	13
Chapter 3 - Installing the Tigercat	19
Introduction	19
System Memory Support	19
Installing the Tigercat	20
Tools Required	20
Equipment Required	20
System Memory	21
Adding Memory	21
Memory Configurations	22
Installing DIMMs	25
Removing DIMMs	25
CPU Installation	26
Installing the CPU Retention Mechanism	26
Installing a CPU	27
CPU Installation Overview	29

CPU Installation (Box version)	30
Installing a PCI Peripheral Card	31
Installing an ISA Peripheral Card	32
Installing an AGP Peripheral Card	33
Installing a CD-ROM Drive	34
Tigercat Sound Option	35

Chapter 4 - The BIOS Setup Utility 37

Configuration	37
Initial Bootup	37
Setup	37
Running the Setup Procedure	39
Setting the Main Screen	39
Setting the Advanced Screen	44
Security Screen	47
Power Screen	50
Boot Screen	52
Exit Screen	53

Chapter 5 - Installing Device Drivers 55

About Device Drivers	55
Installing the Sound Drivers	55

Appendix A - Technical Information 57

Specifications	57
Environmental Specifications	59
Temperature Range	59
Relative Humidity	59
Battery Disposal	60
Support and Information Services	61
Technical Support	61

Appendix B - Post Messages	63
Appendix C - Beep and POST Codes	65
Appendix D - Hard Disk Drive Types	69
Appendix E - Updating the System BIOS	71
Appendix F - Warranties and Notices	73
Limited Warranty	73
FCC Statement	75
Glossary	76
Index	80

List of Figures

Figure 1.1: Power-Up Screen	10
Figure 2.1: Tigercat System Board	12
Figure 2.2: Tigercat Back Panel Connections	12
Figure 3.1: Installing a 168-Pin DIMM	25
Figure 3.2: Installing a CPU	27
Figure 3.3: Installing a CPU (Boxed version)	30
Figure 3.4: Installing a PCI Card	31
Figure 3.5: Installing an ISA Peripheral Card	32
Figure 3.6: Installing an AGP Peripheral Card	33
Figure 3.7: Connecting External Sound Devices	35
Figure 4.1: Power-Up Screen	38
Figure 4.2: CMOS Main Screen	39
Figure 4.3: IDE Device Submenu	42
Figure 4.4: Advanced Screen	44
Figure 4.5: Security Screen	47
Figure 4.6: Supervisor Password Submenu	48
Figure 4.7: Power Screen	50
Figure 4.8: Boot Screen	52
Figure 4.9: Exit Screen	53

List of Tables

Table 2.1: CPU Speed Selection	13
Table 2.2: Clear CMOS Settings	13
Table 2.3: Soft Power-On Setting	14
Table 2.4: Pipeline Mode Setting	14
Table 2.5: CPU Frequency Selection	14
Table 2.6: Onboard Sound Selection	15
Table 2.7: Onboard Sound Wavetable Selection	15
Table 2.8: Flash Memory Setting	15
Table 2.9: Case and Peripheral Connections	16
Table 3.1: Memory Configurations	22
Table A.1: Support and Information Services	62

Introduction

Thank you for choosing the Tigercat system board. The Tigercat is an advanced single processor solution for the industry's most demanding workstation and server applications.

Based on the Intel 440LX PCIsset, the Tigercat supports the latest advanced processor architecture, the Pentium® II (processor-on-a-cartridge), which provides the speed and performance necessary to address the most intensive computational applications. Hardware management support, Ultra DMA/33 IDE hard drive protocol (up to 33MBytes/sec transfer rate), and SDRAM memory support make this board powerful and feature rich.

In addition, the Tigercat comes with an AGP (Accelerated Graphics Port) bus slot, a faster bus than the current 33MHz PCI bus. The AGP bus provides a *direct* connection between the graphics subsystem and system memory.

The Wake-on-LAN and Resume-on-Modem Ring features offer you a way to access a local-area or wide-area network or modem to turn on desktop PCs remotely. The wake-up control located on the Tigercat system board collects input from a Wake-on-LAN enabled adapter and the PC's power switch. It then routes its output to the power-supply activation circuitry. You can power up your PC or multiple PCs from a remote location and manage networks more efficiently.

Micronics builds all products to exacting standards, using the highest quality components available. We are proud to provide this system board and believe you will be pleased with your purchase.

Features

The Tigercat includes the following features:

- ▲ Single Intel Slot 1®
Intel Pentium II® chip 233/266/300/333MHz
Integrated Voltage Regulator Module
- ▲ Intel 440LX PCIset
Intel PIIX 4
SMC FDC37C68x Ultra I/O chip
- ▲ Four 32-bit PCI slots
Two 16-bit ISA slots
(One is a shared PCI/ISA slot)
One AGP slot
- ▲ Four 3.3V unbuffered 64-bit 168-pin DIMM sockets
Maximum memory 512MB for SDRAM
Maximum memory 1GB for EDO
Supports EDO and SDRAM memory
ECC support via chipset
- ▲ Yamaha OPL3 and OPL4 sound (optional)
- ▲ Hardware Management - LM78 microprocessor system
hardware monitor w/ LM75 CPU temperature sensor
- ▲ Ultra DMA/33 IDE support
- ▲ Wake-on-LAN headers
- ▲ ATX form factor

Software Compatibility

The Tigercat system board has been thoroughly tested for compatibility with a variety of operating systems and environments, including:

- ▲ Microsoft
 - DOS 6.2x
 - Windows 95
 - Windows NT 3.5x
 - Windows NT 4.0

- ▲ IBM
 - OS/2 Warp 3.0
 - OS/2 Warp 4.0

- ▲ SCO
 - UNIXWare 2.1.1
 - Open Server 5.02
 - UNIX 3.2.4.2

- ▲ Novell NetWare 3.12
 - Novell NetWare 4.11

Before You Begin

This manual will familiarize you with the features, installation and use of your Tigercat. There are several symbols and conventions used throughout this manual to help draw your attention to a feature or to focus on important information:



When you see the Magnifying Glass, it refers to something you should take a closer look at before proceeding further.



When you see the Exclamation Mark, it gives important information on avoiding damage.

Common Names

AGP	Accelerated Graphics Port
DIMM	Dual Inline Memory Module
DRAM	Dynamic Random Access Memory
ECC	Error Checking and Correction
EDO	Extended Data Out
IDE	Integrated Drive Electronics
PCI	Peripheral Component Interconnect
SDRAM	Synchronous DRAM
USB	Universal Serial Bus
VRM	Voltage Regulator Module

Chapter

1

Quick Installation

We know that many experienced people prefer to read as little of the documentation as possible. If this sounds like you, here's the short form to get up and running quickly.

Installing the Tigercat

**STATIC!**

Before handling the Tigercat, be properly grounded by using a special wrist or ankle strap, or touch a safely grounded object.

1. Make backup copies of your installation and configuration diskettes.
2. Ground yourself to prevent damaging static discharge by using an anti-static wrist or ankle strap, or touch a safely grounded metal object.
3. Remove the Tigercat from its packaging.
4. Configure and verify the system board's jumper settings (refer to Jumper Settings in Chapter 2).
5. Install the CPU and the system memory. Be sure to attach the Retention Mechanism as described in Chapter 3.
6. Install the system board in the chassis and make all necessary case connections.
7. Install any ISA, PCI and/or AGP add-on peripherals (refer to Chapter 2 for the location of the slots).
8. Connect any optional devices.
9. Turn the computer on and press the <F2> key when you see the screen shown in Figure 1.1.
10. Set the time and date. Adjust the BIOS settings to match your configuration. If installing an IDE drive, select the IDE device you wish to configure. Press ENTER with Autotype Fixed Disk selected and the BIOS will automatically configure the drive for you (refer to Chapter 4).




Figure 1.1: Power-Up Screen

11. After you have configured the Main Setup menu, make any desired setting configurations in the Advanced and Security menu. When finished, go to the exit screen, select "Save Changes and Exit" and you are finished with the BIOS configuration (see Chapter 4).
12. Install the sound device drivers (optional). Refer to Chapter 5.

Configuring the Tigercat

Although the Tigercat system board is packaged in materials that are designed to protect it from physical damage and static electricity, it is important to use care while unpacking the board and setting it up.

Static Electricity

The Tigercat is shipped from the factory in an anti-static bag. To reduce the possibility of damage from static discharge, it is important to neutralize any static charges your body may have accumulated before handling the board.

The best way to do this is to ground yourself using a special anti-static wrist or ankle strap. If you do not have an anti-static strap available, touch both of your hands to a safely grounded object, such as the power supply or chassis of a computer that is connected to the power socket. After you have grounded yourself, ground the Tigercat board via one of the solder pads that surround its mounting holes. When you remove the Tigercat from its packaging, place it on top of the anti-static bag, and carefully inspect the board for damage which might have occurred during shipment.

Environment Considerations

Make sure the finished computer system is in an area with good ventilation. The system should not be in direct sunlight, near heaters, or exposed to moisture, dust, or dirt.

Jumper Settings

This section provides the jumper settings for the Tigercat system board.

Table 2-1 lists the jumper settings to select the system speed settings.

System Speed (Intel Processors)	Jumper				
	W1	W3	W3	W3	W3
		1-2	3-4	5-6	7-8
233 MHz External, 66 MHz Internal*	2-3	Close	Close	Open	Open
266 MHz External, 66 MHz Internal	2-3	Close	Open	Close	Close
300 MHz External, 66 MHz Internal	2-3	Close	Open	Close	Open
333 MHz External, 66 MHz Internal	2-3	Close	Open	Open	Close

Table 2-1: System Speed Selection

*Default Setting

Table 2-2 lists the settings to clear the CMOS. With your computer's power off, close pins 2-3, wait ten seconds and place the jumper back on pins 1-2. (The jumper must be placed back on pins 1-2 for the system to function properly.)

NOTE: This will reset all BIOS default settings. Any changes you have made will be lost.

Jumper	Function	Settings
W5	Normal (default)	1-2
	Clear CMOS	2-3

Table 2-2: Clear CMOS Settings

Table 2-3 lists the settings for the system power-on setting. When set for Normal operation the power supply is turned On/Off using a momentary push-button switch connected to J27. When set for Forced Cycling the power supply is always turned on, regardless of the push-button connected to J27.

Jumper	Function	Settings
W6	Normal (default)	Open
	Forced Cycling	Close

Table 2-3: Soft Power On/Off Setting

Table 2-4 lists the settings for the Host Bus Agents Pipelining mode. Host Bus Agents are devices connected to the CPU local bus, which include the CPU and the 440LX chipset. Pipelining allows for the overall task of these devices to be divided into smaller overlapping tasks, and provides fast throughput for sequential processes.

Jumper	Function	Settings
W2	Reserved	1-2
	Normal (default)	2-3

Table 2-4: Pipeline Mode Setting

Table 2-5 lists the settings for the CPU bus speed frequency selection.

External Bus Speeds	W1
60MHz	1-2
66MHz (default)	2-3

Table 2-5: CPU Frequency Selection

Table 2-6 lists the settings to enable or disable the optional onboard sound.

Jumper	Function	Settings
W7	Sound Enabled (default)	1-2
	Sound Disabled	2-3

Table 2-6: Onboard Sound Selection

Table 2-7 lists the settings to enable or disable the optional onboard sound wavetable.

Jumper	Function	Settings
J36	Wavetable Enabled (default)	Close
	Wavetable Disabled	Open

Table 2-7: Onboard Sound Wavetable Selection

Table 2-8 lists the settings for the flash memory to reprogram the BIOS. NOTE: To flash the BIOS, you must place a jumper on W4 in position 2-3 as shown in the table. (Refer to Appendix E for details on reprogramming the system BIOS).

Jumper	Function	Settings
W4	Write Protect (default)	1-2
	Program	2-3

Table 2-8: Flash Memory Setting

Table 2-9 lists the connectors and their functions.

Connector	Function	Notes
J1	AGP Bus Expansion Slot	62 x 2-pin connector
J2-J5	DRAM (168-pin DIMM Sockets)	3.3 volt, unbuffered EDO and SDRAM DIMMs
J7, J8	Primary and Secondary IDE Port Connectors	Both support up to two IDE devices
J9	Floppy Drive Connector	Supports up to two floppy drives
J10	HD LED Connector	1 - Activity LED Input; 2 - No Connect
J11	USB Connector	Lower Level: USB Port 1 Upper Level: USB Port 0
J12	PS/2 Keyboard Connector PS/2 Mouse Connector	Lower Level Upper Level
J13	Parallel Port Connector	Upper Level
J14, J15	Serial Ports	COM A & COM B
J16-J19	PCI Bus Expansion Slots	
J20-J21	ISA Bus Expansion Slots	
J26	ATX Power Supply Connector	
J27	Front Panel I/O Connector	
"	System Power On/Off	1 - Power; 2 - Ground
"	Infrared Port	6 - +5V DC; 7 - No Connect; 8 - Receive Data; 9 - Ground; 10 - Transmit Data
"	Drive Activity LED Note: IDE, SCSI Channels A/B and Add-In Drive Controller share the same LED	13 or 16 - Positive; 15 - Negative
"	Power-On LED	18 - Ground; 20 - Positive
"	System Reset Switch	22 - Ground; 23 - Reset
"	External PC Speaker Note: To use the onboard PC Speaker, jumper pins 26 and 27 on J24	26 - Onboard PC Speaker Signal; 27- External PC Speaker Signal

Table 2-9: Connector Settings and Functions

Connector	Function	Notes
J28	CPU Fan	1 - Ground; 2 - +12V Power; 3 - Fan Speed Monitor
J29	Chassis Fan	2 - 12+V Power; 1 - Ground; 3 - Status (Running or Stopped)
J31	External Temperature Sensor Connector	1 - SMDATA; 2 - Ground; 3 - SMCLOCK; 4 - VCC; 5 - Board temperature interrupt
J32	Chassis Intrusion Sensor Connector	1 - Battery Power (approx +3V); 2 - Trigger Input (pull to pin 1 voltage to indicate intrusion)
J33	CD Audio Line In	1 - Line-In Left Channel; 2 - Ground; 3 - Ground; 4 - Line-In Right Channel
J34	CD-ROM Audio (Sound Blaster Interface)	1 - Ground; 2 - CD-In Left Channel; 3 - Ground; 4 - CD-In Right Channel
J35	Modem/Telephony (ATAPI Interface)	1 - Speaker Input; 2 - Ground; 3 - Ground; 4 - Amplified MIC Output
J36	Wavetable Connector	
J37	Game Port/MIDI MIC In, Line In, Line Out	Upper Level Lower Level
J40	CD-ROM Audio (Sound Blaster Interface)	1 - Ground; 2 - CD-In Left Channel; 3 - Ground; 4 - CD-In Right Channel
J41	Wake-On-LAN Connector	1 - +5V Standby Power Output; 2- Ground; 3 - LAN-Wakeup Signal Input
U1	Pentium II CPU	

Table 2-9a: Connector Settings and Functions

Installing the Tigercat

Introduction

This chapter explains how to install the Tigercat system board, memory, CPU and peripherals.

WARNING: *Before installing or removing any peripherals or components, make sure you have a clear work space and that you adhere to all anti-static precautions described in Chapter 1. Micronics recommends that only trained technicians install and configure the system board.*

Damage which occurs to the board while adding or removing peripherals or components may void the warranty. If problems arise while installing peripherals, contact the computer dealer where you purchased the peripheral or Micronics' Technical Support Department.

System Memory Support

The flexibility of the Tigercat is augmented by its support for EDO and SDRAM memory. The Tigercat supports ECC (with 72-bit DIMMs) via the chipset.

SDRAM speed and synchronous operation have enabled the breakthrough in memory-systems design needed to meet the demands of fast high-performance processors. SDRAM improves bandwidth to main memory because all address, data and control signals are synchronized with a system clock. With all operations in synch, system wait states are eliminated, thus providing increased performance over conventional DRAM.

Installing the Tigercat

Installation of the Tigercat system board depends on the type of case you use. The Tigercat is designed for the ATX form factor and must be installed in an ATX chassis.

NOTE: If you are unfamiliar with installing a system board, Micronics highly recommends that you read the computer user's manual or contact your dealer's technical support department.

Tools Required

Micronics recommends using the following tools to install the Tigercat:

- Small Phillips screwdriver
- Tweezers or a pair of needle-nose pliers
- Tray (to hold loose screws)

Equipment Required

Micronics recommends using the following equipment with the Tigercat for a typical configuration:

- ATX chassis with standard hardware.
- A high-quality ATX power supply capable of providing continuous power within a 3 volt range. A power filter may be used with a noisy AC power source.
- PS/2 mouse and compatible keyboard.
- Eight ohm speaker.
- Standard ribbon cables for internal connections.
- Standard power cord (grounded).

System Memory

System memory is necessary to operate the Tigercat system board. The Tigercat has four 3.3V unbuffered 64/72-bit, 168-pin DIMM sockets for a maximum of 1GB of EDO memory and 512MB of SDRAM memory. This section lists the rules for adding memory to the Tigercat, gives some examples of common memory configurations and shows how to physically install the memory.

Adding Memory

The following is a list of rules to follow when installing DIMMs. If you follow these rules, your upgrade should be trouble-free:



For long term reliability, Micronics recommends using DIMMs with gold-plated contacts. The use of tin-plated contacts may conflict with the gold alloy on the DIMM socket.

- ❑ Use 10ns or faster SDRAM or 60ns or faster EDO DIMMs.
- ❑ DIMM memory modules support EDO and SDRAM (unbuffered) memory types.
- ❑ Singled-sided and double-sided memory modules are supported.
- ❑ Different memory types and sizes in separate banks will cause the performance of the memory to run at the speed of the slowest RAM installed, and/or cause operating system stability problems.



168-Pin DIMM

Memory Configurations

DIMM memory configuration is auto-banking and therefore does not need to be installed in any particular order. The following table lists the most common memory configurations.

Memory	Bank 1	Bank 2	Bank 3	Bank 4
8MB	1Mx64			
16MB	2Mx64			
16MB	1Mx64	1Mx64		
24MB	2Mx64	1Mx64		
24MB	1Mx64	1Mx64	1Mx64	
32MB	2Mx64	2Mx64		
32MB	4Mx64			
32MB	1Mx64	1Mx64	1Mx64	1Mx64
40MB	2Mx64	2Mx64	1Mx64	
40MB	2Mx64	1Mx64	1Mx64	1Mx64
40MB	4Mx64	1Mx64		
48MB	2Mx64	2Mx64	2Mx64	
48MB	2Mx64	2Mx64	1Mx64	1Mx64
48MB	4Mx64	1Mx64	1Mx64	
56MB	4Mx64	2Mx64	1Mx64	
56MB	4Mx64	1Mx64	1Mx64	1Mx64
64MB	2Mx64	2Mx64	2Mx64	2Mx64

Table 3-1: Memory Configurations

Memory	Bank 1	Bank 2	Bank 3	Bank 4
64MB	4Mx64	4Mx64		
64MB	8Mx64			
80MB	4Mx64	2Mx64	2Mx64	2Mx64
80MB	4Mx64	4Mx64	1Mx64	1Mx64
80MB	8Mx64	2Mx64		
80MB	8Mx64	1Mx64	1Mx64	
96MB	4Mx64	4Mx64	2Mx64	2Mx64
96MB	4Mx64	4Mx64	4Mx64	
96MB	8Mx64	2Mx64	1Mx64	1Mx64
112MB	4Mx64	4Mx64	4Mx64	2Mx64
112MB	8Mx64	4Mx64	2Mx64	
112MB	8Mx64	4Mx64	1Mx64	1Mx64
128MB	16Mx64			
128MB	4Mx64	4Mx64	4Mx64	4Mx64
128MB	8Mx64	4Mx64	4Mx64	
128MB	8Mx64	8Mx64		
160MR	16Mx64	2Mx64	1Mx64	1Mx64

Table 3-1a: Memory Configurations

Memory	Bank 1	Bank 2	Bank 3	Bank 4
192MB	16Mx64	4Mx64	4Mx64	
192MB	8Mx64	8Mx64	4Mx64	4Mx64
192MB	8Mx64	8Mx64	8Mx64	
224MB	16Mx64	8Mx64	2Mx64	2Mx64
224MB	16Mx64	8Mx64	4Mx64	
256MB	16Mx64	16Mx64		
256MB	16Mx64	8Mx64	4Mx64	4Mx64
256MB	16Mx64	8Mx64	8Mx64	
256MB	8Mx64	8Mx64	8Mx64	8Mx64
288MB	16Mx64	16Mx64	4Mx64	
320MB	16Mx64	8Mx64	8Mx64	8Mx64
384MB	16Mx64	16Mx64	16Mx64	
384MB	16Mx64	16Mx64	8Mx64	8Mx64
448MB	16Mx64	16Mx64	16Mx64	8Mx64
512MB	16Mx64	16Mx64	16Mx64	16Mx64
1GB	32Mx64	32Mx64	32Mx64	32Mx64

Table 3-1b: Memory Configurations

Installing DIMMs

To install the DIMMs, locate the memory banks on the system board and perform the following steps:

1. Hold the DIMM so that the notched edge is aligned with the notch on the DIMM socket (Figure 3-1).
2. Insert the DIMM at a 90 degree angle.
3. Gently push the DIMM straight down until it locks into place (past the release tabs).




Figure 3-1: Installing a 168-Pin DIMM

Removing DIMMs

To remove DIMMs, follow the steps below:

1. With both thumbs (or fingers), press the release tabs away from the socket.
2. With the DIMM free from the release tabs, lift the module up and place in an anti-static bag or package.

CPU Installation


The Tigercat is designed to support single Pentium II processors. The Pentium II processor comes installed in a Single Edge Contact (SEC) cartridge that connects into "Slot 1" on the system board.

A Retention Mechanism is supplied to anchor the processor to the system board. Attach the Retention Mechanism before inserting the processor.

Installing the CPU Retention Mechanism


Before you begin, verify that your Retention Mechanism Kit contains the following items:

- Retention Base (black plastic module)
- Support Bridges with Studs (plastic mounts).




Follow the steps below to install the kit:


1. Locate the four Retention Base holes (near each end of the Slot 1 socket). Insert the two Support Bridges with studs (plastic mounts) from the bottom side of the Tigercat toward the component side until they snap into place.



2. Place the Retention Base over the Slot 1 connector and insert it down into the Support Bridges with studs. Note the “Keyed” location of both Slot 1 and the Retention Base.



3. Using a screwdriver, tighten all four sides of the Retention Base.




Installing a CPU

Follow the steps below to install the Pentium II processor:

1. Locate the Slot 1 connector (refer to Figure 2-1).
2. If you are installing the boxed version of the Pentium II processor, follow the instructions in the section “CPU Installation (Boxed version).”
3. If you are installing the *optional* Heat Sink Support, continue to step 4; if not, go to step 5.

4. The Heatsink components consist of a top bar, base and two pins. Gently insert the Heatsink base into the holes next to the Slot 1 socket. Push down until the base snaps into place.



5. Gently insert the processor cartridge down into the Retention Module, making sure the connector on the processor cartridge and the Slot 1 connector are aligned (refer to the keyed location on the previous page).
6. Push the processor cartridge down until it snaps into place.
7. Lock the processor cartridge into place by pushing outward on the tabs located on both sides of the processor cartridge. The processor cartridge is locked when the tabs snap into the holes on the side of the Retention Mechanism.
8. After the processor cartridge is locked into place, connect the Heatsink's top bar to the base.
9. Lock the base into place by inserting a pin down into the base on both sides.
10. Make sure the speed selection jumpers are set correctly (refer to Chapter 2 - Jumper Settings).

CPU Installation Overview

CPU Installation Overview

1. Mount the Retention Mechanism for the CPU.
2. Mount the (optional) heatsink support base onto the system board.
3. Slide the CPU into the Retention Mechanism.
4. Lock the CPU into the Retention mechanism using the tabs.
5. Slide in the Heat Sink Top Bar, then insert the pins to lock it in place.




Figure 3-2: Installing a CPU

CPU Installation (Boxed version)

A boxed version of the CPU is offered through Intel. This packaging uses an active cooling fan. The mounting hardware is described below. For detailed instructions, please refer to the documentation that is supplied with your CPU.

NOTE: Make sure the speed selection jumpers are set correctly (refer to Chapter 2 - Jumper Settings).




Figure 3-3: Installing a CPU (Boxed version)

Installing a PCI Peripheral Card

Micronics PCI slots accommodate all PCI peripherals that meet the PCI 2.1 specifications. Follow the steps below to install a PCI card:

1. Turn the computer system off and remove its cover.
2. Choose an unused PCI slot and remove the slot cover.
3. Insert the card with the bottom edge level to the slot. *Never insert the card at an angle.*
4. Carefully push the card straight down, making sure the card is fully inserted.
5. Replace the screw which holds the card in place.
6. Replace the computer cover.
7. Refer to the PCI card's documentation additional instructions regarding installation and software drivers.




Figure 3-4: Installing a PCI Card

Installing an ISA Peripheral Card

Micronics ISA slots accommodate all standard ISA peripherals. Follow the steps below to install an ISA card:

1. Turn the computer system off and remove its cover.
2. Choose an unused ISA slot and remove the slot cover.
3. Insert the card with the bottom edge level to the slot. *Never insert the card at an angle.*
4. Carefully push the card straight down, making sure the card is fully inserted.
5. Replace the screw that holds the card in place.
6. Replace the computer cover.
7. Refer to the ISA card's documentation for additional instructions regarding installation and software drivers.




Figure 3-5: Installing an ISA Peripheral Card

Installing an AGP Peripheral Card

Micronics AGP slot can accommodate all AGP peripherals that meet the Intel AGP bus specifications. Follow the steps below to install an AGP card:

1. Turn the computer system off and remove its cover.
2. Locate the AGP slot (J1) and remove the slot cover.
3. Insert the card with the bottom edge level to the slot.
Never insert the card at an angle.
4. Carefully push the card straight down, making sure the card is fully inserted.
5. Replace the screw which holds the card in place.
6. Replace the computer cover.
7. Refer to the AGP card's documentation for additional instructions regarding installation and software drivers.




Figure 3-6: Installing an AGP Peripheral Card

Installing a CD-ROM Drive

If you are installing a CD-ROM drive, Micronics recommends the installation of an IDE CD-ROM drive. *The instructions below will help you with the installation, but also refer to the documentation that accompanied your CD-ROM drive.*

Before starting the setup and installation, make sure your computer is off and the power cord is disconnected from the wall outlet. Your CD-ROM drive kit should contain the following items for a successful installation:

- CD-ROM Drive with installation hardware
 - Interface Cable
 - CD Audio Cable
1. Connect the ribbon cable as described in the CD-ROM's documentation, making sure the red stripe on the cable is aligned with pin 1 of the connectors.
 2. Connect the audio cable to the CD-ROM drive's audio connector.
 3. Connect the other end of the audio cable to the MPC-2 compatible CD-ROM audio connector on the Tigercat system board (see Figures 2.1 and 2.2).
 4. Connect the power supply cable to the CD-ROM drive's power connector.
 5. Install the CD-ROM device drivers. CD-ROM drives require device drivers to access the drive and are generally provided by the manufacturer of the CD-ROM drive. Usually one device driver is added to the CONFIG.SYS file and one to the AUTOEXEC.BAT file.
 6. If you are using the CD-ROM drive in an MS-DOS environment, the utility MSCDEX.EXE must also be added to the AUTOEXEC.BAT file. Consult your DOS manual for more information.

Tigercat Sound Option

You can connect external sound devices to your Tigercat system board to take advantage of the optional sound support (refer to Figure 2.2). The sound option includes 16-bit stereo sound and a game and MIDI port. See Chapter 5 for information on installing sound device drivers.

Connecting Sound Devices




Figure 3-7: Connecting External Sound Devices

Game Port

You can use the Game Port connector to connect an IBM PC compatible joystick or MIDI instrument.

Line Out

The Line Out jack allows you to connect the audio output of the audio controller to your home stereo, VCR, or amplified speakers.

Line In

You may connect an external mono or stereo audio source to the audio controller, such as a tape player or radio. Use the appropriate converter cable to interface to your external equipment.

MIC In

The MIC In jack will accommodate a 600 ohm microphone.

Configuration

After the Tigercat system board and all hardware is installed, the system is ready for configuration. Before turning on the computer, make sure all cables are correctly connected and all jumpers are correctly set.

We recommend that you keep the computer cover off the first time you boot the system. This makes it faster and easier to correct any difficulties that might arise.

Initial Boot Up

Power up the Tigercat. If the system does not properly boot, check all your cables and peripherals for bad connections. You may also get beep codes or error messages. If this occurs, consult Appendix B for a guide to possible solutions.

After the system properly boots, it is ready to be configured. The following information explains the proper procedures for BIOS configuration.

Setup

The Setup program is used to configure the computer's BIOS (Basic Input/Output System). The computer's BIOS is responsible for configuring the system board and providing hardware information to the operating system. In order for the computer to run properly, run the Setup procedure after first installing the system board and whenever you make a hardware change to the system.

When the system is turned on, it performs a memory test, and a BIOS identification and system information screen is displayed on your monitor, as shown in Figure 4-1.




Figure 4-1: Power-Up Screen

When “Press <F2> to enter Setup” appears at the bottom of the screen, press the <F2> key to start the Setup program. The main CMOS Setup utility screen (Figure 4-2) appears. Note that the Setup program can only be activated during the boot sequence.

Running the Setup Procedure

The Tigercat system board has six primary CMOS configuration screens: Main, Advanced, Security, Power, Boot and Exit. To toggle between the screens, press the right arrow <→> and the left arrow <←> keys.

Setting the Main Screen

The CMOS Main screen is used to set the time and date, to set the floppy drive types, to configure IDE hard disks and to configure the video. This chapter explains how to configure each of these categories. To move between the categories, use the up and down arrow <↑/↓> keys.




Figure 4-2: CMOS Main Screen

System Time and Date

To set the Time, use the <-> key to decrease the number and the <+> key to increase the number. To move the prompt forward, use the <Tab> key; to move the prompt backward, use the <Shift-Tab> key. To set the Date, use the up and down arrows <↑/↓> to highlight the System Date and follow the same procedure used to set the Time.

Diskette A or B

To configure a floppy drive added to or removed from your computer, use the up and down arrow keys <↑/↓> to select the desired drive. Use the <+/-> keys to change the setting until it matches the floppy drive you installed. The BIOS supports 2.88MB, 1.44MB, 1.2MB, 720KB, and 360KB floppy drives.

Numlock

Setting this to ON activates Numlock upon boot. Setting this to Auto (default) activates Numlock if the BIOS detects a numeric keyboard. It may also be set to OFF.

External Cache

This selection allows you to enable the external memory cache. For optimal performance, select Enabled.

Video BIOS

The Video BIOS category allows you to Shadow or Shadow & Cache the video BIOS. Choosing Shadowed & Cached (default) caches the shadowed video BIOS for even higher performance. Choosing Shadowed copies the video BIOS into RAM for faster execution. To disable the Video BIOS category, select Disabled.

System BIOS

The System BIOS category allows you to Shadow or Shadow & Cache the system BIOS. Choosing Shadowed & Cached (default) caches the shadowed system BIOS for even higher performance. Choosing Shadowed copies the system BIOS into RAM for faster execution. To disable the System BIOS category, select Disabled.

System Memory

The System Memory category identifies the size of the base memory. It cannot be changed.

Extended Memory

The Extended Memory category automatically detects the amount of memory installed above the amount in the System Memory category. Because the BIOS automatically calculates the amount of memory installed in your system, you cannot change this category without adding or removing memory.




Figure 4-3: IDE Device Submenu

Type

This category selects the drive type installed in the system. The options are Auto (default), User and None. If Autotype Fixed Disk does not find your drive's parameters, fill this information in manually under the User category. This information may be in the manual which came with your system. If not, contact your dealer or the hard drive manufacturer to fill in this category. If you are using a SCSI hard drive, select None and refer to the documentation which came with the SCSI adapter.

Multiple-Sector Transfers

This category determines the number of sectors per block for multiple sector transfers. The options are Auto (default), Disabled, 2 Sectors, 4 Sectors, 6 Sectors, 8 Sectors and 16 Sectors.

LBA Mode Control

Enabling this selection causes LBA (Logical Block Addressing) to be used in place of Cylinders, Heads and Sectors. The LBA Mode Control supports drives larger than 500MB. The default setting is Enabled.

32-Bit I/O

This category allows you to enable the 32-bit I/O function of the PCI IDE controller. Select Disabled if your drive will not run at this speed. The default setting is Disabled.

Transfer Mode

This category sets the transfer speeds for IDE devices. The Standard option is the default setting. The Fast PIO 1, Fast PIO 2, Fast PIO 3 and Fast PIO 4 options are for higher speed devices.

Ultra DMA Mode

This option will enable or disable the Ultra DMA/33 feature. Ultra DMA/33 is a hard drive interface protocol that increases the burst data transfer rate to 33MBytes per second.

Smart Monitoring

This feature will monitor your hard drive and report any problems detected. The default setting cannot be changed.

Setting the Advanced Screen

To move to the Advanced screen, use the left and right arrow keys <←/→> keys until you see the screen below.




Figure 4-4: Advanced Screen

Serial Port A

Serial Port A may be configured using the following options: Disabled (No configuration), Enabled (User configuration), Auto (BIOS configuration) and PnP O/S (O/S configuration).

Serial Port B

Serial Port B may be configured using the following options: Disabled (No configuration), Enabled (User configuration), Auto (BIOS configuration) and PnP O/S (O/S configuration).

Parallel Port

The parallel port may be configured using the following options: Disabled (No configuration), Enabled (User configuration), Auto (BIOS configuration) and PnP O/S (O/S configuration).

Floppy Disk Controller

The selection allows you to enable or disable the floppy disk controller.

Integrated PCI IDE

Enables or disables the integrated PCI IDE adapter. The IDE controller may be set for Primary, Both (default) or Disabled.

Integrated Sound Card

Enables or disables the integrated sound interface. The option works only if your sound card has been enabled via the jumper (refer to Chapter 2). The default setting is Enabled.

LM78

Enable or disable the integrated LM78 microprocessor system hardware monitor with the proper software. The LM78 can be used to monitor temperatures, power supply voltages and fan speeds.

Plug & Play O/S

This selection allows your system to work with a Plug and Play operating system such as Windows 95. The default setting is Yes. NOTE: This selection should be set to No when using DOS, Windows 3.1 or Windows NT.

Reset Configuration Data

Select Yes to reset Extended System Configuration Data (ESCD) when you exit Setup. This selection allows the PnP BIOS to detect your PCI and ISA PnP devices and reallocate resources to them. The default setting is No.

PCI Configuration

Use this selection for additional setup menus to configure PCI devices.

USB Legacy Mode

Use this selection to provide BIOS support for USB devices to function in alternative operating systems. Your USB device must still have and load its own drivers for that particular operating system. Select Enabled (default) when using DOS and Windows 95 operating systems. Select Disabled when using Windows NT, OS/2 and Unix operating systems.

PS/2 Mouse

When disabled, this selection prevents the PS/2 mouse from functioning and frees up IRQ12. Selecting Enabled (default) allows the operating system to determine whether to enable or disable the mouse.

Secured Setup Configuration

Select Yes if you want the system settings to be secured from change by a Plug and Play operating system. The default setting is No.

Large Disk Access Mode

If you are using a DOS operating system (MS-DOS, Novell DOS or PC-DOS), set to DOS (default). If you are using anything else, set to OTHER.

Smart Monitoring

This feature will monitor your hard drive and report any problems detected. The default setting cannot be changed.

ECC Configuration

If all memory in the system supports ECC (x72), this selection can be set for Error Checking, Error Checking and Correction, or Checking Connection with Scrubbing. The default setting is Disabled.

Security Screen

The Security screen controls access to the computer. The security screen allows for settings of two passwords. The Supervisor Password allows access to the system and Setup. The User Password allows access to the system, but not to all Setup features.




Figure 4-5: Security Setup Screen

Set Supervisor Password

This selection controls access to the Setup utility. Press the ENTER key to enter the Supervisor Password submenu. The screen on the following page appears.




Figure 4-6: Supervisor Password Submenu

Type the password and press the ENTER key. Retype the password and press the ENTER key again. Write down the password somewhere safe so it will not be forgotten. The password may be disabled by setting the new password to nothing (pressing the ENTER key without first typing a password).

WARNING: If you forget the Supervisor Password, it cannot be disabled without discharging the CMOS.

Set User Password

This selection controls access to the Setup utility. Follow the same procedure used to set the Supervisor Password.

NOTE: After a password is entered, it is saved immediately. All other changes may still be discarded (see Exit Screen).

Password on Boot

When enabled, the system requires a password upon power up. Either the Supervisor or User Password may be entered.

Fixed Disk Boot Sector

This selection allows the boot sector of the fixed disk to be write protected. The default setting is Normal. When set for Write Protected, it serves as a form of virus protection. If the passwords are enabled, this option may only be changed by the Supervisor.

Diskette Access

This selection allows floppy disk access with an option of the supervisor or user. Selecting Supervisor (default) gives floppy disk access to the supervisor only. Selecting User gives floppy disk access to both the user *and* the supervisor. If the passwords are enabled, this option may only be changed by the Supervisor.

Power Screen

The Power Screen controls the power management functions of the system. To move to the Power Screen, use the left and right arrow <←/→> keys until it appears. To move between the categories, use the up and down arrow keys <↑/↓>.




Figure 4-7: Power Screen

Power Savings

This selection allows you to change the system power management settings. Maximum Power Savings conserves the greatest amount of system power. Maximum Performance conserves power but allows greatest system performance. To alter these settings, choose Customize. To turn off power management, choose Disabled (default).

Standby Time-out

The Standby Time-out selection sets the amount of time that elapses for the system to enter Standby Mode. Standby Mode turns off various devices in the system, including the display screen, until you start using the system again. The options are Off (default), 1 min., 2 min., 4 min., 6 min., 8 min., 12 min. or 16 min.

Auto Suspend Time-out

The Standby Time-out selection sets the amount of time that elapses for the system to enter Suspend Mode. The options are Off (default), 5 min., 10 min., 15 min., 20 min., 30 min., 40 min. or 60 min. Before making changes, "Customized" must be selected in the Power Management Mode selection.

Resume On Time

When this feature is turned On, the system counts down to zero and awakes from Standby or Suspend mode. Before making changes, "Customized" must be selected in the Power Management Mode category. The default setting is Off.

Resume On Modem Ring

When this feature is turned On, the system will wake up from Suspend mode when an incoming call is detected on your modem. Before making changes, "Customized" must be selected in the Power Management Mode category. The default setting is Off.

Boot Screen

The Boot screen allows you to configure the power up system configuration settings. To move to the Boot Screen, use the left and right arrow <←/→> keys until it appears. To move between the categories, use the up and down arrow keys <↑/↓>.




Figure 4-8: Boot Screen

Boot Device Priority

This feature will set the search order for the types of bootable devices.

Hard Drive

This selection will read the diskette drive (default) and the hard drive in sequence on boot.

Floppy Check

This selection checks for the existence of a floppy drive. The default setting is Enabled.

Exit Screen

After you complete configuring the BIOS, select the Exit screen. To move to the Exit Screen, use the left and right arrow <←/→> keys until it appears. To move between the categories, use the up and down arrow keys <↑/↓>.




Figure 4-9: Exit Screen

Choose “Save Changes and Exit” and reboot the computer. Your computer is ready for use.

Installing Device Drivers

This chapter explains how to install the software device drivers and utilities necessary to utilize the optional sound support. Other drivers and utilities are available through our online services.

About Device Drivers

Device drivers are necessary for the computer system to communicate with devices such as CD-ROM drives, sound controllers, graphics adapters or devices that are not natively supported by the system BIOS. Once started, device drivers remain active in the background of the computer system. Usually a device driver is added to the CONFIG.SYS file, the AUTOEXEC.BAT file or both.

Installing the Sound Drivers

Once you have connected your external sound devices, you can install the sound drivers. **NOTE:** If you are installing a CD-ROM drive, it is recommended you install it before setting up the sound devices. See Installing a CD-ROM Drive in Chapter 3.

1. Follow the instructions in Chapter 3 on connecting external sound devices.
2. If you previously installed another sound card, remove it and all associated files from your AUTOEXEC.BAT and CONFIG.SYS files. If you are using Windows 3.1x, you must also remove all associated files from the WIN.INI and SYSTEM.INI files. (For more information, please contact the sound driver manufacturer.)
3. Start your computer system.

4. Insert the sound driver disk into your floppy drive.
5. If you are using Windows 3.1x, go to the Program Manager File menu, click on Run and type A:\SETUP.
6. If you are using Windows 95, refer to the Windows 95 user's manual for instructions on how to install sound drivers.
7. If you are using Windows NT, refer to the Windows NT user's manual for instructions on how to install sound drivers.
8. If you are using OS/2, refer to the README file on the OS/2 disk for instructions on how to install sound drivers.
9. Once the software is copied, the install program automatically updates the system files.

Appendix

Specifications

A

Part Number:	09-00305-xx
Processor:	Intel Pentium II® chip 233/266/333MHz. Single Intel Slot 1® Integrated VRM
CPU Clock Select:	Support for 60 and 66 MHz CPU bus
Chipset:	Intel 440LX PCIset Intel PIIX 4 SMC FDC37C68x Ultra I/O chip
Form Factor:	ATX footprint Four layer board Stacked I/O connectors (Intel Venus I/O Shield compatible). 20-pin ATX power connector
Expansion:	Four 32-bit PCI slots Two 16-bit ISA slots (One is a shared PCI/ISA slot) One AGP slot
BIOS:	Phoenix 4.06 BIOS on 2MB Flash APM 1.2 PCI auto configuration Auto detection of memory size Auto detection and display of EDO and SDRAM memory. Auto detection of IDE hard disk types Soft Power Down Instant On and Quick Boot Multi-boot II DMI 2.0/SMI/ACPI Wake-on-LAN

Keyboard/Mouse:	PS/2 style keyboard and mouse
Memory Capacity:	Four 3.3V unbuffered 64-bit DIMM sockets Maximum memory - 1GB for EDO Maximum memory - 512KB for SDRAM Supports EDO and SDRAM memory ECC supported via chipset when using parity
Onboard Sound: (optional)	Yamaha OPL3 and OPL4 Sound Blaster™ compatible 16-bit stereo Line In, Line Out, MIC and Game/MIDI ports 4-pin CD-ROM audio header (ATAPI & Sound Blaster). 4-pin CD-ROM modem audio header (ATAPI) 4-pin Line In header (ATAPI) Built-in wavetable synthesis Sound drivers
Hardware Management:	LM78 Microprocessor System Hardware Monitor LM75 CPU Temperature Sensor
I/O Ports:	Two high speed serial ports (16550 compatible) Enhanced 25-pin Parallel Port with ECP and EPP IrDA compliant IR header Two USB ports
Floppy Port:	Supports 360K - 2.88MB formats Auto detection of add-in floppy controllers Multiple sector transfer support
PCI IDE Ports:	Ultra DMA/33 IDE Two 40-pin IDE connectors (Primary and Secondary IDE). Multiple sector transfer support Auto detection of add-in IDE board
Wake-on-LAN:	Wake-on-LAN header (for remote monitoring) (Must use a Wake-on-LAN supported Ethernet adapter).

Environmental Specifications

The environment in which the Tigercat is located is critical. Micronics recommends the following environmental specifications:

Temperature Range

Operating: 50 to 104 degrees Fahrenheit (10 to 40 degrees Celsius).

Non -Operating: 50 to 140 degrees Fahrenheit (10 to 60 degrees Celsius).

Shipping: -22 to 140 degrees Fahrenheit (-30 to 60 degrees Celsius).

Relative Humidity

Operating: 20% to 80%.

Non-Operating: 5% to 90%.

Support and Information Services

Micronics offers a variety of support and information services to help you get the most from your product. The following services are available:

- ▲ Technical Support
- ▲ Electronic Bulletin Board Service (BBS)
- ▲ Return Materials Authorization (RMA)
- ▲ Fax-On-Demand
- ▲ World Wide Web
- ▲ Customer Service

Refer to Table A-1 for details on these services.

Technical Support

If you need technical assistance, our Technical Support Engineers will be glad to help you. You can contact us via telephone, fax or BBS. Before calling Technical Support please have the following information ready:

- The model name and 09 part number of your Micronics product, which is silk screened on the face of the Tigercat system board.
- Your computer information such as CPU type, operating system, amount of installed memory and other peripherals installed in your computer.
- Try to call from the location of your computer.

NOTE: For Return Material Authorization purposes, please keep a copy of your product receipt.

Appendix A: Technical Information

Service	Hours	Country	Telephone Number
Technical Support - Live phone help from Technical Support Engineers	M-F: 7:00am to 5:00pm (PST)	USA France UK	(510) 661-3000 (510) 651-6982 (Fax) +33 (1) 45 43 56 26 +33 (1) 45 43 17 78 (F) +44 (1256) 844899 +44 (1256) 364222 (F)
Electronic Bulletin Board Service (BBS) - Information on software upgrades, new releases and other helpful information	24 hours a day 7 days a week "	USA UK	(510) 651-6837 14400 baud rate, Parity Data Bits=8, Stop Bits: YMODEM and ZMODEM (recommended file transfer protocols) +44 (1256) 363373
RMA (Return Materials Authorization) - Return products for repair	M-F: 8:00am to 4:45pm (PST)	USA	(510) 661-3030 (510) 683-0543 (Fax)
Fax-On-Demand - Automated system for product literature, technical bulletins and other helpful information	24 hours a day 7 days a week	USA	(510) 661-3199
World Wide Web - Product information, technical support, press releases and other helpful information	24 hours a day 7 days a week "	USA Europe	http://www.micronics.com http://www.mcrni.com
Customer Service - Order Micronics and Orchid products	M-F: 8:00am to 5:00pm (PST)	USA France UK	(800) 577-0977 (510) 651-3666 (Fax) +33 (1) 45 43 56 26 +33 (1) 45 43 17 78 (F) +44 (1256) 479 898 +44 (1256) 364222 (F) +886 2 918 5005

Table A-1: Support and Information Services

Appendix

POST Messages**B**

The following table lists the Power On Self Test (POST) messages, possible causes and solutions.

Message	Possible Cause	Solution
DISKETTE DRIVE A FAILURE	Drive A failed or is missing.	Check Setup and cable connections.
DISKETTE DRIVE B FAILURE	Drive B failed or is missing.	Check Setup and cable connections.
EXTENDED RAM FAILED AT OFFSET: nnnn	Extended memory not working or configured properly.	Replace defective memory.
FAILING BITS: nnnn	Memory failure in System, Extended, or Shadow memory.	Replace defective memory.
FIXED DISK X FAILURE (where X =0 or 1)	The hard disk is not configured or working properly.	Rerun SETUP and check connections, or replace hard disk.
FIXED DISK CONTROLLER FAILURE	The controller card has failed.	Check configuration and connections, or replace controller card.
INCORRECT DRIVE A TYPE	Floppy drive A: not set correctly in Setup.	Run Setup.
INCORRECT DRIVE B TYPE	Floppy drive A: not set correctly in Setup.	Run Setup.
INVALID NVRAM MEDIA TYPE	NVRAM chip is bad.	Requires repair of system board.
KEYBOARD ERROR, or KEYBOARD CONTROLLER ERROR	The keyboard or keyboard controller failed.	Check connections. You may have to replace the keyboard or controller.
KEYBOARD ERROR nn	A key is jammed or was held down during boot.	Make sure the keys are not jammed or dirty.
KEYBOARD	Keyswitch on the front of	Unlock the keyswitch.

Message	Possible Cause	Solution
MONITOR TYPE DOES NOT MATCH CMOS	Monitor type not correctly identified in Setup.	Run Setup and enter correct monitor type.
OPERATING SYSTEM NOT FOUND	Operating system cannot be located on Drive C: or Drive A:	Check Setup to see if Drive A: and C: are properly configured, or put a bootable disk in Drive A:
PARITY CHECK 1 nnnn	Parity error found in the system bus.	Check Setup. Board repair may be required.
PARITY CHECK 2 nnnn	Parity error found in the I/O bus.	Check Setup. Board repair may be required.
PREVIOUS BOOT INCOMPLETE - DEFAULT CONFIGURATION USED	Previous POST did not complete successfully.	Run Setup, load default BIOS settings, make any necessary adjustments, and save the changes
REAL TIME CLOCK ERROR	Real-time clock failed BIOS test.	May require battery replacement or board repair.
SHADOW RAM FAILED AT OFFSET	Shadow RAM failed.	May require repair of system board.
SYSTEM BATTERY IS DEAD	System battery died.	Replace the system battery and run Setup to reconfigure the system.
SYSTEM CACHE ERROR - CACHE DISABLED	External (L2) cache failed BIOS test.	System will still run, but slower. Replace cache at convenience.

Beep and POST Codes

C

Beep codes are a series of beeps sent through the speaker which indicate a problem during the Power On Self Test (POST). If text appears on the video screen, the Tigercat has completed POST; any other tone from the speaker indicates something other than a POST error. These tones *are not* described in the tables on the following pages.

The beep error codes are a series of beeps. The duration of the beep tones are constant, but the length of the pauses between the beeps varies. For example: a 1-3-3 beep code will sound like one beep, a pause; three beeps consecutively, another pause and then three more beeps.

One beep code is often misunderstood. If a video card is not installed or is failing, the system board will generate a long-short-long-short beep code. This is often interpreted as a 1-2-1 beep code. But POST errors always vary in the length of the pause and not the duration of the beep tone.

Another way of identifying a POST error is to use a device called a POST card. This peripheral card is inserted into one of the ISA slots and has an LED (or LCD) read out showing the contents of port 80h.

The following tables list all beep codes and POST routines.

Appendix C: Beep and POST Codes

Code	Beeps	POST Routine Description
02		Verify Real Mode.
04		Get CPU type.
06		Initialize system hardware.
08		Initialize chipset registers with initial POST values.
09		Get in POST Reg.
0A		Initialize CPU registers.
0C		Initialize cache initial POST values.
0E		Initialize I/O.
0F		Initialize the localbus IDE.
10		Initialize Power Management.
11		Load alternate registers with initial POST values.
12		Jump to UserPatch0.
14		Initialize keyboard controller.
16	2-2-3	BIOS ROM checksum.
18		8254 timer initialization.
1A		8237 DMA controller initialization.
1C		Reset Programmable Interrupt Controller.
20	3-1-1	Test DRAM refresh.
22	3-1-3	Test 8742 Keyboard Controller.
24		Set ES segment register to 4 GB.
28		Autosize DRAM.
2A		Clear 512K base RAM.
2C	3-4-1	Test 512K base address lines.
2E	3-4-3	Test 512K base memory.
32		Test CPU bus-clock frequency.
34		Test CMOS RAM.
35		Initialize alternate chipset registers.
37		Reinitialize the chipset (MB only).
38		Shadow system BIOS ROM.
39		Reinitialize the cache (MB only).
3A		Autosize cache.

Code	Beeps	POST Routine Description
4A		Initialize all video adapters in system.
4C		Shadow video BIOS ROM.
4E		Display copyright notice.
50		Display CPU type and speed.
51		Initialize EISA board.
52		Test keyboard.
54		Set key click if enabled.
56		Enable keyboard.
58	2-2-3-1	Test for unexpected interrupts.
5A		Display prompt "Press F2 to enter SETUP".
5C		Test RAM between 512 and 640k.
60		Test extended memory.
62		Test extended memory address lines.
64		Jump to UserPatch1.
66		Configure advanced cache registers.
68		Enable external and CPU caches.
6A		Display external cache size.
6C		Display shadow message.
6E		Display non-disposable segments.
70		Display error messages.
72		Check for configuration errors.
74		Test real-time clock.
76		Check for keyboard errors.
7C		Set up hardware interrupt vectors.
7E		Test coprocessor if present.
80		Disable onboard I/O ports.
82		Detect and install external RS232 ports.
84		Detect and install external parallel ports.
86		Re-initialize on-board I/O ports.
88		Initialize BIOSData Area.
8A		Initialize Extended BIOS Data Area.

Appendix C: Beep and POST Codes

Code	Beeps	POST Routine Description
9C		Set up Power Management.
9E		Enable hardware interrupts.
A0		Set time of day.
A2		Check key lock.
A4		Initialize typematic rate.
A8		Erase F2 prompt.
AA		Scan for F2 keystroke.
AC		Enter SETUP.
AE		Clear in-POST flag.
B0		Check for errors.
B2		POST done - prepare to boot operating system.
B4		One beep.
B6		Check password (optional).
B8		Clear global descriptor table.
BC		Clear parity checkers.
BE		Clear screen (optional).
BF		Check virus and backup reminders.
C0		Try to boot with INT 19.
D0		Interrupt handler error.
D2		Unknown interrupt error.
D4		Pending Interrupt.
D6		Initialize option ROM error.
D8		Shutdown error.
DA		Extended Block Move.
DC		Shutdown 10 error.
		The following are for boot block in Flash ROM:
E2		Initialize the chipset.
E3		Initialize refresh counter.
E4		Check for Forced Flash.
E5		Check HW status of ROM.
E6		BIOS ROM is OK

Appendix

Hard Disk Drive Types**D**

The following table lists the IDE hard disk types supported by the Tigercat.

Type	Cylinders	Heads	Write Precomp	Sectors	Size
1	306	4	128	17	10
2	615	4	300	17	21
3	615	6	300	17	32
4	940	8	512	17	65
5	940	6	512	17	99
6	615	4	none	17	21
7	462	8	256	17	32
8	733	5	none	17	31
9	900	15	none	17	117
10	820	3	none	17	21
11	855	5	none	17	37
12	855	7	none	17	52
13	306	8	128	17	21
14	733	7	none	17	44
15	N/A	N/A	N/A	N/A	N/A
16	612	4	0	17	21
17	977	5	300	17	42
18	977	7	none	17	59
19	1024	7	512	17	62
20	733	5	300	17	31
21	733	7	300	17	94
22	733	5	300	17	31
23	306	4	0	17	10
24	612	4	305	17	21
25	612	2	300	17	10
26	614	4	none	17	21
27	820	6	none	17	42
28	977	5	none	17	42

Appendix D: Hard Disk Drive Types

Type	Cylinders	Heads	Write Precomp	Sectors	Size
31	823	10	512	17	71
32	809	6	128	17	42
33	830	7	none	17	50
34	830	10	none	17	72
35	1024	5	none	17	44
36	1024	8	none	17	71
37	615	8	128	17	42
38	1024	8	none	26	109
39	925	9	none	17	72

Updating the System BIOS

E

The Micronics system boards are designed so that the BIOS can be reprogrammed using a BIOS file. You can easily FLASH a BIOS by following the steps below:

1. After downloading the appropriate BIOS file from our BBS or Website, extract it to a bootable MS-DOS 6.X diskette.
2. Turn off your system and set jumper W4 to position 2-3.
3. Reboot your system with the MS-DOS 6.X diskette in the A: drive. To make sure a clean DOS environment is loaded, press the F5 key while "Starting MS-DOS" is displayed. After the system has rebooted, the cursor will appear at the A:> prompt.
4. Now you can run the FLASH utility from the bootable floppy disk. Refer to the README.TXT file included with the BIOS update for detailed instructions.
5. After the update process has completed and the system reboots, verify that the new BIOS version appears on-screen. If you have problems during this process, or if you have questions about the procedure, please call Technical Support.
6. Turn off your system and reset jumper W4 to position 1-2.



If you encounter any problems during this process, or if you have questions about the procedure, please call Technical Support.

NOTE: If you prefer to send your system board in for the upgrade, the RMA department offers this service free of charge if your system board is under warranty.

Appendix **Limited Warranty**

F

Except as described below, Micronics warrants the products to be free from defects in material and workmanship in normal use for a period of one (1) year from date of purchase. Should any product fail to perform according to this warranty at any time during the warranty period, except as provided below, Micronics or its authorized service centers will, at Micronics' option, repair or replace the product at no additional charge.

The warranty does not cover loss or damage which occurs in shipment or which is due to: (1) improper installation or maintenance, misuse, neglect or any cause other than ordinary commercial application, including without limitation, accidents or acts of God; (2) adjustment, repair, or modification by other than a Micronics authorized service center; (3) improper environment, excessive or inadequate heating or air conditioning, or electrical power failures, surges or other irregularities; (4) any statement about the product other than those set forth in this warranty; or (5) nonconformity to models or samples shown to the purchaser. Any models or samples were for the sole purpose of suggesting the character of the product and are not intended to form the basis of the bargain.

A receipt or copy of the invoice with the date of purchase from a Micronics reseller is required before any warranty service can be rendered. Service can be obtained by calling Micronics for a Return Merchandise Authorization (RMA) Number.

The RMA Number should be prominently displayed on the outside of the shipping carton of the returned product. Returned product should be shipped prepaid or hand carried to Micronics. The purchaser assumes risk of loss or damage in transit, and unless otherwise agreed to in writing by Micronics, will pay inbound shipping charges.

The exclusive remedy of the purchaser under this warranty above will be repair or replace at Micronics' option,

but if for any reason that remedy should fail of its essential purpose, the exclusive remedy of the purchaser shall then be actual damages up to amounts paid for the defective product by the purchaser. This limited warranty shall be deemed to “fail of its essential purpose” if, after repeated efforts, Micronics is unable to make the product operate as warranted. Micronics’ liability for damages to the purchaser for any cause whatsoever; regardless of the form of action and whether in contract or in tort, shall be limited to the purchase price in effect when the cause of action arose for the product that is the basis of the claim.

Micronics will not be liable for any lost profits or any indirect, special incidental or consequential damages in connection with the product, even if Micronics has been advised of the possibility of such damages.

Micronics makes no warranties or representations as to performance of products or as to service to distributor or to any person, except as set forth in Micronics; limited warranty accompanying delivery of product.

Micronics disclaims all other warranties whether oral, written, expressed, or implied, including without limitation, the warranties of design, merchantability, or fitness for a particular purpose, if applicable, or arising from a course of dealing, usage or trade practice.

Non-Warranty Service

After the one year warranty service is no longer in effect, repair service is still available for Micronics products. For more information, contact Micronics’ RMA department at (510) 661-3030. The RMA department is open between 8:30 A.M. and 4:45P.M. Pacific Standard Time.

FCC Statement

This equipment has been tested and found to comply within the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not used in accordance with the instructions, may cause harmful interference to radio communications. Interference to radio or television reception can be determined by turning the equipment off and on. You are encouraged to try to correct the interference by one or more of the following measures:

- ▲ Reorient the receiving antenna.
- ▲ Increase the separation between the equipment and the receiver.
- ▲ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▲ Consult your dealer or an experienced radio/TV technician for help.

To meet FCC requirements, shielded cables are required.

NOTE: Changes or modifications not expressly approved by Micronics could void your authority to operate the equipment.

Glossary

16550 UART - A high speed chip for controlling serial ports. Although unnecessary for a mouse, it is required for modems that are 14,400 baud or faster.

AGP - Accelerated Graphics Port. A faster bus than the current 33MHz PCI bus, which will connect the graphics controller to system memory through the chipset.

Asynchronous - Operations that do not require the clocks of communicating devices to be coordinated. See Synchronous.

ATX - A system board size measuring approximately 12" x 9.6".

Bidirectional Parallel Port - A type of parallel port that can send and receive information.

BIOS - An Acronym for Basic Input/Output System. Configures the system board and provides hardware information to the operating system.

Bit - A contraction of Binary digit. The smallest unit of information in a binary number system. A bit represents a choice between either zero or one.

Boot - To start up the computer and load the operating system software. See cold boot and warm boot.

Buffered DIMMs - The 168-pin buffered DIMM modules use buffer logic chips on their control lines to reduce loading on the system board. This buffering action increases the maximum

number of modules on the same system board. The buffered DIMMs come with standard DRAM chips for either 5V or 3.3V operation.

Bus - A group of electronic paths used to send data between parts of the system. On a system board, the bus connects the peripheral cards with the microprocessor via the expansion slots.

Bus Mastering - The ability of a peripheral card to control the bus without requiring intervention of the CPU.

Byte - A group of adjacent bits treated as a unit. Eight bits are typically considered one byte. Also called a character.

Cache - A process where information is copied from the slower memory (DRAM) to the faster memory (SRAM). Information that is likely to be read or edited is stored in the cache providing significant performance increases.

Cache Hit - The percentage of request for data from memory that can be served from the cache.

Cache Miss - A memory access which cannot be supplied from cache.

Cold Boot - Starting the computer by turning on the power or pressing the RESET button. A cold boot makes the processor execute all of the diagnostics. See boot and warm boot.

CPU - An acronym for Central Processing Unit. A CPU performs arithmetic calculations, makes logical decisions, and directs the operation of the computer in conjunction with the operating system.

DIMM - An acronym for Dual Inline Memory Module. A small printed circuit board containing memory chips.

Disk Drive - A hardware device which provides for the storage of data on diskettes or hard metal disks that have a magnetic coating. A disk drive functions by spinning at high speed while moving a device called the read/write head across the disk's surface in order to read or write data in magnetic code.

DRAM - An acronym for Dynamic Random Access Memory. A type of memory chip that only keeps its memory if supplied with regular clock pulses and a chance to regularly refresh its data. It is slower and more cost effective than SRAM. See SRAM.

ECC - An acronym for Error Checking and Correction. ECC is logic designed to correct memory errors. The number of errors that can be corrected depends upon the algorithms used, and the number of error correction bits (non-data bits) present.

ECP - An acronym for Expanded Capabilities Port. A standard set by Hewlett Packard and Microsoft Corporation to expand the capabilities of the parallel port.

EDO Memory - An acronym for Extended Data Out. A DRAM performance feature that permits multiple bit of data in a single row to be accessed quickly.

EPP - An acronym for Enhanced Parallel Port. A standard which increases the capabilities of the parallel port.

EPROM - Acronym for Erasable Programmable Read Only Memory. A type of ROM chip that can be programmed with relatively simple tools that will retain its data until erased. It can only be erased by exposing the circuitry in the chip to ultraviolet light. See also Flash ROM.

Flash ROM - A type of ROM chip that will retain its data until erased. It can be erased or reprogrammed by supplying it with +12V of voltage. See ROM and EPROM.

Gigabyte - A disk storage capacity measurement. Approximately one thousand megabytes or 1,073,741,824 bytes.

IDE - An acronym for Integrated Device Electronics. A standard for communicating between a hard drive and a computer.

Internal Cache - Cache which is built into the CPU. See Cache.

ISA - An acronym for Industry Standard Architecture. A well-established bus standard that originated with the IBM AT. See *PCI and VESA Local Bus*.

LM75 - The LM75 is a temperature sensor. The host can query the LM75 at any time to read the temperature. Its 3.0V to 5.5V supply voltage range, low supply current and I²C interface, make it ideal for a wide range of applications.

LM78 - The LM78 is a highly integrated Data Acquisition system for hardware monitoring of servers, personal computers or virtually any microprocessor based system. In a PC, the LM78 can be used to monitor temperatures, power supply voltages and fan speeds.

NS - An acronym for Nanosecond. One billionth of a second. Measure of the access time of RAM.

Parallel - A form of data transmission in which the data is sent one byte at a time over several wires that each carry one byte. In parallel transmission, all the bytes arrive simultaneously, as opposed to serial transmission in which bits arrive one by one.

Parallel Port - A connection for a printer or similar peripheral. Generally, parallel ports are output only. See Bidirectional Parallel Port and ECP.

Parity - Logic that detects the presence of an error in memory. Generally, a single parity bit is used for each byte (8 bits) of data. The most commonly used forms of parity are even parity, odd parity and checksums.

PCI - An acronym for Peripheral Component Interconnect. A high performance 32-bit or 64-bit bus developed by Intel Corporation. PCI is designed to be independent of the hardware architecture to ensure compatibility with future computer systems. See *VESA Local Bus and ISA*.

Pentium - A high performance 64-bit CISC processor designed and manufactured by Intel Corporation.

Pipeline - In DRAMs and SRAMs, a method for increasing the performance using multistage circuitry to stack or save data while new data is being accessed.

Plug and Play - A standard developed to ensure easy installation of peripherals. Theoretically, a newly installed card will automatically configure itself and work properly without requiring jumper configuration or device drivers.

POST - An acronym for Power On Self Test. A diagnostic program that is run whenever the system is cold booted.

RAM - An acronym for Random Access Memory. A type of memory that is used as the “working memory” of a computer system. See DRAM and SRAM.

ROM - An acronym for Read Only Memory. A type of memory that retains its data without requiring power. Once written, it cannot be modified. See EPROM and Flash ROM.

Serial Port - A communications port used to connect peripherals such as modems and mice.

Setup - A program that allows you to make changes to the system configuration.

Shadow RAM - A technique used to load a duplicate copy of BIOS from slower ROM into faster RAM. This enhances system performance because it provides higher access speed to the BIOS.

SIMM - An acronym for Standard Inline Memory Module. A small printed circuit board containing memory chips.

SDRAM - An acronym for Synchronous Dynamic Random Access Memory or Synchronous DRAM. A DRAM designed to deliver bursts of data at very high speed using automatic addressing, multiple page interleaving and a synchronous (or clocked) interface.

Synchronous Cache - A type of cache that uses a clock signal to latch the inputs and the data output. This structure spreads the cache access across two or three cycles while maintaining a bandwidth of one access per cycle. Improves performance by 5-10%.

Unbuffered DIMMs - The unbuffered DIMM modules do not use any buffer logic chips, thus achieving faster operation due to the elimination of the propagation delay of the logic buffer. This increase in speed comes at the cost of reducing the maximum number of modules on the same system board.

USB - An acronym for Universal Serial Bus. The simple and flexible way to connect devices to your desktop or notebook PC. USB allows virtually unlimited PC expansion with no more hassles over add-in cards, dip switches, jumper cables, software drivers, IRQ settings, DMA channels and I/O addresses. With USB, you can attach and detach peripherals without opening the computer or even shutting it down.

VESA - An acronym for Video Electronics and Standards Association.

VESA Local Bus (VL-Bus) - A high performance bus designed by VESA. A 32-bit version of the ISA bus which operates at the speed of the computer's CPU. See *PCI and ISA*.

VRM - Voltage Regulator Module. Supplies CPU specific voltages for the Secondary CPU.

Warm Boot - Restarting the system by simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys.

Write-Back Cache - Upon a cache hit, the cache is updated and the main memory is not affected. Upon a cache miss, only the main memory is updated.

Index

B

- Battery Disposal - 60
- POST Messages - 63
- BIOS
 - Configuration - 37
 - Setup - 37
- Bulletin Board System (BBS) - 62

C

- Configuring the Tigercat- 11
- CPU
 - Box Version - 30
 - Installation - 20
 - Overview 29, 30
 - Retention Mechanism - 26

D

- Diagram (Tigercat) - 12

E

- Extended Data Out (EDO) Memory - 19, 21
- Environmental Specifications - 59
- Error Checking (ECC) - 19, 21

H

- Help
 - Bulletin Board System (BBS) - 62
 - Telephone Numbers - 62
 - Troubleshooting - 63, 65

I

Installation

CPU - 24

Installing the Tigercat - 20

AGP Peripheral Card - 33

ISA Peripheral Card - 32

PCI Peripheral Card - 31

Quick Installation - 9

J

Jumper Settings - 13

M

Tigercat System Board Diagram - 12

Memory

Configurations - 22

Installing - 25

Removing - 25

Supported - 21

O

Online Services - 62

P

POST Messages - 63

S

Specifications - 57

System BIOS - 37, 71

T

- Technical Specifications - 57
- Technical Support - 61
- Troubleshooting - 63, 65

U

- Updating the System BIOS - 71
- Utility Programs
 - Utility Programs
 - Advanced Screen - 44
 - BIOS Setup - 37
 - Boot Screen - 52
 - Exit Screen - 53
 - IDE Device Submenu - 42
 - Main Screen - 39
 - Security Screen - 47

W

- World Wide Web - 62