

## The **AZZA** KT33-BV Mainboard Manual

[Cover](#) [Click Here](#)

[Table Of Contents](#) [Click Here](#)

[Introduction](#) [Click Here](#)

[Hardware Installation](#) [Click Here](#)

[BIOS Management](#) [Click Here](#)




*Create High Quality  
Service and Technology*



# KT33-BV Mainboard Manual

---

SOCKET A DDR ATX Mainboard



Version 1.x  
UM-KT33-BV-E1  
Rev 1.0V  
Creation Date: 6 March 2002



## User Notice



### **Copyright**

This publication contains information that is protected by copyright. No part of it may be reproduced in any form or by any means or used to make any transformation adaptation without prior written permission from the copyright holders. This publication is provided for informational purposes only. The manufacturer makes no representations or warranties with respect to the contents or use of this manual and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. The user will assume the entire risk of the use or the results of the use of this document. The manufacturer reserves the right to revise this publication and make changes to its contents at any time, without prior notice.

2001. All Rights Reserved.

### **Trademarks**

Microsoft®, MS-DOS®, Windows™, Windows® 95 and Windows® 98 are registered trademarks of Microsoft Corporation. AMD® Athlon™XP, Athlon™ and Duron™ are registered trademarks of AMD Corporation. Award is the registered trademark of Award Software, Inc. Other trademarks and registered trademarks of products appearing in this publication are the properties of their respective holders.

### **Package Checklist**

This package contains the following items:

- Mainboard
- Users manual
- One IDE cable
- One 34-pin floppy disk drive cable
- One Driver Utility CD

If any of these items are damaged or missing, please contact your dealer or sales representative for assistance.

### **Technical Support**

If you require additional information or assistance during installation please contact your dealer. Your dealer will be able to provide the latest information.



# Table of Contents



## Chapter 1:- Introduction *Page 5*

<b>1.1. Mainboard and PC99 External Connector Layout</b> .....	<b>5</b>
<b>1.2. Overview</b> .....	<b>6</b>
1.2.1. The KT33-BV Mainboard .....	6
1.2.2. Mainboard Dimensions.....	6
1.2.3. Environmental Limitations .....	6
<b>1.3. Features and Specifications</b> .....	<b>6</b>
<b>1.4. System Health Monitor Functions</b> .....	<b>9</b>
1.4.1. Hardware Monitoring System Utility .....	9
1.4.2. Installation.....	9
<b>1.5. System Intelligence</b> .....	<b>9</b>

## Chapter 2:- Hardware Installation *Page 11*

<b>2.1. Installation Checklist</b> .....	<b>11</b>
<b>2.2. Installation Steps</b> .....	<b>12</b>
<b>2.3. Expansion Slots, Jumpers and Internal Connectors</b> .....	<b>13</b>
<b>2.4. CPU, Memory and Expansion Slots</b> .....	<b>14</b>
2.4.1. Installation of the CPU.....	14
2.4.2. Memory Modules .....	14
2.4.3. PCI Slots.....	15
2.4.4. AGP (Accelerated Graphics Port) Slot .....	16
<b>2.5. Internal Connectors</b> .....	<b>16</b>
2.5.1. Floppy Disk Drive (FDC).....	16
2.5.2. Primary and Secondary IDE Connectors .....	16
2.5.3. CPU FAN and CHASSIS FAN Connectors.....	17
2.5.4. ATX Power Supply Connector .....	17
2.5.5. WOL (Wake On LAN) Connector .....	18
2.5.6. CD Audio In and Auxiliary-In Connectors .....	18
2.5.7. USB 3 and USB 4 Connectors .....	18
2.5.8. Front Audio Connector .....	19
<b>2.6. System Panel Buttons and LED Connectors</b> .....	<b>19</b>
2.6.1. PW: Power On / Off and External Suspend Switch Connector .....	20
2.6.2. SL LED Connector .....	20
2.6.3. IDE HDD LED Connector .....	20
2.6.4. Reset Button Connector .....	21
<b>2.7. Speaker and Power LED Connector</b> .....	<b>21</b>
2.7.1. Speaker Connector .....	21
2.7.2. Front Panel Power LED .....	21



## Table of Contents




<b>2.8. External Connectors</b> .....	<b>21</b>
2.8.1. PS/2 Keyboard Connector .....	21
2.8.2. PS/2 Mouse Connector.....	21
2.8.3. Serial Port 1 (COM 1) and Serial Port 2 (COM 2) Connectors .....	22
2.8.4. Parallel Port Connector .....	22
2.8.5. USB 1 and USB 2 Port Connectors .....	22
2.8.6. Audio/Game Port Connector.....	22
<b>2.9. Jumper Settings</b> .....	<b>23</b>
2.9.1. JP1: USB1 and USB2 Power .....	23
2.9.2. JP2: Keyboard Power .....	23
2.9.3. JP6: CPU FSB Clock .....	24
2.9.4. JP8: Clears CMOS Memory .....	24

### **Chapter 3:- Managing The PC BIOS *Page 25***


<b>3.1. Award BIOS CMOS Setup Utility</b> .....	<b>25</b>
<b>3.2. Main Menu</b> .....	<b>25</b>
<b>3.3. Standard CMOS Setup</b> .....	<b>26</b>
<b>3.4. Advanced BIOS Features</b> .....	<b>28</b>
<b>3.5. Advanced Chipset Features</b> .....	<b>31</b>
<b>3.6. Integrated Peripherals</b> .....	<b>34</b>
<b>3.7. Power Management Setup</b> .....	<b>38</b>
<b>3.8. PNP/PCI Configuration</b> .....	<b>41</b>
<b>3.9. PC Health Status</b> .....	<b>42</b>
<b>3.10. Frequency/Voltage Control</b> .....	<b>43</b>
<b>3.11. Load Optimized Defaults</b> .....	<b>44</b>
<b>3.12. Set Supervisor Password</b> .....	<b>45</b>
<b>3.13. Set User Password</b> .....	<b>45</b>
<b>3.14. Save &amp; Exit Setup/Exit Without Saving</b> .....	<b>47</b>

## Chapter 1 - Introduction

### 1.1. Mainboard And PC99 ATX External Connector Layout



**PC 99 ATX External Connector**



**1.2. Overview**

**1.2.1. The KT33-BV Mainboard**  
 The **KT33-BV** mainboards are AMD® Socket A platforms which can support Athlon™XP, Athlon™ or Duron™ CPU's. They come with three onboard DDR DIMM slots that are able to support a maximum memory of 3GB. They also come with 5 PCI slots and 1 AGP (Accelerated Graphics Port) slot. They all come with **Onboard Audio** (AC'97 2 channel) . Each **KT33-BV** mainboard comes with 4 (Ver 1.1) USB connectors and two serial ports. They also have a WOL (Wake-On LAN) Connector, 2 fan connectors a CD-IN connector and an AUX-IN connector.

**1.2.2. Mainboard Dimensions**  
 These boards are ATX form factors. Their dimensions are:

Width	305 mm
Length	220 mm

**1.2.3. Environmental Limitations**

Operating Temperature:	10°C to 40°C (50°F to 104°F)
Required Airflow:	50 linear feet per minute across the CPU
Storage Temperature:	-40°C to 70°C (-40°F to 158°F)
Humidity:	0 to 90% non-condensing
Altitude:	0 to 10 000 feet

**1.3. Features and Specifications**

**Processor**  
 The **KT33-BV** mainboards support Socket A AMD® Athlon™XP, Athlon™, and Duron™ CPUs.



# Introduction



## Chipsets

Northbridge	Southbridge	I/O Chipset
VIA KT333	VIA VT8233A	Winbond W83697HF

## CPU Switching Voltage regulator

This mainboard is equipped with a switching voltage regulator that automatically detects a DC power supply from +1.10V to +1.85V.

## System Memory

The **KT33-BV** mainboards use Double Data Rate Dual Inline Memory Modules (DDR DIMM). Each mainboard has three 184-pin DIMM sockets which are able to support 2.5V (power level) single-sided or double sided PC1600 (**DDR200**), PC2100 (**DDR266**) or PC2700 (**DDR333**) DDR DIMM modules.

## Expansion Slots

These mainboards are equipped with five dedicated PCI slots and one AGP slot.

## Onboard Audio Features

Supports Microsoft DirectSound/ DirectSound 3D and AC97 Full Duplex.

## Word Size

- Data Path: 8-bit, 16-bit, 32-bit, 64-bit
- Address Path: 32-bit

## Front Side Bus Frequency (FSB)

The **KT33-BV** mainboards are able to support a Front Side Bus Frequency (FSB) of 200MHz or 266MHz.

## BIOS

- Award BIOS, Windows 95/98 Plug and Play (PnP) compatible.
- Supports SCSI sequential boot-up.
- Flash EPROM for easy BIOS upgrades.
- Supports DMI 2.0 function

## Desktop Management Interface (DMI)

The mainboard comes with DMI 2.0 built into the BIOS. The DMI utility in the BIOS will automatically record different information about your system configuration and store this information in the DMI pool, which is a part of the system board's Plug and Play BIOS. DMI, along with the appropriately networked software, is designed for easy inventory, maintenance and the simplified troubleshooting of computer systems.



## Introduction



### **WOL (Wake-On-LAN) Port**

One WOL connector supports Wake-On-LAN functionality.

### **USB Ports**

USB allows data exchange between your computer and a wide range of simultaneously accessible external Plug and Play peripherals. These models are equipped with **four** (version 1.1) USB connectors. USB 1 and USB 2 are external connectors. They can be found on the PC 99 ATX connector. The other USB connectors are internal connectors and can be used to connect other USB devices. (Cables for the internal connectors are sold separately).

### **Connectors**

- Two IDE connectors.
- One floppy drive interface supports up to two 2.88MB floppy drives.
- One 20-pin ATX power supply connector.
- Two fan connectors.
- One CD audio-IN connector.
- One Aux-IN connector
- One WOL (Wake-On-Lan Connector)
- One Front Audio Connector

### **ATX Double Deck Ports (PC 99 color-coded connectors)**

- Two USB ports.
- Two external DB-9 serial port connectors: **COM 1**(UART) and **COM 2** (UART).
- One SPP/ECP/EPP DB-25 parallel port.
- One mini-DIN-6 PS/2 mouse port.
- One mini-DIN-6 PS/2 keyboard port.
- One game/MIDI port.
- Three audio jacks: speak-out, line-in and mic-in.

### **PCI Bus Master IDE Controller**

- Two PCI IDE interfaces support up to four IDE devices.
- **KT33-BV** mainboards support ATA/33, ATA/66, ATA/100 and ATA/133 hard drives.
- PIO Mode 3 and Mode 4 Enhanced IDE (data transfer rate up to 16.6MB/sec.).
- Bus mastering reduces CPU utilization during disk transfer.
- Supports ATAPI CD-ROM, LS-120 and ZIP.



## 1.4. System Health Monitor Functions

The mainboard is capable of monitoring the following health conditions of your system:

1. Processor temperature. It has an overheat alarm.
2. VCORE/3.3V/5V/12V/-12V voltages and failure alarm.
3. Processor and chassis fan speeds. It has a failure alarm for these fans.
4. Read back capability that displays temperature, voltage and fan speed.

**Note:** Only use this utility in Windows ® 95 or Windows ® 98 operating systems.

### 1.4.1. Hardware Monitoring System Utility

The mainboards both come with the Hardware Monitoring System utility contained on the CD. It is capable of monitoring the system's hardware conditions such as the temperature of the processor, voltage, and the speed of both the CPU and chassis fans. You are allowed to manually set a range to the items being monitored. If the values are over or under the set range a warning message will automatically pop up. We recommend that you use the Default Settings, which are the ideal settings that will maintain the system in a good working condition.

### 1.4.2. Installation

To install this utility, please insert the CD into the CD-ROM drive. The auto run screen (Driver Utility) will automatically appear. Click the Hardware Monitoring button, choose the chipset, model number and the OS that is installed. Please refer to the CD "Readme" file for further installation instructions.

## 1.5. System Intelligence

### Dual Function Power Button

Depending on the setting in the Soft-Off By Power-Button field of the Power Management Setup, this switch allows the system to enter the Soft-Off or Suspend mode.

### RTC Timer to Power-on the System

The RTC installed on the system board allows your system to automatically power-on at a set date and time.

### Wake-On-LAN Ready

The Wake-On-LAN function allows the network to remotely wake up a Soft Power Down (Soft-Off) PC. Your LAN card must support the remote wakeup function. The 5V SB power source of your power supply must be at least 720mA.

### ACPI Ready

The mainboard is designed to meet the ACPI (Advanced Configuration and Power Interface) specification. ACPI has energy saving features that support OS Direct Power Management (OSPM) for round the clock PC operation.



## Introduction



### CPU Thermal Protection

This function is **only** for AMD Athlon XP and Duron (Morgan) processors.

1. If you haven't installed a heat-sink with cooling FAN, or if you have installed it incorrectly, this function will prevent the system from being turned on. If you are unable to turn on the system check to see if the heat-sink with cooling FAN has been installed correctly.
2. If the cooling FAN stops functioning the heat of the CPU will increase and the system will auto power-off to protect the CPU against overheating.



## Chapter 2 - Hardware Installation

### 2.1. Installation Checklist

The following is a checklist of all the expansion slots, jumpers and connectors that should be configured on your mainboard before you can run your pc.

Installation Checklist		
<b>Expansion Slots and Sockets</b>		
<b>CPU Socket</b>	Socket A AMD® Athlon™XP, Athlon™ and Duron™ CPU's.	
<b>DIMM Slots</b>	Three 184 pin slots that support up to 3GB of DDR200/DDR266/DDR333 SDRAM	
<b>PCI Slots</b>	Five 32 bit PCI Slots.	
<b>AGP Slot</b>	One (2x/4x) AGP slot	
<b>Internal Connectors</b>		
<b>CN8</b>	Floppy Disk Drive	<b>FDC</b>
<b>CN9</b>	Primary IDE	<b>IDE1</b>
<b>CN10</b>	Secondary IDE	<b>IDE2</b>
<b>CN13</b>	CPU Fan	<b>CPU Fan</b>
<b>CN15</b>	ATX Power Supply	<b>ATX</b>
<b>CN16</b>	Wake On Lan	<b>WOL</b>
<b>CN17</b>	Chassis Fan	<b>FAN2</b>
<b>CN21</b>	CD Audio In	<b>CD-In</b>
<b>CN30</b>	Universal Serial Bus 3	<b>USB3</b>
<b>CN31</b>	Universal Serial Bus 4	<b>USB4</b>
<b>CN39</b>	Front Audio	<b>Front Audio Connector</b>
<b>CN45</b>	Auxiliary In	<b>Aux-IN</b>
<b>External Connectors</b>		
<b>CN1</b>	PS/2 Keyboard Connector	<b>PS/2 KB</b>
<b>CN2</b>	PS/2 Mouse Connector	<b>PS/2 MS</b>
<b>CN3</b>	Serial Port 1	<b>COM1</b>
<b>CN4</b>	Serial Port 2	<b>COM2</b>
<b>CN5</b>	Parallel Port	<b>LPT</b>
<b>CN6</b>	Universal Serial Port 1	<b>USB1</b>
<b>CN7</b>	Universal Serial Port 2	<b>USB2</b>
<b>CN18</b>	Game/Audio Port	<b>Audio/Game</b>



# Hardware Installation



## Installation Checklist (Continued)

### Speaker and Power LED Connector

PW	Power On/Off and Suspend Switch Connector.
SL	Standby LED Connector
HL	HDD LED Connector
RS	Reset Button Connector

### Speaker and Power LED Connector

PWR-LED	Power LED
SPK	Speaker Connector

### Jumpers and Switches

JP1	USB 1,2 PWR
JP2	KB Power
JP6	CPU CLK
JP8	Clear CMOS


## 2.2. Installation Steps

You need to complete the following installation steps before you can use your PC.

- Check and Set the Mainboard Settings.
- Install the Central Processing Unit (CPU).
- Install the Memory Modules.
- Install the Expansion Cards.
- Connect the Ribbon Cables, Panel Wires and the Power Supply.
- Setup the system BIOS

**Before you start installing your mainboard we strongly recommend that you use a grounded anti-static mat. We further recommend that you attach an anti-static wristband, which is grounded at the same location as the mat, to your wrist.**

## 2.3. Expansion Slots, Jumpers and Internal Connectors




## 2.4. CPU, Memory and Expansion Slots

### 2.4.1. Installation of the CPU

To install your processor, please complete the following set of instructions

1. Locate a small dot marked on the top of the CPU. This mark indicates Pin 1 of the CPU.
2. Locate Pin 1 for the Socket on the mainboard.
3. There is a lever on the side of the socket. First push this lever side-ways and then lift it to a 90-degree angle.
4. Insert the CPU into the Socket. Please make sure that Pin 1 for the CPU is inserted into Pin 1 of the Socket.
5. When the CPU is installed correctly push the lever back into place.
6. **Install a proper heat sink with cooling fan** for proper heat dissipation. Failing to install a heat sink with cooling fan may cause overheating which will burnout your CPU and damage your mainboard.




### 2.4.2. Memory Modules

The **KT33-BV** mainboards have three 184-pin DDR DIMM slots and are able to support a maximum of **3GB of DDR200/266/333 memory**. The DDR DIMM slots are located on the right hand side of the board. To install the DIMM's into these slots, make sure the white lever at each side of the slot has been pulled down to an angle of approximately 45°. Make sure that the DIMM is in the correct orientation. Place the DIMM on the slot and push down firmly. The white levers will come back up and lock the module in place.

**Important: The DIMM's can only be fitted into the slots in one orientation. Make sure that the DIMM's are in the correct orientation and the pins are correctly aligned before you insert them.**

## 184-pin DIMM Slot



### NOTE: "Out Of Memory" Error Message

If you have installed more than 512 MB of RAM and are running Microsoft Windows Millennium Edition, Windows 98 Second Edition, Windows 98 or Windows 95 you may experience memory problems. Two symptoms of these problems are being unable to run an MS-DOS session while you are running Windows or the computer may stop responding while Windows is starting.

There are three possible solutions to this problem:

- 1) Reduce the amount of memory Vcache uses to 512 MB or less by altering the MaxFileCache setting in the System.ini file.
- 2) Use the System Configuration Utility to reduce the amount of memory Windows uses to 512 MB or less.
- 3) Reduce the memory installed on your computer to 512 MB or less.


This problem can also occur if an Advanced Graphic Port (AGP) video adapter is used.

### 2.4.3. PCI Slots

The **KT33-BV** mainboards each come with five PCI slots. They are located on the left hand side of the board. Both PCI and PCI expansion cards may require IRQ's. This mainboard complies with Plug and Play (PnP) specifications. Whenever a PnP compliant card is added the system will automatically be configured and the IRQ's will be assigned automatically.


When you are inserting your PCI card make sure that the pins are correctly aligned. When the pins are properly aligned with the hole's in the slot, push down gently.

## PCI Slots



## 2.4.4. AGP (Accelerated Graphics Port) Slot

AGP is a dedicated bus slot. It operates at 66 MHz and transfers data at a rate up to 1066 MB/s. This allows 3D applications to run more smoothly. The **KT33-BV** mainboards each come with one AGP slot. These slots are able to support 2x and 4x AGP cards.





## 2.5. Internal Connectors

### 2.5.1. Floppy Disk Connector (FDC)

Connector: CN 8  
Type: 34 pin block

The FDC connector can support two Floppy drives. It is located at the front of the mainboard. To connect, use the ribbon-cable that has been provided. **Make sure** that the red strip is connected to **PIN 1** of the connector.



### 2.5.2. Primary and Secondary IDE connectors

Connector:  
CN 9 (primary)/ CN 10 (secondary)

Type: 40 pin blocks


The **KT33-BV** mainboards have two IDE connectors: a primary and secondary. Each IDE connector can support two IDE drives. These mainboards can therefore support up to four IDE devices each. If you install two hard drives, you need to configure the second drive to **slave** mode in the BIOS setup. Please refer to your hard drive manual for the appropriate jumper settings.



## 2.5.5. WOL Connector

**Connector:** CN 16 (WOL)  
**Type:** 3 pin


The Wake-On-LAN (WOL) connector must be connected to a LAN card that has Wake-On-LAN output. This connector powers up the system when a wakeup packet or signal is received through the LAN card.



## 2.5.6. CD-IN/AUX-IN Connector

**Connector:** CN 21 (CD-IN/ CN 45 (AUX-IN))  
**Type:** 4 pin un-housed

The **KT33-BV** mainboards have one CD-IN connector and one AUX-IN connector. The **CD-IN** connector is used to connect the CD ROM audio out and allows the system to receive audio input from the CD ROM. The **AUX-IN** connector allows the system to receive signals from other audio devices like a radio or tape.




## 2.5.7. USB 3 and USB 4 connectors

**Connector:** CN 30 /CN 31  
**Type:** 10 pin

You already have two USB ports available, USB 1 and 2 (see external connectors). The internal USB connectors allow you to add on an optional kit to expand the total number of USB ports available. The **KT33-BV** mainboards has two internal USB connectors (**CN30** and **CN31**). This enables you to use an extra two USB devices. Cable for these additional connectors needs to be purchased separately.


## Connectors for USB3 and USB4



### 2.5.8. Front Audio Connector


**Connector:** CN 39  
**Type:** 10 pin

The front audio connector is an innovative development. This connector is designed to be used with a Front-Utility Panel. The utility panel was developed so that a user is able to bring the speaker out, microphone in connectors to the front of their PC. This makes things like plugging in speakers and earphones much less troublesome. See the diagram on the following page.



## 2.6. System Panel Buttons and LED Connectors

Buttons and Connectors		Pin 1	Pin 2
PW	Power On/OFF and Suspend Switch Connector	+5V DC Pull Up	Ground
SL	Standby LED Connector	Standby DC Pull UP	Ground
HL	HDD LED Connector	+5V DC Pull Up	Ground
RS	Reset Button Connector	Reset Control	Ground



### 2.6.1 PW: Power On/Off and External Suspend Switch Connector

The Power On/Off connector has two functions. It can be the Power Switch or Suspend Switch of your PC system. You can either choose “**Delay 4 Sec**” or “**Instant OFF**” (Please refer to the Award BIOS setup instructions in Chapter 3).

**Option 1:** If you choose “**Delay 4 Sec.**” In the BIOS CMOS Setup, the function of “PW” will be:

- A. When the system power is “OFF”, press this switch, the system will power on.
- B. When system power is “ON”, you can select two different modes: -

**Mode 1:** Press and hold the Power ON button for less than 4 seconds and then release it. The system will be turned into Suspend mode (turned into the GREEN mode) When the system is in the Suspend mode: -

- Press the Power on button (less than 4 seconds), the system will return to Full-ON mode.
- Press and hold the Power On Button for more than 4 seconds, the system will be powered off.

**Mode 2:** Press and hold the Power ON button for more than 4 seconds, the system will be completely powered off.

**Option 2:** If you choose “**Instant OFF.**” In the BIOS CMOS Setup, the power switch will operate like a normal ON / OFF Power button.

### 2.6.2. SL LED Connector

When the AC power is “ON” the mainboard will always have a standby voltage of +5V and the SL LED will be on. If this LED is off it means that the AC power is “OFF” or has been disconnected.


### 2.6.3. IDE HDD LED Connector

Any read and write activity by the HDD will turn this LED on.

## 2.6.4. Reset Button Connector

If you connect this connector, you will be able to reset your computer by pressing the reset button at the front of the chassis.

## 2.7. Speaker and Power LED Connectors



### 2.7.1. Speaker Connector

Connect your chassis speaker to this four pin connector. It allows you to hear systems beeps and warnings sound.

### 2.7.2. Front Panel Power LED

The chassis Power LED connector can be connected to the four pin connector. When you turn your system on, this LED will also be turned on.

## 2.8. External Connectors

### 2.8.1. PS/2 Keyboard connector.

Connector: CN 1  
Type: 6 pin female



This connector only supports a PS/2 keyboard plug. If you have a standard AT size (large DIN) keyboard plug, you need to use a mini DIN adapter.

### 2.8.2. PS/2 Mouse Connector.

Connector: CN 2  
Type: 6 pin female




This connector only supports a PS/2 mouse plug. If a PS/2 mouse is detected then IRQ 12 will be directed to CN 2.


## 2.8.3. Serial Port 1 (COM 1) and Serial Port 2 (COM 2)

**Connector:** CN3 (COM 1)/CN4 (COM 2)  
**Type:** 9 pin male

Two serial ports are available for a mouse and other serial devices. (I/O addresses used are 3F8H/2F8H/3E8H/2E8H and IRQ3/IRQ4, selected by CMOS setup.)



## 2.8.4. Parallel Port Connector (LPT)




**Connector:** CN 5  
**Type:** 25 pin female.

This parallel port is used by printers which support the SPP, EPP and ECP modes IRQ7 or IRQ5 can be selected. The ECP mode will use either DMA 3 or DMA 1 (which can be selected by the BIOS setup program).


## 2.8.5. Universal Serial Bus (USB) Port 1 & 2

**Connector:** CN 6 (USB 1)/ CN 7 (USB 2)  
**Type:** 4 pin female

Two USB ports are available for connecting USB devices. The mainboard is also equipped with an expansion connector that supports two additional USB external connectors. (The USB cable is not included with the mainboard).



## 2.8.6. Audio/Game Port Connector




**Connector:** CN 18  
**Type:** 15 pin female

The Game/MIDI port connector is a dual purpose connector. It can either be used to connect a joystick to the computer for game participation, or it can be used to attach an external MIDI device. All these motherboards have 3D audio interfaces onboard.

## 2.9. Jumper Settings

Jumpers are built on the mainboard to allow the user flexibility to configure the mainboard settings to meet their specific requirements. The **KT33-BV** mainboards come with 4 jumpers, three 3-pin and one 2-pin jumper. When there is no jumper cap inserted into the jumper it is called "OPEN." When a cap is inserted into the jumper it is known as a "SHORT." Below is an example of a short setting on a jumper. The jumper settings and locations are shown below.



### 2.9.1. JP1: USB 1 and USB 2 power

**Type:** 3 pin  
**Default:** Pin 1 and Pin 2 Short

This jumper allows you to select the voltage that is supplied to USB 1 and USB 2. You have two choices: 5 V (pin 1 and pin 2 short) or standby 5 V (pin 2 and pin 3 short). Some USB devices may not follow the standard USB power specifications. If you are using such a device it may unstable. If you do experience problems try to change the setting on Pin 2 and Pin 3. This might help solve this problem.

### 2.9.2. JP2: Keyboard Power

**Type:** 3 pin  
**Default:** Pin 1 and Pin 2 Short

Some keyboards may not follow standard specifications. If you find you are having problems with your keyboard, change the settings on Pin 2 and Pin 3. This might help you to solve the problem.



### 2.9.3. JP6: CPU FSB Clock

**Type:** 2 pin  
**Default:** Open

This allows you to select the speed of your CPU. If you are using a 200 MHz CPU (with a 100 MHz FSB) on your mainboard then you need to SHORT JP6. If you are using a 266 MHz CPU (with a 133 MHz FSB) you need to OPEN JP6.

### 2.9.4. JP8: Clear CMOS Memory

**Type:** 3 pin  
**Default:** Pin 1 and Pin 2 Short

If you have made an improper setting in the BIOS setup and your computer is not functioning, or if you have forgotten your password, you can use this jumper, JP8, to clear the CMOS memory and to reconfigure your system.

**To clear the CMOS, please follow these instructions:**

1. Turn the system power "OFF" and "unplug your computer".
2. Insert the jumper cap on Pin 2 and Pin 3 for 3 ~ 5 seconds.
3. Pull out the jumper cap and replace it on Pin 1 and Pin 2.
5. Turn your PC on and run the BIOS setup program

## Chapter 3 - Managing the PC BIOS

### 3.1. Award BIOS CMOS Setup Utility

Once you have installed the mainboard you still need to setup the BIOS before you can run your PC. The EEPROM on the mainboard stores the AWARD BIOS CMOS Setup Utility, which allows you to configure your system. When you want to configure or make any changes to the configuration of your system BIOS you must run the BIOS CMOS Setup Utility.

#### GETTING STARTED

Every time you start your computer, the system provides you with an opportunity to run the BIOS CMOS Setup Utility. As soon as you turn on your system, press the <Delete> button to activate the BIOS CMOS Setup Utility.

If your computer finishes the POST (Power-On-Self-Test) the BIOS CMOS Setup Utility will **not be** activated. If your computer completes the POST you need to restart the system to activate the BIOS CMOS Setup Utility. To restart the system, you can either turn the power off, press the reset button on your chassis or press the <Ctrl> + <Alt> + <Delete> button. In all three cases the system will restart and, to activate the BIOS CMOS Setup Utility, you must immediately press the <Delete> button.

### 3.2. Main Menu

Phoenix - Award BIOS CMOS Setup Utility	
<ul style="list-style-type: none"><li>▶ Standard CMOS Features</li><li>▶ Advanced BIOS Features</li><li>▶ Advanced Chipset Features</li><li>▶ Integrated Peripherals</li><li>▶ Power Management Setup</li><li>▶ PNP/PCI Configuration</li><li>▶ PC Health Status</li></ul>	<ul style="list-style-type: none"><li>▶ Frequency/Voltage Control</li><li>Load Optimized Defaults</li><li>Set Supervisor Password</li><li>Set User Password</li><li>Save &amp; Exit Setup</li><li>Exit Without Saving</li></ul>
Esc : Quit	← ↑ ↓ → : Select Item
Time, Date, Hard Disk Type ...	

**Note! BIOS software is continuously updated therefore the BIOS menus and the descriptions that are given in this manual are for reference purposes only.**

## Navigation Keys

You will notice a legend bar at the bottom of the main menu. The keys in this legend bar show you how to navigate through the setup menus. The table below lists the control keys with their corresponding functions: -

Control Key	Function
<b>Up Arrow</b>	Moves to the previous item.
<b>Down Arrow</b>	Moves to the next item.
<b>Left Arrow</b>	Moves to the item on the left.
<b>Right Arrow</b>	Moves to the item on the right.
<b>Enter</b>	Selects the desired item.
<b>F1</b>	Displays the help screen for the selected feature.
<b>Esc key</b>	Exits to the previous screen.
<b>PgUp(-)/PgDn(+)</b>	Modifies or changes the content of the highlighted item.
<b>F5</b>	Restores the previous CMOS values to the current page setup. This will not restore the previous values for any other pages.
<b>F7</b>	Loads the SETUP default values from BIOS default table, (only the current page setup will be loaded).
<b>F10</b>	Saves changes to the CMOS and exits the setup.

## 3.3. Standard CMOS Setup (Menu on Page 27)

### Date (mm : dd : yy)

Sets your system to the date that you specify (usually the current date). The format is month, day, and year. Press the right or left arrow key to move to the desired field (month, date, year). Press the PgUp or PgDn key to increment the setting, or type the desired value into the field.

### Time (hh : mm : ss)

Sets your system to the time you specify (usually the current time). The format is hour, minute, second. The time format is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Press the right or left arrow key to move to the desired field. Press the PgUp or PgDn key to increment the setting, or type the desired value into the field.

### IDE Primary / Secondary Master / Slave

This mainboard supports four IDE Hard Drives. These fields allow you to set your Hard Drive parameters. Move the selection bar to the IDE Hard Drive you want to configure. Press the "ENTER" key. If you select "AUTO" the system BIOS will detect the HDD type automatically.



# Managing The PC BIOS



Phoenix - Award BIOS CMOS Setup Utility Standard CMOS Features		
Date (mm : dd : yy)	Wed, Feb 27, 2002	Item Help
Time (hh : mm : ss)	12 : 8 : 38	
▶ IDE Primary Master	[None]	Menu Level ▶  Change the day, month, year and century
▶ IDE Primary Slave	[None]	
▶ IDE Secondary Master	[None]	
▶ IDE Secondary Slave	[None]	
Drive A	1.44, 3.5 in	
Drive B	None	
Floppy 3 Mode Support	[Disabled]	
Video	EGA/VGA	
Halt On	All Errors	
Base Memory	640K	
Extended Memory	65472K	
Total Memory	1024K	

## Drive A /B

The **KT33-BV** mainboard series can support up to two floppy disk drives. These two selection fields allow you to select the floppy drives that are installed on your computer. Select the correct specifications for the diskette drive(s) installed on your computer.

## Floppy 3 Mode Support

If you have installed a 3.5 inch high capacity floppy disk drive you need to enable this option. If you have not installed one of these drives use the default setting.

Diskette Drive	Type of Disk Drive	Capacity
None	No diskette drive installed	
360K 5.25 in	5-1/4 inch PC-type standard drive	360 KB
1.2M 5.25 in	5-1/4 inch AT-type high-density drive	1.2 MB
720K 3.5 in	3-1/2 inch single-sided drive	720 KB
1.44M 3.5 in	3-1/2 inch double-sided drive	1.44 MB
2.88M 3.5 in	3-1/2 inch double-sided drive	2.88 MB

## Video

This field selects the type of primary video subsystem that is on your computer. The BIOS CMOS Setup Utility will automatically detect the correct video type.

Monitors	
EGA/VGA	Enhanced Graphics Adapter/Video Graphics Array. For EGA, VGA , SEGA, SVGA or PGA monitor adapters



## Managing The PC BIOS



<b>Monitors</b>	
CGA 40	Color Graphics Adapter power up in 40 column mode
CGA 80	Color Graphics Adapter power up in 80 column mode
MONO	Monochrome adapter includes high resolution monochrome adapters

### Halt On

This field allows you to decide which errors, detected during the Power On Self Test (POST), will halt the system.

### Base Memory / Extended Memory / Total Memory

This field displays the amount of memory detected by the system during boot up. This is a display only field. You cannot make any changes to this field.

**Base Memory:** Indicates the memory installed below the conventional 1MB space.

**Extended Memory:** Indicates the memory installed above the 1MB space.

**Total Memory:** Indicates the total memory installed in the PC system.

## 3.4. Advanced BIOS Features

Phoenix - Award BIOS CMOS Setup Utility Advanced BIOS Features		
<b>Virus Warning</b>	[Disabled]	<b>Item Help</b>  Menu Level ▶  Allows you to choose the VIRUS warning feature for IDE Hard disk boot sector protection. If this function is enabled and someone attempts to write data into this area, BIOS will show a warning message on screen and alarm beep.
<b>CPU Internal Cache</b>	[Enabled]	
<b>External Cache</b>	[Enabled]	
<b>CPU L2 Cache ECC Checking</b>	[Enabled]	
<b>Quick Power On Self Test</b>	[Enabled]	
<b>First Boot Device</b>	[Floppy]	
<b>Second Boot Device</b>	[HDD-0]	
<b>Third Boot Device</b>	[LS120]	
<b>Boot Other Device</b>	[Enabled]	
<b>Swap Floppy Drive</b>	[Disabled]	
<b>Boot Up Floppy Seek</b>	[Enabled]	
<b>Boot Up NumLock Status</b>	[On]	
<b>Gate A20 Option</b>	[Fast]	
<b>Typematic Rate Setting</b>	[Disabled]	
<b>X Typematic Rate (Chars/Sec)</b>	6	
<b>X Typematic Delay (Msec)</b>	250	
<b>Security Option</b>	[Setup]	
<b>PS/2 Mouse Function Control</b>	[Enabled]	
<b>OS Select For DRAM &gt; 64 MB</b>	[Non-OS2]	
<b>HDD S.M.A.R.T Capability</b>	[Disabled]	
<b>Video BIOS Shadow</b>	[Enabled]	



### Virus Warning

When you enable the virus warning you will receive a warning message whenever a program (specifically, a virus) attempts to write to the boot sector or the partition table of the hard disk drive. If you receive such a message you should immediately run an anti-virus program. Keep in mind that this feature **only** protects the boot sector and not the entire hard drive.

Disk diagnostic programs that access the boot sector table can trigger the virus-warning message. If you run such a program, recommend that you first disable the virus warning.

### CPU Internal Cache / External Cache

Cache memory is additional memory that is much faster than conventional DRAM (system memory). CPUs from 486-type up contain internal cache memory, and most, but not all, modern PCs have an additional (external) cache memory. When the CPU requests data, the system transfers the requested data from the main DRAM into cache memory, for faster access by the CPU.

### CPU L2 Cache ECC Checking

When you select Enabled, the ECC checking will ensure that the data stored on the L2 cache is accurate.

### Quick Power On Self Test

If enabled the amount of time required to run the power-on self-test (POST) will decrease. A quick POST skips certain steps. We recommend that you disable quick POST. It is better to find a problem during POST than to lose data during your work.

### First / Second / Third Boot Device

These fields allow you to decide the boot sequence of your bootable devices such as Floppy Drive, Hard Drive, CD ROM...etc

### Boot Other Device

When this field is enabled you will be able Boot your computer from a different device, not your HDD or FDD.

### Swap Floppy Drive

This field is effective only in systems with two floppy drives. When Enabled is selected physical drive B is assigned to logical drive A, and physical drive A is assigned to logical drive B.

### Boot Up Floppy Seek

When enabled, the BIOS tests (seeks) floppy drives to determine whether they have 40 or 80 tracks. Only 360-KB floppy drives have 40 tracks; drives with 720 KB, 1.2 MB, and 1.44 MB capacity all have 80 tracks. Very few modern PCs have 40-track floppy drives so we therefore recommend that you set this field to Disabled to save time.



## Managing The PC BIOS



### Boot Up NumLock Status

This controls the state of the NumLock key when the system boots. This field is toggled between On or Off. When it is on the numeric keypad generates numbers instead of controlling the cursor operations. When it is off the numeric keypad controls cursor operations and does not generate numbers.

### Gate A20 Option

Gate A20 is a signal that gives the system access to addresses higher than A19. If you select Fast the chipset will control this signal. If you select normal a pin in the keyboard controller will control the signal.

### Typematic Rate Setting

The keyboard controller determines the rate at which the keystrokes from the keyboard are repeated. If enabled the typematic rate and the typematic delay can be selected.

### Typematic Rate

The rate a character will repeat itself on the screen when you hold down a key.

### Typematic Delay

This is the delay time (Msec) before the repetition of characters starts.

### Security Option

This field allows you to select the "Setup" or "System" security option. It works concurrently with the "Set Supervisor Password" in the main menu.

When the "Setup" option is selected, you will be prompted to enter your "Password" before you can start the BIOS CMOS Setup Utility. When you select "System" option, you will be prompted to enter your password in order to load the Operating System.

**TIP:** If you forget your password you can use Jumper 8 (JP8) to clear the password by erasing the CMOS Real Time Clock (RTC) Ram. Please see section 2.9.4 on page 24.

### PS/2 Mouse Function Control

If you have installed a serial pointing device and your system has a PS/2 mouse port you should disable this option.

### OS Select For DRAM > 64MB

Only select OS2 if you are running an OS/2 operating system with a RAM greater than 64 Mb. Otherwise, for all other operating systems, use the default setting "Non-OS2".

### HDD S.M.A.R.T Capability

You may "enable" this option if your Hard Drive supports the S.M.A.R.T technology (Self Monitoring Analysis Reporting Technology) feature. S.M.A.R.T will monitor and report your Hard Drive health status. Ask your Hard Drive vendor for more information. **(Note: Using this feature may decrease system performance.)**



# Managing The PC BIOS



## Video BIOS Shadow

These fields allow you to change the Video BIOS location from ROM to RAM. Information access is faster through RAM than ROM. Therefore when you enable this option you will enhance your system performance.

## 3.5. Advanced Chipset Features

Phoenix - Award BIOS CMOS Setup Utility Advanced Chipset Features		
▶ DRAM Clock/Drive Control	[Press Enter]	Item Help
▶ AGP & P2P Bridge Control	[Press Enter]	Menu Level ▶
▶ CPU & PCI Bus Control	[Press Enter]	
Memory Hole	[Disabled]	
System BIOS Cacheable	[Disabled]	
Video RAM Cacheable	[Disabled]	

### Dram Clock Drive Control

This field allows you to select the FSB and DRAM frequency. When you press enter the following menu will appear.

Phoenix - Award BIOS CMOS Setup Utility DRAM Clock/Drive Control		
Current FSB Frequency	100 MHz	Item Help
Current DRAM Frequency	133 MHz	Menu Level ▶ ▶
DRAM Clock	[By SPD]	
DRAM Timing	[By SPD]	
X SDRAM CAS Latency	2.5	
X Bank Interleave	[Disabled]	
X Precharge to Active (Trp)	3T	
X Active to Precharge (Tras)	6T	
X Active to CMD (Trcd)	3T	
DRAM Queue Depth	[4 level]	
DRAM Command Rate	[2T Command]	

▶ **Current FSB Frequency**

The setting for this field will be automatically selected by the BIOS.

▶ **Current Dram Frequency**

The setting for this field will be automatically detected by the BIOS. The value that is selected in derived from the RAM clock.



## Managing The PC BIOS



### ▶ DRAM Clock

When you press enter you will have three options:

**By SPD** :The BIOS will automatically detect the actual DRAM Clock.

**100 MHz** :The DRAM clock speed will be PC1600 (100 MHz DDR).

**133 MHz** :The DRAM clock speed will be PC2100 (133 MHz DDR).

**166MHz** :The DRAM clock speed will be PC2700 (166 MHz DDR).

### ▶ DRAM Timing

This field enables/disables you from selecting the values for following six fields manually. These (six) fields determine the DRAM read/write timing. If you select **By SPD** then those fields will be automatically configured by the system BIOS. (The performance parameters of the installed memory chips (DRAM) determines the value in those fields.) If you select Manual you will need to enter the values for those fields. You should not change the values of those fields from the factory setting unless you have installed new memory that has a different performance rating than the original DRAMs.

### ▶ DRAM CAS Latency

Before DRAM can execute a read command that it receives, there is a delay time, which is measured in clock cycles (CLK). Some memory modules are unable to deal with short delay times. We recommend that you set this delay time between 2 and 2.5 CLK's (the default is 2.5). If your system becomes unstable we recommend that you increase the delay time.

### AGP & P2P Bridge Control

When you press enter the following menu will appear:

Phoenix - Award BIOS CMOS Setup Utility AGP & P2P Bridge Control		
AGP Aperture Size	[128M]	Item Help
AGP Mode	[4X]	Menu Level ▶ ▶
AGP Driving Control	[Auto]	
X AGP Driving Value	DA	
AGP Fast Write	[Disabled]	
AGP Master 1 WS Write	[Disabled]	
AGP Master 1 WS Read	[Disabled]	

### ▶ AGP Aperture Size

This field selects the size of the Accelerated Graphics Port (AGP) aperture. The aperture is a portion of the PCI memory address range dedicated for graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation. The default is 128MB. You may increase this memory when you need to have faster access for 3D graphics applications (e.g. games).

### ▶ AGP Mode

This item allows you to select 1x, 2x or 4x AGP mode.



## Managing The PC BIOS



### ▶ AGP Driving Control

The recommended setting for this field is the default "Auto". If you have an unstable AGP card you may use this field to choose the appropriate settings. If you do need to tune the timing, please consult your AGP Card manual or Vendor.

### ▶ AGP Driving Value

This item allows you to adjust the AGP driving force.

### ▶ AGP Fast Write

Some AGP cards, like G-Force, support AGP fast write. If you have an AGP card that supports this mode you can enable this field. If your AGP card does not support the fast write mode then leave this field "disabled".

### ▶ AGP Master 1 WS Write

When Enabled, writes to the AGP are executed with one-wait states.

### ▶ AGP Master 1 WS Read

When Enabled, reads to the AGP are executed with one-wait states.

## CPU & PCI Bus Control

When you select this field the following menu will appear:

Phoenix - Award BIOS CMOS Setup Utility CPU & PCI Bus Control		
PCI1 Master 0 WS Write	[Enabled]	Item Help
PCI2 Master 0 WS Write	[Enabled]	Menu Level ▶ ▶
PCI1 Post Write	[Enabled]	
PCI2 Post Write	[Enabled]	
PCI Delay Transaction	[Disabled]	

### ▶ PCI 1/PCI 2 Master 0 WS Write

When enabled, writes to the PCI 1/PCI 2 bus are executed with zero wait states.

### ▶ PCI 1/PCI 2 Post Write

You can Enable or Disable the chipset's ability to use a buffer for posted writes initiated on the PCI 1/PCI 2 bus.

### ▶ PCI Delay Transaction

The chipset has an embedded 32-bit posted write buffer to support delay transactions cycles. Select Enabled to support compliance with PCI specification version 2.1. Select enabled to support compliance with PCI specification version 2.1.

## Memory Hole

You can reserve this area of system memory for ISA adapter ROM. When this area is reserved, it cannot be cached. The user information of peripherals that need to use this area of system memory usually discusses their memory requirements.



# Managing The PC BIOS



## System BIOS Cacheable

Selecting "Enabled" allows caching of the system BIOS ROM. This results system performance. However, if any program writes to this memory area, a system error may occur.

## Video RAM Cacheable

Select Enabled allows caching of the video RAM, resulting in better system performance. However, if any program writes to this memory area, a system error may occur.

## 3.6. Integrated Peripherals

Phoenix - Award BIOS CMOS Setup Utility Integrated Peripherals		
▶ VIA OnChip IDE Device	[Press Enter]	Item Help
▶ VIA OnChip PCI Device	[Press Enter]	Menu Level ▶
▶ SuperIO Device	[Press Enter]	
Init Display First	[PCI Slot]	
OnChip USB Controller	[All Enabled]	
USB Keyboard Support	[Disabled]	
IDE HDD Block Mode	[Enabled]	

### VIA OnChip IDE Device

When you press enter the following menu will appear:

Phoenix - Award BIOS CMOS Setup Utility VIA OnChip IDE Device		
OnChip IDE Channel0	[Enabled]	Item Help
OnChip IDE Channel1	[Enabled]	Menu Level ▶
IDE Prefetch Mode	[Enabled]	
Primary Master PIO	[Auto]	
Primary Slave PIO	[Auto]	
Secondary MasterPIO	[Auto]	
Secondary Slave PIO	[Auto]	
Primary Master UDMA	[Auto]	
Primary Slave UDMA	[Auto]	
Secondary MasterUDMA	[Auto]	
Secondary Slave UDMA	[Auto]	

#### ▶ OnChip IDE Channel 0/1

The chipset contains a PCI IDE interface with support for two IDE channels. To activate the primary IDE interface select Enabled. If you want to disable the onboard IDE 1 and/or 2, then select Disabled.



## Managing The PC BIOS



### ▸ IDE Prefetch Mode

The onboard IDE drive interfaces supports IDE pre-fetching for faster drive access. If you install a primary and/or secondary add-in IDE interface which does not support pre-fetching set this field to Disabled.

### ▸ Primary/Secondary, Master/Slave PIO


The four IDE PIO (Programmed Input/Output) fields let you set a PIO mode (0-4) for each of the four IDE devices that the onboard IDE interface supports. Modes 0 through 4 provide successively increased performance. In Auto mode, the system automatically determines the best mode for each device.

### ▸ Primary/Secondary, Master/Slave UDMA

Ultra DMA/66 implementation is possible only if your IDE hard drive supports it and the operating environment includes a DMA driver (Windows 98 OSR2 or a third-party IDE bus master driver). If your hard drive and your system software both support Ultra DMA/66, select Auto to enable BIOS support.

### VIA OnChip PCI Device

When you select this field the following menu will appear:



### ▸ VIA-3058 AC97 Audio

If you want to enable the on-chip audio capabilities of your system you need use the default setting "Auto". If you install an add on sound card you must disable this field.

### SuperIO Device

When you press enter the following menu on page 36 is shown

### ▸ Onboard FDC Controller

Select Enabled if your system has a floppy disk controller (FDC) installed on the system board and you want to use it. If you install an add-in FDC or the system has no floppy drive, select Disabled in this field.

### ▸ Onboard Serial Port 1/2

These two selection fields allow you to select the I/O address and corresponding interrupts for the first and second serial port.

### ▸ UART Mode Select

Your system may offer a variety of infrared modes on the second serial port. The options are Standard, HPSIR or ASKIR.



## Managing The PC BIOS



Phoenix - Award BIOS CMOS Setup Utility SuperIO Device		
Onboard FDC Controller	[Enabled]	Item Help
Onboard Serial Port 1	[3F8/IRQ4]	Menu Level ▶
Onboard Serial Port 2	[2F8/IRQ3]	
UART Mode Select	[Normal]	
X RxD, TxD Active	Hi, Lo	
X IR Transmission Delay	Enabled	
X UR2 Duplex Mode	Half	
X Use IR Pins	IR-Rx2Tx2	
Onboard Parallel Port	[378/IRQ7]	
Parallel Port Mode	[SPP]	
X EPP Mode Select	[EPP1.7]	
X ECP Mode Use DMA	[3]	
Game Port Address	[201]	
Midi Port Address	[330]	
Midi Port IRQ	[10]	

### ▶ RxD, TxD Active

This field allows you to set the IR reception/transmission polarity as high or low. To determine which polarity is appropriate you must refer to the documentation for your IR peripheral.

This field is usually found under the Onboard Serial Port 2 option. If you disable the Onboard Serial Port 2 option then you will probably not be able to configure this field.

### ▶ IR Transmission Delay

This field allows you to "Enable" or "Disable" the IR Transmission Delay.

### ▶ UR2 Duplex Mode

This field appears in an infrared port mode. You have two options: half or full duplex function. The full duplex mode allows bi-directional transmission at a single time where as the half duplex mode only allows transmission in one direction at a time. This setting depends on the nature of your IR peripheral device. Check the IR device's manual to determine the appropriate setting.

### ▶ Use IR Pins

To determine the correct settings for the TxD and RxD signals of your IR peripheral component, you need to consult the components manual.

### ▶ Onboard Parallel Port

This item allows you to determine the I/O address and the IRQ for the on-board parallel port. The default settings are adequate and should not give you any problems. If they do you can try to change them.



### ▶ Parallel Port Mode

This field allows you to select an operating mode for the onboard parallel (printer) port. Select Normal, Compatible, or SPP unless you are certain your hardware and software both support one of the other available modes.

### ▶ EPP Mode Select

This field allows you to choose the EPP version you want to use. We recommend that you use EPP 1.9 for the best performance but if you do you may have some connection problems so try setting it to EPP 1.7.

### ▶ ECP Mode Use DMA

This item allows you to select a DMA channel for the parallel port for use during ECP.

### ▶ Game Port Address

This field allows you to select the I/O address for the onboard game port. The default is 201.

### ▶ Midi Port Address

This field allows you to select the I/O address for the onboard MIDI port. The default is 330.

### ▶ MIDI Port IRQ

This field allows you to select the IRQ for the onboard MIDI port. The default is 10.

## Init Display First

This field allows a user, with two graphics cards installed on his system, to select which graphics card will be activated first: either the PCI graphics card or the AGP graphics card. If you have only installed one graphics card the BIOS will automatically detect it and you do not need to set this field.

## OnChip USB Controller

This field allows you to enable or disable the onboard USB controller.

## USB Keyboard Support

This field should only be enabled if you are using a USB keyboard. If you are not using this kind of keyboard you should disable it.

## IDE HDD Block Mode

Block mode is also known as block transfer, multiple commands, or multiple sector read/write. If your IDE hard drive supports block mode select "Enabled" for automatic detection of the optimal number of block read/writes per sector the drive can support.



## 3.7. Power Management Setup

Phoenix - Award BIOS CMOS Setup Utility Power Management Setup		
ACPI Function	[Enabled]	Item Help
ACPI Suspend Type	[S1(POS)]	Menu Level ▶
Power Management Option	[User Define]	
HDD Power Down	[Disable]	
Suspend Mode	[Disable]	
Video Off Option	[Suspend -> Off]	
Video Off Method	[Blank Screen]	
MODEM Use IRQ	[3]	
Soft-Off by PWRBTN	[Instant-Off]	
PWRON After PWR-Fail	[Off]	
▶ IRQ/Event Activity Detect	[Press Enter]	

### ACPI function

This item allows you to enable/disable the Advanced Configuration and Power Management (ACPI).

### ACPI Suspend Type

This field selects the **S1(POS)** (Power On Suspend) suspend state mode.

### Power Management

This category allows you to select the degree of power saving. The choices are shown in the table below.

<b>Min. Power Saving</b>	Minimum power management. Suspend Mode = 1 hr.
<b>Max. Power Saving</b>	Maximum power management -- <b>ONLY AVAILABLE FOR SL CPU</b> . Suspend Mode = 1 min.
<b>User Defined</b>	Allows you to set each mode individually. When not disabled, each of the ranges are from 1 min. to 1 hr. except for HDD Power Down which ranges from 1 min. to 15 min. and disable.

### HDD Power Down

When enabled and after the set time of system inactivity, the hard disk drive will be powered down while all other devices remain active.

### Suspend Mode

When enabled, after the set time of system inactivity, all devices except the CPU will be shut off.



## Managing The PC BIOS



### Video Off Option

When enabled, this feature allows the VGA adapter to operate in a power saving mode.

<b>Always On</b>	Monitor will remain on during power saving modes.
<b>Suspend --&gt; Off</b>	Monitor blanked when the systems enters the Suspend mode.
<b>MODEM Use IRQ</b>	This determines the IRQ the modem can use.

### Modem Use IRQ

This determines the IRQ which the MODEM can use for Power Saving purposes. This mainboard has the ACPI feature designed on the board and it will "wake-up" automatically when it detects an incoming modem Ring-in signal. Before you can use the Ring-in signal to wakeup your PC system, you have to install the "External" modem to your PC system and tell the PC system which serial port connects to the modem by selecting the IRQ in this field. (Officially COM1 uses IRQ4)

### Video Off Method

This determines the manner in which the monitor goes blank.

<b>V/H SYNC+Blank</b>	This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.
<b>Blank Screen</b>	This option only writes blanks to the video buffer.
<b>DPMS Support</b>	Select this option if your monitor supports the Display Power Management Signaling (DPMS) standard of the Video Electronics Standards to select video power management values.

### MODEM Use IRQ

This determines the IRQ which the MODEM can use for power saving purposes. This mainboard has the ACPI feature designed on the board and it will "wakeup" automatically when it detects an incoming modem Ring-in signal. Before you can use the Ring-in signal to wakeup your PC system, you have to install the "External" modem to your PC system and tell the PC system which serial port connects to the modem by selecting the IRQ in this field, (officially, COM 1 uses IRQ4, and COM 2 uses IRQ3)

### Soft-Off by PWRBTN

Pressing the power button for more than 4 seconds forces the system to enter the Soft-Off state when the system has "hung".

### PWRON After PWR-Fail

See the following table for all the options.



## Managing The PC BIOS



<b>Off:</b>	When the power returns after an AC power failure the system's power is off. You must press the Power button to power-on the system
<b>Former - Sts:</b>	When power returns after an AC power failure, the system will return to the state where you left off before the power failure occurred. If the system's power is off when the AC power failure occurred, it will remain off when the power returns. If the system's power is on when the AC power failure occurred, the system will power-on when the power returns.

### IRQ/Event Activity Detect

When you press the "Enter" the following menu will appear:

Phoenix - Award BIOS CMOS Setup Utility IRQ/Event Activity Detect		
VGA	[OFF]	Item Help
LPT & COM	[LPT/COM]	Menu Level ▶
HDD & FDD	[ON]	
PCI Master	[OFF]	
PowerOn by PCI Card	[Disabled]	
Modem/LAN Resume	[Disabled]	
RTC Alarm Resume	[Disabled]	
X Date (of Month)	0	
X Resume Time (hh:mm:ss)	0 : 0 : 0	
▶ IRQs Activity Monitoring	[Press Enter]	

#### ▶ VGA

When you enable this option, any VGA signal will wake up the system.

#### ▶ LPT & COM

When this field is "ON" any activity from these devices, or their IRQ's will wake up the system.

#### ▶ HDD & FDD

When this field is "ON" any activity from the HDD or the FDD will wake up the system.

#### ▶ PCI Master

When you enable the PCI Master mode, any activity from one of the listed system peripheral devices wakes up the system.

#### ▶ Power On by PCI Card

The system can be woken up by the PME# on the PCI card.

#### ▶ Modem/LAN Resume

An input signal from the modem/LAN will wake up the system from a soft off state.

#### ▶ RTC Alarm Resume

When enabled, you can use the following two fields to select the time and date to wake up the PC system from power saving mode.



# Managing The PC BIOS



## ▸ Date (of Month)/Resume Time (hh:mm:ss)

When RTC Alarm Resume is enabled, you can set the date and time at which the RTC (real-time clock) alarm awakens the system from Suspend mode.

## ▸ IRQs Activity Monitoring

The following is a list of IRQ's, Interrupt ReQuests, which can be exempted much as the COM ports and LPT ports above can. When an I/O device wants to gain the attention of the operating system, it signals this by causing an IRQ to occur. When the operating system is ready to respond to the request, it interrupts itself and performs the service.

**Note: When set On, activity will neither prevent the system from going into a power management mode nor awaken it.**

Phoenix - Award BIOS CMOS Setup Utility IRQs Activity Monitoring		
Primary INTR	[ON]	Item Help
IRQ3 (COM 2)	[Disabled]	Menu Level ▸
IRQ4 (COM 1)	[Enabled]	
IRQ5 (LPT 2)	[Enabled]	
IRQ6 (Floppy Disk)	[Enabled]	
IRQ7 (LPT 1)	[Enabled]	
IRQ8 (RTC Alarm)	[Disabled]	
IRQ9 (IRQ2 Redir)	[Disabled]	
IRQ10 (Reserved)	[Disabled]	
IRQ11 (Reserved)	[Disabled]	
IRQ12 (PS/2 Mouse)	[Enabled]	
IRQ13 (Coprocessor)	[Enabled]	
IRQ14 (Hard Disk)	[Enabled]	
IRQ15 (Reserved)	[Disabled]	

## 3.8. PNP/PCI Configuration

Phoenix - Award BIOS CMOS Setup Utility PnP/PCI Configurations		
PNP OS Installed	[No]	Item Help
Reset Configuration Data	[Disabled]	Menu Level ▸ Select Yes if you are using a Plug and Play capable operating system. Select No if you need the BIOS to configure non-boot devices.
Resources Controlled By	[Auto(ESCD)]	
× IRQ Resources	[Press Enter]	
PCI/VGA Palette Snoop	[Disabled]	
Assign IRQ For VGA	[Enabled]	
Assign IRQ For USB	[Enabled]	



## Managing The PC BIOS



### PNP OS Installed

This item allows you to determine if a PnP OS is installed or not.

### Reset Configuration Data

Normally, you leave this field Disabled. If you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the operating system cannot boot then select Enabled. Selecting Enabled will reset the Extended System Configuration Data (ESCD).

### Resources controlled By

Award Plug and Play BIOS has the capacity to automatically configure all of the boot and Plug and Play compatible devices. However, this capability means absolutely nothing unless you are using a Plug and Play operating system such as Windows 98.

### IRQ Resources

When resources are controlled manually, assign each system interrupt a type, depending on the type of device using the interrupt

### PCI/VGA Palette Snoop

Some display cards are non-standard VGA cards (such as graphics accelerators and MPEG cards) which may not display color properly on your screen. If this field is **Enabled** it may correct the problem. If you have a normal display card then leave this field **Disabled** as the default setting .

### Assign IRQ For VGA/USB

A system's IRQs are limited. Sometimes you may need to use more IRQ signals for your add-on cards. BIOS allows you to disable the IRQ which is supposed to be connected to the VGA and USB ports. If you choose to disable the IRQ on the VGA or USB port, the IRQ will be released and becomes available for other devices. Please make sure that you have a USB or VGA adapter that does not need an IRQ before you select Disabled.

### Assign IRQ For VGA/USB

A system's IRQs are limited. Sometimes you may need to use more IRQ signals for your add-on cards. BIOS allows you to disable the IRQ which is supposed to be connected to the VGA and USB ports. If you choose to disable the IRQ on the VGA or USB port, the IRQ will be released and becomes available for other devices. Please make sure that you have a USB or VGA adapter that does not need an IRQ before you select Disabled.

## 3.9. PC Health Status (The menu is on the next page)



### CPU Warning Temperature

This field allows you to select an operating temperature range for your CPU. If the CPU temperature moves out of this range, any warning mechanism you have programmed into your system will be activated.



## Managing The PC BIOS



Phoenix - Award BIOS CMOS Setup Utility PC Health Status		
CPU Warning Temperature	[Disabled]	Item Help Menu Level ▶
Current CPU Temperature	55°C/131°F	
Current CPU FAN Speed	4821 RPM	
Current CHASSIS FAN Speed	0 RPM	
Vcore (V)	1.74 V	
Vcc3(V)	3.41V	
+ 5 V	4.75 V	
+ 12 V	12.09 V	
- 12 V	-12.11 V	
VBAT (V)	2.99 V	
5VSB (V)	5.26 V	
Shutdown Temperature	[Disabled]	

### CPU Warning Temperature

This field allows you to select an operating temperature range for your CPU. If the CPU temperature moves out of this range, any warning mechanism you have programmed into your system will be activated.

### Current CPU Temp.

This field shows the current temperature for CPU 1.

### Current CPU FAN Speed

This field shows you the present CPU Cooling FAN1 speed.

### Current Chassis FAN Speed

This field shows you the present CPU Cooling FAN2 speed.

### Vcore

This field and the files below show you the current system voltage

### Shutdown Temperature

When the system reaches a certain maximum temperature the system will automatically shutdown.

## 3.10. Frequency/Voltage Control


Phoenix - Award BIOS CMOS Setup Utility Frequency/Voltage Control		
Auto Detect DIMM/PCI Clk	[Enabled]	Item Help Menu Level ▶
Spread Spectrum	[Disabled]	
X Linear Spread Model	2	
X Linear Spread Range	1	
CPU Clock	[100MHz]	







## 3.14. Save & Exit Setup/ Exit Without Saving



### Save & Exit Setup

This option will save all the setup values to CMOS RAM and exit the SETUP utility. Move the selection bar to "SAVE & EXIT SETUP" and press the "Enter" key, then type "Y" and press the "Enter" key again. The values you have entered will be saved and all the information stored in the CMOS memory.

### Exit Without Saving

This option will exit the setup utility without saving any of the values you changed in the CMOS RAM. If you do not want to save any of the changes, or settings you selected in the BIOS SETUP utility, move the selection bar to the "EXIT WITHOUT SAVING" option. Press the "Enter" key. Then press "Y"