

Acer Altos R710

User's Guide

Copyright © 2004 Acer Incorporated
All Rights Reserved.

Acer Altos R710
User's Guide

1st Issue: September 2004

Changes may be made periodically to the information in this publication without obligation to notify any person of such revision or changes. Such changes will be incorporated in new editions of this manual or supplementary documents and publications. This company makes no representations or warranties, either expressed or implied, with respect to the contents herein and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose.

Record the model number, serial number, purchase date, and place of purchase information in the space provided below. The serial number and model number are recorded on the label affixed to your computer. All correspondence concerning your unit should include the serial number, model number, and purchase information.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopy, recording, or otherwise, without the prior written permission of Acer Incorporated.

Model Number : _____

Serial Number: _____

Purchase Date: _____

Place of Purchase: _____

Acer and the Acer logo are registered trademarks of Acer Inc. Other company's product names or trademarks are used herein for identification purposes only and belong to their respective companies.

Notices

FCC notice

Class A devices do not have an FCC logo or FCC IDE on the label. Class B devices have an FCC logo or FCC IDE on the label. Once the class of the device is determined, refer to the following corresponding statement.

Class A equipment

This device has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this device in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the device and receiver
- Connect the device into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/television technician for help

Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class A or Class B limits may be attached to this equipment. Operation with noncertified peripherals is likely to result in interference to radio and TV reception.



.....

Caution: Changes or modifications not expressly approved by the manufacturer could void the user's authority, which is granted by the Federal Communications Commission, to operate this server.

Use conditions

This part complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canadian users

This Class A/Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Laser compliance statement

The CD-ROM drive in this server is a laser product. The CD-ROM drive's classification label (shown below) is located on the drive.

CLASS 1 LASER PRODUCT

CAUTION: INVISIBLE LASER RADIATION WHEN OPEN. AVOID EXPOSURE TO BEAM.

Important safety instructions

Read these instructions carefully. Save these instructions for future reference.

- 1 Follow all warnings and instructions marked on the product.
- 2 Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
- 3 Do not use this product near water.
- 4 Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
- 5 Slots and openings on the back or bottom side of the chassis are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register, or in a built-in installation unless proper ventilation is provided.
- 6 This product should be operated from the type of power indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
- 7 Do not allow anything to rest on the power cord. Do not locate this product where persons will walk on the cord.
- 8 If an extension cord is used with this product, make sure that the total ampere rating of the equipment plugged into the extension cord does not exceed the extension cord ampere rating. Also, make sure that the total rating of all products plugged into the wall outlet does not exceed the fuse rating.
- 9 Never push objects of any kind into this product through chassis slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- 10 Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.
- 11 Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a When the power cord or plug is damaged or frayed
 - b If liquid has been spilled into the product
 - c If the product has been exposed to rain or water
 - d If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions since improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal condition.
 - e If the product has been dropped or the cabinet has been damaged
 - f If the product exhibits a distinct change in performance, indicating a need for service.
- 12 Replace the battery with the same type as the product's battery we recommend. Use of another battery may present a risk of fire or explosion. Refer battery replacement to a qualified service technician.
- 13 **Warning!** Batteries may explode if not handled properly. Do not disassemble or dispose of them in fire. Keep them away from children and dispose of used batteries promptly.
- 14 Use only the proper type of power supply cord set (provided in your accessories box) for this unit. It should be a detachable type: UL listed/CSA certified, type SPT-2, rated 7A 125V minimum, VDE approved or its equivalent. Maximum length is 15 feet (4.6 meters).

Notices	iii
FCC notice	iii
Class A equipment	iii
Shielded cables	iii
Peripheral devices	iv
Use conditions	iv
Canadian users	iv
Laser compliance statement	iv
Important safety instructions	v
1 System information	1
Product briefing	3
Processor	3
Memory subsystem	3
Storage	4
Graphics interface	4
Networking	4
I/O ports	4
Caring features	6
Product specification summary	7
2 System tour	9
System board	11
Connector and Header Locations	11
Back Panel Connectors	13
SCSI Backplane	15
External and internal structure	16
Front view (with bezel)	16
Front view (w/o bezel)	16
Front panel	18
Front Panel LED and Buttons description	18
Control Button Functions	19
LED Indicator Status	19
Rear view	21
Optional Peripherals	22
Internal components	23
3 Getting Started	25
Setting up the system	27
Preinstallation requirements	27
Selecting a site	27
Checking the package contents	27

Contents

System startup	28
Turning on the system	28
Turning off the system	28
Power-on problems	29
4 Configuring the system	31
Upgrading the system	33
Installation precautions	34
ESD precautions	34
Preinstallation instructions	34
Post-installation instructions	35
Opening the server	36
Before opening the server	36
Removing the Chassis Cover	37
Installing the Chassis Cover	38
Removing and Installing the Processor Air Duct	39
Removing the Processor Air Duct	39
Installing the Processor Air Duct	39
Removing the Processor Air Dam (if required)	41
Removing the Processor Air Dam	41
Installing and removing a hard disc drive	42
Removing a hard disc	42
Installing a hard disc	43
Installing or Removing a Floppy, CD-ROM, or DVD-ROM Drive	45
Install a Slimline Floppy Drive into Altos R710	45
Removing a Floppy Drive from the Slim Line Drive bay with Altos R710	47
Installing a Floppy Drive into the Converted Hard Drive Bay on Altos R710 Server System	48
Removing a Floppy Drive from the Converted Hard Drive Bay	52
Installing the SCSI 6th HD upgrade kit in Altos R710	53
Installing a Tape Drive in Altos R710	55
Install a Slimline Optical drive into Altos R710	59
Removing a Slim line Optical Drive from Altos R710	61
Removing and Installing the PCI Riser Assembly	62
Removing the PCI Riser Assembly	62
Installing the PCI Riser Assembly	63
Replacing the PCI Riser Board	64
Installing a PCI Add-in Card	65
Replacing a System Fan	67
Connecting peripherals	67

Hard Disk Drives	68
Floppy / CD-ROM / DVD-ROM Slimline Cages	68
Rack-Mounted Systems	69
Configuration Jumpers	70
Hardware Requirements	71
Processor	71
Memory	72
Power Supply	75
Optional Hardware	76
Hard Disk Drives	76
Intelligent Management Module	76
Upgrading the CPU	77
Installing a CPU	77
Removing a CPU	79
Upgrading the system memory	80
To remove a DIMM	80
To install a DIMM	81
Reconfiguring the system memory	81
5 BIOS setup	83
Before You Begin	85
Tools and Supplies Needed	85
Installing and Removing Memory	85
RJ45 Serial Port Configuration	85
Replacing the Backup Battery	86
BIOS Setup Utility	89
Main	93
Advanced	95
Upgrading the BIOS	139
Preparing for the Upgrade	139
Recording the Current BIOS Settings	139
Obtaining the Upgrade	139
Upgrading the BIOS	140
Clearing the Password	141
Clearing the CMOS	142
6 Troubleshooting	143
Resetting the System	145
Problems following Initial System Installation	145
First Steps Checklist	145
Hardware Diagnostic Testing	147
Verifying Proper Operation of Key System Lights	147
Confirming Loading of the Operating System	148

Specific Problems and Corrective Actions	148
Power Light Does Not Light	148
No Characters Appear on Screen	149
Characters Are Distorted or Incorrect	150
System Cooling Fans Do Not Rotate Properly	150
Diskette Drive Activity Light Does Not Light	150
CD-ROM Drive or DVD-ROM Drive Activity Light Does Not Light	151
Cannot Connect to a Server	151
Problems with Network	151
System Boots when Installing PCI Card	152
Problems with Newly Installed Application Software	152
Problems with Application Software that Ran Correctly Earlier	153
Devices are not Recognized under Device Manager (Windows* Operating System)	153
Hard Drive(s) are not recognized	154
Bootable CD-ROM Is Not Detected	154
BIOS POST Beep Codes	156

Appendix A: Management software installation

	159
Installing ASM	161
System requirements	161
ASM Agent	161
ASM Console	161
System setup	161
Installing ASM Agent (Windows version)	162
Installing ASM Console (Windows version)	162
Installing ASM Agent (Linux version)	163

Appendix B: Tool-less rail kit installation 165

Tool-less rail kit installation	167
Setting the Multi-Pin Adapters for Rack Type	167
Installing the Slide Rails into the Rack	168
Installing the Component into the Slide Rails	170
Cable Management ARM installation	171
Required Installation Position of the CMA	172
Installing the CMA on the Slide Rails	173
Placing and Securing Cabling Within the CMA	174

General Safety Information	175
Appendix C: RAID Configuration	177
Configuring the SCSI/SCSI RAID HBA	179
How to use SCSI HBA setup utility	179
Loading HBA Default Settings	179
How to use SCSI RAID HBA setup utility	179
How To Create RAID 1 (Mirror) volume with a	
Hot Spare Disk	179
RAID Volume Initialization	180
Exit and Restart the server	180
MegaRAID Configuration Utility	180
Load RAID Card Default Setting	180
Create RAID1 Volume	181
Assign Hot Spare Disk	181
Initialize RAID Volume	181
Save And Exit MegaRAID Configuration Utility	182
Appendix D: BIOS POST Checkpoint Codes	183
BIOS POST Checkpoint Codes	185

Index 201

1 System information

The Acer Altos R710 is a high density, rack optimised single processor system loaded with features. The system offers a new standard for flexible productivity ideal for local or wide area networks and multiuser server environments.

Product briefing

This section provide basic information concerning the configuration of your Altos R710 system.

Processor

- Single or dual Intel® Xeon™ processor with 800 MHz FSB
- CPU Hyper-Threading™ Technology support
- Supports Extended memory 64bit technology (EM64T)

Memory subsystem

- Six (240 - pin) DIMM slots
- DDR-2 400 MHz registered memory modules supported
- Maximum upgrade - 12 GB
- 2-way memory interleave
- SDDC (Single Device Data Correction) for memory error detection and correction of any number of bit failures in a single x4 memory device
- Memory sparing technology
 - When memory sparing is enabled, the spare DIMM will not be detected by OS
 - The sparing DIMM will be reserved for the standby purpose and cannot be accessed by the system¹
- Memory mirroring technology
 - When memory mirroring is enabled, only half of the memory capacity will be detected by the OS.
- Please refer to page115 "Memory Configuration Sub-menu Selections" for more information about configuring the memory sparing or mirroring in the BIOS Setup utility



.....

¹ For example, if six 1GB DIMMs are installed (6 GB memory) only 4GB of memory (in DIMM 1B, 1A, 2B, 2A) can be accessed by the system. Memory in DIMM 3B and DIMM 3A would be reserved as spare DIMMs



.....

Caution! When using multiple memory modules it is recommended that you AVOID using modules from different manufacturers or that run at different speeds from each other.



.....

Warning! Functionality issues may be encountered if mixed memory types are installed on the same server board. DIMM modules of identical type, banking and stacking technology, and vendor should be installed in the Altos R710.

Storage

- Slim-type IDE CD-ROM drive
- Slim-type 3.5 inch Floppy disk drive (optional)
- Support for six (max) hard disk drives



.....

Warning: If FDD and Tape Drive are installed, R710 would support 4 hard disk drives only.

Graphics interface

- On-board ATI Rage XL video controller with 8MB SDRAM

Networking

- Dual port, Intel® 82546GB 10/100/1000 NICs

I/O ports

- Front
 - One USB 2.0 port
- Rear
 - Two USB 2.0 ports
 - Two PS/2 ports (keyboard/mouse)
 - Two LAN port (RJ-45)
 - One SVGA video port
 - One serial port
 - One external SCSI connector

Serial ATA ports

- Two SATA ports

Management Controller

- Onboard National Semiconductor PC87431 management controller
- IPMI 1.5 compliant
- Optional IMM (Intelligent Management Module) can be upgraded to support IPMI 2.0

SCSI Controller

- Onboard LSI Logic 1030 dual-channel U320 SCSI Controller
- One internal SCSI channel, one external SCSI channel
- Supports RAID1

Service ID

- Front service ID button
 - Front and rear service ID LED

Operating Systems supported

- Microsoft® Windows® Server 2003
- Microsoft® Windows® 2000
- Red Hat Enterprise Linux 3
- Novell NetWare 6.5
- SCO OpenServer™ 5.0.7
- SCO Unixware 7.1.4

Zero Channel RAID (Optional)

- Must be installed on the top slot of the full-height PCI riser card.

Caring features

Part of Acer's mission, as a company that cares about its end users, is to provide features that make operation, maintenance, and upgrading your system simpler and faster. The Altos R710 is no exception to this rule. The following features and options are provided.

- Cost efficient operation in a value oriented package
- Tool-less design
- Front accessible USB port
- Acer EasyBUILD™ for efficient system setup and installation
- Acer Server Manager (ASM) suite of comprehensive management tools

Product specification summary

Highlighted below are the system's key features:

- Single or dual Intel® Xeon™ processor supporting Hyper-Threading Technology
- 800 MHz FSB supports processor speeds from 2.8 GHz to 3.6 GHz
- Intel® E7520 chipset consisting of:
 - Intel® E7520 Memory Controller Hub (MCH)
 - PXH
 - Intel® 82801ER I/O Controller Hub 5-R (ICH-5R)
- One Low profile riser slot
 - Three 64-bits/100MHz/3.3V PCI-X slots
- One full height riser slot supporting one of three riser card options:
 - Option 1: Three 64-bits/100MHz/3.3V PCI-X slots
 - Option 2: One 64-bits/100MHz/3.3V PCI-X slot + Two 64-bits/133MHz/3.3V PCI-X slots
 - Option 3: One 64-bits/100MHz/3.3V PCI-X slot + Two x4 PCI-Express slots with x8 connectors
- Six DIMM sockets supporting DDR-2 400 registered ECC modules for a maximum memory capacity of 12 GB
- Media storage
 - Optional slim-type 3.5 inch 1.44 MB floppy drive or Optical drive
- Additional media storage capacity
 - Support for five 3.5 Inch ATA, or SCSI hard disk drives
- External ports
 - PS/2 keyboard and mouse ports
 - Three USB ports (1 front, 2 rear)
 - One external SCSI port
 - Two LAN (RJ-45) ports
 - SVGA video port
- Power supply unit (PSU)
 - One 700W powers supply
 - Optional hot swap redundant 700W power supply kit
- Internal I/O controller connections
 - Two USB port headers
 - One DB9 Serial A header mounted on motherboard
 - One Ultra320 80-pin SCSI connector (Channel A)
 - Two SATA-150 connectors
 - One ATA-100 connector

- SSI-compliant 34-pin, high-density 100-pin, and alternate 50-pin control panel headers
- Intelligent Management Module 120-pin connector, supporting the optional Professional server management modules
- Chassis Intrusion
 - Lockable front bezel
 - Chassis intrusion switch
 - Lock attach point for chassis cover
- Up to eight system fans
 - Four system fans in default configuration
 - Two non-redundant fans in each power supply
- LEDs
 - Standard Control Panel: NIC1 Activity, NIC2 Activity & Power / Sleep
 - System Status (with optional light pipe kit, system status LEDs can be viewed with bezel closed)
 - Service ID
 - Power subsystem: Status LED on each power module
 - Fault LED for each system fan
- Server Management / Diagnostics
 - On-board Platform Instrumentation using the National Semiconductor* PC87431M mini-Baseboard Management Controller (mBMC) (Default).
 - Support for optional Intelligent Management Module - Professional Edition
 - Support for Acer Altos Server Management 6.x
 - Light-Guided Diagnostics on all field replaceable units (FRUs)


2 System tour

This chapter provides locations of various components and ports and instructions on how to set up the system.

System board

Connector and Header Locations


The mainboard becomes accessible once you open the system. The figure below is provided to help you identify and locate connectors, slots and ports.



Item	Description
A	Serial Port A
B	SCSI Channel B
C	8-pin ARMC connector
D	CMOS Battery
E	Full-height riser slot
F	Low-profile riser slot
G	Back panel I/O ports
H	DIMM slots 1B, 1A, 2B, 2A, 3B, 3A (from right to left)
I	Processor 1 fan header
J	Processor socket 1
K	Processor socket 2
L	Processor 2 fan header
M	+12V processor power
N	Fan board connector
O	Floppy connector
P	System fan 3-pin header
Q	Secondary IDE channel
R	Control panel 100-pin connector
S	24-pin SSI power connector
T	50-pin control panel connector
U	34-pin SSI control panel connector
V	SATA port 1

Item	Description
W	SATA port 2
X	Power supply signal cable
Y	USB header (DH-10)
Z	USB header (1 x 10)
AA	IPMB connector
BB	IDE power connector
CC	SCSI channel A
DD	ICMB connector
EE	120-pin connector for optional Acer® Intelligent Management Module

Back Panel Connectors




Item	Description
A	PS/2 Mouse port
B	PS/2 Keyboard port
C	Com Port (RJ-45 connector)
D	Gigabit LAN # 1 Port (RJ45)
E	Gigabit LAN # 2Port (RJ45)
F	Video Port
G	USB port #1
H	USB port #2
I	SCSI Channel A external connector

The NIC LEDs at the right and left of each NIC provide the following information.

LED Color	LED State	Description
Left LED	Off	No network connection
Left LED	Solid Amber	Network connection in place
Left LED	Blinking Amber	Transmit/receive activity
Right LED	Off	10 Mbps connection (if left LED is on or blinking)
Right LED	Solid Amber	100 Mbps connection
Right LED	Solid Green	1000 Mbps connection

SCSI Backplane

The Hot-Swap SCSI Backplane installs on the back side of the hot-swap drive bay inside the chassis. Alignment features on the chassis and backplane assembly make for easy tool-less installation. The following diagram shows the layout of components and connectors on the Hot-swap SCSI Backplane printed circuit board.



Item	Description
A	Floppy Drive Connector
B	IDE Optical Drive Connector
C	SCA2 Hard Drive Connectors
D	6 th Hard Drive Upgrade Kit
E	Control Panel Connector



.....

Note: To prevent the backplane from flexing when installing or removing hard drives from the drive bay, the system top cover must be on the system. Having the top cover installed will ensure the drives attach securely to the drive connectors on the backplane.

External and internal structure

Front view (with bezel)



No.	Description
1	Name Plane
2	Keylock
3	LEDs


Front view (w/o bezel)



No.	Description
1	Slim CDROM or FDD Bay

No.	Description
2	3.5" SCSI HDD bay
3	Tape Device bay / 6th SCSI HDD bay
4	Front VGA output port
5	Front USB port
6	Power Button
7	Service ID Button

Front panel



Front Panel LED and Buttons description

Item	Description
A	Power Button
B	LAN #2 Activity LED
C	LAN #1 Activity LED
D	Power LED
E	System Status LED
F	Hard Drive Activity LED
G	Service ID LED
H	Service ID Button
I	System Reset Button
J	USB connector
K	Recessed NMI Button (Tool Required)
L	VGA connector

Control Button Functions

Item	Description
Power/ Sleep button	Toggles the system power on/off. Sleep button for ACPI-compatible operating systems.
Reset button	Reboots and initializes the system.
ID button	Toggles the front panel ID LED and the baseboard ID LED on and off. The baseboard LED is visible from the rear of the chassis and allows you to locate the server from the rear of a rack of systems.
NMI button	Puts the server in a halt-state for diagnostic purposes.

LED Indicator Status


Item	Description
NIC 1 activity LED	Continuous green light indicates a link between the system and the network to which it is connected.
NIC 2 activity LED	Blinking green light indicates network activity.
Power/ Sleep LED	Continuous green light indicates the system has power applied to it. Blinking green indicates the system is in S1 sleep state (see Note) No light indicates the power is off / is in ACPI S4 or S5 state.
Hard disk drive status LED	Random blinking green light indicates hard disk drive activity (SCSI or SATA). No light indicates no hard disk drive activity.
System Status LED	Solid green indicates normal operation Blinking green indicates degraded performance Solid amber indicates a critical or non-recoverable condition Blinking amber indicates a non-critical condition No light indicates POST is running or the system is off (see Note 1)





Item	Description
System Identification on LED	Solid blue indicates system identification is active No light indicates system identification is not activated



Note :If the system is powered down without going through the BIOS, the LED state that was in effect at the time of the power-down is restored when the system is powered back on or until the BIOS clears the LED. If the system is not powered down normally, the Power LED may blink and the System Status LED may be off due to a failure or configuration change that prevents the BIOS from running


Rear view



Item	Icon	Description
A		Low Profile PCI Add-in Card Slots
B		Full Height PCI Add-in Card slots
C		Power Supply Modules (1+1 Configuration Shown)
D		PS2 keyboard and Mouse Ports
E		RJ45 Serial B port
F		LAN #1 Connector
G		LAN #2 Connector
H		Optional DB9 Serial A port Cut out
I		Videon Connector
J		USB #1 Connector
K		USB #2 Connector
L		Diagnostic POST code LEDs
M		Management NIC connector (Optional)
N		External SCSI Channel B connector


Item	Icon	Description
O		Cooling fan for Redundant Power Fan Module

Optional Peripherals



Item	Description
A	Slim-line Device cage, support for floppy drive / DVD / CD-ROM drive
B	Optional 6 th hard drive or Tape Drive Bay
C	System Control Panel
D	1 st Hard Drive Bay or Optional Floppy drive bay
E	Hard Drive Bays (5)

Internal components



Item	Description
A	Power Supply Modules
B	Power Distribution Board
C	Riser Card Assembly
D	CPU Air Duct
E	Fan Module
F	Air Baffle
G	Slim Line Drive Bay

Item	Description
H	Front Bezel
I	Chassis Handles
J	Control Panel
K	Hard Drive Bays

3 Getting Started

This chapter gives information on setting up and starting to use your system

Setting up the system

Preinstallation requirements

Selecting a site

Before unpacking and installing the system, select a suitable site for the system for maximum efficiency. Consider the following factors when choosing a site for the system:

- Near a grounded power outlet
- Clean and dust-free
- Stable surface free from vibration
- Well-ventilated and away from sources of heat
- Secluded from electromagnetic fields produced by electrical devices such as air conditioners, radio and TV transmitters, etc.

Checking the package contents

Check the following items from the package:

- Acer Altos R710 system
- Acer Altos R710 User's guide
- Acer EasyBUILD™
- Acer Altos R710 Accessory box
- System keys

If any of the above items are damaged or missing, contact your dealer immediately.

Save the boxes and packing materials for future use.

System startup

Turning on the system

After making sure that you have properly set up the system and connected all the required cables, you can now power on the system.

To power on the system, press the power button on the front panel. Refer to "Front view (w/o bezel)" on page 16, for help locating the power button.

The system starts up and displays a welcome message. After that, a series of power-on self-test (POST) messages appears. The POST messages indicate if the system is running well or not.



.....
Note: If the system does not turn on or boot after pressing the power button, go to "Power-on problems" on page 29 for possible causes of boot failure.

Aside from the POST messages, you can determine if the system is in good condition by checking if the following occur during startup:

- Power indicator on the front panel lights up (green)
- Num Lock, Caps Lock, and Scroll Lock indicators on the keyboard light up

Turning off the system

To turn off the server, on the Windows task bar click on the **Start** button, point to **Shut Down...**, select **Shut down** from the drop-down window then click on **OK**. You can then turn off all peripherals connected to your server.

If you are unable to shutdown the server within Windows, press and hold the power button for at least four seconds to force quit all applications and shut down.

Power-on problems

If the system does not boot after you have applied power, check the following factors that might have caused the boot failure.

- The external power cable may be loosely connected.

Check the power cable connection from the power source to the power cable socket on the rear panel. Make sure that the cable is properly connected to the power source and to the power cable socket.

- No power comes from the grounded power outlet.

Have an electrician check your power outlet.

- Loose or improperly connected internal power cables.

Check the internal cable connections. If you are not confident to perform this step, ask a qualified technician to assist you.



.....
Warning! Make sure all power cords are disconnected from the electrical outlet before performing this task.



.....
Note: If you have gone through the preceding actions and the system still fails to boot, ask your dealer or a qualified technician for assistance.

4 Configuring the system

This chapter discusses the precautionary measures and installation procedures you need to know when upgrading the system.

Upgrading the system

Certain components of the server are upgradeable such as the drives, the CPU, the memory, and the expansion cards. However, for safety purposes, we do not recommend that you perform these upgrades yourself. If you want to replace or upgrade any of these components, contact your dealer or a qualified service technician for assistance.



.....

Important: Observe the installation precautions described in the subsequent section when installing or removing a server component.

Installation precautions

Before you install any server component, we recommend that you read the following sections. These sections contain important ESD precautions along with preinstallation and post-installation instructions.

ESD precautions

Electrostatic discharge (ESD) can damage the processor(s), motherboard, disk drive(s), expansion board(s), or other components. Always observe the following precautions before you install server components:

- 1 Do not remove a component from its protective packaging until you are ready to install it.
- 2 Wear a wrist grounding strap and attach it to a metal part of the server before handling components. If a wrist strap is not available, maintain contact with the server throughout any procedure requiring ESD protection.

Preinstallation instructions

Always observe the following before you install any component:

- 1 Turn off the system and all the peripherals connected to it.
- 2 Unplug all cables from the power outlets.
- 3 Open the system according to the instructions on page 36.
- 4 Follow the ESD precautions described in this section when handling a server component.
- 5 Remove any expansion board(s) or peripheral(s) that block access to the DIMM socket or other component connector.

See the following sections for specific installation instructions on the component you want to install.



.....
Warning! Failure to properly turn off the server before you start installing components may cause serious damage. Do not attempt

the procedures described in the following sections unless you are a qualified service technician.

Post-installation instructions

Observe the following after installing a server component:

- 1 See to it that all components are installed according to the described step-by-step instructions.
- 2 Reinstall any expansion board(s) or peripheral(s) that you have previously removed.
- 3 Reinstall the chassis panels.
- 4 Connect the necessary cables.
- 5 Turn on the system.

Opening the server



.....

Caution! Before you proceed, make sure that you have turned off your system and all peripherals connected to it. Read the “Preinstallation instructions” on page 34.

You need to open the server before you can install additional components. The top panel is removable to allow access to the system’s internal components. Refer to the following sections for instructions.

Before opening the server

Before opening the server, observe the following precautions:

- 1 Turn off the system and all the peripherals connected to it.
- 2 Unplug all cables from the power outlets.
- 3 Place the system unit on a flat, stable surface.




.....

Note: Because of the R710 design specification, the top panel needs to be removed to access the system board.

Removing the Chassis Cover


The Altos R710 Server must be operated with the top cover in place to ensure proper cooling. You will need to remove the top cover to add or replace components inside of the platform. Before removing the top cover, power down the server system and unplug all peripheral devices and the AC power cable. None of the components inside of the platform is hot-swappable.

- 1 Observe the safety and ESD precautions at the beginning of this book.
- 2 Turn off all peripheral devices connected to the server. Turn off the server.
- 3 Disconnect the AC power cord.
- 4 Remove the shipping screw if it is installed.
- 5 While holding the blue button at the top of the chassis in, slide the top cover back until it stops.
- 6 Lift the cover straight up to remove it from the platform.



Installing the Chassis Cover

- 1 Place the cover over the chassis so that the side edges of the cover sit just inside the chassis sidewalls.
- 2 Slide the cover forward until it clicks into place.
- 3 (Optional) Insert the shipping screw at the center of the top cover.
- 4 Reconnect all peripheral devices and the AC power cord.



Observe the post-installation instructions described on page 35.


Removing and Installing the Processor Air Duct

Always operate your server chassis with the processor air duct in place. The air duct is required for proper airflow within the chassis.

For instructions on adding or replacing a processor, first remove the processor air duct and the processor air dam, and then see your server board User Guide for instructions on processor installations and removals. Return to these instructions to reinstall the processor air dam and processor air duct after installing your processor and heat sink.

Removing the Processor Air Duct


- 1 Remove the chassis cover. For instructions, see "Removing the Chassis Cover."
- 2 Lift the processor air duct from its location over the two processor sockets.



Installing the Processor Air Duct

- 1 If you are installing the processor air duct for the first time after installing a second processor, break out the airflow tab over on the side of the processor air duct that will fit over the CPU2 processor socket.
- 2 Place the processor air duct over the two processor sockets, regardless of whether one or two processors is installed. The front edge of the air duct should contact the front fan module and the top of the installed air duct should be flush with the top surface of

the power supply. Use caution not to pinch or disengage cables that may be near or under the air duct.



Removing the Processor Air Dam (if required)



If you are using a server board that includes sockets for two processors and you install only a single processor or remove the second processor, you must install the processor air dam in the location for processor 2. If you install two processors, do not install the processor air dam.

For instructions on adding or replacing a processor, first remove the processor air duct and the processor air dam, and then see your server board User Guide for instructions on processor installations and removals. Return to these instructions to reinstall the processor air dam and processor air duct.

Removing the Processor Air Dam

The air dam is installed only on a server board that supports two processors but only one processor is to be installed. Remove the air dam only if you will be installing a second processor.

- 1 To remove the air dam, disengage the tabs on the air dam to pull it from under the sides of the retention mechanism as shown.
- 2 Save the air dam to replace it over the CPU2 socket in case the second processor is removed.



Installing and removing a hard disc drive


Up to five hot-swaps SCSI drives can be installed into your chassis. The number of drives and the drive type allowed depend on the Altos R710 Server system and the add-in components that you are installing.

Removing a hard disc

- 1 Press in on the green latch at the front of the hard drive carrier.
- 2 Pull out on the black lever to slide the carrier from the chassis.
- 3 Remove the four screws that attach the hard drive to the drive carrier. Lift the drive from the carrier. Store the drive in an anti-static bag.
- 4 (optional) Place the plastic retention device into the drive carrier, using the four screws you removed from the hard drive.
- 5 Insert the screws that held the drive in the carrier into the screw locations on the carrier for future use.
- 6 With the black lever in the fully open position, slide the drive carrier back into the chassis. The green latch must be to the right. Do not push on the black lever until the lever begins to close by itself.
- 7 When the black lever begins to close by itself, push on it to lock the drive carrier into place.


Installing a hard disc

- 1 Press in on the green latch on the front of the hard drive carrier.
- 2 Pull out on the black lever to slide the carrier from the chassis.



- 3 Remove the four screws that attach the plastic retention device or the previously installed hard drive to the drive carrier. Two screws are at each side of the retention device or the hard drive. Store the plastic retention device for future use.
- 4 Remove the hard drive from its wrapper and place it on an antistatic surface.
- 5 Set any jumpers and/or switches on the drive according to the drive manufacturer's instructions.
- 6 With the drive circuit-side down, position the connector end of the drive so that it is facing the rear of the drive carrier.
- 7 Align the holes in the drive to the holes in the drive carrier and attach it to the carrier with the screws that were attached to the plastic retention device. With the black lever in the fully open position, slide the drive assembly into the chassis. Insert the primary drive in the right bay. The green latch at the front of the drive carrier must be to the right. Do not push on the black drive carrier lever until the lever begins to close by itself. on device.

- 8 When the black drive carrier lever begins to close by itself, push on it to lock the drive assembly into place.




Installing or Removing a Floppy, CD-ROM, or DVD-ROM Drive



Floppy, CD-ROM, and DVD-ROM drives are NOT hot swappable. Before removing or replacing the drive, you must first take the server out of service, turn off all peripheral devices connected to the system, turn off the system by pressing the power button, and unplug the AC power cord from the system or wall outlet or disconnect the DC mains.


Install a Slimline Floppy Drive into Altos R710

- 1 Power down the server system and unplug all peripheral devices and the AC power cable.
- 2 Remove the chassis cover.
- 3 Remove the front bezel.
- 4 Align the two holes at the left side of the floppy drive with the two cutouts in the floppy drive carrier. See letter "A" in the figure below.
- 5 Lower the right side of the floppy drive into the carrier until it clicks into place.




- 6 Open the connector on the rear of the floppy drive by pulling up on the connector cover. See letter "A" in the figure below.

- 7 Insert one end of the 26-pin floppy drive data cable end into the connector.
- 8 Push down on the connector cover to lock the cable into place.



TP01144

- 9 Slide the floppy drive assembly into the chassis until it clicks into place. See letter "A" in the figure below.
- 10 Open the connector on the backplane by pulling out on the connector cover. See letter "B" in the figure below.



- 11 Insert the loose end of the floppy cable into the backplane connector. See letter "C" in the figure.

- 12 Push in on the connector cover to lock the cable into place. See letter "D" in the figure.
- 13 Install the chassis cover.
- 14 Install the front bezel.


Removing a Floppy Drive from the Slim Line Drive bay with Altos R710

- 1 Power down the server system and unplug all peripheral devices and the AC power cable.
- 2 Remove the chassis cover.
- 3 Remove the front bezel.
- 4 Open the connector on the rear of the floppy drive by pulling up on the connector.
- 5 Remove the data cable from the rear of the floppy.
- 6 Push in on the blue lever at the rear of the drive carrier Remove the drive carrier at the left side of the chassis to release the drive carrier.
- 7 Slide the drive carrier out through the front of the chassis.
- 8 Press downward on the side of the drive tray and release the drive.
- 9 Remove the small screw that attaches the interposer board to the drive.
- 10 Store the screw and floppy carrier for future use. Suggestion: tape the screw and backplate to the top surface of the drive bracket.
- 11 Install the slim line filler panel into slim-line bay.
- 12 If installing a new floppy drive start from step "Install a Slimline Floppy Drive into Altos R710"
- 13 Install the chassis cover.
- 14 Install the front bezel.

Installing a Floppy Drive into the Converted Hard Drive Bay on Altos R710 Server System

The floppy drive conversion kit can only be installed into a system that is using the SCSI backplane. You will know if you have one of these backplanes installed if you can install hot-swap SCSI drives. The floppy drive conversion kit must be installed in the left, top hard drive bay, directly under the slimline drive bay.


1. Power down the server and unplug all peripheral devices and the AC power cable.
2. Remove the chassis cover.
3. Remove the front bezel if it is installed.
4. Remove the upper left hot-swap hard drive carrier from the chassis.
5. Remove the screws that attach the slide rails to the floppy drive conversion kit carrier.



TP01307

Figure 1. Removing the Rails from the Floppy Drive Conversion Kit Carrier

6. Slide the floppy drive into the drive carrier, rear of the drive first, with the underside of the drive facing down.
7. Line up the holes in the side of the drive with the holes in the carrier. See letter "A" in the figure below.



TP01308

Figure 2. Inserting a Floppy Drive into the Floppy Drive Conversion Kit Carrier

8. Attach the floppy drive to the carrier with the screws that came with your floppy drive conversion kit. One screw attaches at each side. See the figure below.





Figure 3. Attaching a Floppy Drive to the Floppy Drive Conversion Kit Carrier

9.Reattach the slide rails onto floppy drive conversion kit carrier. See the figure below.




TP01309

Figure 4. Installing the Rails onto the Floppy Drive Conversion Kit Carrier

10.Open the connector on the rear of the floppy drive by pulling up on the connector cover. See letter "A" in the figure below.

11.Insert one end of the flat flex cable end into the floppy drive connector. See letter "B" in the figure.

12.Push down on the connector cover to lock the cable into place. See letter "C" in the figure.



TP013


Figure 5. Connecting the Flat Flex Cable to a Floppy Drive

13. Slide the carrier assembly into the upper left hard drive bay until it clicks into place. See letter "A" in the figure below.

14. Open the connector labeled "Floppy Con" on the backplane by pulling up on the connector cover. See letter "B" in the figure below. For assistance in locating connectors on the SATA backplane." For assistance in locating connectors on the SCSI backplane.

15. Insert the loose end of the flat flex cable into the backplane connector. See letter "C" in the figure.

16. Push in on the connector cover to lock the cable into place. See letter "D" in the figure.



TP01310

Figure 6. Installing the Floppy Drive into the Chassis

17. Install the chassis cover.

18. (Optional) Install the front bezel.

19. Plug all peripheral devices and the AC power cable back into the server.


Removing a Floppy Drive from the Converted Hard Drive Bay

1. Power down the server and unplug all peripheral devices and the AC power cable.
2. Remove the chassis cover.
3. Remove the front bezel if it is installed.
4. Open the connector labeled "Floppy Con" on the backplane by pulling up on the connector cover. Remove the flat flex cable from the backplane.
5. Push in on the lever at the rear of the floppy carrier and slide the drive from the front of the chassis.
6. Open the connector cover on the rear of the floppy drive by pulling up on it. Release the flat flex cable from the drive.
7. Remove the two screws at each side that hold the drive rails to the drive carrier. Lift the two rails from the carrier.
8. Disconnect the two screws attaching the drive to the converted hard drive bay carrier.
9. Install an empty hot-swap hard drive carrier into chassis drive bay if no floppy or hard drive is to be installed into the bay.
10. Store the screws, the converted drive bay carrier, the side rails, and the flat flex cable for future use.
11. Install the chassis cover.
12. (Optional) Install the front bezel.
13. Plug all peripheral devices and the AC power cable back into the server.

Installing the SCSI 6th HD upgrade kit in Altos R710

The SCSI sixth HD upgrade kit is used when a sixth SCSI hot-swap drive is needed.

1. Power down the server and unplug all peripheral devices and the AC power cable.
2. Remove the chassis cover.
3. Remove the front bezel if it is installed.
4. Remove the drive blank from the sixth drive bay by using a long screwdriver to push it out through the front of the chassis.




TP01366

Figure 1. Remove the Drive Blank from the Chassis

5. Remove the fan module.

6. Hold the SCSI sixth drive board about 2-inch above the opening in the backplane to allow alignment notches to clear the top of the backplane bracket. Move the board forward into the opening and set it into place while lining up the two tabs on the sixth drive kit board

with the matching holes on backplane. Be sure the board seats into the plastic retainer at the bottom of the backplane opening.



TP01084

Figure 2. Installing the Sixth Drive Board

7. Connect the end of the long SCSI cable that is labeled "Backplane" to the connector on the sixth drive board that is labeled "M/B." Connect the remaining end of the SCSI connector to the server board or add in card. See server board or add in card documentation for the connection location.

8. Connect the end of short SCSI cable that is labeled "Backplane" to the backplane connector labeled "SCSI CH A." Connect the other end to the sixth drive board connector.

9. Included with your sixth HDD upgrade kit is a power cable connector labeled "Drive 5 Pwr." Connect one end of this cable into the connector labeled "OPT" on sixth drive board. Connect the remaining

end of the Drive 5 power cable to the connector on the backplane that is labeled "OPT CONN."

10. Install the fan module.
11. Install the chassis cover.
12. Install the SCSI hard disk drive into the sixth drive position.
13. Install the front bezel.

Installing a Tape Drive in Altos R710

To install a tape drive into your Altos R710 System, your system must meet the following requirements:


You must purchase the optional tape drive kit.

You must purchase a 3.5-inch SCSI tape drive.

After purchasing the tape drive kit and the tape drive, use the instructions below to install them. In addition to these instructions, refer to the instructions that came with your tape drive for additional requirements.

1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover.
4. Remove the front bezel.

5. Push the tape drive filler panel from the chassis by using a long screwdriver to push it out from the inside of the chassis. See the figure below to locate the tape drive filler panel.




TP01355

Figure 1. Removing the Tape Drive Bay Filler Panel

6. The sixth drive bay is directly below the tape drive bay in the chassis. Lift the lever at the rear of the hard drive blank that is installed in the sixth drive bay to remove the blank from the chassis.


7. Attach the tape drive to the tape drive carrier kit using the four screws that were included with the tape drive kit. See the figure below.



TP01356

Figure 2. Inserting a Tape Drive into the Carrier


8. Slide the tape drive carrier with the installed tape drive into the combined tape drive bay / sixth drive bay until the carrier clicks into place.



TP01357

Figure 3. Inserting the Tape Drive Carrier into the Chassis

9. Attach the end of the SCSI cable that is labeled "Tape Drive" to the SCSI connection on the tape drive.
10. Route the SCSI cable along the front of the fan module and then through the front and rear openings on the underside of the air baffle. You may need to remove the air baffle to route the cable.
11. Route the end of the SCSI cable that is labeled "Server Board" to the server board or add-in card connector. Push the cable through the opening in the backplane, as shown in the figure below. See your server board or add-in card documentation to locate the connection point on the server board or add-in card.
12. Connect the 7-pin tape drive power cable to the backplane connector that is labeled "OPT CONN".
13. Connect the 4-pin tape drive power cable to the tape drive.
14. Install the chassis cover.
15. (Optional): Install the front bezel.



TP01358


Figure 4. Connecting the Tape Drive Cables

Install a Slimline Optical drive into Altos R710




NOTE: The carrier for the slimline Optical drive was pre-installed in the slimline drive bay of your Altos R710 Server. You will need to remove it from the chassis before beginning.

- 1 Power down the server system and unplug all peripheral devices and the AC power cable.
- 2 Remove the chassis cover.
- 3 Remove the front bezel.
- 4 Align the two holes at left edge of DVD-ROM /CD-ROM drive with the cutouts in drive carrier. See letter "A" in the figure below.
- 5 Lower the right side of the DVD-ROM / CD-ROM drive into the carrier until it clicks into place. See letter "B" in the figure below.
- 6 Use the two screws indicated in the figure to attach the interposer board to the DVD-ROM / CD-ROM drive. See letters "C" and "D" in the figure.
- 7 Attach the 44-pin CD-ROM drive cable to the exposed side / back of the interposer board. See letter "E" in the figure.



- 8 Insert the DVD-ROM / CD-ROM drive into the chassis. See letter "A" in the figure below.

- 9 Connect the loose end of the CD-ROM drive cable to the backplane connector. See letter "B" in the figure.
- 10 Power down the server system and unplug all peripheral devices and the AC power cable.
- 11 Install the chassis cover.
- 12 Install the front bezel.



TP01086

Removing a Slim line Optical Drive from Altos R710

- 1 Power down the server system and unplug all peripheral devices and the AC power cable.
- 2 Remove the chassis cover.
- 3 Remove the front bezel.
- 4 Open the connector on the rear of the CD-ROM by pulling up on the connector.
- 5 Disconnect the data cable from the rear of the CD-ROM, or DVD-ROM drive.
- 6 Push in on the blue lever at the rear of the drive carrier Remove the drive carrier at the left side of the chassis to release the drive carrier.
- 7 Slide the drive carrier out through the front of the chassis.
- 8 Disconnect the interposer board by removing the two screws for a CD-ROM or DVD ROM.
- 9 Press downward on the side of the tray and release the drive from the tray. Lift the Optical Drive out of the CD-ROM Carrier.
- 10 Store the tray for future use.
- 11 Install Slimline filler panel.If installing a new Optical Drive start from step "Install a Slimline Optical Drive into Altos R710".
- 12 Install Slimline filler panel.
- 13 Install the chassis cover.
- 14 Install the front bezel.

Removing and Installing the PCI Riser Assembly

You will need to remove the PCI riser assembly from the chassis to replace the PCI riser boards, or to add or remove a PCI add-in card.




Removing the PCI Riser Assembly

Use the following instructions to remove the PCI riser assembly from the chassis.

- 1 Remove the chassis cover
- 2 Remove Processor Air Duct.
- 3 Disconnect any cables attached to add in cards.
- 4 Lift up on the two blue levers to lift the PCI Riser assembly from the chassis.

- 5 Push back on the blue release lever at the end of one of the riser boards. While holding the lever back, push firmly on the other edge of the board to disengage the board from the riser.



Installing the PCI Riser Assembly

Use the following instructions to install the PCI riser assembly from the chassis.

- 1 Install any cables into add in cards.
- 2 Set the riser assembly straight down, matching the hooks in the back of the riser assembly to the notches in the rear of the chassis.
- 3 Press firmly to push the riser into the slots on the server board.
- 4 Install Processor Air Duct.
- 5 Install the chassis cover.

Replacing the PCI Riser Board

Altos R710 have three kinds of PCI riser option ca be choosed. The default installed riser card for the three PCI-X 66/100MHz slots be mounted on riser card with your can choice of one of two PCI riser cards for upgrade options:

- PCI-Express Riser card option: Two 4 lanes PCI-Express slot (x8 lanes connector mounted) and one PCI-X 66/100MHz slots.
- PCI-X 133 Riser card options: Two 133MHz PCI-X slots and one 66/100MHz PCI-X slot.

The PCI riser board can be replaced if it fails or if a different option is required. To replace the PCI riser board, use the following instructions.



NOTE: To eliminate the possibility of installing the replacement boards on the wrong side of the PCI riser assembly, replace one board at a time.


- 1 Remove the chassis cover.
- 2 Remove Processor Air Duct.
- 3 Lift up on the two blue levers to lift the PCI Riser assembly from the chassis.
- 4 Push back on the blue release lever at the end of one of the riser boards. While holding the lever back, push firmly on the other edge of the board to disengage the board from the riser.
- 5 Line up the screws on the riser assembly with the slot and the large hole on the replacement riser board.
- 6 Push on the riser slot while pulling the card away from the blue release lever. The blue release lever will click into place.a

Installing board onto PCI Riser assembly. This refers to the two small boards on the riser assembly itself. These are the boards into which an add-in card is inserted

Install Riser Card(s)

Depending upon your system configuration, you must install the PCI riser card(s) that matches your add-in card(s).

- 1 Press and hold the blue PCI riser locking lever.
- 2 Place riser onto pins, then slide riser card to the left to lock. Then release blue lever.



- 7 Repeat steps 3 – 5 on the other riser card.
- 8 Install the PCI add-in card(s), if desired.
- 9 Install the riser assembly into the chassis.
- 10 Install Processor Air Duct.
- 11 Install the chassis cover.

Installing a PCI Add-in Card

In the slots provided by the PCI riser card, you can install either three or six PCI add-in cards.

Peripherals and add-in cards are not included in your system and must be purchased separately. The riser card at the center of the chassis supports three full-height add-in card or three low profile PCI add-in card. If a low profile card is installed in the standard full-height riser card, it must be equipped with a standard full-height PCI mounting bracket.




NOTES: Add-in cards must be attached to a riser card when the riser card is removed from the chassis.

- 1 Remove the chassis cover.
- 2 Remove Processor Air Duct.
- 3 Remove the PCI Riser assembly.
- 4 Insert the PCI card edge connector into the PCI slot on the riser assembly.
- 5 Install the riser assembly.
- 6 Install the chassis cover.

Install Add-in Card(s)

- 1 Open rear retention clip.
- 2 Remove filler panel.
- 3 Insert add-in card until it seats in riser connector.
- 4 Make sure add-in card bracket inserts into slot. Close retention clip.

CAUTION: Observe normal ESD precautions when installing add-in cards.



NOTE: The Altos R710 has support for Zero Channel RAID (ZCR) which follows the RUBI2 standard. It will not have support for zero channel RAID cards that follow the RADIOS standard. See the Altos R710 AVL for a list of supported ZCR cards. On the Altos R710 Server, a ZCR card is only supported on the full-height riser slot. When installing the card, it **MUST** be populated in the PCI-X add-in slot furthest from the baseboard. No other add-in card slot has support for a ZCR card.



NOTE: To ensure proper signal integrity on a given PCI bus, add-in cards must be installed in order starting with the top PCI slot

Replacing a System Fan

The system fans at the front of the Server Chassis can be individually replaced if one of them fails. The fans that are integrated into the power supply cannot be replaced separately. If one of these fans fails, the power supply must be replaced.

To replace a system fan, use the following instructions.

- 1 Remove the chassis cover.
- 2 There are no screws to loosen. Grab hold of the fan by the lever and lift fan from the module..
- 3 Install new fan by pushing down until the fan is completely installed into the fan module.
- 4 Installing the Chassis Cover.

Connecting peripherals


The system unit, keyboard, mouse, and monitor constitute the basic system. Before connecting any other peripherals, connect these basic peripherals first to test if the system is running properly.



Note: Unless otherwise indicated, all illustrations showed in this section show the Altos R710 server chassis.

Finishing Up

Before installing your operating system, you must finish your chassis installation and connect back panel I/O connectors and AC power.



Hard Disk Drives

The Altos R710 Server system ships with drive brackets for installing five SCSI Hard Disk Drives for hot-swap configuration available. The left drive bay can be converted to be used as a floppy bay. To use the bay for a floppy drive, the Hard Disk Drive must be change to Floppy converter.

Floppy / CD-ROM / DVD-ROM Slimline Cages

The slimline drive cages can be used with one of the optional floppy / CD-ROM / DVD-ROM drives. One slimline cage is included with your server chassis for installing either a slimline CD-ROM or DVD-ROM drive and one is included for installing a slimline floppy drive. The drives must be purchased separately.


The floppy drive / CD-ROM / DVD-ROM cage can be inserted or removed only when system power is turned off. Drives in the slimline cage are NOT hot swappable.

Rack-Mounted Systems

The Altos R710 Server SERIES can be mounted into a rack. Acer provides a tool-less rail kit and a cable management arm to mount this server chassis into a rack. When installing chassis into a rack, Acer recommends you install systems from the bottom of the rack to the top. In other words, install the first system in the rack into the bottom position of the rack, the second system in the second position from the bottom, and so on. Instructions for installing your chassis into a rack are included in the rail kit. The order numbers are as follows:

- Tool-less Rail Kit: (Acer P/N: TC.R0703.006)
- Cable Management Arm (Acer P/N: TC.R0703.007 , requires the tool-less rail kit installed)

Configuration Jumpers



Jumper Name	Pins	What happens at system reset??
Password Clear (line "A" in figure above)	1-2	These pins should be jumpered for normal system operation.
	2-3	If these pins are jumpered, administrator and user passwords will be cleared on the next reset. These pins should not be jumpered for normal operation.
Recovery Boot (line "B" in figure above)	1-2	These pins should be jumpered for normal system operation.
	2-3	If these pins are jumpered, the system will attempt to recover the BIOS by loading the BIOS code into the flash device from a floppy disk. This jumper is typically used when the BIOS has become corrupted. These pins should not be jumpered for normal operation.

Jumper Name	Pins	What happens at system reset??
CMOS Clear (line "C" in figure above)	1-2	These pins should be jumpered for normal system operation.
	2-3	If these pins are jumpered, the CMOS settings will be cleared on the next reset. These pins should not be jumpered for normal operation.

Hardware Requirements

To avoid integration difficulties and possible board damage, your system must meet the requirements outlined below. For a list of qualified components.

Processor

One or two Intel® Xeon™ processors with an 800MHz front side bus and a minimum of 2.8 GHz frequency must be installed. The following table outlines the supported processors. For a complete list of supported processors.

Processor Family	FSB Frequency	Frequency
Intel® Xeon™	800 MHz	2.8 GHz
Intel® Xeon™	800 MHz	3.0 GHz
Intel® Xeon™	800 MHz	3.2 GHz
Intel® Xeon™	800 MHz	3.4 GHz
Intel® Xeon™	800 MHz	3.6 GHz

DIMM 1B	DIMM 1A	DIMM 2B	DIMM 2A	DIMM 3B	DIMM 3A	Memory Interleave
1GB	1GB	1GB	1GB	1GB	1GB	2-way
2GB	2GB	2GB	2GB	2GB	2GB	2-way

The minimum memory configuration is one DIMM, installed in DIMM 1B slot. However, for optimum performance and 2-way memory interleave operation, two DIMMs with identical size should be installed. DIMMs on memory channel A are paired with DIMMs on memory channel B to configure 2-way memory interleave.

Both DIMM 1B and 1A must be populated before any DIMMs are installed. DIMM 2B and DIMM 2A must be populated in pairs.

All DIMMs installed must be identical (same manufacturer, CAS latency, number of rows, columns and devices, timing parameters, etc.).



.....

Warning! Functionality issues may be encountered if mixed memory types are installed on the same mainboard. DIMM modules of identical type, banking and stacking technology, and manufacturer should be installed in the Altos R710 system.

Memory configurations for the DDR2 DIMMs

The memory modules of identical type, banking, stacking and manufacturer must be installed and removed in the following order:

- DIMM 1B and DIMM 1A
- DIMM 2B and DIMM 2A
- DIMM 3B and DIMM 3A

Altos R710 includes Memory Sparing and Mirroring support. These features prevent a single memory module failure to occur and result in a system crash.



.....

Important: Four DIMM population of completely identical devices (two per channel) are required for memory mirroring and sparing functionality (i.e., DIMM 1A, 1B, 2A, and 2B must be identical) .

Memory sparing and mirroring configuration cannot be used simultaneously.

Memory Sparing

To provide a more fault tolerant system, Altos R710 includes specialized hardware to support fail-over to a spare DIMM device in the event that a primary DIMM in use exceeds a specified threshold of runtime errors. One of the DIMMs installed per channel will not be used, but kept in reserve. In the event of significant failures in a particular DIMM, it and its corresponding partner in the other channel (if applicable), will, over time, have its data copied over to the spareDIMM(s) held in reserve. When all the data has been copied, the reserve DIMM(s) will be put into service and the failing DIMM will be removed from service. Only one sparing cycle is supported. If this feature is not enabled, then all DIMMs will be visible in normal address space.

Refer to "Memory Configuration Sub-menu Selections" on page 103 for more information about configuring the memory spare or mirror parameter in the BIOS Setup utility.

Below table lists the suggested memory population for memory sparing:

DIMM 1B	DIMM 1A	DIMM 2B	DIMM 2A	DIMM 3B	DIMM 3A	Total Memory	
						Physical Memory	Detected by OS
512 MB	512 MB	512 MB (Spare)	512 MB (Spare)			2 GB	1 GB
1 GB	1 GB	1 GB (Spare)	1 GB (Spare)			4 GB	2 GB
2 GB	2 GB	2 GB (Spare)	2 GB (Spare)			8 GB	4 GB
512 MB	512 MB	512 MB	512 MB	512 MB (Spare)	512 MB (Spare)	3 GB	2 GB
1 GB	1 GB	1 GB	1 GB	1 GB (Spare)	1 GB (Spare)	6 GB	4 GB
2 GB	2 GB	2 GB	2 GB	2 GB (Spare)	2 GB (Spare)	12 GB	8 GB

Memory Mirroring

The Memory Mirroring feature designates a channel, two DDR2 DIMM slots, as spare memory and all system memory are sent to both mirrors by the Intel E7520 MCH chipset. When an uncorrectable error occurs

from the Primary mirror, the chipset will automatically replace the data in the defective slot with data from the Secondary mirror.

Below table list the suggested memory population for memory mirroring:

DIMM 1B	DIMM 1A	DIMM 2B	DIMM 2A	DIMM 3B	DIMM 3A	Total Memory	
						Physical Memory	Detected by OS
512 MB	512 MB	512 MB (Mirror)	512 MB (Mirror)			2 GB	1 GB
1 GB	1 GB	1 GB (Mirror)	1 GB (Mirror)			4 GB	2 GB
2 GB	2 GB	2 GB (Mirror)	2 GB (Mirror)			8 GB	4 GB

Power Supply

The Acer Altos R710 server used 700 watt 1 + 0 / 1+1 hot-swappable redundant power supply. Default one power module installed.

Optional Hardware

Hard Disk Drives

The Altos R710 Server supports Ultra 320 SCSI, 10K or 15Krpm hard disk drive options.

Intelligent Management Module

The Intelligent Management Module are available to provide enhanced server management features.

- The Intelligent Management Module: contains a hardware mezzanine card that plugs into the server board.

For installation instructions on installing the Intelligent Management Module, see the instructions provided with the management module.

Upgrading the CPU


This section includes instructions for removing and installing a CPU.




Important! Always observe the ESD precautions when installing or removing a system component. Refer to page 34.

Installing a CPU

- 1 Insert the CPU into the mainboard socket, making sure the indicator on the processor is aligned with the indicator on the socket **(A)**. Lower the CPU locking lever to secure the processor **(B)**.




- 2 Replace the heatsink over the CPU socket and tighten the four corner screws .



- 3 Replace the system cover, making sure to observe the post-installation instructions described on page 35.

Removing a CPU

- 1 Remove the AC power cord from the server.
- 2 Remove the system cover. See “Removing the Chassis Cover” on page 37.
- 3 Unplug the processor fan cable from the server board.
- 4 Loosen the four captive screws on the corners of the heat sink.
- 5 Twist the heat sink slightly to break the seal between the heat sink and the processor. Lift the heat sink from the processor.
- 6 Locate and lift the CPU socket locking lever to release the processor. Gently pull up on the processor to remove it.



Upgrading the system memory

To remove a DIMM

Before installing a new DIMM in a socket, remove first any previously installed DIMM from that socket.



Important: Before removing any DIMM from the mainboard, make sure to create a backup file of all important data.


- 1 Observe the ESD precautions and pre-installation procedures described on page 34.
- 2 Locate the DIMM sockets on the mainboard.
- 3 Press the holding clips on both sides of the socket outward to release the DIMM .
- 4 Gently pull the DIMM upward to remove it from the socket .



Note: Place your forefingers on the top of the DIMM before pressing the holding clips to gently disengage the DIMM from the socket.

To install a DIMM

- 1 Observe the ESD precautions and pre-installation procedures described on page 34.
- 2 Locate the DIMM sockets on the mainboard.
- 3 Open the clips on the socket.
- 4 Align and insert the DIMM into the socket .
- 5 Press the holding clips inward to lock the DIMM in place .



Note: The DIMM socket is slotted to ensure proper installation. If you insert a DIMM but it does not fit easily into the socket, you may have inserted it incorrectly. Reverse the orientation of the DIMM and insert it again.

- 6 Observe the post-installation instructions described on page 35.

Reconfiguring the system memory

The system automatically detects the amount of memory installed. Run the BIOS setup to view the new value for total system memory and make a note of it.

5 BIOS setup

This chapter gives information about the system BIOS and discusses how to configure the system by changing the settings of the BIOS parameters.

Before You Begin

Before working with your server product, pay close attention to the at the beginning of this manual.

Tools and Supplies Needed

- Phillips* (cross head) screwdriver (#1 bit and #2 bit)
- Needle nosed pliers
- Antistatic wrist strap and conductive foam pad (recommended)

Installing and Removing Memory

The silkscreen on the board for the DIMMs displays DIMM1B, DIMM1A, DIMM2B, DIMM2A, DIMM3B, DIMM3A starting from the edge of the board. DIMM3A is the socket closest to the processor socket. NOTE


The DIMMs being installed match the correct version of the server board. DDR DIMMs will not physically fit into a server board designed to support DDR2 DIMMs. DDR2 DIMMs will not physically fit into a server board designed to support DDR DIMMs.

RJ45 Serial Port Configuration

The RJ45 serial port connector can be configured to support either a DSR signal or a DCD signal. As the server board is shipped, it is configured to support DSR signals. To change the configuration to support DCD signals a jumper on the board must be changed. Use the following instructions to configure your server board to support DCD signals.

- 1 Observe the safety and ESD precautions at the beginning of this book.
- 2 Turn off all peripheral devices connected to the server. Turn off the server.
- 3 Disconnect the AC power cord from the server.
- 4 Remove the server's cover. See the documentation that accompanied your server chassis for instructions on removing the server's cover.
- 5 Locate the jumper block for the serial port.

- 6 Move the jumper from the default position covering pins 1 and 3 to cover pins 2 and 4.



Replacing the Backup Battery


The lithium battery on the server board powers the RTC for up to 10 years in the absence of power. When the battery starts to weaken, it loses voltage, and the server settings stored in CMOS RAM in the RTC (for example, the date and time) may be wrong. Contact your customer service representative or dealer for a list of approved devices.



.....

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Discard used batteries according to manufacturer's instructions.

- 1 Observe the safety and ESD precautions at the beginning of this book.
- 2 Turn off all peripheral devices connected to the server. Turn off the server.
- 3 Disconnect the AC power cord from the server.
- 4 Remove the server's cover and locate the battery. See the documentation that accompanied your server chassis for instructions on removing the server's cover.
- 5 Insert the tip of a small flat bladed screwdriver, or an equivalent, under the tab in the plastic retainer. Gently push down on the screwdriver to lift the battery.
- 6 Remove the battery from its socket.



- 7 Dispose of the battery according to local ordinance.
- 8 Remove the new lithium battery from its package, and, being careful to observe the correct polarity, insert it in the battery socket.

- 9 Close the chassis.
- 10 Run Setup to restore the configuration settings to the RTC.

BIOS Setup Utility

The BIOS Setup utility is provided to perform system configuration changes and to display current settings and environment information.

The BIOS Setup utility stores configuration settings in system non-volatile storage. Changes affected by BIOS Setup will not take effect until the system is rebooted. The BIOS Setup Utility can be accessed during POST by using the F2 key.

Localization

The BIOS Setup utility uses the Unicode standard and is capable of displaying setup forms in English, French, Italian, German, and Spanish. The BIOS supports these languages for console strings as well.

Console Redirection

The BIOS Setup utility is functional via console redirection over various terminal standards emulation. This may limit some functionality for compatibility, e.g., usage of colors or some keys or key sequences or support of pointing devices.

Configuration Reset

Setting the Clear CMOS jumper (board location J1H4) produces a "reset system configuration" request. When a request is detected, the BIOS loads the default system configuration values during the next POST.

Alternatively, the user can clear CMOS without opening the chassis. Using the control panel, the user can hold the reset button for 4 seconds and then press the power button while still pressing the reset button.

The Intel Management Module, when installed, provides a software method to issue a "reset system configuration" request. Software can send a specific OEM command to the Sahalee BMC to indicate the request.

Keyboard Commands

While in the BIOS Setup utility, the Keyboard Command Bar supports the keys specified in the following table.

BIOS Setup Keyboard Command Bar Options


key	option	description
Enter	Execute Command	The Enter key is used to activate sub-menus, pick lists, or to select a sub-field. If a pick list is displayed, the Enter key will select the pick list highlighted item, and pass that selection in the parent menu.
ESC	Exit	<p>The ESC key provides a mechanism for backing out of any field. This key will undo the pressing of the Enter key. When the ESC key is pressed while editing any field or selecting features of a menu, the parent menu is re-entered.</p> <p>When the ESC key is pressed in any sub-menu, the parent menu is re-entered. When the ESC key is pressed in any major menu, the exit confirmation window is displayed and the user is asked whether changes can be discarded. If "No" is selected and the Enter key is pressed, or if the ESC key is pressed, the user is returned to where they were before ESC was pressed without affecting any existing any settings. If "Yes" is selected and the Enter key is pressed, setup is exited and the BIOS continues with POST.</p>
↑	Select Item	The up arrow is used to select the previous value in a pick list, or the previous options in a menu item's option list. The selected item must then be activated by pressing the Enter key.
↓	Select Item	The down arrow is used to select the next value in a menu item's option list, or a value field's pick list. The selected item must then be activated by pressing the Enter key.
↔	Select Menu	The left and right arrow keys are used to move between the major menu pages. The keys have no affect if a sub-menu or pick list is displayed.
Tab	Select Field	The Tab key is used to move between fields. For example, Tab can be used to move from hours to minutes in the time item in the main menu.

key	option	description
-	Change Value	The minus key on the keypad is used to change the value of the current item to the previous value. This key scrolls through the values in the associated pick list without displaying the full list.
+	Change Value	The plus key on the keypad is used to change the value of the current menu item to the next value. This key scrolls through the values in the associated pick list without displaying the full list. On 106-key Japanese keyboards, the plus key has a different scan code than the plus key on the other keyboard, but will have the same effect.
F9	Setup Defaults	<p>Pressing F9 causes the following to appear:</p> <p>Load Setup Defaults? <input type="button" value="OK"/> <input type="button" value="Cancel"/></p> <p>If "OK" is selected and the Enter key is pressed, all setup fields are set to their default values. If "Cancel" is selected and the Enter key is pressed, or if the ESC key is pressed, the user is returned to where they were before F9 was pressed without affecting any existing field values.</p>
F7	Discard Changes	<p>Pressing F7 causes the following message to appear:</p> <p>Discard Changes? <input type="button" value="OK"/> <input type="button" value="Cancel"/></p> <p>If "OK" is selected and the Enter key is pressed, all changes are not saved and setup is exited. If "Cancel" is selected and the Enter key is pressed, or the ESC key is pressed, the user is returned to where they were before F7 was pressed without affecting any existing values.</p>

key	option	description
F10	Save Changes and Exit	<p>Pressing F10 causes the following message to appear:</p> <p style="text-align: center;">Save configuration changes and exit setup? [OK] [Cancel]</p> <p>If "OK" is selected and the Enter key is pressed, all changes are saved and setup is exited. If "Cancel" is selected and the Enter key is pressed, or the ESC key is pressed, the user is returned to where they were before F10 was pressed without affecting any existing values.</p>

Main

The first screen displayed when entering the BIOS Setup Utility is the Main Menu selection screen. This screen displays the major menu selections available. The following tables describe the available options on the top level and lower level menus. Default values are shown in bold text.



Feature	Options	Help Text	Description
System Overview			
AMI BIOS			
Version	N/A	N/A	BIOS ID string (excluding the build time and date)
Build Date	N/A	N/A	BIOS build date
Processor			

Feature	Options	Help Text	Description
Type	N/A	N/A	Processor brand ID string
Speed	N/A	N/A	Calculated processor speed
Count	N/A	N/A	Detected number of physical processors
System Memory			
Size	N/A	N/A	Amount of physical memory detected
System Time	HH:MM:SS	Use [ENTER], [TAB] or [SHIFT-TAB] to select a field. Use [+] or [-] to configure system Time.	Configures the system time on a 24 hour clock. Default is 00:00:00
System Date	DAY MM/DD/YYYY	Use [ENTER], [TAB] or [SHIFT-TAB] to select a field. Use [+] or [-] to configure system Date.	Configures the system date. Default is [Build Date]. Day of the week is automatically calculated.
Language	English French German Italian Spanish	Select the current default language used by the BIOS.	Select the current default language used by BIOS.

Advanced


The Advanced menu contains parameter values that define how the system behaves on startup.



.....

Be cautious in setting parameter values in the Advanced menu as any incorrect value may cause the system to malfunction.


BIOS Setup, Advanced Menu Options



Feature	Options	Help Text	Description
Advanced Settings			
<p>WARNING: Setting wrong values in below sections may cause system to malfunction.</p>			

Feature	Options	Help Text	Description
Processor Configuration	N/A	Configure processors.	Selects submenu.
IDE Configuration	N/A	Configure the IDE device(s).	Selects submenu.
Floppy Configuration	N/A	Configure the Floppy drive(s).	Selects submenu.
Super I/O Configuration	N/A	Configure the Super I/O Chipset.	Selects submenu.
USB Configuration	N/A	Configure the USB support.	Selects submenu.
PCI Configuration	N/A	Configure PCI devices.	Selects submenu.
Memory Configuration	N/A	Configure memory devices.	Selects submenu.

Processor Configuration Sub-menu Options




Feature	Options	Help Text	Description
Configure Advanced Processor Settings			
Manufacturer	Intel	N/A	Displays processor manufacturer string
Brand String	N/A	N/A	Displays processor brand ID string
Frequency	N/A	N/A	Displays the calculated processor speed
FSB Speed	N/A	N/A	Displays the processor front-side bus speed.
CPU 1			
CPUID	N/A	N/A	Displays the CPUID of the processor.

Feature	Options	Help Text	Description
Cache L1	N/A	N/A	Displays cache L1 size.
Cache L2	N/A	N/A	Displays cache L2 size.
Cache L3	N/A	N/A	Displays cache L3 size. Visible only if the processor contains an L3 cache.
CPU 2			
CPUID	N/A	N/A	Displays the CPUID of the processor.
Cache L1	N/A	N/A	Displays cache L1 size.
Cache L2	N/A	N/A	Displays cache L2 size.
Cache L3	N/A	N/A	Displays cache L3 size. Visible only if the processor contains an L3 cache.
Processor Retest	Disabled Enabled	If enabled, all processors will be activated and retested on the next boot. This option will be automatically reset to disabled on the next boot.	Rearms the processor sensors. Only displayed if the Intel Management Module is present.
Max CPUID Value Limit	Disabled Enabled	This should be enabled in order to boot legacy OSes that cannot support processors with extended CPUID functions.	

Feature	Options	Help Text	Description
Hyper-Threading Technology	Disabled Enabled	Enable Hyper-Threading Technology only if OS supports it.	Controls Hyper-Threading state. Primarily used to support older Operating Systems that do not support Hyper Threading.
Intel ® Speed Step™ Tech	Auto Disabled	Select disabled for maximum CPU speed. Select enabled to allow the OS to reduce power consumption.	Note: This option may not be present in early Beta releases.

BIOS Setup IDE Configuration Menu Options



Feature	Options	Help Text	Description
IDE Configuration			
Onboard P-ATA Channels	Disabled	Disabled: disables the integrated P-ATA Controller.	Controls state of integrated P-ATA controller.
	Primary	Primary: enables only the Primary P-ATA Controller.	
	Secondary	Secondary: enables only the Secondary P-ATA Controller.	
	Both	Both: enables both P-ATA Controllers.	

Feature	Options	Help Text	Description
Onboard S-ATA Channels	Disabled Enabled	Disabled: disables the integrated S-ATA Controller. Enabled: enables the integrated S-ATA Controller.	Controls state of integrated S-ATA controller.
Configure S-ATA as RAID	Disabled Enabled	When enabled the S-ATA channels are reserved to be used as RAID.	
S-ATA Ports Definition	A1-3 rd M/ A2-4 th M A1-4 th M/ A2-3 rd M	Defines priority between S-ATA channels.	Default set the S-ATA Port0 to 3 rd IDE Master channel & Port1 to 4 th IDE Master channel. Otherwise set S-ATA Port0 to 4 th IDE Master channel & Port1 to 3 rd IDE Master channel.
Mixed P-ATA / S-ATA	N/A	Lets you remove a P-ATA and replace it by S-ATA in a given channel. Only 1 channel can be S-ATA.	Selects submenu for configuring mixed P-ATA and S-ATA.
Primary IDE Master	N/A	While entering setup, BIOS auto detects the presence of IDE devices. This displays the status of auto detection of IDE devices.	Selects submenu with additional device details.
Primary IDE Slave	N/A	While entering setup, BIOS auto detects the presence of IDE devices. This displays the status of auto detection of IDE devices.	Selects submenu with additional device details.

Feature	Options	Help Text	Description
Secondary IDE Master	N/A	While entering setup, BIOS auto detects the presence of IDE devices. This displays the status of auto detection of IDE devices.	Selects submenu with additional device details.
Secondary IDE Slave	N/A	While entering setup, BIOS auto detects the presence of IDE devices. This displays the status of auto detection of IDE devices.	Selects submenu with additional device details.
Third IDE Master	N/A	While entering setup, BIOS auto detects the presence of IDE devices. This displays the status of auto detection of IDE devices.	Selects submenu with additional device details.
Fourth IDE Master	N/A	While entering setup, BIOS auto detects the presence of IDE devices. This displays the status of auto detection of IDE devices.	Selects submenu with additional device details.
Hard Disk Write Protect	Disabled Enabled	Disable/Enable device write protection. This will be effective only if device is accessed through BIOS.	Primarily used to prevent unauthorized writes to hard drives.
IDE Detect Time Out (Sec)	0 5 10 15 20 25 30 35	Select the time out value for detecting ATA/ATAPI device(s).	Primarily used with older IDE devices with longer spin up times.

Feature	Options	Help Text	Description
ATA(PI) 80Pin Cable Detection	Host & Device Host Device	Select the mechanism for detecting 80Pin ATA(PI) Cable.	The 80 pin cable is required for UDMA- 66 and above. BIOS detects the cable by querying the host and/or device.


Mixed P-ATA-S-ATA Configuration with only Primary P-ATA



Feature	Options	Help Text	Description
Mixed P-ATA / S-ATA			

Feature	Options	Help Text	Description
First ATA Channel	P-ATA M-S S-ATA M-S	Configure this channel to P-ATA or S-ATA. P-ATA: Parallel ATA Primary channel. S-ATA: Serial ATA.	Defines the S-ATA device for this channel. If the Second ATA is assigned S-ATA, this option reverts to P-ATA.
Second ATA Channel	P-ATA M-S S-ATA M-S	Configure this channel to P-ATA or S-ATA. P-ATA: Parallel ATA Primary channel. S-ATA: Serial ATA.	Defines the S-ATA device for this channel. If the First ATA is assigned S-ATA, this option reverts to P-ATA.
3rd & 4th ATA Channels	A1-3 rd M/ A2-4 th M A1-4 th M/ A2-3 rd M None	Configure this channel to P-ATA or S-ATA. P-ATA: Parallel ATA Primary channel. S-ATA: Serial ATA.	Display only. If the First ATA or Second ATA is assigned S-ATA, this option reverts to None.

IDE Device Configuration Sub-menu Selections



Feature	Options	Help Text	Description
Primary/Secondary/Third/Fourth IDE Master/Slave			
Device	N/A	N/A	Display detected device info
Type	Not Installed Auto CDROM ARMD	Select the type of device connected to the system.	The Auto setting should work in most cases.
LBA/Large Mode	Disabled Auto	Disabled: Disables LBA Mode. Auto: Enabled LBA Mode if the device supports it and the device is not already formatted with LBA Mode disabled.	The Auto setting should work in most cases.


Feature	Options	Help Text	Description
Block (Multi-Sector Transfer) Mode	Disabled Auto	Disabled: The Data transfer from and to the device occurs one sector at a time. Auto: The data transfer from and to the device occurs multiple sectors at a time if the device supports it.	The Auto setting should work in most cases.
PIO Mode	Auto 0 1 2 3 4	Select PIO Mode.	The Auto setting should work in most cases.
DMA Mode	Auto SWDMA0-0 SWDMA0-1 SWDMA0-2 MWDMA0-0 MWDMA0-1 MWDMA0-2 UWDMA0-0 UWDMA0-1 UWDMA0-2 UWDMA0-3 UWDMA0-4 UWDMA0-5	Select DMA Mode. Auto :Auto detected SWDMA :Single-wordDMA MWDMA :Multi-wordDMA UWDMA :UltraDMA	The Auto setting should work in most cases.
S.M.A.R.T.	Auto Disabled Enabled	Self-Monitoring, Analysis and Reporting Technology.	The Auto setting should work in most cases.
32Bit Data Transfer	Disabled Enabled	Enable/Disable 32-bit Data Transfer	

Floppy Configuration Sub-menu Selections



Feature	Options	Help Text	Description
Floppy Configuration			
Floppy A	Disabled 720 KB 3 1/2" 1.44 MB 3 1/2" 2.88 MB 3 1/2"	Select the type of floppy drive connected to the system.	Note: Intel no longer validates 720Kb & 2.88Mb drives.
Onboard Floppy Controller	Disabled Enabled	Allows BIOS to Enable or Disable Floppy Controller.	

Super I/O Configuration Sub-menu



Feature	Options	Help Text	Description
Configure Nat42x Super IO Chipset			
Serial Port A Address	Disabled 3F8/IRQ4 2F8/IRQ3 3E8/IRQ4 2E8/IRQ3	Allows BIOS to Select Serial Port A Base Addresses.	Option that is used by other serial port is hidden to prevent conflicting settings.
Serial Port B Address	Disabled 3F8/IRQ4 2F8/IRQ3 3E8/IRQ4 2E8/IRQ3	Allows BIOS to Select Serial Port B Base Addresses.	Option that is used by other serial port is hidden to prevent conflicting settings.


USB Configuration Sub-menu



Feature	Options	Help Text	Description
USB Configuration			
USB Devices Enabled	N/A	N/A	List of USB devices detected by BIOS.
USB Function	Disabled Enabled	Enables USB HOST controllers.	When set to disabled, other USB options are grayed out.

Feature	Options	Help Text	Description
Legacy USB Support	Disabled Keyboard only Auto Keyboard and Mouse	Enables support for legacy USB. AUTO option disables legacy support if no USB devices are connected. If disabled, USB Legacy Support will not be disabled until booting an OS.	
Port 60/64 Emulation	Disabled Enabled	Enables I/O port 60/64h emulation support. This should be enabled for the complete USB keyboard legacy support for non-USB aware OSes.	
USB 2.0 Controller	Disabled Enabled	N/A	
USB 2.0 Controller mode	FullSpeed HiSpeed	Configures the USB 2.0 controller in HiSpeed (480Mbps) or FullSpeed (12Mbps).	
USB Mass Storage Device Configuration	N/A	Configure the USB Mass Storage Class Devices.	Selects submenu with USB Device enable.


USB Mass Storage Device Configuration Sub-menu



Feature	Options	Help Text	Description
USB Mass Storage Device Configuration			
USB Mass Storage Reset Delay	10 Sec 20 Sec 30 Sec 40 Sec	Number of seconds POST waits for the USB mass storage device after start unit command.	
Device #1	N/A	N/A	Only displayed if a device is detected, includes a DeviceID string returned by the USB device.

Feature	Options	Help Text	Description
Emulation Type	Auto Floppy Forced FDD Hard Disk CDROM	If Auto, USB devices less than 530MB will be emulated as Floppy and remaining as hard drive. Forced FDD option can be used to force a HDD formatted drive to boot as FDD (Ex. ZIP drive).	
Device #n	N/A	N/A	Only displayed if a device is detected, includes a DeviceID string returned by the USB device.
Emulation Type	Auto Floppy Forced FDD Hard Disk CDROM	If Auto, USB devices less than 530MB will be emulated as Floppy and remaining as hard drive. Forced FDD option can be used to force a HDD formatted drive to boot as FDD (Ex. ZIP drive).	Å@

PCI Configuration




This sub-menu provides control over PCI devices and their option ROMs. If the BIOS is reporting POST error 146, use this menu to disable option ROMs that are not required to boot the system.

Parameter	Description	Option
PCI Configuration		
Onboard Video	Disabled Enabled	Enable/Disable on board VGA Controller
Dual Monitor Video	Disabled Enabled	Select which graphics controller to use as the primary boot device. Enabled selects the on board device.
Onboard NIC 1 (Left)	Disabled Enabled	
Onboard NIC 1 ROM	Disabled Enabled	

Parameter	Description	Option
Onboard NIC 2 (Right)	Disabled Enabled	
Onboard NIC 2 ROM	Disabled Enabled	
Onboard SCSI	Disabled Enabled	
Onboard SCSI ROM	Disabled Enabled	
Onboard SCSI Mode	IM/IME IS	IM/IME = Integrated Mirroring/Integrated Mirroring Enhanced IS = Integrated Striping Before changing modes, back up array data and delete existing arrays, if any. Otherwise, loss of all data may occur.
Slot 1 Option ROM	Disabled Enabled	PCI-X 64/133
Slot 2 Option ROM	Disabled Enabled	PCI-X 64/133
Slot 3 Option ROM	Disabled Enabled	PCI-X 64/133
Slot 4 Option ROM	Disabled Enabled	PCI-X 64/133
Slot 5 Option ROM	Disabled Enabled	PCI-X 64/133
Slot 6 Option ROM	Disabled Enabled	PCI-X 64/133

Memory Configuration Sub-menu Selections



This sub-menu provides information about the DIMMs detected by the BIOS. The DIMM number is printed on the baseboard next to each device.

Feature	Options	Help Text	Description
System Memory Settings			
DIMM 1A	Installed Not Installed Disabled Mirror Spare		Informational display.
DIMM 1B	Installed Not Installed Disabled Mirror Spare		Informational display.

Feature	Options	Help Text	Description
DIMM 2A	Installed Not Installed Disabled Mirror Spare		Informational display.
DIMM 2B	Installed Not Installed Disabled Mirror Spare		Informational display.
DIMM 3A	Installed Not Installed Disabled Mirror Spare		Informational display.
DIMM 3B	Installed Not Installed Disabled Mirror Spare		Informational display.
Extended Memory Test	1 MB 1 KB Every Location Disabled	Settings for extended memory test	
Memory Retest	Disabled Enabled	If "Enabled", BIOS will activate and retest all DIMMs on the next system boot. This option will automatically reset to "Disabled" on the next system boot.	


Feature	Options	Help Text	Description
Memory Remap Feature	Disabled Enabled	<p>Enable: Allow remapping of overlapped PCI memory above the total physical memory.</p> <p>Disable: Do not allow remapping of memory.</p>	
Memory Mirroring / Sparing	Disabled Spare Mirror	Disabled provides the most memory space. Sparing reserves memory to replace failures. Mirroring keeps a second copy of memory contents.	Sparing or Mirroring is grayed out if the installed DIMM configuration does not support it.

Boot Menu Selections



Feature	Option	Help Text	Description
Boot Settings			
Boot Settings Configuration	N/A	Configure settings during system boot.	Selects sub-menu.
Boot Device Priority	N/A	Specifies the boot device priority sequence.	Selects sub-menu.
Hard Disk Drives	N/A	Specifies the boot device priority sequence from available hard drives.	Selects sub-menu.
Removable Drives	N/A	Specifies the boot device priority sequence from available removable drives.	Selects sub-menu.
CD/DVD Drives	N/A	Specifies the boot device priority sequence from available CD/DVD drives.	Selects sub-menu.


Boot Settings Configuration Sub-menu Selections



Feature	Options	Help Text
Boot Settings Configuration		
Quick Boot	Disabled Enabled	Allows BIOS to skip certain tests while booting. This will decrease the time needed to boot the system.
Quiet Boot	Disabled Enabled	Disabled: Displays normal POST messages. Enabled: Displays OEM Logo instead of POST messages.
Bootup Num-Lock	Off On	Select power-on state for Numlock.
PS/2 Mouse Support	Disabled Enabled Auto	Select support for PS/2 mouse.

Feature	Options	Help Text
POST Error Pause	Disabled Enabled	If enabled, the system will wait for user intervention on critical POST errors. If disabled, the system will boot with no intervention, if possible.
Hit 'F2' Message Display	Disabled Enabled	Displays "Press 'F2' to run Setup" in POST.
Scan User Flash Area	Disabled Enabled	Allows BIOS to scan the Flash ROM for user binaries.

Boot Device Priority Sub-menu Selections



Feature	Options	Help Text	Description
Boot Device Priority			


Feature	Options	Help Text	Description
1st Boot Device	Varies	Specifies the boot sequence from the available devices. A device enclosed in parenthesis has been disabled in the corresponding type menu.	Number of entries will vary based on system configuration.
nth Boot Device	Varies	Specifies the boot sequence from the available devices. A device enclosed in parenthesis has been disabled in the corresponding type menu.	

Hard Disk Drive Sub-Menu Selections



Feature	Options	Help Text	Description
Hard Disk Drives			
1st Drive	Varies	Specifies the boot sequence from the available devices.	Varies based on system configuration.
nth Drive	Varies	Specifies the boot sequence from the available devices.	Varies based on system configuration.

Removable Drives Sub-menu Selections




Feature	Options	Help Text	Description
Removable Drives			
1st Drive	Varies	Specifies the boot sequence from the available devices.	Varies based on system configuration.
nth Drive	Varies	Specifies the boot sequence from the available devices.	Varies based on system configuration.

CD/DVD Drives Sub-menu Selections



Feature	Options	Help Text	Description
CD/DVD Drives			
1st Drive	Varies	Specifies the boot sequence from the available devices.	Varies based on system configuration.
nth Drive	Varies	Specifies the boot sequence from the available devices.	Varies based on system configuration.

Security Menu Options




Feature	Options	Help Text	Description
Security Settings			
Administra- tor Pass- word is	N/A	Install / Not installed	Informational display.
User Pass- word is	N/A	Install / Not installed	Informational display.
Set Admin Password	N/A	Set or clear Admin pass- word	Pressing enter twice will clear the password. This option is grayed out when entering setup with a user pass- word.

Feature	Options	Help Text	Description
Set User Password	N/A	Set or clear User password	Pressing enter twice will clear the password.
User Access Level	No Access View Only Limited Full Access	LIMITED: allows only limited fields to be changed such as Date and Time. NO ACCESS: prevents User access to the Setup Utility. VIEW ONLY: allows access to the Setup Utility but the fields can not be changed. FULL: allows any field to be changed.	This node is grayed out and becomes active only when Admin password is set.
Clear User Password	N/A	Immediately clears the user password.	Admin uses this option to clear User password (Admin password is used to enter setup is required). This node is gray if Administrator password is not installed.
Fixed disk boot sector protection	Disabled Enabled	Enable/Disable Boot Sector Virus Protection.	
Password On Boot	Disabled Enabled	If enabled, requires password entry before boot.	This node is grayed out if a user password is not installed.

Feature	Options	Help Text	Description
Secure Mode Timer	1 minute 2 minutes 5 minutes 10 minutes 20 minutes 60 minutes 120 minutes	Period of key/PS/2 mouse inactivity specified for Secure Mode to activate. A password is required for Secure Mode to function. Has no effect unless at least one password is enabled.	This node is grayed out if a user password is not installed.
Secure Mode Hot Key (Ctrl-Alt-)	[L] [Z]	Key assigned to invoke the secure mode feature. Cannot be enabled unless at least one password is enabled. Can be disabled by entering a new key followed by a backspace or by entering delete.	This node is grayed out if a user password is not installed.
Secure Mode Boot	Disabled Enabled	When enabled, allows the host system to complete the boot process without a password. The keyboard will remain locked until a password is entered. A password is required to boot from diskette.	This node is grayed out if a user password is not installed.
Diskette Write Protect	Disabled Enabled	Disable diskette write protection when Secure mode is activated. A password is required to unlock the system.	This node is grayed out if a user password is not installed. This node is hidden if the Intel Management Module is not present.

Feature	Options	Help Text	Description
Video Blanking	Disabled Enabled	Blank video when Secure mode is activated. A password is required to unlock the system. This option controls the embedded video controller only.	This node is grayed out if a user password is not installed. This node is hidden if the Intel Management Module is not present.
Power Switch Inhibit	Disabled Enabled	Disable the Front Panel Power Switch when Secure mode is activated. A password is required to unlock the system.	This node is grayed out if a user password is not installed. This node is hidden if the Intel Management Module is not present.
NMI Control	Disabled Enabled	Enable / disable NMI control for the front panel NMI button.	

Server Menu Selections




Feature	Options	Help Text	Description
System management	N/A	N/A	Selects submenu.
Serial Console Features	N/A	N/A	Selects submenu.
Event Log configuration	N/A	Configures event logging.	Selects submenu.
Assert NMI on SERR	Disabled Enabled	If enabled, NMI is generated on SERR and logged.	
Assert NMI on PERR	Disabled Enabled	If enabled, NMI is generated. SERR option needs to be enabled to activate this option.	Grayed out if "NMI on SERR" is disabled.

Feature	Options	Help Text	Description
Resume on AC Power Loss	Stays Off Power On Last State	Determines the mode of operation if a power loss occurs. Stays off, the system will remain off once power is restored. Power On, boots the system after power is restored.	“Last State” is only displayed if the Intel Management Module is present. When displayed, “Last State” is the default. When set to “Stays Off,” “Power Switch Inhibit” is disabled.
FRB-2 Policy	Disable BSP Do not disable BSP Retry on Next Boot Disable FRB2 Timer	This controls action if the boot processor will be disabled or not.	“Disable BSP” and “Do not disable BSP” are only displayed if the Intel Management Module is present.
Late POST Timeout	Disabled 5 minutes 10 minutes 15 minutes 20 minutes	This controls the time limit for add-in card detection. The system is reset on timeout.	
Hard Disk OS Boot Timeout	Disabled 5 minutes 10 minutes 15 minutes 20 minutes	This controls the time limit allowed for booting an operating system from a Hard disk drive. The action taken on timeout is determined by the OS Watchdog Timer policy setting.	
PXE OS Boot Timeout	Disabled 5 minutes 10 minutes 15 minutes 20 minutes	This controls the time limit allowed for booting an operating system using PXE boot. The action taken on timeout is determined by OS Watchdog Timer policy setting.	

Feature	Options	Help Text	Description
OS Watchdog Timer Policy	Stay On Reset Power Off	Controls the policy upon timeout. Stay on action will take no overt action. Reset will force the system to reset. Power off will force the system to power off.	
Platform Event Filtering	Disabled Enabled	Disable trigger for system sensor events.	


System Management Sub-menu Selections



Feature	Options	Help Text	Description
Server Board Part Number	N/A	N/A	Field contents varies

Feature	Options	Help Text	Description
Server Board Serial Number	N/A	N/A	Field contents varies
NIC 1 MAC Address	N/A	N/A	Field contents varies
NIC 2 MAC Address	N/A	N/A	Field contents varies
System Part Number	N/A	N/A	Field contents varies
System Serial Number	N/A	N/A	Field contents varies
Chassis Part Number	N/A	N/A	Field contents varies
Chassis Serial Number	N/A	N/A	Field contents varies
BIOS Version	N/A	N/A	BIOS ID string (excluding the build time and date).
BMC Device ID	N/A	N/A	Field contents varies
BMC Firmware Revision	N/A	N/A	Field contents varies
BMC Device Revision	N/A	N/A	Field contents varies
PIA Revision	N/A	N/A	Field contents varies
SDR Revision	N/A	N/A	Field contents varies
HSC FW Revision (HSBP)	N/A	N/A	Firmware revision of the Hot-swap controller. Displays n/a if the controller is not present.


Serial Console Features Sub-menu Selections



Feature	Options	Help Text	Description
Serial Console Features			
BIOS Redirection Port	Disabled Serial A Serial B	If enabled, BIOS uses the specified serial port to redirect the console to a remote ANSI terminal. Enabling this option disables Quiet Boot.	When the Management Module is present, the help text directs the user to select Serial B for Serial Over LAN.
		If enabled, BIOS uses the specified serial port to redirect the console to a remote ANSI terminal. Enabling this option disables Quiet Boot. For Serial Over LAN, select Serial B.	

Feature	Options	Help Text	Description
Baud Rate	9600 19.2K 38.4K 57.6K 115.2K	N/A	
Flow Control	No Flow Control CTS/RTS XON/XOFF CTS/RTS + CD	If enabled, it will use the Flow control selected. CTS/RTS = Hardware XON/XOFF = Software CTS/RTS + CD = Hardware + Carrier Detect for modem use.	
Terminal Type	PC-ANSI VT100+ VT-UTF8	VT100+ selection only works for English as the selected language. VT-UTF8 uses Unicode. PC-ANSI is the standard PC-type terminal.	
ACPI Redirection port	Disabled Serial A Serial B	Enable / Disable the ACPI OS Headless Console Redirection.	
Serial Port Connector	Serial A Serial B	Selects which serial port will be routed to the serial port connector on the back of the chassis. Serial A selects UARTA and Serial B selects UARTB.	


Event Log Configuration Sub-menu Selections



Feature	Options	Help Text	Description
Event Log Configuration			
Clear All Event Logs	Disabled Enabled	Setting this to Enabled will clear the System Event Log during the next boot.	
BIOS Event Logging	Disabled Enabled	Select enabled to allow logging of BIOS events.	Enables BIOS to log events to the SEL. This option controls BIOS events only.

Feature	Options	Help Text	Description
Critical Event Logging	Disabled Enabled	If enabled, BIOS will detect and log events for system critical errors. Critical errors are fatal to system operation. These errors include PERR, SERR, ECC.	Enable SMM handlers to detect and log events to SEL.
ECC Event Logging	Disabled Enabled	Enables or Disables ECC Event Logging.	Grayed out if "Critical Event Logging" option is disabled.
PCI Error Logging	Disabled Enabled	Enables or Disables PCI Error Logging.	Grayed out if "Critical Event Logging" option is disabled.
FSB Error Logging	Disabled Enabled	Enables or Disables Front-Side Bus Error Logging.	Grayed out if "Critical Event Logging" option is disabled.
Hublink Error Logging	Disabled Enabled	Enables or Disables Hublink Error Logging.	Grayed out if "Critical Event Logging" option is disabled.

Exit Menu Selections



Feature	Options	Help Text	Description
Exit Options			Exit Options
Save Changes and Exit	N/A	Exit system setup after saving the changes. F10 key can be used for this operation.	Save Changes and Exit
Discard Changes and Exit	N/A	Exit system setup without saving any changes. ESC key can be used for this operation.	Discard Changes and Exit
Discard Changes	N/A	Discards changes done so far to any of the setup questions. F7 key can be used for this operation.	Discard Changes

Feature	Options	Help Text	Description
Load Setup Defaults	N/A	Load Setup Default values for all the setup questions. F9 key can be used for this operation.	Load Setup Defaults
Load Custom Defaults	N/A	Load custom defaults.	Load Custom Defaults
Save Custom Defaults	N/A	Save custom defaults	Save Custom Defaults

Upgrading the BIOS

The upgrade utility allows you to upgrade the BIOS in flash memory. The code and data in the upgrade file include the following:

- On-board system BIOS, including the recovery code, BIOS Setup Utility, and strings.
- On-board video BIOS, SCSI BIOS, and other option ROMs for devices embedded on the server board.
- OEM binary area
- Microcode
- A means to change the BIOS Language

Preparing for the Upgrade

The steps below explain how to prepare to upgrade the BIOS, including how to record the current BIOS settings and how to obtain the upgrade utility.



.....

Note: In the unlikely event that a BIOS error occurs during the BIOS update process, a recovery process may need to be followed to return the system to service.

Recording the Current BIOS Settings

- 1 Boot the computer and press <F2> when you see the message: Press <F2> Key if you want to run SETUP
- 2 Write down the current settings in the BIOS Setup program.



.....

Note: Do not skip step 2. You will need these settings to configure your computer at the end of the procedure.

Obtaining the Upgrade

Download the BIOS image file to a temporary folder on your hard drive.



.....

Note: Review the instructions and release notes that are provided in the readme file distributed with the BIOS image file before attempting a BIOS upgrade. The release notes contain critical information regarding jumper settings, specific fixes, or other information to complete the upgrade.

Upgrading the BIOS

Follow the instructions in the readme file that came with the BIOS upgrade. When the update completes, remove the bootable media from which you performed the upgrade.




.....

Note: Do not power down the system during the BIOS update process! The system will reset automatically when the BIOS update process is completed. You may encounter a CMOS Checksum error or other problem after reboot. If this happens, shut down the system and boot it again. CMOS checksum errors require that you enter Setup, check your settings, save your settings, and exit Setup.

Clearing the Password

If the user or administrator password(s) is lost or forgotten, moving the password clear jumper into the "clear" position clears both passwords. The password clear jumper must be restored to its original position before a new password(s) can be set. The password clear jumper is shown on the line labeled "A" in the figure below.

- 1 Power down the system and disconnect the AC power.
- 2 Open the server chassis.
- 3 **Move the jumper from the normal operation position, Password Clear Protect, at pins 1 and 2 to the Password Clear Erase position, covering pins 2 and 3 as indicated in the following diagram.**




- 4 Reconnect the AC power, power up the system.
- 5 Power down the system and disconnect the AC power.
- 6 Return the Password Clear jumper to the Password Clear Protect position, covering pins 1 and 2.
- 7 Close the server chassis.
- 8 Reconnect the AC power and power up the server.

Clearing the CMOS

If you are not able to access the BIOS setup screens, the CMOS Clear jumper will need to be used to reset the configuration RAM. The CMOS Clear jumper is shown on the line labeled "C" in the figure below.

- 1 Power down the system and disconnect the AC power.
- 2 Open the server.
- 3 Move the jumper from the normal operation position, CMOS Clear by BMC, at pins 1 and 2 to the CMOS Clear Force Erase position, covering pins 2 and 3 as indicated in the following diagram.



- 4 Reconnect the AC power, power up the system.
- 5 When the system begins beeping, power it down and disconnect the AC power.
- 6 Return the CMOS Clear jumper to the CMOS Clear by BMC location, covering pins 1 and 2.
- 7 Close the server chassis.
- 8 Reconnect the AC power and power up the system.

6 Troubleshooting

This chapter helps you identify and solve problems that might occur while you are using the system.

Troubleshooting

For any issue, first ensure you are using the latest firmware and files. Firmware upgrades include updates for BIOS, the baseboard management controller (BMC), and the hot-swap controller (HSC). In addition to the server firmware and files, also update any drivers used for components you have installed in your system, such as video drivers, network drivers, and SCSI drivers.

Acer provides a package called the “Platform Confidence Test” that may help with your diagnostics.

If you are unable to resolve your server problems on your own.

Resetting the System

Before going through in-depth troubleshooting, attempt first to perform reset your system using one of the methods below.

To do this:	Press:
Soft boot reset to clear the system memory and reload the operating system.	<Ctrl+Alt+Del>
Clear system memories, restarts POST, and reload the operating system.	Reset button
Cold boot reset. Turn the system power off and then on. This clears system memory, restarts POST, reloads the operating system, and halts power to all peripherals.	Power off/on

Problems following Initial System Installation

Problems that occur at initial system startup are usually caused by an incorrect installation or configuration. Hardware failure is a less frequent cause. If the problem you are experiencing is with a specific software application.

First Steps Checklist

- Is AC power available at the wall outlet?
- Are the power supplies plugged in? Check the AC cable(s) on the back of the chassis and at the AC source.

- Are all cables correctly connected and secured?
- Are the processors fully seated in their sockets on the server board?
- Are all standoffs in the proper location and not touching any components, causing a potential short?
- Are all add-in PCI boards fully seated in their slots on the server board?
- Are all jumper settings on the server board correct?
- Are all jumper and switch settings on add-in boards and peripheral devices correct? To check these settings, refer to the manufacturer's documentation that comes with them. If applicable, ensure that there are no conflicts—for example, two add-in boards sharing the same interrupt.
- Are all peripheral devices installed correctly?
- If the system has a hard disk drive, is it properly formatted or configured?
- Are all device drivers properly installed?
- Are the configuration settings made in Setup correct?
- Is the operating system properly loaded? Refer to the operating system documentation.
- Did you press the system power on/off switch on the front panel to turn the server on (power on light should be lit)?
- Is the system power cord properly connected to the system and plugged into a NEMA 5-15R outlet for 100-120 V~ or a NEMA 6-15R outlet for 200-240 V~?
- Are all integrated components from the tested components lists? Check the tested memory, and chassis lists, as well as the supported hardware and operating system list.

Hardware Diagnostic Testing

This section provides a more detailed approach to identifying a hardware problem and locating its source.



Caution: Turn off devices before disconnecting cables: Before disconnecting any peripheral cables from the system, turn off the system and any external peripheral devices. Failure to do so can cause permanent damage to the system and/or the peripheral devices.

- 1 Turn off the system and all external peripheral devices. Disconnect each device from the system, except for the keyboard and the video monitor.
- 2 Make sure the system power cord is plugged into a properly grounded AC outlet.
- 3 Make sure your video display monitor and keyboard are correctly connected to the system. Turn on the video monitor. Set its brightness and contrast controls to at least two thirds of their maximum ranges (see the documentation supplied with your video display monitor).
- 4 If the operating system normally loads from the hard disk drive, make sure there is no diskette in drive A and no CD-ROM disk in the CD-ROM drive.
- 5 If the power LED does light, attempt to boot from a floppy diskette or from a CD-ROM disk.
- 6 Turn on the system. If the power LED does not light, see "Power Light Does Not Light."

Verifying Proper Operation of Key System Lights

As POST determines the system configuration, it tests for the presence of each mass storage device installed in the system. As each device is checked, its activity light should turn on briefly. Check for the following:

- Does the diskette drive activity light turn on briefly? If not, see "Diskette Drive Activity Light Does Not Light." "Diskette Drive Activity Light Does Not Light"
- If system LEDs are illuminated, see "LED Information" for a description of

the light and steps to take to correct the problem.

Confirming Loading of the Operating System

Once the system boots up, the operating system prompt appears on the screen. The prompt varies according to the operating system. If the operating system prompt does not appear, see “No Characters Appear on Screen”

Specific Problems and Corrective Actions

This section provides possible solutions for these specific problems:

- Power light does not light.
- No characters appear on screen.
- Characters on the screen appear distorted or incorrect.
- System cooling fans do not rotate.
- Diskette drive activity light does not light.
- Hard disk drive activity light does not light.
- CD-ROM drive activity light does not light.
- There are problems with application software.
- The bootable CD-ROM is not detected.

Try the solutions below in the order given. If you cannot correct the problem, contact your service representative or authorized dealer for help.

Power Light Does Not Light

Check the following:

- Did you press the power-on button?
- Is the system operating normally? If so, the power LED might be defective or the cable from the control panel to the server board might be loose.
- Have you securely plugged the server AC power cord into the power supply?
- Some ATX power supplies have a power switch on the back of the power supply, next to the fan. If your system has one, is it turned on?
- Remove all add-in cards and see if the system boots. If successful, add the cards back in one at a time with a reboot between each addition.
- Make sure the memory DIMMs comply with the system requirements.
- Make sure the memory DIMMs have been populated according to the system requirements.

- Remove the memory DIMMs and re-seat them.
- Make sure the processor(s) comply with the system requirements.
- Make sure the processor(s) have been populated according to the system requirements.
- Remove the processor(s) and re-seat them.
- **Make sure the chassis standoffs are installed only below mounting holes. Misplaced standoffs can contact the pins on the bottom of the server board and cause a short.**

No Characters Appear on Screen

Check the following:

- Is the keyboard functioning? Test it by turning the "Num Lock" function on and off to make sure the Num Lock light is functioning.
- Is the video monitor plugged in and turned on? If you are using a switch box, is it switched to the correct system?
- Are the brightness and contrast controls on the video monitor properly adjusted?
- Is the video monitor signal cable properly installed?
- Does this video monitor work correctly if plugged into a different system?
- Is the onboard video controller enabled in the BIOS?
- Remove all add-in cards and see if the video returns. If successful, add the cards back in one at a time with a reboot between each addition.
- Make sure the memory DIMMs comply with the system requirements.
- Make sure the memory DIMMs have been populated according to the system requirements.
- Remove the memory DIMMs and re-seat them.
- Make sure the processor(s) comply with the system requirements.
- Make sure the processor(s) have been populated according to the system requirements.
- Remove the processor(s) and re-seat them.

If you are using an add-in video controller board, do the following:

- 1 Verify that the video works using the onboard video controller.
- 2 Verify that the video controller board is fully seated in the server board connector.
- 3 Reboot the system for changes to take effect.

- 4 If there are still no characters on the screen after you reboot the system and POST emits a beep code, write down the beep code you hear. This information is useful for your service representative.
- 5 If you do not receive a beep code and characters do not appear, the video display monitor or video controller may have failed. Contact your service representative or authorized dealer for help.

Characters Are Distorted or Incorrect

Check the following:

- Are the brightness and contrast controls properly adjusted on the video monitor? See the manufacturer's documentation.
- Are the video monitor's signal and power cables properly installed?
- Does this video monitor work correctly if plugged into a different system?

System Cooling Fans Do Not Rotate Properly

If the system cooling fans are not operating properly, it is an indication of possible system component failure.

Check the following:

- Is the power-on light lit? If not, see "Power Light Does Not Light"
- If your system has LED lights for the fans, is one or more of these LEDs lit?
- Are any other control panel LEDs lit?
- Have any of the fan motors stopped? Use the server management subsystem to check the fan status.
- Have your fans speeded up in response to an overheating situation?
- Have your fans speeded up in response to a fan that has failed?
- Are the fan power connectors properly connected to the server board?
- Is the cable from the control panel board connected to the both the control panel board and to the server board?
- Are the power supply cables properly connected to the server board?
- Are there any shorted wires caused by pinched-cables or have power connector plugs been forced into power connector sockets the wrong way?

Diskette Drive Activity Light Does Not Light

Check the following:

- Are the diskette drive's power and signal cables properly installed?

- Are all relevant switches and jumpers on the diskette drive set correctly?
- Is the diskette drive properly configured?
- Is the diskette drive activity light always on? If so, the signal cable may be plugged in incorrectly.

If you are using the onboard diskette controller, use the BIOS setup to make sure that “Onboard Floppy” is set to “Enabled.” If you are using an add-in diskette controller, make sure that “Onboard Floppy” is set to “Disabled.”

CD-ROM Drive or DVD-ROM Drive Activity Light Does Not Light

Check the following:

- Are the CD-ROM/DVD-ROM drive’s power and signal cables properly installed?
- Are all relevant switches and jumpers on the drive set correctly?
- Is the drive properly configured?

Cannot Connect to a Server

- Make sure the network cable is securely attached to the correct connector at the system back panel.
- Try a different network cable.
- Make sure you are using the correct and the current drivers.
- Make sure the driver is loaded and the protocols are bound.
- Make sure the hub port is configured for the same duplex mode as the network controller.
- Make sure the correct networking software is installed.
- If you are directly connecting two servers (without a hub), you will need a crossover cable.
- Check the network controller LEDs next to the NIC connectors.

Problems with Network

The server hangs when the drivers are loaded.

- Certain drivers may require interrupts that are not shared with other PCI drivers. For these drivers, it may be necessary to alter settings so that interrupts are not shared. See the documentation that came with your PCI card(s) for information on changing interrupts.

Diagnostics pass but the connection fails.

- Make sure the network cable is securely attached.
- Make sure you specify the correct frame type in your NET.CFG file.

The controller stopped working when an add-in adapter was installed.

- Make sure the cable is connected to the port from the onboard network controller.
- Make sure your BIOS is current.
- Make sure the other adapter supports shared interrupts. Make sure your operating system supports shared interrupts.
- Try reseating the add-in adapter.

The add-in adapter stopped working without apparent cause.

- Try reseating the adapter first; then try a different slot if necessary.
- The network driver files may be corrupt or deleted. Delete and then reinstall the drivers.
- Run the diagnostics.

System Boots when Installing PCI Card

System Server Management features require full-time “standby” power. This means some parts of the system have power going to them whenever the power cord is plugged in, even if you have turned the system power off with the power button on the front panel. If you install a PCI card with the AC power cord plugged in, a signal may be sent to command the system to boot. Before installing a PCI card, you should always:

- Turn off the server power by using the power button on the front of the system.
- Unplug the AC power cord(s) from the server.

Problems with Newly Installed Application Software

Problems that occur when you run new application software are usually related to the software, not the server hardware. Faulty equipment is unlikely, especially if other software runs correctly.

Check the following:

- Make sure the system meets the minimum hardware requirements for the software. See the software documentation.
- Make sure the software is properly installed and configured for the system. See the software documentation.
- Use only an authorized copy. Unauthorized copies often do not work.

- If you are running the software from a floppy disk, CD-ROM or DVD-ROM, try a different disk.
- Make sure the correct device drivers installed.
- If the problems persist, contact the software vendor's customer service representative.

Problems with Application Software that Ran Correctly Earlier

Problems that occur after the system hardware and software have been running correctly sometimes indicate equipment failure. However, they can also be caused by file corruption or changes to the software configuration.

Check the following:

- If you are running the software from a floppy disk, CD-ROM or DVD-ROM, try a different disk.
- Check your system for a virus infection.
- Uninstall and reinstall the software. Make sure all necessary files are installed.
- If the problems are intermittent, there may be a loose cable, dirt in the keyboard (if keyboard input is incorrect), a marginal power supply, or other random component failures.
- If you suspect that a transient voltage spike, power outage, or brownout might have occurred, reload the software and try running it again. Symptoms of voltage spikes include a flickering video display, unexpected system reboots, and the system not responding to user commands.



.....

Note: Random errors in data files: If you are getting random errors in your data files, they may be getting corrupted by voltage spikes on your power line. If you are experiencing any of the above symptoms that might indicate voltage spikes on the power line, you may want to install a surge suppressor between the power outlet and the system power cord.

Devices are not Recognized under Device Manager (Windows* Operating System)

The Windows(*) operating systems do not include all of the drivers for the Intel® chipsets, onboard NICs, and other components.

Hard Drive(s) are not recognized

Check the following:

- Make sure the drive is not disabled in BIOS Setup.
- Make sure the drive is connected correctly and that it is plugged into the power supply.
- Make sure the drive is compatible.
- Make sure you have not exceeded the power budget for the server.
- If using SCSI drives, verify that each SCSI ID number is unique on the SCSI bus. See your drive documentation for details on setting the SCSI ID for your drives.
- If using ATA drives, verify that the master/slave settings are set correctly. See your drive documentation for details on setting the master/slave settings.
- If using a RAID configuration with SCSI or SATA drives, make sure the RAID card is installed correctly.

Bootable CD-ROM Is Not Detected

Check the following:

- Make sure the BIOS are configured to allow the CD-ROM to be the first bootable device.

LED Information

The Acer Altos R710 includes LEDs that can aid in troubleshooting your system. A table of these LEDs with a description of their use is listed below.

Name	Function	Location	Color	Notes
ID	Aid in server identification from the back panel	Control panel and board rear left corner	Blue	Press ID LED button or user Server Management software to turn on the LED.

Name	Function	Location	Color	Notes
System fault	Visible fault warning	Control panel and board rear left corner	Green or Amber	<ul style="list-style-type: none"> • Green = No Fault • Green Blink = degraded • Amber = critical error or non-recoverable • Amber blink = non-critical
Hard drive activity	Control panel	Control panel	Green	Blinking = Activity. No action required.
Memory fault 1–6	Identify failing memory module	DIMM end rear of board	Amber	On = Fault
Diagnostic LEDs. 1–4 (LSB, bit1, bit2, MSB)	Displays port 80 POST codes	Center back edge of board	Each LED can be Off, Green, Amber, Red	See the POST code table
CPU 1 & 2 Fan Fault	Identify fan failure	Front center board	Amber	On = Fault
CPU 1 & 2 Fault	Identify processor failure	1" behind processor socket	Amber	On = Fault
5v Standby	Identify 5v standby power on state	Front left board	Amber	On = 5v standby power on

Name	Function	Location	Color	Notes
Power LED	Identify the power state of the system	Control Panel	Green	<ul style="list-style-type: none"> • Off = Power is off (off or S5) • On = Power on or S0) • Slow Blink = Low power state (S1 – S3)

BIOS POST Beep Codes

The table below lists the POST error beep codes. Prior to system video initialization, the BIOS uses these beep codes to inform users of error conditions. Please note that not all error conditions are supported by BIOS beep codes.

POST Error Beep Codes

Number of Beeps	Reason for the beeps and action to take
1, 2, or 3	Memory error. Reseat the memory or replace the DIMMs with known good modules.
4 – 7 or 9 – 11	Fatal error indicating a possible serious system problem. Remove all add-in cards and re-start the system. If the error still occurs, contact your system manufacturer. If the beep codes are not generated after the add-in cards are removed, insert the cards one at a time, booting the system between each card addition, until the beeps again occur to reveal the malfunctioning card.
8	Replace or reseat the system video add-in card. If on-board video is being used, the server board may be faulty.

In addition to the beep codes above, additional beep codes are provided if an Acer® Intelligent Management Module is installed. The

Acer Management Modules provide the following additional beep codes.

Error Beep Codes Provided by Acer® Management Modules

Beep Code	Reason for the beeps and action to take
1	Control panel CMOS clear has been initiated.
1-5-1-1	Processor failure. Reseat or replace the failed processor.
1-5-2-1	No processor is installed or the CPU 1 socket is empty. Reseat or replace the failed processor.
1-5-2-3	Processor configuration error or CPU 1 socket is empty. Reseat or replace the failed processor. In a two-processor system, make sure the processors are identical.
1-5-2-4	Front-side bus selects configuration error.
1-5-4-2	DC power unexpectedly lost.
1-5-4-3	Chipset control failure.
1-5-4-4	Power control failure.

Appendix A:
Management
software installation

This appendix shows you how to install the ASM software packages.

Installing ASM

Acer Server Manager (ASM) consists of the ASM Console and the ASM Agent. These two components are both required to perform server management tasks.

System requirements

ASM requires TCP/IP connectivity between the ASM Console and the ASM Agent.

ASM Agent

- Altos Server System
- Minimum of 128 MB RAM
- SCSI/IDE hard drive with at least 100 MB free hard disk space
- Windows 2000 server/advanced server, Windows server 2003 web/standard/Enterprise editions, or Red Hat Linux 9.0 or Red Hat Enterprise Linux 3.0

ASM Console

- Intel Pentium III (500 MHz) or higher processor
- 128 MB of RAM
- SCSI/IDE hard drive with at least 100 MB free hard disk space
- Microsoft Windows 2000 Professional/XP/Server/Advanced Server operating system
- Ethernet card
- Windows 2000 professional, Windows XP, Windows 2000 server/advanced server, Windows server 2003 web/standard/Enterprise editions, Red Hat Linux 9.0 or Red Hat Enterprise Linux 3.0

System setup

Make sure that your system meets the requirements listed above before proceeding. You may also want to change your screen to 800 x 600 resolution or higher for optimum viewing.

Installing ASM Agent (Windows version)

To install ASM Agent:

- 1 Log in to the managed server using the Administrator account.
- 2 Insert the EasyBUILD™ Management CD into the server's CD-ROM drive.

The installation sequence will automatically begin.

- 3 Select the option for ASM installation.

The installation wizard will be initialized.

- 4 Follow all onscreen instructions to complete installation.

For detailed instructions on installing ASM Agent, refer to the ASM User's manual.



.....
ASM Agent will auto-launch as a Windows service after rebooting the system.

Installing ASM Console (Windows version)

To install ASM Console:

- 1 Log in to the target Windows-based PC using the Administrator account.
- 2 Insert the EasyBUILD™ Management CD into the computer's CD-ROM drive.

The installation sequence will automatically begin.

- 3 Select the option for ASM installation.

The installation wizard will be initialized.

- 4 Follow all onscreen instructions to complete installation.

For detailed instructions on installing ASM Console, refer to the ASM User's manual.



.....
To launch the program, on the Windows taskbar click on the **Start** button, point to **programs**, select **Acer Server Manager** then click **Acer Server Manager**

Installing ASM Agent (Linux version)

To install the ASM6 Agent on RedHat Linux 9.0

- 1 Insert the ASM6 installation CD into your computer's optical drive.
- 2 Mount the CD-ROM drive with "mount /dev/cdrom /mnt/cdrom" command. For more information on mount command and the options, please refer to RedHat Linux user's guide.
- 3 Change the working directory to ASM6 Linux Agent subdirectory with the command "cd /mnt/cdrom/LinuxAgent".
- 4 Type in the command ".asmsetup install" to install the ASM6 Linux Agent. Follow the prompted installation guide, and you can install the ASM6 Linux Agent with ease.
- 5 Umount the CD-ROM Drive with "umount /mnt/cdrom" command.

For detailed instructions on installing ASM Agent on Linux systems, refer to the ASM User's manual.



.....
ASM agent will auto-launch demon service after rebooting the system. There is no Linux version of ASM Console.

Appendix B: Tool-less rail kit installation


This appendix shows you how to use the optional rail kit to put your Altos R710 server into a server rack.

Tool-less rail kit installation



Note: Read the General Safety Information on the other side of this sheet before attempting installation.

The Slide Rails consist of individual left and right Slide Rails. Details of the Slide Rails are shown below.



Setting the Multi-Pin Adapters for Rack Type




The 10-32 threaded hole in the center of the Multi-Pin Adapter is for securing during shipping (if desired) and for the attachment of front panel blanks (if desired).



The Slide Rails are shipped with the Multi-Pin Adapters set for square holes. If your rack has square mounting holes, skip this section.

The Multi-Pin Adapters allow the Slide Rails to be used in racks that have square mounting holes or round mounting holes.


1. On each Slide Rail, reverse the Multi-Pin Adapter position to match the rack mounting hole type if necessary. Remove the Multi-Pin Adapter by rotating the Swivel Lock up, pressing the mounting pins together, and then pulling the adapter from the Multi-Pin Bracket.
2. Install the Multi-Pin Adapter by pressing the pins together while inserting adapter into bracket. Multi-Pin Adapter must be fully locked in bracket. Make certain both mounting pins on Multi-Pin Adapter are fully engaged in Multi-Pin Bracket, then lock Multi-Pin Adapter in place using the Swivel Lock.
3. Repeat the above steps for both ends of each Slide Rail.



Installing the Slide Rails into the Rack

1. At all four rack uprights, determine the vertical position in the rack where the Slide Rails are to be installed. The top-most mounting hole for a particular Rack Unit (RU) mounting position is


typically identified by a mark or hole.



Caution! If Slide Rail is mounted in holes which are not vertically aligned from front to back, the Slide Rail may be damaged and mounting will not be secure.

2. Noting the holes determined in the previous step, align the left Slide Rail with its mounting holes.

3. Hold the Slide Rail in desired rack mounting position. At the rear of Slide Rail, press the Multi-Pin Adapter mounting pins together and insert the Slide Rail into rack upright.



4. Making certain the proper mounting holes on rack upright are selected, repeat the above step at the Slide Rail front mounting position. Ensure Slide Rail is level.

5. Fully extend the Slide Rail to its fully extended (locked) position. Press the Slide Extension Release Levers to release the lock. Move the Slide Rail in and out throughout its entire range of motion and make certain it does not bind. If binding is noticed, recheck the mounting positions.

6. Repeat steps 2 through 5 for the right Slide Rail, ensuring that it is parallel and level with the left Slide Rail.

Installing the Component into the Slide Rails



.....

Note: If optional Cable Management Arm (CMA) is to be installed, install it now before installing the component. Access to rear of Slide Rails is required to install the CMA. (See Cable Management Arm Installation on the other side of this sheet for CMA installation instructions.)


1. Extend both Slide Rails into the fully extended (locked) position.

2. Align the mounting studs with the Component Mounting Channels on the Slide Rails.

3. Carefully place the component's mounting studs in the Component Mounting Channels on the Slide Rails.

Allow the component mounting studs to fully seat in the Component Mounting Channels. The Component Release Levers (one on each Slide Rail) pivot out of the way and then back in place when the studs are

fully engaged in the mounting channels. Ensure that the Component Release Levers are in locked position.



4. Press and hold the left and right Slide Extension Release Levers and slowly slide the component and Slide Rails into the fully retracted position.


Cable Management ARM installation



.....


Note: Read the General Safety Information below before attempting installation. The Cable Management Arm (CMA) pivots at its rear mounting position, and slides along its front

mounting position with the Slide Rail track. An overall view of the CMA and its details are shown below.



Required Installation Position of the CMA

The CMA can be installed on either the left Slide Rail or right Slide Rail (the mounting tabs on either end are identical). Regardless of the selected position, the CMA must be oriented as shown below to properly function.



Installing the CMA on the Slide Rails


1. Pull the Slide Rails out to the fully extended (locked) position.
2. Loosely position the CMA in mounting position, noting the placement requirements specified above.




.....

Note: The CMA is shipped with the Spacer Block not installed. Install the Spacer Block on the CMA mounting point chosen to be the rear (pivoting) end of the installed assembly.

3. Place the Spacer Block in mounting position on the end of the CMA chosen to be the rear (pivoting) end. Attach the CMA (along with Spacer Block) to the rear of Slide Rail using the captive thumbscrew.




4. Attach the Anti-sag Bar to the Anti-sag Bar Sliders on the left and right Slide Rails.



5. At the front (sliding) end of the CMA, fully extend the CMA, then attach the CMA to the Slide Rail track using the captive


thumbscrew.



6. Press and hold the left and right Slide Extension Release Levers and slowly move the Slide Rails throughout their entire range of motion. Ensure the CMA folds and expands without binding. If binding is noticed, recheck mounting of CMA as described in Required Installation Position of the CMA.

Placing and Securing Cabling Within the CMA

1. After installing the component in the Slide Rails, fully extend the Slide Rails until they lock.
2. Connect all required cables to the component.
3. Place the cables in the cable cut-outs and into the cabling channels.
4. Use the six supplied straps to secure the cables within the cabling channels.



5. Press and hold the left and right Slide Extension Release Levers and slowly slide the component throughout its entire range of motion to ensure that cabling is not strained or restricting movement of Slide Rails. Make certain cabling is not pinched when slides and CMA are in the fully retracted position.

General Safety Information



.....
WARNING! WARNING statements indicate a possible hazard which, if not avoided, could result in personal injury or death.



.....
 Caution! Caution statements indicate a problem or unsafe practice which, if not avoided, could result in product or property damage.

Note: Note statements provide supplemental information.



.....
WARNING !

- For complete safety and regulatory information, see your System Information document.
- This Slide Rail kit is intended only for use with components of 1 RU or 2 RU height.
- Maximum component weight: 18.2 kg (40 lb.) for 1 RU; 38.6 kg (85 lb.) for 2 RU.
- Installing components in a rack without the front and side stabilizers could cause the rack to tip over. Always install the stabilizers before installing components in the rack.
- Always load the rack from the bottom up. Load the heaviest component in the rack first in the lowest position.
- When preparing to install a component in the rack, always extend the Slide Rails into the locking position, and then slide the component into the Slide Rail mounting positions.
- Use caution when pressing the Slide Rail release latches and sliding the component in or out of the rack; the Slide Rails can pinch your fingers.

- If component being installed into Slide Rails exceeds 22.6 kg (50 lb.), two persons should lift the component into the Slide Rails.
- NEVER use the Slide Rails as a step. Do not stand or sit on the Slide Rails.!



.....

Caution !Ensure that the position selected for each installed component allows for proper ventilation of each component. Consult component documentation as required.

Note: Your system is safety-certified as a free-standing unit and as a component for use in a rack cabinet using the customer rack kit when both the rack cabinet and the rack kit were designed for your system. The installation of your system and rack kit in any other rack cabinet has not been approved by any safety agency. It is your responsibility to have the final combination of system and rack kit in a cabinet evaluated for suitability by a certified safety agency. The manufacturer disclaims all warranties and liability in connection with such combinations.

Appendix C: RAID Configuration

This appendix shows you how to create RAID.

Configuring the SCSI/SCSI RAID HBA

This section briefly shows how to create a RAID 1 (mirror) volume. This feature requires installation/presence of LSI Logic 20320-R or LSI Logic 22320-R U32 SCSI controllers.

How to use SCSI HBA setup utility

During the Power-On Self Test (POST), press <Ctrl> + <C> to enter the LSI Logic Configuration Utility.

Loading HBA Default Settings

- 1 In the LSI Logic MPT SCSI Setup Utility, please press F2 and select Global Properties. Then, select <Restore Defaults>.
- 2 Press ESC, then select <Save changes then exit this menu>.
- 3 Move cursor to <53C1020/1030> and press Enter.
- 4 Move cursor to <Restore Defaults> and press Enter.
- 5 Press ESC, then select <Save changes then exit this menu>.

How to use SCSI RAID HBA setup utility

How To Create RAID 1 (Mirror) volume with a Hot Spare Disk

- 1 In the LSI Logic MPT SCSI Setup Utility, please select <53C1020/1030> and press Enter.
- 2 Move cursor to <RAID Properties> and press Enter.
- 3 In Array Disk field, press Space key to change the hard disk to [Yes].



.....

Note: In the Array Disk field, if you change settings, you will see the following messages. Press the DELETE key to erase data.

F3 - keep Data (Create 2 disk array)
Delete - Erase Disk (Create 2 to 6 disk array)

- 4 In Hot Spare field, press Space key to change the hard disk to [Yes].



Note: In the Hot Spare field, if you change settings, you will see the following messages. Press the DELETE key to ignore it.

WARNING: Data on drive will be LOST!
Press DELETE if data loss OK or any other key to cancel.

- 5 Press ESC, then select <Save changes then exit this menu>.

RAID Volume Initialization

After you create RAID volume and save the changes, the disk controller will initialize RAID volume automatically. As LSI Logic 20320-R/22320-R can support background initialization, you don't have to wait for the initialization to complete. Now, you can exit LSI Logic Configuration Utility.

Exit and Restart the server

- 1 Press ESC, then select <Exit the Configuration Utility>. Then, you will see a [Global properties saved. Hit any key to reboot.] message.
- 2 Press a key to reboot system.

MegaRAID Configuration Utility

Turn on the system power. When prompted, press <Ctrl> + <M> to enter the MegaRAID Configuration Utility. After entering the MegaRAID Configuration Utility, you will see the Management Menu on the screen.

Load RAID Card Default Setting

- 1 Select Objects from Management menu.
- 2 Select Adapter from Objects. The adapter setting will be shown on the screen. You can change the setting from this menu.
- 3 Select Factory Default and YES to load the default settings.
- 4 Press <Ctrl> + <Alt> + to reboot the server.

Create RAID1 Volume

- 1 After the server has rebooted, press <Ctrl> + <M> to enter the MegaRAID Configuration Utility again.
- 2 Select Configuration from Management Menu.
- 3 Select New Configuration from the Configuration menu and select YES to continue. An array selection window displays the devices connected to the current controller.
- 4 Press the arrow keys to choose specific physical drives and press spacebar to associate the selected drive with the current array. The indicator for selected drive change from READY to ONLINE A[array number]-[drive number]. For example, ONLINE A1-2 means disk drive 2 in array 1.
- 5 Add 2 drives to current array and press <Enter> to finish creating current array.
- 6 Press <F10> to configure the logical drives.
- 7 The default RAID level for 2 disk drives is RAID1. Just select Accept to use the default setting and press <Enter> to return to the ARRAY SELECTION MENU.
- 8 Press <Enter> to end the array configuration.
- 9 Select YES to Save Configuration and press any key to return to the Configure menu.

Assign Hot Spare Disk

- 1 Select Add/View Configuration from Configuration menu.
- 2 Press arrow keys to choose specific physical drives and press <F4> to set the drive as Hot Spare Disk. Select YES to confirm and the indicator for selected drive change from READY to HOTSP.
- 3 Press <Esc> to end the array configuration.
- 4 Select YES to Save Configuration and press any key to return to the Configure menu.

Initialize RAID Volume

- 1 Press <Esc> to return to the Management Menu.
- 2 Select Initialize from Management menu. All logical drives should be listed under Logical Drives.
- 3 Press <Spacebar> to select drives for initialization. The selected drive will be shown in yellow.

- 4 After selecting the drives, press <F10> and select YES to start the initialization process.
- 5 When initialization is complete, press any key to continue.
- 6 Press <Esc> to return to the Management Menu.

Save And Exit MegaRAID Configuration Utility

- 1 When RAID configuration and initialization is complete, press <Esc> in the Management Menu and select YES to exit the MegaRAID Configuration Utility.
- 2 Press <Ctrl> + <Alt> + to reboot the server. Now you can start installing an OS on the RAID array.

Appendix D: BIOS POST Checkpoint Codes

This appendix shows you the POST code checkpoints which are references and instructions used during the BIOS pre-boot process.

BIOS POST Checkpoint Codes

The following table describes the checkpoints and associated beep codes, if any, that may occur during the POST portion of the BIOS.

Checkpoint Code	Beep Code	Description
01h	One short beep before boot	
02h		Verify Real Mode. If the CPU is in protected mode, turn on A20 and pulse the reset line, forcing a shutdown 0. NOTE: Hook routine should not alter DX, which holds the powerup CPUID.
03h		Disabel Non-Maskable Interrupts (NMI).
04h		Get CPU type from CPU registers and other methods. Save CPU type in NVRAM. NOTE: Hook routine should not alter DX, which holds the powerup CPUID.
06h		Initialize system hardware. Reset the DMA controllers, disable video, clear any pending interrupts from the real-time clock and setup port B register.
07h		Disable system ROM shadow and start to execute ROMEXEC code from the flash part. This task is pulled into the build only when the ROMEXEC relocation is installed.
08h		Initialize chipset registers to the Initial POST Values.

Checkpoint Code	Beep Code	Description
09h		<p>Set in-POST flag in CMOS that indicates we are in POST. If this bit is not cleared by post-ClearBootFlagJ (AEh), the BIOS on next boot determines that the current configuration caused POST to fail and uses default values for configuration.</p> <p>Clear the CMOS diagnostic byte (register E). Check the real-time clock and verify the battery has not lost power. Checksum the CMOS and verify it has not been corrupted.</p>
0Ah		Initialize CPU registers.
0Bh		Enable CPU cache. Set bits in CMOS related to cache.
0Ch		Set the initial POST values of the cache registers if not integrated into the chipset.
0Eh		Set the initial POST values of registers in the integrated I/O chip.
0Fh		Enable the local bus IDE as primary or secondary depending on other drives detected.
10h		Initialize power management.
11h		<p>General dispatcher for alternate register initialization.</p> <p>Set initial POST values for other hardware devices defined in the register tables.</p>
12h		Restore the contents of the CPU control word whenever the CPU is reset.
13h		Early reset of PCI devices required to disable bus master. Assumes the presence of a stack and running from decompressed shadow memory.

Checkpoint Code	Beep Code	Description
14h		Verify that the 8742 keyboard controller is responding. Send a self-test command to the 8742 and wait for results. Also read the switch inputs from the 8742 and write the keyboard controller command byte.
16h	1-2-2-3	Verify that the ROM BIOS checksums to zero.
17h		Initialize external cache before autosizing memory.
18h		Initialize all three of the 8254 timers. Set the clock timer (0) to binary count, mode 3 (square wave mode), and read/write LSB then MSB. Initialize the clock timer to zero. Set the RAM refresh timer (1) to binary count, mode 2 (Rate Generator), and read/write LSB only. Set the counter to 12H to generate the refresh at the proper rate. Set sound timer (2) to binary count, mode 3, and read/write LSB, then MSB.
1Ah		<p>Initialize DMA command register with these settings:</p> <ol style="list-style-type: none"> 1. Memory to memory disabled 2. Channel 0 hold address disabled 3. Controller enabled 4. Normal timing 5. Fixed priority 6. Late write selection 7. DREQ sense active 8. DACK sense active low <p>Initialize all 8 DMA channels with these settings:</p> <ol style="list-style-type: none"> 1. Single mode 2. Address increment 3. Auto initialization disabled (channel 4 - Cascade) 4. Verify transfer

Checkpoint Code	Beep Code	Description
1Ch		Initialize interrupt controllers for some shut-downs.
20h	1-3-1-1	Verify that DRAM refresh is operating by polling the refresh bit in PORTB.
22h	1-3-1-3	Reset the keyboard.
24h		Set segment-register addressability to 4 GB.
28h	1-3-3-1	Using the table of configurations supplied by the specific chipset module, test each DRAM configuration to see if that particular configuration is valid. Then program the chipset to its autosized configuration. Before autosizing, disable all caches and all shadow RAM.
29h	1-3-3-2	Initialize the POST Memory Manager.
2Ah		Zero the first 512K of RAM.
2Ch	1-3-4-1	Test 512K base address lines.
2Eh	1-3-4-3	Test first 512K of RAM.
2Fh		Initialize external cache before shadowing.
32h		Compute CPU speed.
33h		Initialize the Phoenix Dispatch Manager.
34h	1-4-2-1	CMOS test.
36h		Vector to proper shutdown routine.
38h		Shadow the system BIOS.
3Ah		Autosize external cache and program cache size for enabling later in POST.

Checkpoint Code	Beep Code	Description
3Ch		If CMOS is valid, load chipset registers with values from CMOS, otherwise load defaults and display Setup prompt. If Auto Configuration is enabled, always load the chipset registers with the Setup defaults.
3Dh		Load alternate registers with CMOS values. Register-table pointers are in the altreg-table segment.
41h		Initialize extended memory for RomPilot.
42h		Initialize interrupt vectors 0 thru 77h to the BIOS general interrupt handler.
45h		Initialize all motherboard devices.
46h	2-1-2-3	Verify the ROM copyright notice
47h		Initialize support for I2O by initializing global variables used by the I2O code. Pause POST table processing if a CMOS bit is set (for debugging).
48h		Verify that the equipment specified in the CMOS matches the hardware currently installed. If the monitor type is set to 00 then a video ROM must exist. If the monitor type is 1 or 2 set the video switch to CGA. If monitor type 3, set the video switch to mono. Also specify in the equipment byte that disk drives are installed. Set appropriate status bits in CMOS or the BDA if configuration errors are found.

Checkpoint Code	Beep Code	Description
49h		Perform these tasks: <ol style="list-style-type: none"> 1. Size the PCI bus topology and set bridge bus numbers 2. Set the system max bus number 3. Write a 0 to the command register of every PCI device 4. Write a 0 to all 6 base registers in every PCI device 5. Write a -1 to the status register of every PCI device 6. Find all IOPs and initialize them.
4Ah		Initialize all video adapters in system.
4Bh		Initialize QuietBoot if it is installed. Enable both keyboard and timer interrupts (IRQ0 and IRQ1). If your POST tasks require interrupts off, preserve them with a PUSHF and CLI at the beginning and a POPF at the end. If you change the PIC, preserve the existing bits.
4Ch		Shadow video BIOS ROM if specified by Setup, and CMOS is valid and the previous boot was OK.
4Eh		Display copyright notice.
4Fh		Initialize MultiBoot. Allocate memory for old and new MultiBoot history tables.
50h		Display CPU type and speed.
51h		Checksum CMOS and initialize each EISA slot with data from the initialization data block.
52h		Verify keyboard reset.
54h		Initialize keystroke clicker if not enabled in Setup.
55h		Enable USB devices.

Checkpoint Code	Beep Code	Description
58h	2-2-3-1	Test for unexpected interrupts. First do an STI for hot interrupts. Secondly, test the NMI for an unexpected interrupt. Thirdly, enable the parity checkers and read from memory, checking for an unexpected interrupt.
59h		Register POST Display Services, fonts, and languages with the POST Dispatch Manager.
5Ah		Display prompt "Press F2 to enter SETUP."
5Bh		Disable CPU cache.
5Ch		Test RAM between 512K and 640K.
60h		Determine and test the amount of extended memory available. Determine if memory exists by writing to a few strategic locations and see if the data can be read back. If so, perform an address-line test and a RAM test on the memory. Save the total extended memory size in the CMOS at cmosExtended.
62h		Perform an address line test on A0 to the amount of memory available. This test is dependent on the processor, since the test will vary depending on the width of memory (16 or 32 bits). This test will also use A20 as the skew address to prevent corruption of the system memory.
64h		Jump to UserPatch1. See "The POST Component."
66h		Set cache registers to their CMOS values if CMOS is valid, unless auto configuration is enabled, in which case load cache registers from the Setup default table.
67h		Quick initialization of all Application Processors in a multi-processor system.

Checkpoint Code	Beep Code	Description
68h		Enable external cache and CPU cache if present. Configure non-cacheable regions if necessary. NOTE: Hook routine must preserve DX, which carries the cache size to the DisplayCacheSizeJ routine.
69h		Initialize the handler for SMM.
6Ah		Display external cache size on the screen if it is non-zero. NOTE: Hook routine must preserve DX, which carries the cache size from the cache-ConfigureJ routine.
6Bh		If CMOS is bad, load Custom Defaults from flash into CMOS. If successful, reboot.
6Ch		Display shadow message.
6Eh		Display the starting offset of the non-disposable segment of the BIOS.
70h		Check flags in CMOS and in the BIOS data area for errors detected during POST. Display error messages on the screen.
72h		Check status bits to see if configuration problems were detected. If so, display error messages on the screen.
76h		Check status bits for keyboard-related failures. Display error messages on the screen.
7Ch		Initialize the hardware interrupt vectors from 08 to 0F and from 70h to 77h. Also set the interrupt vectors from 60h to 66h to zero.
7Dh		Initialize Intelligent System Monitoring.

Checkpoint Code	Beep Code	Description
7Eh		The Coprocessor initialization test. Use the floating point instructions to determine if a coprocessor exists instead of the ET bit in CR0.
80h		Disable onboard COM and LPT ports before testing for presence of external I/O devices.
81h		Run late device initialization routines.
82h		Test and identify RS232 ports.
83h		Configure Fisk Disk Controller.
84h		Test and identify parallel ports.
85h		Display any ESCD read errors and configure all PnP ISA devices.
86h		Initialize onboard I/O and BDA according to CMOS and presence of external devices.
87h		Initialize motherboard configurable devices.
88h		Initialize interrupt controller.
89h		Enable NMI.
8Ah		Initialize Extended BIOS Data Area and initialize the mouse.
8Bh		Setup interrupt vector and present bit in Equipment byte.
8Ch		Initialize both of the floppy disks and display an error message if failure was detected. Check both drives to establish the appropriate diskette types in the BIOS data area.
8Fh		Count the number of ATA drives in the system and update the number in bdaFdiskcount.

Checkpoint Code	Beep Code	Description
90h		Initialize hard-disk controller. If the CMOS RAM is valid and intact, and fixed disks are defined, call the fixed disk init routine to initialize the fixed disk system and take over the appropriate interrupt vectors.
91h		Configure the local bus IDE timing register based on the drives attached to it.
92h		Jump to UserPatch2.
93h		Build MPTABLE for multi-processor boards.
95h		<ol style="list-style-type: none"> 1. Check CMOS for CD-ROM drive present 2. Activate the drive by checking for media present 3. Check sector 11h (17) for Boot Record Volume Descriptor 4. Check the boot catalog for validity 5. Pick a boot entry 6. Create a Specification Packet
96h		Reset segment-register addressability from 4GB to normal 64K by generating a Shutdown 8.
97h		Create pointer to MP table in Extended BDA.
98h	1-2	Search for option ROMs. ROM scan the area from C800h for a length of BCP_ROM_Scan_Size (or to E000h by default) on every 2K boundary, looking for add on cards that need initialization.
99h		Check support status for Self-Monitoring Analysis Reporting Technology (disk-failure warning).
9Ah		Shadow miscellaneous ROMs if specified by Setup and CMOS is valid and the previous boot was OK.

Checkpoint Code	Beep Code	Description
9Ch		Set up Power Management. Initiate power - management state machine.
9Dh		Initialize Security Engine.
9Eh		Enable hardware interrupts.
9Fh		Check the total number of Fast Disks (ATA and SCSI) and update the bdaFdiskCount.
A0h		Verify that the system clock is interrupting.
A2h		Setup Numlock indicator. Display a message if key switch is locked.
A4h		Initialize the typematic rate.
A8h		Overwrite the "Press F2 for Setup" prompt with spaces, erasing it from the screen.
AAh		Scan the key buffer to see if the F2 key was struck after keyboard interrupts were enabled. If an F2 keystroke is found, set a flag.
ACh		Enter SETUP If (F2 was pressed) go to SETUP Else if (errors were found) display "Press F1 or F2" prompt if (F2 is pressed) go to setup else if (F1 is pressed) boot Else boot
A Eh		Clear ConfigFailedBit and InPostBit in CMOS.

Checkpoint Code	Beep Code	Description
B0h		Check for errors If (errors were found) beep twice display "F1 or F2" message if (F2 keystroke) go to SETUP if (F1 keystroke) go to BOOT
B1h		Inform RomPilot about the end of POST.
B2h		Change status bits in CMOS and/or the BIOS data area to reflect the fact that POST is complete.
B4h		One quick beep.
B5h		Turn off <Esc> and <F2> key checking. IF (VGA adapter is present) IF (OEM screen is still up) Note OEM screen is gone. Fade out OEM screen. Reset video: clear screen, reset cursor, reload DAC. ENDIF ENDIF
B6h		If password on boot is enabled, a call is made to Setup to check password. If the user does not enter a valid password, Setup does not return.
B7h		Initialize ACPI BIOS.
B9h		Clear all screen graphics before booting.
BAh		Initialize the SMBios header and sub-structures.
BCh		Clear parity-error latch.
BDh		Display Boot First menu if MultiBoot is installed.

Checkpoint Code	Beep Code	Description
BEh		If BCP option is enabled, clear the screen before booting.
BFh		Check virus and backup reminders. Display System Summary.
C0h		Try to boot with INT 19.
C1h		Initialize the Post Error Manager.
C2h		Write PEM errors.
C3h		Display PEM errors.
C4h		Initialize system error handler.
C5h		PnPnd dual CMOS (optional).
C6h		Initialize note dock.
C7h		Initialize note dock late.
C8h		Force check (optional).
C9h		Extended checksum (optional).
CAh		Redirect Int 15h to enable target board to use remote keyboard (PICO BIOS).
CBh		Redirect Int 13h to Memory Technologies Devices such as ROM, RAM, PCMCIA, and serial disk (PICO BIOS).
CDh		Redirect Int 10h to enable target board to use a remote serial video (PICO BIOS).
CEh		Initialize digitizer device and display installed message if successful.
D2h		Unknown interrupt.
Dfh	4-2-4-4	A20 test error.
E0h		Initialize the chipset.

Checkpoint Code	Beep Code	Description
E1h		Initialize the bridge.
E2h		Initialize the CPU.
E3h		Initialize system timer.
E4h		Initialize system I/O.
E5h		Check force recovery boot.
E6h		Checksum BIOS ROM.
E7h		Go to BIOS.
E8h		Initialize Multi-Processor
E9h		Set huge segment.
EAh		Initialize OEM special code.
EBh		Initialize PIC and DMA.
ECh		Initialize Memory type.
EDh		Initialize Memory size.
EEh		Shadow Boot Block.
EFh		System memory test.
F0h		Initialize interrupt vectors.
F1h		Initialize Run Time Clock.
F2h		Initialize video.
F3h		Initialilze System Management Mode.
F4h		Output one beep.
F5h		Boot to Mini DOS.
F6h		Clear Huge Segment.

Checkpoint Code	Beep Code	Description
F7h		Boot to Full DOS.

Index

A

- Acer Server Manager (ASM) 161
 - system requirements 161
 - ASM Agent 161
 - ASM Console 161
 - system setup 161
 - install ASM Agent 162
 - install ASM Console 162

B

- BIOS POST Checkpoint Codes 179, 185
- BIOS setup 27, 89, 145
 - Advanced 95
 - Boot Settings Configuration 118
 - PCI Configuration 113
 - Peripheral Configuration 118

C

- Caring features 6

E

- ESD precautions 34
- External 16

F

- Front panel 16, 22

G

- Graphics 4

I

- I/O ports 4
- Installation precautions 34
- Installing a CPU 45, 47, 59, 61, 77
- Installing a hard disc 43
- Installing and removing storage devices 42
- Installing expansion cards 39, 41
- Internal components 23

J

- Jumper (JP1) settings 14

M

- Memory 3
 - installing 81
 - reconfiguring 81
 - removing 80

N

- Networking 4
- Notices iii

O

- opening the system 36
- Opening your system 36

P

- package contents 27
- Post-installation instructions 35
- Preinstallation instructions 34
- Preinstallation requirements 27
- Processor 3
- Product 3
- Product specifications 7

R

- Rack installation 171
 - Screw types 170
- Rear panel 21
- Removing a CPU 79
- Removing a hard disc 42
- removing the top panel 37
- replacing the top cover 38

S

- Secure mode 127, 128
- Serial ATA ports 5
- Storage 4
- system upgrade 33
 - ESD precautions 34
 - post-installation instructions 35
 - preinstallation instructions 34

T

- turning off the system 28
- turning on the system 28
 - power-on problems 29

U

Upgrading the CPU 45, 62, 80

Upgrading the system 33