

JP7 - IDE fixed disk interface enable Disable Enable**JP8 - IDE fixed disk interface address** 3F6, 3F7, 1F0-1F7 376, 377, 170-177**JP9 - Floppy drive interface enable** Disable Enable**JP10 - Floppy drive interface address** 3F0-3F7 370-377**JP11 - Floppy drive select**

This jumper allows you to swap the designation of the drives in your system. When swap A/B is selected drive A will now be B and drive B will now be A.

 Swap A / B Normal operation**JP12 - Printer port interrupt** IRQ5 IRQ7**JP13, JP14 - Serial port interrupt** Serial port 1 IRQ4, Serial port 2 IRQ3 Serial port 1 IRQ3, Serial port 2 IRQ4**JP15, JP16 - Serial port 1 configuration**

JP15 JP16

  Disable  COM1, address 3F8H  COM3, address 3E8H  COM4, address 2E8H**JP17, JP18 - Serial port 2 configuration**

JP17 JP18

  Disable  COM2, address 2F8H  COM3, address 3E8H  COM4, address 2E8H