

# 4D845A

## User's Manual Version 1.0

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.  
Socket478 is a trademark of Intel Corporation  
AWARD is a registered trademark of Phoenix Software Inc.  
MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

**Trademarks and/or registered trademarks are the properties of their respective owners.**

---

## Table of Contents

### Introduction

### 1. Motherboard Description

1.1 Introduction	1-1
1.2 Package Contents	1-1
1.3 Features	1-2
1.4 4D845A Motherboard Layout	1-4
1.5 CPU Installation	1-7
1.6 DDR DRAM Installation	1-8
1.7 Connectors & Jumper Setting	
1.7.1 Back Panel Connectors	
1.7.1.1 PS/2 Mouse/Keyboard CONN.	1-9
1.7.1.2 USB Connector (USB1)	1-9
1.7.1.3 Serial Interface ports	1-10
1.7.1.4 Parallel Interface port	1-10
1.7.1.5 Joystick / Midi Connector	1-10
1.7.1.6 Audio Port Connector	1-10
1.7.2 ATX 4-pin/20-pin Power Conn.: J8/CN9/ATX	1-10
1.7.3 Floppy Disk Connector: FDC	1-12
1.7.4 Hard Disk Connectors: IDE1/IDE2	1-12
1.7.5 CPU Fan Connectors: FAN1/2/3	1-12
1.7.6 CD-Audio-IN Connector: CDIN1/CDIN2	1-13
1.7.7 Wake-On-LAN Header: WOL	1-14
1.7.8 Telephone in Connector: TAD (optional)	1-14
1.7.9 Front USB2 Connector: USB2	1-15
1.7.10 Front Panel Connector: PANEL1	1-15
1.7.11 CMOS Function Selection: JP7	1-17
1.7.12 CPU Clock Freq. Setting: J2	1-18
1.7.13 AGP 4X/1.5V Protect: JP9	1-19
1.7.14 Onboard AC'97 Setting: JP11	1-19
1.7.15 Smart Panel Function (optional)	1-20

## Table of Contents

1.7.15.1 Port 80 Debug Function(ERR)	1-20
1.7.15.2 Second BIOS Connector(JP5)	1-21
1.7.15.3 AUX LINE Connector(JP2)	1-21
1.7.15.4 Front COM2 Header Conn.(JP8)	1-21
1.7.15.5 Front USB3,4 Header Conn.(USB2)	1-21

## 2. BIOS Setup

2.1 Main Menu	2-4
2.2 Standard CMOS Features	2-7
2.3 Advanced BIOS Features	2-10
2.4 Advanced Chipset Features	2-14
2.5 Integrated Peripherals	2-18
2.6 Power Management Setup	2-24
2.7 PnP/PCI Configurations	2-28
2.8 PC Health Status	2-32
2.9 Frequency/Voltage Control	2-34
2.10 Load Fail-Safe Defaults	2-35
2.11 Load Optimized Defaults	2-36
2.12 Set Supervisor/user Password	2-37
2.13 Save & Exit Setup	2-39
2.14 Exit Without Saving	2-40

## 3. Driver Installation

3.1 Auto-run Menu	3-1
3.2 Installing Intel INF Driver	3-2
3.3 Installing Intel Application Accelerator Driver	3-4
3.4 Installing Audio Driver	3-8

## a. Appendix