

694XA

User's Manual Version 1.0

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Socket370 is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Features	
1.1.1 Hardware	2
1.1.2 Software	4
1.1.3 Attachments	4
1.2 Motherboard Installation	
1.2.1 Layout of Motherboard	5
1.3 Motherboard Connectors	
1.3.1 Front Panel Connectors(PANEL1)	7
1.3.2 Floppy Disk Connector(FDC1)	8
1.3.3 Hard Disk Connectors(IDE1/IDE2)	8
1.3.4 ATX 20-pin Power Connector(PW1)	9
1.3.5 Infrared Connector(IR1)	9
1.4 Back Panel Connectors	
1.4.1 PS/2 Mouse/Keyboard CONN.	10
1.4.2 USB Connectors	10
1.5 Serial and Parallel Interface ports	12
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 370)	14
1.6.2 CPU Frequency Selection(CLK1)	15
1.7 Jumper Setting	
1.7.1 CPU Fan Connector(FAN1/2)	16
1.7.2 Wake-On-Modem Header(WOM1)	17
1.7.3 Wake-On-LAN Header(WOL1)	17
1.7.4 AMR Set Function(J1)	17
1.7.5 CMOS Function Select(CMOS1)	17
1.8 DRAM Installation	
1.8.1 DIMM	18
1.8.2 How to install a DIMM Module	18

Table of Contents

1.9 Audio Subsystem	
1.9.1 CD-Audio-IN Connectors(CDIN1/CDIN2)	19
1.10 Smart Panel Onboard Connector (option)	
1.10.1 System State Show Connector(J2)	21
1.10.2 Second BIOS Connector(BIOS1)	21
1.10.3 Port 80 Debug Function Connector (ERR1/JP1)	22

2. BIOS Setup

2.1 Main Menu	26
2.2 Standard CMOS Features	29
2.3 Advanced BIOS Features	32
2.4 Advanced Chipset Features	36
2.5 Integrated Peripherals	41
2.6 Power Management Setup	46
2.7 PnP/PCI Configurations	52
2.8 PC Health Status	56
2.9 Frequency/Voltage Control	57
2.10 Load Fail-Safe Defaults	59
2.11 Load Optimized Defaults	60
2.12 Set Supervisor/user Password	61
2.13 Save & Exit Setup	63
2.14 Exit Without Saving	64