

Table of Contents

| | |
|------------------------------------------------------------|-----------|
| Overview | 1 |
| Features | 1 |
| <i>Pentium-MMX Performance</i> | <i>1</i> |
| <i>Highly Integrated Support Chipset.....</i> | <i>1</i> |
| <i>SDRAM Memory Support</i> | <i>1</i> |
| <i>Integrated Audio & Video Sub-systems</i> | <i>2</i> |
| <i>Three Usable Expansion Slots.....</i> | <i>2</i> |
| <i>Full Set of I/O Ports</i> | <i>2</i> |
| <i>Programmable Firmware</i> | <i>2</i> |
| Mainboard Illustration | 3 |
| Key to Mainboard Components | 3 |
| I/O Port Array Illustration | 4 |
| Key to I/O Port Components | 4 |
| Installation Procedure | 5 |
| Prepare the Mainboard | 5 |
| <i>Install the Processor.....</i> | <i>5</i> |
| Install the Memory Modules..... | 5 |
| Check the Jumper Settings | 6 |
| <i>CPU Setting</i> | <i>6</i> |
| <i>JP1: Set CPU Voltage Jumper.....</i> | <i>7</i> |
| <i>J2: Set PCI Bus Speed Jumper.....</i> | <i>7</i> |
| <i>J8: Set CPU Clock Speed Jumper</i> | <i>7</i> |
| <i>J18: Clear CMOS Memory Jumper.....</i> | <i>8</i> |
| Make the Internal Connections | 8 |
| Make the Optional Internal Connections | 9 |
| System BIOS | 10 |
| <i>Standard CMOS Setup.....</i> | <i>10</i> |
| <i>BIOS Features Setup</i> | <i>10</i> |
| <i>Chipset Features Setup.....</i> | <i>10</i> |
| <i>Power Management Setup</i> | <i>11</i> |
| <i>PNP/PCI Configuration.....</i> | <i>11</i> |
| <i>Load BIOS Defaults.....</i> | <i>11</i> |
| <i>Load Setup Defaults</i> | <i>11</i> |
| <i>Integrated Peripherals.....</i> | <i>11</i> |
| <i>Supervisor Password and User Password</i> | <i>11</i> |
| <i>IDE Auto Detection</i> | <i>11</i> |
| <i>Save & Exit Setup and Exit Without Saving</i> | <i>11</i> |
| System Software..... | 12 |
| Installing the Audio Driver..... | 12 |
| Installing the Graphics Driver..... | 12 |
| PCI Bridge Driver..... | 13 |