

## **Important Information**

---

### **Copyright**

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without the express written consent of the manufacturer.

Version 1.0

### **Disclaimer**

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further, the manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

### **Trademark Recognition**

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corp.

MMX, Pentium, Pentium-II, Pentium-III, Celeron are registered trademarks of Intel Corporation.

Other product names used in this manual are the properties of their respective owners and are acknowledged.

## **Federal Communications Commission (FCC)**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment onto an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interconnect cables and a shielded AC power cable must be employed with this equipment to ensure compliance with the pertinent RF emission limits governing this device. Changes or modifications not expressly approved by the system's manufacturer could void the user's authority to operate the equipment.

## **Declaration of Conformity**

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

## Canadian Department of Communications

This class B digital apparatus meets all requirements of the Canadian Interference-causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

### About the Manual

---

The manual consists of the following chapters:

#### **Introduction**

Use the **Introduction** Chapter to learn about the features of the mainboard and view a checklist of items that are shipped with the package.

#### **Installation**

Use the **Installation** Chapter to learn how to install the mainboard and get your system up and running.

#### **Setup**

Use the **Setup** Chapter to configure the mainboard for optimum performance.

#### **Software**

Use the **Software** Chapter to learn how to use the software drivers and support programs that are provided with this mainboard.

# Contents

---

<b>IMPORTANT INFORMATION</b>	<b>I</b>
Copyright	i
Disclaimer	i
Trademark Recognition	i
Federal Communications Commission (FCC)	ii
Declaration of Conformity	ii
Canadian Department of Communications	iii
<b>ABOUT THE MANUAL</b>	<b>III</b>
<b>CHAPTER 1: INTRODUCTION</b>	<b>1</b>
<b>WELCOME</b>	<b>1</b>
<b>CHECKLIST</b>	<b>2</b>
<b>RECOMMENDATIONS</b>	<b>3</b>
<b>FEATURES</b>	<b>4</b>
<b>CHAPTER 2: INSTALLATION</b>	<b>7</b>
<b>QUICK INSTALLATION TABLE</b>	<b>7</b>
<b>QUICK JUMPER SETTINGS REFERENCE</b>	<b>8</b>
<b>BEFORE YOU BEGIN</b>	<b>11</b>
Static Electricity	11
Choosing a Case	11
How to Set Jumpers	12
<b>PREPARING THE MAINBOARD</b>	<b>13</b>
Mainboard Guide	13
I/O Ports Side View	15
Check the Jumper Settings	16
Installing the Mainboard in a Case	19
Connecting Internal Components	20
<b>INSTALLING OTHER HARDWARE</b>	<b>22</b>
Installing the Processor	22
Installing a Processor	22
Install the Memory Modules	24

Installing a Hard Disk Drive and CD-ROM	25
Installing a Floppy Diskette Drive	28
Using the Expansion Slots	29
Other Options	31
Making External Connections	34
External Connector Color Coding	35
<b>CHAPTER 3: SETUP</b>	<b>37</b>
<b>ABOUT THE SETUP UTILITY</b>	<b>37</b>
Entering the Setup Utility	39
BIOS Navigation Keys	40
Using BIOS	41
How to Flash a New BIOS	42
Standard CMOS Features Option	43
Advanced BIOS Features Setup Option	46
Advanced Chipset Features Option	49
Integrated Peripherals Option	53
Power Management Setup Option	56
PnP/PCI Configurations Option	61
PC Health Status Option	62
Frequency Control Option	64
Load Fail-Safe Defaults Option	65
Load Optimized Defaults Option	65
Set Supervisor and User Passwords Options	66
Save & Exit Setup Option	67
Exit Without Saving Option	67
<b>CHAPTER 4: SOFTWARE</b>	<b>69</b>
<b>ABOUT THE SOFTWARE</b>	<b>69</b>
<b>FOLDERS FOR THIS MAINBOARD</b>	<b>69</b>
<b>AUTO-INSTALLING UNDER WINDOWS 98</b>	<b>71</b>
<b>UTILITY FOLDER INSTALLATION NOTES</b>	<b>75</b>
Award Flash Memory Utility	75
GAMUT	75
MediaRing Talk	75

PC-Cillin Software	75
Super Voice	76
<b>CMI8X38 FOLDER INSTALLATION NOTES</b>	<b>76</b>
Audio_ITE_GAME Software	76
<b>INTEL FOLDER INSTALLATION NOTES</b>	<b>79</b>
<b>MAINBOARD (P6ISM) INSTALLATION NOTES</b>	<b>79</b>
<b>APPENDIX: JUMPER SETTING REFERENCE</b>	<b>81</b>
Jumper Setting Quick Reference	81

# Chapter 1: Introduction

## Welcome

---

Congratulations on purchasing the P6ISM mainboard. The P6ISM mainboard is a Micro ATX mainboard that uses a 4-layer printed circuit board and measures 222 mm x 244 mm. The mainboard has a Socket 370 for FC-PGA Intel Celeron or FC-PGA Pentium III processors that support frontside bus (FSB) speeds up to 133 MHz. The P6ISM is installed with the Intel 815 chipset.

The mainboard delivers high-level performance with a 4xAGP (Accelerated Graphics Port) slot and two Bus Master Ultra DMA (UDMA) ports that support up to four ATAPI (AT Attachment Packet Interface) devices. The PCI IDE also supports PIO Mode 3 and 4, UDMA33/66 IDE, and an ATAPI CD-ROM. The mainboard accommodates PC 100 and PC 133 SDRAM (Synchronous DRAM) up to 512 MB using two 3.3V unbuffered DIMM modules.

Other features include an embedded 10Base-T/100Base-TX network interface, a built-in PCI 3D sound system, and a V.90 fax/modem DAA module. The mainboard has a full set of I/O ports, such as dual-channel IDE interfaces, a floppy controller, one FIFO serial port connector, a VGA port, an EPP/ECP-capable bi-directional parallel port connector, a dual USB (Universal Serial Bus) connector, and PS/2 keyboard and mouse connectors.

Two extra USB ports can be added using the extended USB module that connects to the mainboard. An extra COM port can be connected using an extension bracket.

One AGP slot, three PCI local bus slots and an optional TV-out/LCD panel link riser slot provide expandability for add-in expansion cards.

This chapter contains the following information:

- Checklist** comprises a list of the standard and optional components that are shipped with this mainboard
- Recommendations** lists some Do's and Don'ts from the manufacturer to help ensure reliability and performance from this product
- Features** highlights the functions and components that make this one of the best value mainboards on the market

## Checklist

---

Compare the contents of your mainboard package with the standard checklist below. If any item is missing or appears damaged, please contact the vendor of your mainboard package.

### ***Standard Items***

- One P61SM mainboard
- One diskette drive ribbon cable and bracket
- One IDE drive ribbon cable and bracket
- This user's manual
- Software support CD-ROM disc

### ***Optional items***

- One V.90 fax/modem card

## Recommendations

---

This mainboard automatically determines the CPU clock frequency and system bus frequency for the kind of processor that you install. You may be able to change these automatic settings by changing the settings in the system Setup Utility. We strongly recommend that you do not overclock the mainboard to run processors or other components faster than their rated speed.

---

**Warning:** *Overclocking components can adversely affect the reliability of the system and introduce errors into your system. Overclocking can permanently damage the mainboard by generating excess heat in components that are run beyond the rated limits.*

Components on this mainboard can be damaged by discharges of static electricity. Handle the board carefully holding it by the edges. Don't flex or stress the circuit board. Keep the board in its static-proof packing until you are ready to install it. Follow the static guidelines given at the beginning of Chapter 2.

## Features

---

The key features of this mainboard are the wide range of processors that can be installed, and the high level of integration, which includes built-in audio, video, networking, and communications.

### ***Processors***

Functioning as a platform for a value PC, the P6ISM features a Socket 370 accommodating FC-PGA Celeron 533 MHz (533A) and higher CPUs that support a 66 MHz FSB as well as FC-PGA Pentium III CPUs that support a 100 or 133 MHz FSB.

### ***Intel's 815 Chipset***

This board features the 815 chipset from Intel. The 815 chipset is designed for high-end desktops and workstations and provides ATA-66, 4xAGP and SDRAM support.

The 82801AA I/O Controller Hub makes a direct connection between the graphics system, the IDE controller, and the PCI bus. It uses Accelerated Hub Architecture to effectively double the bandwidth between these components enabling more lifelike audio and video.

The 82802 Firmware Hub allows the system and video BIOS to be stored (eliminating the need for non-volatile CMOS memory) for faster execution, and provides a random number generator to enable strong encryption routines.

### ***Inexpensive Memory***

The board has two DIMM sockets for the installation of 168-pin, 3.3V non-buffered DIMM memory modules. The DIMM memory modules must use SDRAM memory chips. The P6ISM board supports a memory bus of 100 MHz or 133 MHz.

Each installed memory module can be populated with from 32 to 512 MB of memory; a maximum of 512 MB memory can be installed. The integrated video system uses shared memory architecture, so you must reserve some of the installed memory as video memory using the system BIOS. You must install at least one module, but it makes no difference which slot you use to install the module.

### ***4xAGP Graphics Adapter Slot***

In addition to the onboard Accelerated Graphics Port (AGP) capability provided by 82815 (Graphics and Memory Controller Hub), the P6ISM includes a 4xAGP slot to support an AGP card that provides four times the bandwidth of the original AGP specification. AGP technology provides a direct connection between the graphics sub-system and the processor so that the graphics do not have to compete for processor time with other devices on the PCI bus. The AGP design allows the graphics controller to use part of the main memory when it needs it, for example, in handling the very large texture maps required by virtual reality and 3D video games and applications.

### ***Built-in PCI 3D Sound***

The built-in PCI Audio CMI8738 is a single-chip solution for PCI-bus 3D audio. The chip provides Sound Blaster 16-bit-compatible audio, plus support for Microsoft's DirectSound 3D specification and the Aureal A3D interface. The sound ports include speaker, microphone, and stereo-jacks and a MIDI/game port. The audio system supports full-duplex operation. Drivers are available for WIN 200/98/95/NT 4.0 and Linux.

### ***Built-in V.90 fax/modem function***

The built-in CMI8738 chip is a single chip solution for value PC communications and integrates with the built-in audio system to support voice as well as data transmission. The chip supports 56 Kbps transmission using the V.90 protocol. Plugging an optional card (with RJ-11 line and telephone sockets) onto the mainboard facilitates the modem.

## ***Expansion Options***

The P6ISM mainboard is pre-installed with features such as audio and an optional DAA module for a modem that normally require add-in cards. The three 32-bit PCI slots provide expansion options.

## ***Built-in Ethernet LAN***

The onboard 10Base-T/100Base-TX Ethernet LAN controller integrates IEEE802.3u compliant Fast Ethernet MAC and PHY. The controller is also compliant with the ACPI Power Management 1.0 protocol and enables high performance data transfers through a 100 Mbps clock generator and data recovery circuit for 100 Mbps receiver. The board supports 10/100 Mbps N-Way auto-negotiation operation.

## ***Integrated I/O***

The mainboard has a full set of I/O ports and connectors. The I/O template on the backplane includes two PS/2 ports for mouse and keyboard, one serial port, one VGA port, one parallel port, one MIDI/game port, two USB ports, a LAN port, and audio jacks for microphone, line-in and line-out. The board has a header for the optional installation of an IR port. An extra COM port can be connected using an extension bracket. The board includes two IDE channels and a floppy disk drive interface.

## ***Programmable Firmware***

The mainboard includes BIOS that allows firmware setting of CPU parameters. The fully programmable firmware enhances the system features and allows users to set power management, CPU and memory timing, and LAN and modem wake-up alarms. The firmware can also be used to set parameters for different processor clock speeds so that you don't need to change mainboard jumpers and switches.

This concludes Chapter 1. The next chapter covers installing and building a working system.

## Chapter 2: Installation

### Quick Installation Table

---

This chapter explains how to successfully install the mainboard into a computer case and build a working system. The installation procedure is as follows:

<b>Quick Jumper Setting Reference</b>	Provides a quick reference for the jumper settings on this mainboard.
<b>Before you Begin</b>	Provides advice on choosing a case, avoiding static electricity damage, and setting jumpers.
<b>Preparing the Mainboard</b>	Provides a guide to the mainboard and I/O port locations, full details on the jumper settings, and advice on installing the mainboard in the system case.
<b>Install Other Hardware</b>	Provides guidance on installing essential hardware: processor, memory, hard disk drive, CD-ROM, floppy disk drive, and expansion cards.
<b>Make External Connections</b>	Provides advice on using the external I/O ports to install peripheral devices such as a keyboard, a monitor, a mouse, a printer, and loudspeakers.

## Quick Jumper Settings Reference

If you are familiar with most of the material in this chapter, you can prepare the mainboard for installation by using this quick reference to set the jumpers. A detailed description of the jumper settings appears later in this chapter.

### **JP1: CPU frequency select jumper**

Use this jumper to force a 66 MHz CPU to run at 100 MHz.

Function	Jumper Setting
Normal operation	Short pins 1-2
Force 66 MHz CPU to run at 100 MHz	Short pins 2-3



### **JP2: CPU frequency select jumper**

Use this jumper to force a 100 MHz CPU to run at 133 MHz.

Function	Jumper Setting
Normal operation	Short pins 1-2
Force 100 MHz CPU to run at 133 MHz	Short pins 2-3



### **JP3: Clear BIOS jumper**

Use this 3-pin jumper to clear the system BIOS.

Function	Jumper Setting
Normal operation	Short pins 1-2
Clear CMOS	Short pins 2-3



### **JP4: BIOS flash protect jumper**

Use this 2-pin jumper to protect the system BIOS from being accidentally flashed (updated).

Function	Jumper Setting
Protect	Short
Unprotect	Open



**JP5: Keyboard power on jumper**

Use this 3-pin jumper to enable the keyboard to power on the computer.

Function	Jumper Setting
Enable	Short pins 1-2
Disable	Short pins 2-3



**JP7: USB wakeup jumper**

Use this 3-pin jumper to enable a USB signal to wake up the computer from a power saving mode.

Function	Jumper Setting
Enable	Short pins 1-2
Disable	Short pins 2-3



**JP8: Front Panel USB wakeup jumper**

Use this 3-pin jumper to enable a USB signal from the front panel to wake up the computer from a power saving mode.


Function	Jumper Setting
Enable	Short pins 1-2
Disable	Short pins 2-3



**PANEL1: Panel connectors for switches and indicators**

Use the panel connector to implement the switches and indicators on your system case.

Function	Pins
Speaker	1, 3, 5, 7
Power LED	+2, 4, 6
Keylock	8, 10
Green LED	+13, 14
Hard Disk LED	+15, 16
Reset Switch	17, 18
System Management Interrupt (SMI) Button	+19, 20
Power Button	21, 22



## Before You Begin

---

During installation, avoid damaging the mainboard with static electricity. Ensure that you are installing the mainboard into a suitable case.

### Static Electricity

In adverse conditions, static electricity can accumulate and discharge through the integrated circuits and silicon chips on this product. These circuits and chips are sensitive and can be permanently damaged by static discharge.

- If possible, wear a grounding wrist strap clipped to a safely grounded device during the installation.
- If you don't have a wrist strap, discharge any static by touching the metal case of a safely grounded device before beginning the installation.
- Leave all components inside their static-proof bags until they are required for the installation procedure.
- Handle all circuit boards and electronic components carefully. Hold boards by the edges only. Do not flex or stress circuit boards.


### Choosing a Case

The mainboard complies with the specifications for the Micro ATX system case. Some features on the mainboard are implemented by cabling connectors on the mainboard to indicators and switches on the system case. Ensure that your case supports all the features required. The P6ISM mainboard can support one or two floppy diskette drives and four enhanced IDE drives. Ensure that your case has sufficient power and space for all the drives that you intend to install.


The mainboard has a set of I/O ports on the rear edge. Ensure that your case has an I/O template that supports the I/O ports and expansion slots.

## How to Set Jumpers


A jumper consists of two or more pins mounted on the mainboard. Some jumpers might be arranged in a series with each pair of pins numbered differently. Jumpers are used to change the electronic circuits on the mainboard. When a jumper cap (or shunt) is placed on two jumper pins, the pins are **SHORT**. If the jumper cap is removed (or placed on just a single pin), the pins are **OPEN**.



This illustration shows a 2-pin jumper. When the jumper cap is placed on both pins, the jumper is **SHORT**. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is **OPEN**.



This illustration shows a 3-pin jumper. The jumper cap is placed on pins 2 and 3, so this jumper setting is **SHORT PINS 2-3**.




This illustration shows the same 3-pin jumper. The jumper cap is placed on pins 1 and 2, so this jumper setting is **SHORT PINS 1-2**.

In this manual, all the jumper illustrations clearly show the pin numbers. When you are setting the jumpers, make sure that the jumper caps are placed on the correct pins to select the function or feature that you want to enable or disable.

# Preparing the Mainboard

## Mainboard Guide

Use the following illustration and key to identify the components on your mainboard.




## **Key to Mainboard Components**

<b>Component</b>	<b>Description</b>
Socket 370	CPU Socket
PCI1/2/3	Three 32-bit PCI slots
AGP1	Accelerated Graphics Port slot
DIMM1/2	Two slots for 168-pin SDRAM memory module
FDD1	Connector for floppy disk drives
IDE1, IDE2	Primary and secondary IDE channels
ATX1	Connector for ATX power supply
SIR1	Connector for optional infrared port
PANEL1	Panel connector for switches and indicators
WOM1	Connector for modem wake up
LED1	3VSB LED for SDRAM
CASEFAN1	Power connector for case cooling fan
CPUFAN1	Power connector for CPU cooling fan
MODEM1	Connector for modem DAA module
CD1	Audio connector for CD-ROM/DVD drive
CD2	Auxiliary audio connector for CD-ROM/DVD drive
LTI1	TV-out/LCD panel link riser slot
BT1	3 volt battery for realtime clock
FP1	Extra IR/KB/mouse header
FP2	Extra MIC/line-out header
COM2	COM port header
J1	Chassis open detect jumper
JP1	CPU frequency select jumper (66 ~ 100 MHz)
JP2	CPU frequency select jumper (100 ~ 133 MHz)
JP3	Clear BIOS jumper
JP4	BIOS flash protect jumper
JP5	Keyboard wakeup enable jumper
JP7	USB wakeup enable jumper
JP8	Front panel USB wakeup enable jumper
FPUSB	Extra USB port header

---

**Notes:**

- **LED1:** The red indicator LED1 turns on if your system is still powered to warn you that you cannot install or uninstall memory modules (SDRAM).
- **J1:** This 2-pin jumper is the chassis open detection jumper. A cap on the chassis is released when the chassis is opened causing the jumper to be open, at which time you will receive a warning that the chassis is open at system startup.


**I/O Ports Side View****Key to I/O Ports**

Component	Description
PS/2 mouse	PS/2 port for pointing device (upper port)
PS/2 keyboard	PS/2 port for keyboard (lower port)
LAN	Local Area Network port
USB ports	Two stacked Universal Serial Bus ports
LPT1	External parallel port
COM 1	External serial port COM 1
VGA	VGA port
Game port	External MIDI/game port
Audio ports	Audio jacks for (from left to right) line-out, line-in, microphone

## Check the Jumper Settings

Check all the mainboard jumpers to ensure that the board is configured correctly.

**Note:** Pin 1 is indicated by a "1."



### **JP1: CPU frequency select jumper**

This jumper enables you to force the CPU to clock at a higher frequency than it is rated. Short pins 2 and 3 to force the CPU to run at 100 MHz instead of 66 MHz. We recommend that you leave the jumper on the normal operation setting.

Function	Jumper Setting
Normal operation	Short pins 1-2
Force 66 MHz CPU to run at 100 MHz	Short pins 2-3

The diagram shows a three-pin jumper labeled JP1. The pins are numbered 1, 2, and 3 from left to right. A jumper cap is shown bridging pins 1 and 2.

**Note:** Forcing the CPU to run at a higher clock speed than it was rated for is called *overclocking* and is not recommended.

### ***JP2: CPU frequency select jumper***

This jumper enables you to force the CPU to clock at a higher frequency than it is rated. Short pins 2 and 3 to force the CPU to run at 133 MHz instead of 100 MHz. We recommend that you leave the jumper on the normal operation setting.

Function	Jumper Setting
Normal operation	Short pins 1-2
Force 100 MHz CPU to run at 133 MHz	Short pins 2-3



**Note:** Forcing the CPU to run at a higher clock speed than it was rated for is called *overclocking* and is not recommended.

### ***JP3: Clear BIOS jumper***

This jumper lets you erase the system setup settings that are stored in CMOS memory. You might need to erase this data if incorrect settings are preventing your system from operating. You must first set JP4 to open before you can flash the CMOS.

To clear the CMOS memory, turn off the system, disconnect the power cable from the mainboard, and short the appropriate pins for a few seconds. Then return the jumper to the normal operation setting, and restart the system.


Function	Jumper Setting
Normal operation	Short pins 1-2
Clear CMOS	Short pins 2-3



### ***JP4: BIOS flash protect jumper***

Use this 2-pin jumper to protect the system BIOS from being accidentally flashed (updated).

Function	Jumper Setting
Protect	Short
Unprotect	Open



### ***JP5: Keyboard power on jumper***

Use this 3-pin jumper to enable the keyboard to power on the computer.

Function	Jumper Setting
Enable	Short pins 1-2
Disable	Short pins 2-3



### ***JP7: USB wakeup jumper***

Use this 3-pin jumper to enable a USB signal to wake up the computer from a power saving mode.

Function	Jumper Setting
Enable	Short pins 1-2
Disable	Short pins 2-3



### ***JP8: Front Panel USB wakeup jumper***

Use this 3-pin jumper to enable a USB signal from the front panel to wake up the computer from a power saving mode.

Function	Jumper Setting
Enable	Short pins 1-2
Disable	Short pins 2-3




## Installing the Mainboard in a Case

Most system cases have mounting brackets installed in the case, which correspond to the holes in the mainboard. Place the mainboard over the mounting brackets and drive screws through the mainboard into the mounting brackets.

Most cases have a choice of I/O templates in the rear panel. Make sure that the I/O template in the case matches the I/O ports installed on the rear edge of the mainboard.


This illustration shows a mainboard installed in a standard desktop case.

**Note:** Do not over-tighten the screws as this can stress the mainboard.




This illustration shows a mainboard installed in a tower-type case.

**Note:** Do not over-tighten the screws as this can stress the mainboard.



## Connecting Internal Components


After you have installed the mainboard into the system case, connect the power cable from the case power supply unit to the mainboard power connector ATX1. Connect the CPU/case fans (if your case has them) to CPUFAN1 and CASFAN1 on the mainboard. Then connect the case switches and indicators to the PANEL1 connector.



## Panel Connector

The mainboard PANEL connector has a standard set of switch and indicator connectors that are commonly found on system cases. Use the illustration below to make the correct connections to the case switches and indicators.

Function	Pins
Speaker	1, 3, 5, 7
Power LED	+2, 4, 6
Keylock	8, 10
Green LED	+13, 14
Hard Disk LED	+15, 16
Reset Switch	17, 18
System Management Interrupt (SMI) Button	+19, 20
Power Button	21, 22



## Installing Other Hardware

---


Start installing the essential hardware required to get your system started.

### Installing the Processor


This mainboard has a Socket 370 processor socket. To choose a processor, you need to consider the performance requirements of the system and the price of the processor. Performance is based on the processor design, the clock speed and system bus frequency of the processor, and the quantity of internal cache memory and external cache memory. Higher clock speeds and larger amounts of cache memory deliver greater performance.

### Installing a Processor

To install a processor on the mainboard, refer to the illustrations and follow the steps below.



1. On the mainboard, locate the Socket 370 and CPUFAN1.
2. On the Socket 370, pull the locking lever away from the socket to unhook it and then raise the locking lever to the upright position.



3. Identify the pin-1 corner on the Socket 370 and the pin-1 corner on the processor. The processor pin-1 corner is beveled.
4. Matching the pin-1 corners, drop the processor into the socket. No force is required and the processor should seat into the socket easily.
5. Swing the locking lever down and hook it under the latch on the edge of the socket. This locks the processor in place.
6. Plug the heatsink/cooling fan power cable into the CPUFAN1 connector on the mainboard.

The mainboard must be configured to deliver the correct clock speed and the correct system bus for the kind of processor that you have installed. You can do this by using the *Frequency/Voltage Control* screen in the CMOS (BIOS) Setup Utility. The first time you start the system, immediately enter the Setup Utility and make the appropriate settings. See Chapter 3 for more information.

## Install the Memory Modules


For this mainboard, you must use 168-pin 3.3V non-buffered Dual In-line Memory Modules (DIMMs). The memory chips are standard SDRAM (Synchronous Dynamic Random Access Memory). The table at the right shows the supported frequencies.	Front Side Bus (FSB) Frequency	System Memory Bus (SMB) Frequency
	66 MHz	100 MHz
	100 MHz	100 MHz
	133 MHz	100 MHz
	133 MHz	133 MHz

**Note:** The memory bus runs at either 100 MHz or 133 MHz independent of the system bus frequency.

### *Installation Procedure*

There are two slots for memory modules. You must install at least one module, but it makes no difference which slot you use to install the module.

1. Locate the DIMM slots on the mainboard.



2. The DIMM slots are keyed with notches and the DIMMs are keyed with cutouts so that they can only be installed correctly. Check that the cutouts on the DIMM module edge connector match the notches in the DIMM slot.
3. Push the latches on each side of the DIMM slot down.
4. Install the DIMM module into the slot and press firmly down so that it seats correctly. The latches at either side of the slot will be levered upwards and latch on to the edges of the DIMM when it is installed correctly.

## Installing a Hard Disk Drive and CD-ROM

This section describes how to install IDE devices such as a hard disk drive and a CD-ROM drive.

---

**Note:** *Ribbon cable connectors are usually keyed so that they can only be installed correctly on the device connector. If the connector is not keyed, make sure that you match the pin-1 side of the cable connector with the pin-1 side of the device connector. Each connector has the pin-1 side clearly marked. The pin-1 side of each ribbon cable is always marked with a colored stripe on the cable.*

### **About IDE Devices**

Your mainboard has a primary IDE channel interface (IDE1) and a secondary IDE interface (IDE2). The mainboard ships with one IDE ribbon cable that supports one or two IDE devices. All IDE devices have jumpers or switches that can be used to set the IDE device as MASTER or SLAVE.

If you install two IDE devices on one cable, you must make sure that one device is set to MASTER and the other device is set to SLAVE. The documentation of your IDE device explains how to do this.


If you want to install more than two IDE devices, obtain a second IDE cable; then you can add two more devices to the secondary IDE channel. If there are two devices on the cable, make one MASTER and one SLAVE.

## **About UDMA**

This board supports UltraDMA 33/66. UDMA is a technology that speeds the performance of devices in the IDE channel. We recommend that you install IDE devices that support UDMA, and use IDE cables that support UDMA.


## **Installing a Hard Disk Drive**

1. Install the hard disk drive into the drive cage in your system case.
2. Plug the IDE cable into the primary IDE channel on the mainboard IDE1.
3. Plug one of the cable IDE connectors into the hard disk drive IDE connector. It doesn't matter which connector on the cable that you use. Make sure that you have the pin-1 side of the cable matched with the pin-1 side of the connector.
4. Plug a power cable from the case power supply unit into the power connector on the back edge of the hard disk drive.
5. When you first start up your system, go immediately to the Setup Utility and use the IDE Hard Disk Auto Detect feature to configure the IDE devices that you have installed. See Chapter 3 for more information.



## **Installing a CD-ROM/DVD Drive**

1. Install the CD-ROM/DVD drive into the drive cage in your system case. Plug the IDE cable into the primary IDE channel on the mainboard IDE1.




2. Plug one of the connectors on the IDE cable into the IDE connector on the back edge of the CD-ROM/DVD drive. It doesn't matter which connector on the cable that you use. Make sure that you have the pin-1 side of the cable matched with the pin-1 side of the connector.
3. Plug a power cable from the case power supply unit into the power connector on the back edge of the CD-ROM/DVD drive.
4. Use the audio cable provided with the CD-ROM/DVD drive to connect the audio connector on the rear edge of the CD-ROM/DVD drive to the one of the two audio-in connectors CD1 and CD2 on the mainboard.
5. When you first start up your system, go immediately to the Setup Utility and use the IDE Hard Disk Auto Detect feature to configure the IDE devices that you have installed. See Chapter 3 for more information.

## Installing a Floppy Diskette Drive

The mainboard has a floppy diskette drive interface and it ships with a diskette drive ribbon cable that supports one or two floppy diskette drives. You can install a 5.25-inch and a 3.5-inch drive with various capacities.

1. Install the floppy diskette drive into the drive cage in your system case. Plug the diskette drive cable into the diskette drive interface on the mainboard FDD1.



2. Plug one of the connectors on the diskette drive cable into the data connector on the back edge of the floppy diskette drive. Make sure that you have the pin-1 side of the cable matched with the pin-1 side of the connector.
3. Plug a power cable from the case power supply unit into the power connector on the back edge of the diskette drive.
4. When you first start up your system, go immediately to the Setup Utility and use *Standard CMOS Setup* to configure the floppy diskette drives that you have installed. See Chapter 3 for more information.


## Using the Expansion Slots

This mainboard has three 32-bit PCI expansion slots, one 4xAGP slot, and one TV-out/LCD panel link riser slot.

**PCI Slots:** The PCI slots can be used to install add-in cards that have the 32-bit PCI (Peripheral Components Interconnect) interface.


**AGP Slot:** The 4xAGP slot can be used to install a graphics adapter that supports the 4xAGP specification and has the 4xAGP edge connector.

**TV-out/LCD Panel Link Riser Slot:** This slot enables you to install a TV-out or LCD panel card that allows you to connect a TV monitor or LCD panel.



1. Before installing an expansion card, check the documentation for the card. If the card is not Plug and Play, you may have to manually configure the card before installation.

2. In the system case, remove the blanking plate from the slot in the system case that corresponds to the expansion slot that you are going to use.
3. Position the edge connector of the add-in card over the expansion slot. Position the metal bracket of the card in the empty slot in the system case.
4. Install the edge connector of the add-in card into the expansion slot. Press down quite firmly so that you are sure that the edge connector is correctly seated in the slot.
5. Secure the metal bracket of the card in the empty slot in the system case with a screw.
6. For some add-in cards, for example graphics adapters and network adapters, you have to install drivers and software before you can begin using the add-in card.




## Other Options

The mainboard has a Wake On Modem (WOM) feature that can be used if you have installed a fax/modem card.

### ***WOM1: Wake on Modem***


If you have installed a fax/modem card, you can use the cable provided with the card to plug into the WOM1 connector on the mainboard. This is the Wake On Modem feature. When your system is in a power-saving mode, any incoming calls to the modem automatically resume the system. You must enable this item using the Power Management page of the Setup Utility. See Chapter 3 for more information.



### ***Fax/modem Card***


You must install the fax/modem card in order to use the built-in fax/modem. The fax/modem card is an optional item supplied with this mainboard.

1. Locate the MODEM1 connector on the mainboard.
2. Remove the expansion slot blanking plate from the system chassis that is adjacent to the Modem1 connector.
3. Install the fax/modem card on to the MODEM1 connector as shown below. The RJ-11 Line and Telephone sockets on the bracket are positioned in the expansion slot with the removed blanking plate.



## **Infrared Port**

This option can be purchased from third-party vendors.




1. Connect the cable from the optional IR port to SIR (for SIR infrared).
2. After you have connected the cable, secure the optional IR port to the appropriate location on your system case.

---

**Note:** An IR port may use some of the resources required by a second serial port or a fax/modem card. If you have more than one of these items installed, you may not be able to use them at the same time. You can use the Integrated Peripherals page of the Setup Utility to switch resources between an IR port and a second serial port. See Chapter 3 for more information.

## Making External Connections

After you have installed the mainboard, make the connections to the external ports.



1. There are two stacked PS/2 ports. The upper port can be used by a PS/2 mouse or pointing device. The lower port can be used by a PS/2 keyboard.
2. Connect to your local area network with the LAN port.
3. Use the USB ports to connect USB devices.
4. LPT1 is a parallel port that can be used by printers or other parallel communications devices. The system identifies the parallel port as LPT1.
5. COM1 is a serial port that can be used by serial devices such as a mouse or a fax/modem.
6. The VGA port is used to connect an external monitor.
7. You can use the game port to connect a joystick or a MIDI device to your system.
8. Three audio ports are provided: the left side jack is for a stereo line-out signal; the middle jack is for a stereo line-in signal; the right side jack is for a microphone.

## External Connector Color Coding

To help identify the external connectors, many connectors now use standard colors as shown in the table below.

Connector	Color
Analog VGA	Blue
Audio line-in	Light blue
Audio line-out	Lime
Digital monitor / flat panel	White
IEEE 1394	Grey
Microphone	Pink
MIDI/Game	Gold
Parallel	Burgundy
PS/2 compatible keyboard	Purple
PS/2 compatible mouse	Green
Serial	Teal or Turquoise
Speaker out/subwoofer	Orange
Right-to-left speaker	Brown
USB	Black
Video out	Yellow
SCSI, network, telephone, modem	None

— Notes —

## Chapter 3: Setup

### About the Setup Utility

---

The computer employs the latest Award BIOS CMOS chip with support for Windows Plug and Play. This CMOS chip contains the ROM setup instructions for configuring the mainboard's BIOS. The BIOS (Basic Input and Output System) Setup Utility is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters. These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

Using easy-to-use pull down menus, you can configure such items as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the Setup Utility intimately affect how the computer performs. It is important, therefore, first to try to understand all the Setup Utility's options, and second, to make settings appropriate for the way you use the computer. This chapter guides you through the Setup Utility by providing clear explanations for all Setup Utility options.

A standard configuration has already been set in the Setup Utility, so you will very likely have little to worry about for now. However, we recommend that you read this chapter just in case you need to make any changes in the future.

This program should be executed under the following conditions:

- When changing the system configuration
- When a configuration error is detected by the system and you are prompted to make changes to the Setup Utility
- When resetting the system clock
- When setting the CPU clock speed so that it runs either fast or slow
- When redefining the communication ports to prevent any conflicts
- When making changes to the Power Management configuration
- When changing the password or making other changes to the security setup

Normally, running the Setup Utility is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.

## Entering the Setup Utility

When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:

1. If the error occurs before the display device is initialized, a series of beeps will be transmitted.
2. If the error occurs after the display device is initialized, the screen will display an error message.

After the POST routines are completed, the following message appears:

**Press DEL to enter SETUP**

To access the Award BIOS Setup Utility, press the delete key to display the "CMOS Setup Utility" screen:

**CMOS Setup Utility – Copyright (C) 1984 – 2000 Award Software**

<ul style="list-style-type: none"><li>▶ Standard CMOS Features</li><li>▶ Advanced BIOS Features</li><li>▶ Advanced Chipset Features</li><li>▶ Integrated Peripherals</li><li>▶ Power Management Setup</li><li>▶ PnP/PCI Configurations</li><li>▶ PC Health Status</li></ul>	<ul style="list-style-type: none"><li>▶ Frequency/Voltage Control<ul style="list-style-type: none"><li>Load Fail-Safe Defaults</li><li>Load Optimized Defaults</li><li>Set Supervisor Password</li><li>Set User Password</li><li>Save &amp; Exit Setup</li><li>Exit Without Saving</li></ul></li></ul>
Esc : Quit      F9: Menu in BIOS      ↑ ↓ → ← : Select Item F10 : Save & Exit Setup	
Time, Date, Hard Disk Type . . .	

This screen provides access to the utility's various functions.

## BIOS Navigation Keys

Listed below are explanations of the keys displayed at the bottom of the screens:

<b>Key</b>	<b>Function</b>
Esc	<b>Escape key:</b> Exits the current menu
← ↓ ↑ →	<b>Cursor keys:</b> Scroll through the items on a menu
+/-/PU/PD	<b>Plus, minus, Page Up and Page Down keys:</b> Modify the selected field's values
F10	<b>F10 key:</b> Saves the current configuration and exits setup
F1	<b>F1 key:</b> Displays a screen that explains all key functions
F5	<b>F5 key:</b> Loads previously saved values to CMOS
F6	<b>F6 key:</b> Loads a minimum configuration for troubleshooting.
F7	<b>F7 key:</b> Loads an optimum set of values for peak performance

## Using BIOS

When you start the Setup Utility, the main menu appears. The main menu of the Setup Utility shows a list of the options that are available. A highlight indicates which option is currently selected. You can use the cursor arrow keys to move the highlight to other options. When an option is highlighted, you can execute the option by pressing the enter key.

Some options lead to pop-up dialog boxes that may ask you to verify that you wish to execute that option. You usually answer these dialogs by typing **Y** for yes and **N** for no. Some options may lead to more dialog boxes that ask for more information. Setting passwords have this kind of dialog box.

<b>Enter Password:</b>
------------------------

Selecting some fields and pressing the enter key displays a list of options for that field. In the Standard CMOS Features screen, selecting "Drive A" and pressing <Enter> displays this screen:

Drive A		
None	.....	[ ]
360K , 5.25 in.	.....	[ ]
1.2M , 5.25 in.	.....	[ ]
720K , 3.5 in.	.....	[ ]
1.44M , 3.5 in.	.....	[ ]
2.88M , 3.5 in.	.....	[ ]

↑↓ : Move    Enter : Accept    ESC: Abort


Select the setting you want with the cursor keys. Press <Enter> to select, or <ESC> to discard changes and return to the previous menu. Alternatively, you can select a field and press the minus, plus, Page Up or Page Down keys to scroll through the options for that field.

Some options (marked with a triangle ►) lead to submenus that enable you to change the values for the option. Use the cursor arrow keys to scroll through the items in the submenu.

## How to Flash a New BIOS

You can install updated BIOS for this mainboard that you can download from the manufacturer's web site. New BIOS may provide support for new peripherals, improvements in performance or fixes for known bugs. Install new BIOS as follows:

1. Some mainboards have a Flash BIOS jumper that protects the current BIOS from being changed or overwritten. If your mainboard has this jumper, change the setting to allow BIOS flashing.
2. Some Setup Utilities have an item called Firmware Write Protect that prevents the BIOS from being overwritten. If your BIOS has this item (check the Advanced BIOS Features Setup page) disable it for the present.
3. Your computer must be running in a real-mode DOS environment, not the DOS window of Windows NT or Windows 95/98. We recommend that you create a new formatted DOS system floppy diskette.
4. Download the Flash Utility and new BIOS file from the manufacturer's Web site. Copy these files to a system diskette.
5. Turn off your computer and insert the system diskette in your computer's diskette drive.
6. You might need to run the Setup Utility and change the boot priority items on the Advanced BIOS Features Setup page, to force your computer to boot from the floppy diskette drive first.
7. At the A:\ prompt, type the Flash Utility program name (for example, AWDxxx.EXE) and press <Enter>. You see a screen similar to the following.



8. In the "File Name to Program" dialog box, type in the file-name of the new BIOS and follow the onscreen directions to flash the new BIOS to the mainboard.
9. When the installation is complete, remove the floppy diskette from the diskette drive and restart your computer. If your mainboard has a Flash BIOS jumper, reset the jumper to protect the newly installed BIOS from being overwritten.

## Standard CMOS Features Option

This option displays a table of items defining basic information about your system.

CMOS Setup Utility – Copyright (C) 1984 – 2000 Award Software  
Standard CMOS Features

Date (mm:dd:yy)	Tue, <u>May</u> 15 2000	Item Help
Time (hh:mm:ss)	12 : 8 : 59	
▶ IDE Primary Master	Press Enter 4303 MB	Menu Level ▶
▶ IDE Primary Slave	Press Enter None	Change the day, month, year and century.
▶ IDE Secondary Master	Press Enter None	
▶ IDE Secondary Slave	Press Enter None	
Drive A	1.44M, 3.5 in.	
Drive B	None	
Floppy 3 Mode Support	Disabled	
Video	EGA/VGA	
Halt On	All Errors	
Base Memory	640K	
Extended Memory	63488	
Total Memory	64512K	

↑↓ → ← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### ***Date and Time***

The date and time items show the current date and time held by your computer. If you are running a Windows OS, these items are automatically updated whenever you make changes to the Windows Date and Time Properties utility.

► **IDE Devices**

**Default: None**

Your computer has two IDE channels (Primary and Secondary) and each channel can be installed with one or two devices (Master and Slave). Use these items to configure each device on the IDE channel. Press <Enter> to display the IDE sub-menu:

CMOS Setup Utility – Copyright © 1984 – 2000 Award Software  
IDE Primary Master

IDE HDD Auto-Detection	Press Enter	Item Help
IDE Primary Master	Auto	Menu Level ►► To auto-detect the HDD's size, head . . . on this channel
Access Mode	Auto	
Capacity	8448 MB	
Cylinder	16368	
Head	16	
Precomp	0	
Landing Zone	16367	
Sector	63	

↑ ↓ → ← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

**IDE HDD Auto-Detection**

Press <Enter> while this item is highlighted if you want the Setup Utility to automatically detect and configure a hard disk drive on the IDE channel.

**Note:** If you are setting up a new hard disk drive that supports LBA mode, more than one line will appear in the parameter box. Choose the line that lists LBA for an LBA drive.

**IDE Primary/Secondary Master/Slave**

If you leave this item at Auto, the system will automatically detect and configure any IDE devices it finds. If it fails to find a hard disk, change the value to Manual and then manually configure the drive by entering the characteristics of the drive in the items below (Capacity, Cylinder, Head, Precomp, etc.) Refer to your drive's documentation or look on the drive if you need to obtain this information. If no device is installed, change the value to None.

---

**Note:** Before attempting to configure a hard disk drive, make sure you have the configuration information supplied by the manufacturer of your hard drive. Incorrect settings can result in your system not recognizing the installed hard disk.

---

#### **Access Mode**

This item defines specific ways that can be used to access IDE hard disks such as LBA (Large Block Addressing). Leave this value at Auto and the system will automatically decide the fastest way to access the hard disk drive.

Press <ESC> to close the IDE device sub-menu and return to the Standard CMOS Features page.

---

#### **Drive A and Drive B** **Default: 1.44M, 3.5 in., None**

These items define the characteristics of any diskette drive attached to the system. You can connect one or two diskette drives.

---

#### **Floppy 3 Mode Support** **Default: Disabled**

Floppy 3 mode refers to a 3.5-inch diskette with a capacity of 1.2 MB. Floppy 3 mode is sometimes used in Japan.

---

#### **Video** **Default: EGA/VGA**

This item defines the video mode of the system. This mainboard has a built-in VGA graphics system; you must leave this item at the default value.

---

#### **Halt On** **Default: All Errors**

This item defines the operation of the system POST (Power On Self Test) routine. You can use this item to select which types of errors in the POST are sufficient to halt the system.

---

#### **Base Memory, Extended Memory, and Total Memory**

These items are automatically detected by the system at start up time. These are display-only fields. You cannot make changes to these fields.



---

**External Cache****Default: Enabled**

Most processors that can be installed in this system use external (L2) cache memory to improve performance. The exceptions are older SEPP Celeron CPUs running at 266 or 300 MHz. Enable this item for all but these two processors.

---

**CPU L2 Cache ECC Checking****Default: Enabled**

This item enables or disables ECC (Error Correction Code) error checking on the CPU cache memory. We recommend that you leave this item at the default value.

---

**Processor Number Feature****Default: Enabled**

Some of the new generations of Socket 370 processors are installed with a unique processor number. This number may be used for verification in Internet transactions and e-commerce. If you prefer not to use or distribute the unique processor number, use this item to suppress the processor number.

---

**Quick Power On Self Test****Default: Enabled**

You can enable this item to shorten the power on testing (POST) and have your system start up a little faster. You might like to enable this item after you are confident that your system hardware is operating smoothly.

---

**1st/2nd/3rd Boot Device****Default: Floppy/HDD-0/LS120**

Use these three items to select the priority and order of the devices that your system searches for an operating system at start-up time.

---

**Boot Other Device****Default: Enabled**

If you enable this item, the system will search all other possible locations for an operating system if it fails to find one in the devices specified under the first, second, and third boot devices.

---

**Swap Floppy Drive****Default: Disabled**

If you have two floppy diskette drives in your system, this item allows you to swap the assigned drive letters so that drive A becomes drive B, and drive B becomes drive A.

---

**Boot Up Floppy Seek** **Default: Enabled**

If this item is enabled, it checks the geometry of the floppy disk drives at start-up time. You don't need to enable this item unless you have an old diskette drive with 360K capacity.

---

**Boot Up NumLock Status** **Default: On**

This item defines if the keyboard Num Lock key is active when your system is started.

---

**Gate A20 Option** **Default: Fast**

This item defines how the system handles legacy software that was written for an earlier generation of processors. Leave this item at the default value.

---

**FirmWare Write Protect** **Default: Disabled**

If you enable this item, it protects the firmware (BIOS) from being overwritten. Disable this item if you plan to flash a new BIOS to the system.

---

**Typematic Rate Setting** **Default: Disabled**

If this item is enabled, you can use the following two items to set the typematic rate and the typematic delay settings for your keyboard.

---

**Typematic Rate (Chars/Sec)** **Default: 6**

If the item Typematic Rate Setting is enabled, you can use this item to define how many characters per second are generated by a held-down key.

---

**Typematic Delay (Msec)** **Default: 250**

If the item Typematic Rate Setting is enabled, you can use this item to define how many milliseconds must elapse before a held-down key begins generating repeat characters.

---

**Security Option** **Default: Setup**

If you have installed password protection, this item defines if the password is required at system start up, or if it is only required when a user tries to enter the Setup Utility.

---

**OS Select For DRAM > 64 MB****Default: Non-OS2**

This item is only required if you have installed more than 64 MB of memory and you are running the OS/2 operating system. Otherwise, leave this item at the default value.

---


**Report No FDD for WIN 95****Default: Yes**

If you are running a system with no floppy drive and using the Windows 95 OS, select Yes for this item to ensure compatibility with the Windows 95 logo certification.

## Advanced Chipset Features Option

This option displays a table of items that defines critical timing parameters of the mainboard components including the memory, and the system logic. Generally, you should leave the items on this page at their default values unless you are very familiar with the technical specifications of your system hardware. If you change the values incorrectly, you may introduce fatal errors or recurring instability into your system.

CMOS Setup Utility – Copyright (C) 1984 – 2000 Award Software  
Advanced Chipset Features

SCSO Buffer Strength	2x		Item Help
SCS1 Buffer Strength	2x		Menu Level ▶
SCS2 Buffer Strength	2x		
SCS3 Buffer Strength	2x		
SCS4 Buffer Strength	2x		
SCS5 Buffer Strength	2x		
CKE5 Buffer Strength	2x		
CKE4 Buffer Strength	2x		
CKE3 Buffer Strength	2x		
CKE2 Buffer Strength	2x		
CKE1 Buffer Strength	2x		
CKE0 Buffer Strength	2x		
SMAA Buffer Strength	2x		
SMAB Buffer Strength	2x		
SMAC Buffer Strength	1x		
SMD&SDQM Buffer Strength	1.5x		
SWE Buffer Strength	2x		

↑ ↓ → ← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

---

<b>SCSO – SCS5 Buffer Strength</b>	<b>Default: 2x</b>
<b>CKE0 – CKE5 Buffer Strength</b>	<b>Default: 2x</b>
<b>SMAA/SMAB/SMAC Buffer Strength</b>	<b>Default: 2x/2x/1x</b>
<b>SMD&amp;SDQM Buffer Strength</b>	<b>Default: 1.5x</b>
<b>SWE Buffer Strength</b>	<b>Default: 2x</b>

These items set the memory buffer strength for SDRAM memory. We recommend that you leave these items at the default value.

**\*Other Timing Settings\***

These items set the timing and wait states for SDRAM memory, the BIOS and video cache options, and other settings related to system performance. We recommend that you leave these items at the default value.

---

<b>SDRAM CAS Latency Time</b>	<b>Default: 3</b>
-------------------------------	-------------------

Enables you to select the CAS latency time in HCLKs of 2/2 or 3/3. The value is set at the factory depending on the DRAM installed. Do not change the values in this field unless you change specifications of the installed DRAM or the installed CPU.

---

<b>SDRAM Cycle Time Tras/Trc</b>	<b>Default: 6/8</b>
----------------------------------	---------------------

This item sets the minimum time from activation to activation of the same memory bank.

---

<b>SDRAM RAS-to-CAS Delay</b>	<b>Default: 3</b>
-------------------------------	-------------------

This sets the relative delay between the Row Address Strobe (RAS) and the Column Address Strobe (CAS).

---

<b>SDRAM RAS Precharge Time</b>	<b>Default: 3</b>
---------------------------------	-------------------

These four items set the timing and wait states for SDRAM memory. We recommend that you leave these items at the default value.

---

<b>System/Video BIOS Cacheable</b>	<b>Default: Enabled</b>
------------------------------------	-------------------------

These items allow the video and/or system to be cached in memory for faster execution. We recommend that you leave these items at the default value.

---

<b>Memory Hole at 15M-16M</b>	<b>Default: Disabled</b>
-------------------------------	--------------------------

This item can be used to reserve memory space for some ISA expansion cards that require it.

---

**CPU Latency Timer** **Default: Disabled**

This item sets a timing parameter for CPU access. Since the CPU timing is determined by the system hardware, leave this item at the default value.

---

**Delayed Transaction** **Default: Enabled**

If the chipset has an embedded 32-bit write buffer to support delay transaction cycles, you can enable this item to provide compliance with PCI Ver. 2.1 specifications. We recommend that you leave this item at the default value.

---

**On-Chip Video Window Size** **Default: 64 MB**

This item defines the size of the aperture if you use an onboard video adapter. It refers to a section of the PCI memory address range used for graphics memory. We recommend that you leave this item at the default value.

---

**AGP Aperture Size** **Default: 64 MB**

This item defines the size of the aperture if you use an AGP graphics adapter. It refers to a section of the PCI memory address range used for graphics memory. We recommend that you leave this item at the default value.

---

**Display Cache Frequency** **Default: 100 MHz**

This item enables you to set the display cache frequency. We recommend that you leave this item at the default value.

---

**System Memory Frequency** **Default: Auto**

This item enables you to set the frequency of the system memory, either 100 or 133 MHz. We recommend that you leave this item at the default value.

**\*Onboard Display Cache Setting\***

The items under this heading are used to set the parameters for display cache memory that may be optionally installed on your mainboard. If you have display cache memory, we recommend that you leave these items at the default settings.

---

**CAS# Latency** **Default: 3**

This item sets a timing parameter for the Column Address Strobe memory access. Leave this item at the default setting.

---

**Paging Mode Control****Default: Open**

This item allows you to enable and disable page open mode. If set to Open, the GMCH memory controller tends to leave the page open.

---

**RAS-to CAS Override****Default: by CAS# LT**

This item sets the timing parameters for the system memory such as the CAS (Column Address Strobe) and RAS (Row Address Strobe). We recommend that you set this item to the default value.

---

**RAS# Timing****Default: Fast**

Sets the Row Address Strobe (RAS) timing. Leave this at the default value.

---

**RAS# Precharge Timing****Default: Fast**

DRAM must continually be refreshed or it will lose its data. Normally, DRAM is refreshed entirely as the result of a single request. This option allows you to determine the number of CPU clocks allocated for the Row Address Strobe (RAS) to accumulate its charge before the DRAM is refreshed. If insufficient time is allowed, refresh may be incomplete and data lost.

## Integrated Peripherals Option

This option displays a list of items that defines the operation of some peripheral components on the system's input/output ports.

CMOS Setup Utility – Copyright (C) 1984 – 2000 Award Software  
Integrated Peripherals

On-Chip Primary	PCI IDE	Enabled		Item Help
On-Chip Secondary	PCI IDE	Enabled		Menu Level ▶
IDE Primary Master	PIO	Auto		
IDE Primary Slave	PIO	Auto		
IDE Secondary Master	PIO	Auto		
IDE Secondary Slave	PIO	Auto		
IDE Primary Master	UDMA	Auto		
IDE Primary Slave	UDMA	Auto		
IDE Secondary Master	UDMA	Auto		
IDE Secondary Slave	UDMA	Auto		
USB Controller		Enabled		
USB Keyboard Support		Disabled		
Init Display First		PCI Slot		
Onboard PCI Audio		Enabled		
Onboard PCI Modem		Enabled		
Onboard PCI LAN		Enabled		
IDE HDD Block Mode		Enabled		
POWER ON Function		Hot KEY		
KB Power ON Password		Enter		

↑ ↓ → ← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

---

### ***On-Chip Primary/Secondary PCI IDE      Default: Enabled***

Use these items to enable or disable the PCI IDE channels that are integrated on the mainboard.

---

### ***IDE Primary/Secondary Master/Slave PIO      Default: Auto***

Each IDE channel supports a master device and a slave device. These four items let you assign which kind of PIO (Programmed Input/Output) is used by IDE devices. You can choose Auto, to let the system auto detect which PIO mode is best, or you can install a PIO mode from 0-4.

---

### ***IDE Primary/Secondary Master/Slave UDMA      Default: Auto***

Each IDE channel supports a master device and a slave device. This motherboard supports UltraDMA. UltraDMA technology provides faster access to IDE devices.

If you install a device that supports UltraDMA, change the appropriate item on this list to Auto. You may have to install the UltraDMA driver supplied with this motherboard in order to use an UltraDMA device.

---

**USB Controller** **Default: Enabled**

Use this item to enable the USB ports that are integrated on this mainboard.

---

**USB Keyboard Support** **Default: Disabled**

Enable this item if you are using a keyboard connected through the USB Port.

---

**Init Display First** **Default: PCI Slot**

Use this item to define if your graphics adapter is installed in one of the PCI slots or select Onboard if you have a graphics system integrated on the mainboard.

---

**Onboard PCI Audio/Modem/LAN** **Default: Enabled**

Enable these items to use the onboard audio, modem, and LAN controllers. If you are installing an audio, modem, or LAN add-in card, disable the appropriate item.

---

**IDE HDD Block Mode** **Default: Disabled**

Block mode transfers can improve the access to IDE devices. Enable this item if your IDE devices support block mode transfers.

---

**Power ON Function** **Default: Hot KEY**  
**KB Power ON Password** **Default: Enter**  
**Hot Key Power ON** **Default: Ctrl-F12**

The Power On Function item allows you to power on the system by pressing hot-keys, or typing a password. If you choose Password, you can use the item KB Power On Password to install a power on password. Press Enter to display the Password dialog box. If you set it to Hot Key, you can then use the item Hot Key Power On to choose which hot keys are used to power on the system.

---

**Onboard FDC Controller** **Default: Enabled**

This option enables the onboard floppy disk drive controller.

---

**Onboard Serial Port 1** **Default: 3F8/IRQ4**

This option is used to assign the I/O address for the onboard serial port 1.

---

**Onboard Serial Port 2** **Default: Disabled**

This option is used to assign the I/O address for the onboard serial port 2.

---

**UART Mode Select** **Default: Normal**

This field is available if the Onboard Serial Port 2 field is set to any option but Disabled. UART Mode Select enables you to select the infrared communication protocol—Normal, IrDA, ASKIR or SCR.

The UART mode setting depends on which type of infrared module is used in the system. When set to SCR, ASKIR or IrDA, the UART mode is used to support the infrared module connected on the mainboard. If this option is not set to Normal, a device connected to the COM2 port will no longer work.

---

**UR2 Duplex Mode** **Default: Half**

This field is available when UART Mode Select is set to SCR, ASKIR or IrDA. This item enables you to determine the infrared (IR) function of the onboard infrared chip. The options are Full and Half.

Full-duplex means that you can transmit and send information simultaneously. Half-duplex is the transmission of data in both directions, but only one direction at a time.

---

**Onboard Parallel Port** **Default: 3F8/IRQ7**

This option is used to assign the I/O address for the onboard parallel port.

---

**Parallel Port Mode** **Default: ECP**

Enables you to set the data transfer protocol for your parallel port. There are four options: SPP (Standard Parallel Port), EPP (Enhanced Parallel Port), ECP (Extended Capabilities Port) and ECP+EPP.

SPP allows data output only. Extended Capabilities Port (ECP) and Enhanced Parallel Port (EPP) are bi-directional modes, allowing both data input and output. ECP and EPP modes are only supported with EPP and ECP aware peripherals.

---

**ECP Mode Use DMA** **Default: 3**

When the onboard parallel port is set to ECP mode, the parallel port has the option to use DMA 3 or DMA 1.

---

**PWRON After PWR-Fail** **Default: Off**

This item enables your computer to automatically restart or return to its last operating status after power returns from a power failure.

---

**Game Port Address** **Default: 201**

Enables you to specify the I/O address of the game port.

---

**Midi Port Address** **Default: 330**

Enables you to specify the I/O address of the MIDI port.

---

**Midi Port IRQ** **Default: 10**

Enables you to specify the IRQ of the MIDI port.

## Power Management Setup Option

This option displays items that let you control the system power management. Modern operating systems take care of much of the power management. This mainboard supports ACPI (advanced configuration and power interface). The system has various power saving modes including powering down the hard disk, turning off the video, suspending to RAM, and a software power down that allows the system to be automatically resumed by certain events.

### **Power Management Timeouts**

The power-saving modes can be controlled by timeouts. If the system is inactive for a time, the timeouts begin counting. If the inactivity continues so that the timeout period elapses, the system enters a power-saving mode. If any item in the list of *Reload Global Timer Events* is Enabled, then any activity on that item will reset the timeout counters to zero.

## Wake Up Calls

If the system is in suspend mode, or has been powered down by software, it can be resumed by a wake up call that is generated by incoming traffic to a modem, a LAN card, a PCI card, or a fixed alarm on the system realtime clock.

CMOS Setup Utility – Copyright (C) 1984 – 2000 Award Software  
Power Management Setup

ACPI Function	Enabled		Item Help
ACPI Suspend Type	S1(POS)		Menu Level ▶
Power Management	User Define		
Video Off Method	DPMS		
Video Off In Suspend	Yes		
Suspend Type	Stop Grant		
MODEM Use IRQ	3		
Suspend Mode	Disabled		
HDD Power Down	Disabled		
Soft-Off by PWR-BTTN	Instant-Off		
Wake-Up by PCI card	Disabled		
Power On by Ring	Disabled		
Wake Up On LAN	Enabled		
USB KB Wake-Up From S3	Disabled		
CPU Thermal-Throttling	50.0%		
Resume by Alarm	Disabled		
x Date(of Month) Alarm	0		
x Time(hh:mm:ss) Alarm	0 0 0		

↑ ↓ → ← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### ACPI Function

**Default: Enabled**

This mainboard supports ACPI (Advanced Configuration and Power management Interface). Use this item to enable or disable the ACPI feature.

### ACPI Suspend Type

**Default: S1 (POS)**

Use this item to define how your system suspends. In the default, S1 (POS), the suspend mode is equivalent to a software power down. If you select S3 (STR), the suspend mode is a suspend to RAM – the system shuts down with the exception of a refresh current to the system memory.

---

**Power Management** **Default: User Define**

This item acts like a master switch for the power-saving modes and hard disk timeouts. If this item is set to Max Saving, power-saving modes occur after a short timeout. If this item is set to Min Saving, power-saving modes occur after a longer timeout. If the item is set to User Define, you can set your own timeouts for the power-saving modes.

---

**Video Off Method** **Default: DPMS**

This item defines how the video is powered down to save power. This item is set to DPMS (Display Power Management Software) by default.

---

**Video Off In Suspend** **Default: Yes**

This option defines if the video is powered down when the system is put into suspend mode.

---

**Suspend Type** **Default: Stop Grant**

If this item is set to the default Stop Grant, the CPU will go into Idle Mode during power saving mode.

---

**MODEM Use IRQ** **Default: 3**

If you want an incoming call on a modem to automatically resume the system from a power-saving mode, use this item to specify the interrupt request line (IRQ) that is used by the modem. You have to connect the fax/modem to a mainboard Wake On Modem connector for this feature to work.

---

**Suspend Mode** **Default: Disabled**

If you have selected User Define for the Power Management item, you can set this item to a timeout from 1 Min to 1 Hour. The system will go into the power saving suspend mode if the timeout passes without any system activity.

---

**HDD Power Down** **Default: Disable**

If you have selected User Define for the Power Management item, you can set this item to a selection of timeouts from 1 to 15 minutes. The hard disk drive will power down if the selected timeout passes without any activity on the hard disk.

---

**Soft-Off by PWR-BTTN****Default: Instant-Off**

Under ACPI (Advanced Configuration and Power management Interface) you can create a software power down. In a software power down, the system can be resumed by Wake Up Alarms. This item lets you install a software power down that is controlled by the normal power button on your system. If the item is set to Instant-Off, then the power button causes a software power down. If the item is set to Delay 4 Sec. then you have to hold the power button down for four seconds to cause a software power down.

---

**Wake-Up by PCI card****Default: Disabled**

When this item is enabled, the system power will be turned on if there is any PCI card activity.

---

**Power On by Ring****Default: Disabled**

If this item is enabled, it allows the system to resume from a software power down or a power-saving mode whenever there is an incoming call to an installed fax/modem. You might have to connect the fax/modem to a mainboard Wake On Modem connector for this feature to work.

---

**Wake Up On LAN****Default: Enabled**

When set to Enabled, the system power will be turned on if the LAN port receives an incoming signal.

---

**USB KB Wake-Up From S3****Default: Disabled**

If you are using a USB keyboard, and the ACPI suspend type is set to S3, you can enable this item to allow a keystroke to wake up the system from power saving mode.

---

**CPU Thermal-Throttling****Default: 12.5%**

This item sets the percentage of time that the CPU is idled if CPU throttling is initiated by excess heat.

---

**Resume by Alarm****Default: Disabled**

When set to Enabled, you may set the date (day of the month), hour, minute and second to turn on your system. When set to set 0 (zero) for the day of the month, the alarm will power on your system every day at the specified time.

---

**Date (of Month) Alarm** **Default: 0**

When Resume by Alarm is enabled, you can set the date you wish the computer to turn on.

---

**Time (hh:mm:ss) Alarm** **Default: 0 0 0**

When Resume by Alarm is enabled, you can set the time you wish the computer to turn on.

**\*\*Reload Global Timer Events\*\***

Global Timer (power management) events are I/O events whose occurrence can prevent the system from entering a power saving mode or can awaken the system from such a mode. In effect, the system remains alert for anything that occurs to a device that is configured as Enabled, even when the system is in a power down mode.

---

**Primary/Secondary IDE 1/0** **Default: Disabled**

When these items are enabled, the system will restart the power-saving timeout counters when any activity is detected on any of the drives or devices on the primary or secondary IDE channels.

---

**FDD, COM, LPT Port** **Default: Disabled**

When this item is enabled, the system will restart the power-saving timeout counters when any activity is detected on the floppy diskette drives, the serial ports, or the parallel port.

---

**PCI PIRQ[A-D]#** **Default: Disabled**

When enabled, any activity on the PCI card channels will wake up the system from a power saving mode.

## PnP/PCI Configurations Option

This option displays a table of items that configures how PnP (Plug and Play) and PCI expansion cards operate in your system.

CMOS Setup Utility – Copyright (C) 1984 – 2000 Award Software  
PnP/PCI Configurations

Reset Configuration Data	<b>Disabled</b>	Item Help
Resources Controlled by	Auto(ESCD)	Menu Level ► Default is Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the OS cannot boot.
x IRQ Resources	Press Enter	
PCI/VGA Palette Snoop	Disabled	

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

---

### **Reset Configuration Data**

**Default: Disabled**

If you enable this item and restart the system, any PnP configuration data stored in the BIOS Setup Utility is cleared from memory. New updated data is created.

---

### **Resources Controlled By**

**Default: Auto(ESCD)**

You should leave this item at the default Auto (ESCD). Under this setting, the system dynamically allocates resources to Plug and Play devices as they are required. If you cannot get a legacy ISA (Industry Standard Architecture) expansion card to work properly, you might be able to solve the problem by changing this item to Manual, and then opening up the IRQ Resources and Memory Resources sub-menus.

In the IRQ Resources sub-menu, if you set any of the IRQs to Legacy ISA, then that Interrupt Request Line is reserved for a legacy ISA expansion card. Press <Esc> to close the IRQ Resources sub-menu.

---

**PCI/VGA Palette Snoop****Default: Disabled**

This item is designed to overcome some problems that can be caused by some non-standard VGA cards. This board includes a built-in VGA system that does not require palette snooping so you must leave this item disabled.

## PC Health Status Option

On mainboards that support hardware monitoring, this item lets you monitor the parameters for critical voltages, critical temperatures, and fan speeds.

CMOS Setup Utility – Copyright (C) 1984 – 2000 Award Software  
PC Health Status

		Item Help
<b>Shutdown Temperature</b>	85°C/185°F	
VCOREIN	1.98V	
+1.800V	1.82V	
+3.300V	3.36V	
VCCIN	5.02V	
+12.00V	11.36V	
-12.00V	(-)12.11V	
Voltage Battery	3.36V	
System Temperature	34°C	
CPU Temperature	42°C	
CPU FAN Speed	5152 RPM	
Case FAN Speed	0 RPM	
Chassis has been	CLOSING	
<b>Chassis Open Warning</b>	<b>Disabled</b>	

↑ ↓ → ← : Move   Enter : Select   +/-/PU/PD:Value   F10: Save   ESC: Exit   F1:General Help  
F5:Previous Values   F6:Fail-Safe Defaults   F7:Optimized Defaults

---

**Shutdown Temperature**

Enables you to set the maximum temperature the system can reach before powering down.

---

### **System Component Characteristics**

These fields provide you with information about the systems current operating status. You cannot make changes to these fields. The following information is displayed:

- VCOREIN (CPU Core voltage)
- 2.5V NB core voltage
- Vcc3 (onboard 3.3 volt)
- VCCIN (power supply's +5 volt)
- +12V (power supply's +12 volt)
- -12V (power supply's -12 volt)
- Voltage Battery
- System Temperature
- CPU Temperature
- CPU FAN Speed (in RPMs)
- CASE FAN Speed (in RPMs)
- Chassis has been: (indicates whether the chassis has been opened)

---

### **Chassis Open Warning**

**Default: Disabled**

Set this to Enabled if you want to receive a warning whenever the chassis is open.

## Frequency Control Option

This item enables you to set the clock speed and system bus for your system. The clock speed and system bus are determined by the kind of processor you have installed in your system.

CMOS Setup Utility – Copyright (C) 1984 – 2000 Award Software  
Frequency Control

Auto Detect DIMM/PCI Clk	Enabled	Item Help
CPU Internal Core Speed	Manual	
Spread Spectrum Modulated	Enabled	Menu Level ▶
CPU Host/PCI Clock	66/33MHz	
CPU Clock Ratio	X 3.5 / X 11.5	

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

---

### **Auto Detect DIMM/PCI Clk** **Default: Enabled**

When this item is enabled, BIOS will disable the clock signal of free DIMM and PCI slots.

---

### **CPU Internal Core Speed** **System Auto Detect**

The value for this item will be automatically detected by the system. If you set this value to manual, the CPU Host/PCI Clock and CPU Clock Ratio items appear.

---

### **Spread Spectrum Modulated** **Default: Disabled**

If you enable Spread Spectrum Modulated, it can significantly reduce the EMI (Electro-Magnetic Interference) generated by the system.

---

**CPU Host/PCI Clock**  
**CPU Clock Ratio**

These items appear if you have set the CPU Internal Core Speed to Manual. Use the CPU/DIMM/PCI Clock to set the system bus frequency for the installed processor (usually 133 MHz, 100 MHz or 66 MHz). Then use CPU Clock Ratio to set a multiple. The multiple times the system bus must equal the core speed of the installed processor e.g., **3.5 (multiple) x 100 MHz (system bus) = 350 MHz (installed processor clock speed)**.

## Load Fail-Safe Defaults Option

This option opens a dialog box that lets you install fail-safe defaults for all appropriate items in the Setup Utility. Press <Y> and then <Enter> to install the defaults. Press <N> and then <Enter> to not install the defaults. The fail-safe defaults place no great demands on the system and are generally stable. If your system is not functioning correctly, try installing the fail-safe defaults as a first step in getting your system working properly again. If you only want to install fail-safe defaults for a specific option, select and display that option, and then press <F6>.

## Load Optimized Defaults Option

This option opens a dialog box that lets you install optimized defaults for all appropriate items in the Setup Utility. Press <Y> and then <Enter> to install the defaults. Press <N> and then <Enter> to not install the defaults. The optimized defaults place demands on the system that may be greater than the performance level of the components, such as the CPU and the memory. You can cause fatal errors or instability if you install the optimized defaults when your hardware does not support them. If you only want to install setup defaults for a specific option, select and display that option, and then press <F7>.

## Set Supervisor and User Passwords Options

These items can be used to install a password. A Supervisor password takes precedence over a User password, and the Supervisor can limit the activities of a User. To install a password, follow these steps:

1. Highlight the item Set Supervisor/User Password on the main menu and press <Enter>.
2. The password dialog box appears.

**Enter Password:**

3. If you are installing a new password, type in the password. You cannot use more than eight characters or numbers. The Set Supervisor/User Password item differentiates between upper case and lower characters. Press <Enter> after you have typed in the password. If you are deleting a password that is already installed just press <Enter> when the password dialog box appears. You see a message that indicates that the password has been disabled.

**PASSWORD DISABLED !!!  
Press any key to continue . . .**

4. Press any key. You are prompted to confirm the password:

**Confirm Password:**

5. Type the password again and press <Enter>, or just press <Enter> if you are deleting a password that is already installed.
6. If you typed the password correctly, the password will be installed.

## Save & Exit Setup Option

Highlight this item and press <Enter> to save the changes that you have made in the Setup Utility and exit the Setup Utility. When the Save and Exit dialog box appears, press <Y> to save and exit, or press <N> to return to the main menu:

SAVE to CMOS and EXIT (Y/N)? **Y**

## Exit Without Saving Option

Highlight this item and press <Enter> to discard any changes that you have made in the Setup Utility and exit the Setup Utility. When the Exit Without Saving dialog box appears, press <Y> to discard changes and exit, or press <N> to return to the main menu.

Quit Without Saving (Y/N)? **N**

---

**Note:** *If you have made settings that you do not want to save, use the "Exit Without Saving" item and press Y to discard any changes you have made.*

This concludes Chapter 3. Refer to the next chapter for information on the software supplied with the mainboard.

— Notes —

## Chapter 4: Software

### About the Software

---

The software for this mainboard is supplied on a CD-ROM. The disk has some folders that can be used by many different mainboards, for example the **UTILITY** and **PERIPHERAL** folders. Some folders can only be used by mainboards which have certain brands of chipsets, for example the **INTEL** and **VIA** folders. In addition, software that is specifically intended for one kind of mainboard is stored in a folder with the name of that board. The folder for this mainboard is stored in the **P6ISM** folder.

---

***Note:** Never try to install software from a folder that is not specified for use with your mainboard.*

### Folders for this Mainboard

---

For this board, you can install software from the following folders:

#### ***Utility Folder***

You can use the software in the following sub-folders:

- AWDFLASH:** Software to erase and install revisions of the system BIOS
- GAMUT:** Audio rack for built-in sound system
- MEDIARING TALK:** Telephony software
- PC-CILLIN:** Anti-virus software
- SUPER VOICE:** Fax/modem software

### ***CMI8X38 Folder***

You can use the software from the following sub-folders:

- AUDIO\_ITE\_GAME:** Drivers and software for the built-in audio system
- MODEM:** Drivers and software for the built-in fax/modem

### ***Peripheral Folder***

You can use the software in the following sub-folders:

- KEYBOARD, CD-ROM, LAN, MOUSE:** These folders have drivers for accessories manufactured by BTC. Some system assemblers ship these accessories with complete systems based on this mainboard.

### ***Intel Folder***

- 81XVGA:** This folder has Intel 815 chipset graphics drivers for Windows 2000/98/95/NT.
- IDE:** This folder has IDE drivers for Windows 2000/98/95/NT.
- INST:** Provides software update patches for Intel chipsets.

### ***P6ISM Folder***

You can use the software in the following sub-folders:

- AUDIO, IDE, INST, LAN, MODEM, VGA:** These folders are empty. A Readme file directs you to an alternate location with the required software.
- MONITOR :** Hardware monitoring software for Windows 98/95, and Windows NT5.0/4.0

---

**Note:** *Some folders are subdivided into different operating systems such as DOS, Windows 95, and Windows NT. Always make sure that you are installing the correct software for the operating system on your computer. Some folders are also subdivided into different language versions, such as English, French, and German.*

*Before installing any software, inspect the folder for files named README.TXT, INSTALL.TXT, or something similar. These files*

may contain important information that is not included in this manual.


## Auto-installing under Windows 98

The Auto-install CD-ROM makes it easy for you to install the drivers and software for your mainboard.

**Note:** If the Auto-install CD-ROM does not work on your system, you can still install drivers through the file manager for your OS (for example, Windows Explorer).


The support software CD-ROM disc loads automatically under Windows 98. When you insert the CD-ROM disc in the CD-ROM drive, the autorun feature will automatically bring up the install screen:

**Note:** The following screens are examples only. The screens and driver lists will be different according to the mainboard you are installing.




The mainboard identification is located in the upper left-hand corner. Click which drivers you want to install, and then click **OK**. Click **Cancel** if you do not want to install drivers at this time.

After clicking **OK**, the install Wizard will start.




A driver installation screen appears:



Follow the instructions on the screen to install the driver.

Software is automatically installed in sequence. You will need to follow the onscreen instructions, confirm commands and allow the computer to restart a few times to complete installing whatever software you selected to install:



When the process is finished, all the support software will be installed and working.

After you finish installing the drivers for your mainboard, the Applications screen appears:



Select which applications you want to install, and click **OK**. If the autoinstalled driver cannot be installed completely, you can still use your operating system's file manager (for example Windows Explorer) to install all the drivers manually.

If the mainboard doesn't support the autoinstall feature, you will see the following screen:



---

**Note:** If the opening screen doesn't appear, double-click the file "autorun.exe" in the \AUTORUN directory.

Click READ ME to read the latest installation instructions. Click BROWSE THE CD TITLE to open Windows Explorer and show the contents of the support CD.

Double-click a folder to display the sub-folders. Before installing the software, look for a file named README.TXT, INSTALL.TXT or something similar. This file may contain important information to help you install the software correctly.

Some software is installed in separate folders for different operating systems, such as DOS, WIN NT, or WIN98/95. Always go to the correct folder for the kind of OS you are using.

To install the software, execute a file named SETUP.EXE or INSTALL.EXE by double-clicking the file and then following the instructions on the screen.

---

**Note:** Enable Windows Explorer to display file extensions (for example, EXE).

## Utility Folder Installation Notes

---

### Award Flash Memory Utility

This utility lets you erase the system BIOS stored on a Flash Memory chip on the mainboard, and lets you copy an updated BIOS to the chip. Take care how you use this program. If you erase the current BIOS and fail to write a new BIOS, or write a new BIOS that is incorrect, your system will malfunction.

For this mainboard, you must use the **AWD763.EXE** utility. To use the utility, you must be in real-mode DOS (not the DOS box that is available in Windows 98/95/NT). If you are using WINDOWS 98/95, shut down your computer and select the option "Restart in DOS" in the shutdown dialog box. If you are running Windows NT, shut down your computer and boot from a DOS diskette temporarily in order to run the flash memory utility.

### GAMUT

The Gamut audio rack software for the built-in sound system is provided for different languages. Go to the directory \UTILITY\GAMUT; then run SETUP.EXE to install the application software.

### MediaRing Talk

To install the MediaRing Talk voice modem software for the built-in modem, go to the directory \UTILITY\MEDIARING TALK; then run MRTALK-SETUP7.2.EXE to install the application software.

### PC-Cillin Software

The PC-Cillin software program provides anti-virus protection for your system. This program is available for:

- DOS – \UTILITY\PC-CILLIN\DOS\PCSCAN.EXE
- Win98 – \UTILITY\PC-CILLIN\WIN98\SETUP.EXE

Anti-virus software is provided for DOS and WIN 98. Browse to the appropriate directory for your operating system. For DOS, copy all the files in the DOS folder to your hard disk drive and run PSCAN to scan your system. For Windows 98, run SETUP to install the application software.

## Super Voice

To install the Super Voice voice, fax, and data communication application for use with the built-in fax/modem, go the directory \UTILITY\SUPER VOICE; then run PICSHELL.EXE to install the application software.

## CMI8X38 Folder Installation Notes

---

### Audio\_ITE\_GAME Software

This folder has software and drivers for the sound system that is integrated on this mainboard. Drivers are provided for Windows 2000/98/95/NT, DOS, and LINUX.

The audio drivers allow the system to generate optimal sound effects. Use the drivers listed below:

- DOS & Win3.x – \CMI8X38\AUDIO\_ITE\_GAME\DOSDRV\
- Windows 9x – \CMI8X38\AUDIO\_ITE\_GAME\W95-98\DRV\
- Windows 2000 – \CMI8X38\AUDIO\_ITE\_GAME\W2K
- Windows NT – \CMI8X38\AUDIO\_ITE\_GAME\NT40\DRV\
- Linux – \CMI8X38\AUDIO\_ITE\_GAME\LINUX\

Audio applications are located in the following folders:

- Windows 9x – \UTILITY\GAMUT\
- Windows 95 – \CMI8X38\AUDIO\_ITE\_GAME\W95-98\APP\W95\
- Windows 98 – \CMI8X38\AUDIO\_ITE\_GAME\W95-98\APP\W98\
- Windows NT – \CMI8X38\AUDIO\_ITE\_GAME\NT40\APP\

## **DOS**

Browse to the DOSDRV folder and run INSTALL.EXE

## **Windows 98/95**

Specify the path to the driver for your operating system when your system detects the installed audio system. To install the audio applications, browse to the W95-98 folder, and then browse to the APP folder. Run the SETUP program.

## **Windows NT 4.0**

1. Click Start. Select Settings and then Control Panel.
2. Double-click the Multimedia icon.
3. Select the Devices tab.
4. Click the Add button.
5. Select the item *Unlisted or Updated Driver* in the *List of Drivers* list box.
6. Specify the path to the PCI audio NT drivers.
7. Select *C-Media CM8338 PCI Device* and click OK.
8. Choose the proper I/O or click OK for the default setting.
9. Restart the Windows NT system.

To install the audio applications, browse to the NT4 folder, and then browse to the APPS folder. Run the SETUP program.

## **Linux**

To install the audio driver for the Linux system, refer to the readme file in the directory \CMI8X38\AUDIO\_ITE\_GAME\LINUX.

## **Fax/Modem Drivers and Software**

Install the Modem driver from the sub-folders for Windows 2000/98/95/NT or Linux.

The fax/modem drivers and software are listed here:

- Windows 9x/NT –  
    \CMI8X38\MODEM\WIN9XNT4\setup.exe
- Windows 2000 – \CMI8X38\MODEM\W2K
- \CMI8X38\MODEM\LINUX\  
    (Refer to the README.TXT for installation instructions.)

### ***Windows 98/95/NT***

The modem is a Plug and Play device so Windows will automatically detect the presence of your modem. When the Plug and Play wizard begins to look for modem drivers, click on the button that says *Have Disk* and then browse or type in the path-name to the CMI8X38\MODEM\WIN9XNT4\ folder.

### ***Windows 2000***

The modem is a Plug and Play device so Windows will automatically detect the presence of your modem. When the Plug and Play wizard begins to look for modem drivers, click on the button that says *Have Disk* and then browse or type in the path-name to the CMI8X38\MODEM\W2K\ folder.

## Intel Folder Installation Notes

---

### ***81XVGA***

This folder has the software and drivers for the graphics system built into the 815 chipset. Select the folder for the operating system that you are running, browse to the subfolder 81XVGA\WIN9X\GRAPHICS\ and then begin the installation by running SETUP.EXE.

### ***IDE***

This folder has the Intel Ultra ATA Storage Driver. Browse to the folder \Intel\IDE and run SETUP.EXE to install the driver.

### ***INST***

This folder has software that applies update patches to the Intel chipset. To run the patches, browse to the directory \INTEL\INST and run SETUP.EXE.

## Mainboard (P6ISM) Installation Notes

---

Most of the sub-folders in this folder are empty, with a short README file giving directions to alternate folders for the appropriate software.

### ***Monitor Sub-folder***

The software in this folder provides a graphical interface to the hardware monitoring feature of this mainboard. The software will run under Windows 98/95 or Windows NT4.0. To install the software, browse to the folder \P6ISM\MONITOR\ and run ITESMART.EXE.

— Notes —

# Appendix: Jumper Setting Reference

## Jumper Setting Quick Reference

### ***JP1: CPU frequency select jumper***

Use this jumper to force a 66 MHz CPU to run at 100 MHz.

Function	Jumper Setting
Normal operation	Short pins 1-2
Force 66 MHz CPU to run at 100 MHz	Short pins 2-3



### ***JP2: CPU frequency select jumper***

Use this jumper to force a 100 MHz CPU to run at 133 MHz.

Function	Jumper Setting
Normal operation	Short pins 1-2
Force 100 MHz CPU to run at 133 MHz	Short pins 2-3



### ***JP3: Clear BIOS jumper***

Use this 3-pin jumper to clear the system BIOS.


Function	Jumper Setting
Normal operation	Short pins 1-2
Clear CMOS	Short pins 2-3



### ***JP4: BIOS flash protect jumper***

Use this 2-pin jumper to protect the system BIOS from being accidentally flashed (updated).

Function	Jumper Setting
Protect	Short
Unprotect	Open



**JP5: Keyboard power on jumper**

Use this 3-pin jumper to enable the keyboard to power on the computer.

Function	Jumper Setting
Enable	Short pins 1-2
Disable	Short pins 2-3



**JP7: USB wakeup jumper**

Use this 3-pin jumper to enable a USB signal to wakeup the computer from a power saving mode.

Function	Jumper Setting
Enable	Short pins 1-2
Disable	Short pins 2-3



**JP8: Front Panel USB wakeup jumper**

Use this 3-pin jumper to enable a USB signal from the front panel to wakeup the computer from a power saving mode.

Function	Jumper Setting
Enable	Short pins 1-2
Disable	Short pins 2-3



**FP1: Panel connectors for switches and indicators**

Use the panel connector to implement the switches and indicators on your system case.

Function	Pins
Speaker	1, 3, 5, 7
Power LED	+2, 4, 6
Keylock	8, 10
Green LED	+13, 14
Hard Disk LED	+15, 16
Reset Switch	17, 18
System Management Interrupt (SMI) Button	+19, 20
Power Button	21, 22

