

**Kapitel 1 Montage**

CMOS löschen: SW1-5 .....	2
Kennwort löschen: SW1-6 .....	2
Auswahl des Flash-ROM: EP1, EP2 .....	3
DIMM-Frequenz und Systemfrequenz: FREQ1, FREQ2 .....	3
Prozessorfrequenz: SW-1, SW-2, SW-3, SW-4 .....	4

**Kapitel 2 BIOS-Einrichtung**

CMOS Setup Utility .....	5
Standard CMOS Setup .....	6
Festplattenkonfiguration .....	6
Software Turbo Speed .....	7
BIOS Features Setup .....	7
Chipset Features Setup .....	11
Power Management Setup .....	15
PNP/PCI-Konfiguration .....	19
Load BIOS Defaults .....	22
Load Setup Defaults .....	22
Integrated Peripherals .....	23
Kennworte (Supervisor/User Password) .....	27
 Autom. Festplattenerkennung (IDE HDD Auto Detection) .....	28
Save and Exit Setup .....	29
Exit without Saving .....	29