

Item Checklist

Completely check your package. If you discover damaged or missing items, contact your retailer.

- WinneX 1 mainboard
- QDI Mainboard Utility CD-ROM
- I/O shield
- 1 IDE ribbon cable
- 1 floppy ribbon cable
- 1 9-pin ribbon cable with bracket for serial port 2 (manufacturing option)
- User' s manual

Notice

The information in this document is subject to change in order to improve reliability, design, or function without prior notice and does not represent a commitment on the part of this company. In no event will we be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or the possibility of such damages.

All trademarks are the property of their respective owners.

If you require further information, please visit our web-site: "www.qdigrp.com".

Declaration of conformity



QUANTUM DESIGNS(HK) LTD.

**5/F Somerset House, TaiKoo Place 979 Kings Road,
Quarry Bay, Hong Kong**

declares that the product

**Mainboard
WinneX 1**


is in conformity with

(reference to the specification under which conformity is declared in
accordance with 89/336 EEC-EMC Directive)

- EN 55022 Limits and methods of measurements of radio disturbance characteristics of information technology equipment
- EN 50081-1 Generic emission standard Part 1:
Residential, commercial and light industry
- EN 50082-1 Generic immunity standard Part 1:
Residential, commercial and light industry

European Representative:

| | |
|----------------------------|----------------------------------|
| QDI COMPUTER (UK) LTD | QDI COMPUTER (SCANDINAVIA) A/S |
| QDI SYSTEM HANDEL GMBH | QDI COMPUTER (NETHERLANDS) B. V. |
| QDI COMPUTER (FRANCE) SARL | QDI COMPUTER HANDELS GMBH |
| QDI COMPUTER (ESPANA) S.A. | QDI COMPUTER (SWEDEN) AB |

Signature :  . Place / Date : HONG KONG/1999

Printed Name : Anders Cheung Position/ Title : President

Declaration of conformity



Trade Name: QDI Computer (U. S . A.) Inc.
Model Name: WinneX 1
Responsible Party: QDI Computer (U. S. A.) Inc.
Address: 41456 Christy Street
Fremont, CA 94538
Telephone: (510) 668-4933
Facsimile: (510) 668-4966

Equipment Classification: FCC Class B Subassembly
Type of Product: Mainboard
Manufacturer: Quantum Designs (HK) Inc.
Address: 5/F, Somerset House, TaiKoo Place
979 Kings Road, Quarry Bay, HONG
KONG

Supplementary Information:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Signature :  Date : 1999



CONTENTS

| | |
|---|----------|
| SpeedEasy Quick Setup(English) | S.1 |
| SpeedEasy Schnell-Installation(Deutsch) | S.3 |
| Fácil Y Veloz Rápida Instalación(Español) | S.5 |
| Facilité de vitesse Initialisation(Français) | S.7 |
| Setup Della Scheda SpeedEasy(Italiano) | S.9 |
| SpeedEasy Ć Ę Ů Ț Ö Å Ÿ Œ Ä ĩ ȧ | S.11 |
| SpeedEasy Ć Ę Ů Ț Ö Å Ÿ Œ ĩ ȧ | S.13 |
| 1. Introduction | 1 |
| Overview | 1 |
| Flexibility in Designing Cost-effective System | 1 |
| Key Features | 2 |
| Introduction to New Features | 4 |
| 2. Installation Instructions | 7 |
| External Connectors | 7 |
| PS/2 Keyboard & PS/2 Mouse Connector | 7 |
| USB1 & USB2 | 7 |
| Parallel Port Connector and Serial Port Connector | 7 |
| Line-in jack, Microphone-in jack, Speaker-out jack and MIDI/Joystick connector | 8 |
| ATX Power Supply Connector & Power Switch | 8 |
| Hard Disk LED Connector (HDLED) | 9 |
| Reset Switch (RESET) | 9 |
| Speaker Connector (SPEAKER) | 9 |
| Power LED Connector (PWR_LED) | 9 |
| Key-Lock Connector (KEY_L) | 9 |
| ACPI LED Connector (GREEN_LED) | 9 |
| Hardware Green Connector (SLEEP) | 9 |
| Infrared Header (IrDA) | 10 |
| Fan Connector (CPUFAN & CHSFAN) | 10 |
| Wake-Up On LAN (WOL) | 11 |
| Wake-Up On Internal Modem (WOM) | 11 |
| Digital Audio Connector (CDLIN1) | 11 |



CONTENTS

| | |
|---|-----------|
| 4 pin SMBus Connector(SMBUS) | 12 |
| Sound Connector (PC-PCI) | 12 |
| Chassis Security Switch (CHSSEC) | 12 |
| Audio/Modem Riser Interface Connector (AMR) | 13 |
| Expansion Slots & I/O Ports description | 13 |
| Jumper Settings | 13 |
| Clear CMOS | 14 |
| Enable/Disable on-board audio (JSD) | 14 |
| Enable keyboard password power-on function(JKB) | 14 |
| Connector PCI 3.3VSB Voltage Jumper (JSB) | 15 |
| Overclocking Jumper Setting (JFS0, JFS1) | 15 |
| FWH Protection Jumper (JAV) | 16 |
| Installation of All Drivers | 17 |
| PC-cillin 98 | 18 |
| QDI ManageEasy | 18 |
| 3. BIOS Description | 19 |
| Utility Support | 19 |
| AWDFLASH.EXE | 19 |
| AWARD BIOS Description | 20 |
| Entering Setup | 20 |
| Load Optimized Defaults | 20 |
| Standard CMOS Features Setup | 20 |
| CPU SpeedEasy Setup | 24 |
| Advanced BIOS Features Setup | 25 |
| Advanced Chipset Features Setup | 27 |
| Power Management Setup | 28 |
| PNP/PCI Configuration Setup | 30 |
| Integrated Peripherals | 31 |
| PC Health Status | 33 |
| Password Setting | 35 |
| Boot with BIOS defaults | 35 |
| Appendix A QDI Mainboard Utility CD-ROM | 37 |



Caution

Be sure to unplug the AC power supply before adding or removing expansion cards or other system peripherals, especially the SDRAM memory, otherwise your mainboard or the system memory might be seriously damaged.

The power status of the system is indicated by the red LED in the center of the mainboard.



SpeedEasy Quick Setup

Procedures :

1. Correctly insert the Intel®Celeron™PPGA processor.
2. Plug in other configurations and restore the system.
3. Switch on power to the system and press the key to enter BIOS Setup.
4. Enter "CPU SpeedEasy Setup" menu to set up the CPU speed.

Note: If you do not set the CPU speed, your system will run at the default setting (200MHz for processor with 100MHz host bus speed, 133MHz for processor with 66MHz host bus speed, for bus ratio locked processor, run its real speed.

5. Save and exit BIOS Setup, your system will now boot successfully.



CPU SpeedEasy Setup Menu

Select <CPU SpeedEasy Setup> item from the main menu and enter the sub-menu:




Figure - 1 CPU SpeedEasy Setup Menu

BIOS provides you with a set of basic values for your processor selection instead of the jumper settings. The processor speed can be manually selected on the “CPU SpeedEasy SETUP” menu screen.



Warning:

Do not set CPU frequency higher than its working frequency. If you do, we will not be responsible for any damages caused.



CPU SpeedEasy Installationsmenü

Wählen Sie < CPU SpeedEasy Setup> aus dem Hauptmenü und öffnen Sie das untergeordnete Menü



Abb. 1 CPU SpeedEasy Setup menü

Das BIOS stellt Ihnen eine Reihe von Grundeinstellungen für Ihren CPU zur Verfügung, anstelle von "jumper setting". Sie können manuell die Geschwindigkeit des CPU innerhalb des "CPU SpeedEasy SETUP" einstellen

⚠ Warnung:

Bitte Setzen Sie die Taktfrequenz der CPU nicht höher als die tatsächliche freigegebene Taktfrequenz, ansonsten kann QDI für rechtliche Ansprüche nicht herangezogen werden.



SpeedEasy Instalación rápida

Procedimiento:

1. Introduzca correctamente el Intel®Celeron™PPGA.
2. Finalize el proceso de ensamblaje de su equipo.
3. Presione la tecla <Supr> y encienda el sistema, para entrar en BIOS.
4. Entre al menu "CPU SpeedEasy Setup" para establecer la velocidad de su CPU.

Nota: Si no establece la velocidad del CPU, su sistema funcionará a la velocidad minima por defecto (200MHz para CPU con velocidad de bus de 100MHz, 133MHz para CPU con velocidad de bus de 66MHz)

5. Salve y salga de BIOS, luego su sistema arrancará a la velocidad por Ud. seleccionada.



Menu del CPU SpeedEasy

Seleccione el ítem <CPU SpeedEasy Setup> desde el menú principal, y entre en el submenú:




Figura-1 Menu del CPU SpeedEasy Setup

BIOS le proporcionará unos valores básicos para la elección de su CPU, en vez de tener que configurar jumpers. Ud. puede seleccionar manualmente la velocidad de CPU en el menú “CPU SpeedEasy Setup”.



Aviso

No es recomendable seleccionar una frecuencia de trabajo superior a la a la cual esta diseñada su CPU. De otra manera, no seremos responsables de los daños que esto pudiera ocasionar.



Facilité de vitesse Initialisation

Procédure:

1. Ins, rez le Intel®Celeron™PPGA correctement.
2. Connectez les autres configurations et restaurez le systšme.
3. Appuyez sur la touche et mettez le systšme sous tension pour entrer dans l' initialisation BIOS.
4. Entrez le menu "CPU SpeedEasy Setup" (=initialisation de la facilit, de vitesse dans l' unit, centrale) pour d, terminer la vitesse de l' unite centrale.

Note: Si vous ne déterminez pas la vitesse de votre unité centrale, votre système fonctionnera par défaut (200MHz pour le CPU avec vitesse bus d' hôte de 100MHz, 133MHz pour le CPU avec vitesse bus d' hôte de 66MHz).

5. Sauvegardez et sortez de la position BIOS. Le système pourra alors démarrer avec le succès auquel vous vous attendez.



Menu d'initialisation de "SpeedEasy" dans l'unité centrale.

Sélectionnez la rubrique <CPU SpeedEasy Setup> dans le menu principal et entrez le sous-menu:




Figure-1 Menu d'initialisation de "SpeedEasy" dans l'unité centrale

BIOS fournira un jeu de valeurs de base pour votre section de CPU au lieu de positions cavaliers. Vous pouvez sélectionner manuellement la vitesse de CPU dans l'affichage du menu "CPU SpeedEasy SETUP".



Avertissement:

Ne vous laissez pas aller à installer une fréquence à l'unité centrale supérieure à sa fréquence de travail. Sinon nous déclinons toute responsabilité en ce qui concerne les dommages qui en résulteraient.



SETUP DELLA SCHEDA SPEEDEASY

Procedura di installazione:

1. Inserite il microprocessore Intel®Celeron™PPGA come da istruzioni.
2. Modificate la configurazione del computer e ripristinate il sistema.
3. Premete il tasto e accendete il computer per entrare nel setup BIOS.
4. Entrate nel menu "CPU SpeedEasy Setup" per regolare la velocità del microprocessore. ¹

Nota: se non regolate la velocità del microprocessore, il sistema funzionerà con le regolazioni standard (Microprocessore da 200MHz con velocità di "host bus" da 100MHz e microprocessore da 133MHz con velocità di "host bus" da 66MHz).

5. Salvate e uscite dal Setup BIOS, e fate ripartire il computer.

*CPU= microprocessore



Menu del Setup del Microprocessore SpeedEasy

Selezionare <CPU SpeedEasy Setup> dal menu principale ed entrare nel seguente sottomenu:




Figure -1 Menu del Setup del Microprocessore SpeedEasy

Il sistema BIOS Vi fornirà una serie di valori base per la selezione del microprocessore al posto della regolazione jumper (dell'accoppiamento). Potete selezionare manualmente la velocità del microprocessore sulla schermata "CPU SpeedEasy SETUP".



Avvertenza:

non dovete regolare la frequenza del microprocessore più alta di quella predisposta, altrimenti la casa produttrice non si farà carico di eventuali danni al microprocessore.



SpeedEasy ȷ Ę Ũ ȳ Ō Ą Ĩ

ȳ Ĩ ȳ

1. Ō Ÿ ȳ Ō Ę Ę Intel®Celeron™PPGA Ō Ĩ Ę Ą Ę ȳ
2. ȳ Ę Ę Ą Ō Ą × Ę ȳ Ę Ō ȳ Ą ȳ Ĩ ȳ ȳ
3. ȷ Ę Ę Ĩ ȳ Ō ; ȳ ȳ Ō × ȳ Del > ȳ Ÿ ȳ Ę BIOS Ę Ō Ĩ ȳ
4. ȳ Ę Ę CPU SpeedEasy Setup ȳ ȳ ȳ Ō ȳ Ÿ Ō Ę Ę Ę Ę Ę Ę


× Ō Ą Ę Ō ȳ ȳ Ÿ Ō Ę Ą Ę ȳ Ę Ÿ Ę Ĩ ȳ ȳ ȳ Ō Ę ȳ Ę Ÿ Ę Ę Ę 100 Ō × Ō Ÿ Ĩ ȳ Ą CPU » Ę Ō 200 Ō × Ō Ę Ę 66 Ō × Ō Ÿ ȳ Ą CPU » Ę Ō 33 Ō × Ō Ę Ę ȳ Ō Ō Ę Ę ȳ Ę Ą CPU, Ō Ę Ę Ę ȳ Ę Ÿ Ę.

5. ȳ Ę Ę Ō ȳ Ĩ BIOS, Ĩ ȳ ȳ Ÿ Ō Ō Ę Ę ȳ Ę Ÿ Ę Ę Ę Ę




SpeedEasy

» CPU SpeedEasy Setup



» CPU SpeedEasy

BIOS » CPU SpeedEasy Setup



» CPU SpeedEasy Setup