

Item Checklist

Completely check your package. If you discover damaged or missing items, contact your retailer.

- P5MVP3/A3 motherboard
- QDI Motherboard Utility CD-ROM
- Retention Module
- I/O shield
- 1 IDE ribbon cable
- 1 floppy ribbon cable
- User' s manual

Notice

The information in this document is subject to change in order to improve reliability, design, or function without prior notice and does not represent a commitment on the part of this company. In no event will we be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or the possibility of such damages.

All trademarks are the property of their respective owners.

If you need any further information, please visit our web-site: "www.qdigrp.com".

Declaration of conformity



QUANTUM DESIGNS(HK) LTD.
5/F Somerset House, TaiKoo Place 979 Kings Road,
Quarry Bay, Hong Kong

declares that the product

Pentium® Motherboard
P5MVP3/A3

is in conformity with

(reference to the specification under which conformity is declared in
accordance with 89/336 EEC-EMC Directive)

- EN 55022 Limits and methods of measurements of radio disturbance characteristics of information technology equipment
- EN 50081-1 Generic emission standard Part 1:
Residential, commercial and light industry
- EN 50082-1 Generic immunity standard Part 1:
Residential, commercial and light industry

European Representative:

QDI COMPUTER (UK) LTD.	QDI COMPUTER (SCANDINAVIA) A/S
QDI SYSTEMHANDEL GMBH	QDI COMPUTER (NETHERLANDS) B. V.
QDI COMPUTER (FRANCE) SARL	QDI COMPUTER HANDELS GMBH
QDI COMPUTER (ESPANA) S.A.	QDI COMPUTER (SWEDEN) AB

Signature :  . Place / Date : HONG KONG/1998

Printed Name : Anders Cheung Position/ Title : President

Declaration of conformity



Trade Name: QDI Computer (U . S . A .) Inc.
Model Name: P5MVP3/A3
Responsible Party: QDI Computer (U . S . A .) Inc.
Address: 41456 Christy Street
Fremont, CA 94538
Telephone: (510) 668-4933
Facsimile: (510) 668-4966

Equipment Classification: FCC Class B Subassembly
Type of Product: AGP Pentium® Motherboard
Manufacturer: Quantum Designs (HK) Inc.
Address: 5/F, Somerset House, TaiKoo Place
979 Kings Road, Quarry Bay, HONG
KONG

Supplementary Information:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Signature :

A handwritten signature in black ink, appearing to be 'John King', written over a horizontal line.

Date : 1998



CONTENTS

SpeedEasy Quick Setup(English)	1
Schneller Überblick über die Einstellungen(Deutsch)	3
Setup Rápido(Español)	5
Sélection rapide de la vitesse du processeur(Français)	7
Setup Rapido(Italiano)	9
SpeedEasy ()	11
SpeedEasy ()	13
1. Introduction	15
Overview	15
Highlighted Features	15
Key Features	15
2. Installation Instructions	19
External Connectors	19
PS/2 Keyboard/Mouse Connector	19
USB1, USB2	19
Parallel/Serial Port Connector	20
ATX Power Supply Connector&Power Switch	20
Hard Disk LED Connector	20
Reset Switch	20
Speaker Connector	21
Power LED Connector	21
Keylock Connector	21
Green LED Connector	21
Hardware Green Connector	21
Infrared Header	22
CPU Fan Connector	22
Wake-Up On LAN(WOL)	22
Wake-Up On Internal Modem(WOM)	23
Expansion Slots & I/O Ports description	23



CONTENTS

Jumper Settings	23
Clear CMOS	24
Memory Configuration	24
3. BIOS Description	25
Utility Support	25
FLASH.EXE	25
AWARD BIOS Description	27
Entering Setup	27
Load Setup Defaults	27
Standard CMOS Setup	27
SpeedEasy CPU Setup	30
BIOS Features Setup	31
Chipset Features Setup	33
Power Management Setup	35
PNP/PCI Configuration Setup	37
Integrated Peripherals	39
Supervisor/UserPassword	41
IDE HDD Auto Detection	42
Boot with BIOS defaults	43
Appendix A QDI Motherboard Utility CD-ROM	45
Appendix B Introducing Intel Pentium® with MMX™	46
Appendix C Introducing AMD K6™-2 CPU	47
Appendix D Introducing Cyrix 6x86MX™ CPU	48
Appendix E Introducing idt Winchip™ C6™ CPU	49
Appendix F Boot Logo	50



SpeedEasy Quick Setup

Procedures :

1. Correctly insert the processor.
2. Plug in other configurations and restore the system.
3. Switch on power to the system and press the key to enter BIOS Setup.
4. Enter ' SpeedEasy CPU SETUP' menu to set up the CPU speed.

Note: If you don' t set CPU speed, your system will run at default setting.

5. Save and exit BIOS Setup, your system can now boot successfully as expected.



SpeedEasy CPU Setup Menu

Select <SpeedEasy CPU SETUP> item from the main menu and enter the sub-menu:




Figure - 1 SpeedEasy CPU Setup

BIOS will provide you with a set of basic values for your processor selection instead of the jumper settings. The processor speed can be manually selected on the "SpeedEasy CPU SETUP" menu screen.

BIOS also provides you with two choices, SDRAM Syn. or SDRAM Asyn. If PC-100 Spec. SDRAMs are used on your system, set as 'Syn'. If PC-66 Spec. SDRAM are used on your system, and the host bus clock is lower than 83MHz, set as 'Syn'. However, if the host bus clock equals to or higher than 83MHz, set as 'Asyn'.

Regarding the CPU voltage, it is recommended that users set CPU Voltage Ctrl as 'Auto'.



Warning:

Do not set CPU frequency higher than its working frequency. If you do, we will not be responsible for any damages caused.

Note: In addition, if your system can not boot up again because of wrong CPU setting, hold down the hot-key while powering on the system, the system will reboot and run at the basic values.



Schneller Überblick über die Einstellungen:

Vorgehensweise:

1. Setzen Sie die CPU richtig ein.
2. Stecken Sie weitere Komponenten ein und vervollständigen Sie das System.
3. Drücken < DEL > oder < ENTF > und schalten Sie das System ein, um in das BIOS-Setup zu gelangen.
4. Wählen Sie das Menü „SpeedEasy CPU SETUP“, um die CPU-Taktfrequenz einzustellen.

Anmerkung: Wenn Sie die CPU-Taktfrequenz nicht einstellen, wird Ihr System in der Grundeinstellung laufen .

5. Wählen Sie die Option „Save and Exit BIOS Setup“, um die vorgenommen Änderungen abzuspeichern. Anschließend können Sie wie erwartet das System erfolgreich hochfahren.



Menü für die SpeedEasy CPU-Einstellungen

Wählen Sie das Menü < SpeedEasy CPU SETUP > aus und gehen Sie in das folgende Untermenü:




Bild 1 „ SpeedEasy CPU SETUP“ Menü

Beim den SpeedEasy-Mainboard stellt Ihnen das BIOS anstelle von Jumper-Einstellungen eine Auswahl von Grundeinstellungen zur Verfügung. Um Ihr System optimal zu betreiben, können Sie von Hand die Werte für die CPU-Taktfrequenz unter der Option „CPU-Taktfrequenz unter der Option „CPU Speed“ im „SpeedEasy CPU SETUP“ Menü einstellen.



warnung:

Sie sollten die CPU-Taktfrequenz nicht höher als die angegebene Betriebsgeschwindigkeit einstellen. Anderfalls sehen wir uns für irgendwelche hierdurch hervorgerufene Schäden nicht verantwortlich.

Anmerkung: Falls Ihr System aufgrund einer falschen CPU-Einstellung nicht mehr hochfahren kann, halten Sie beim Einschalten des Rechners die Taste < DEL > bzw. < ENTF > gedrückt. Das System wird dann mit den Grundeinstellungen neu gestartet.



Setup Rápido

Procedimiento:

1. Insertar la CPU correctamente.
2. Insertar otros dispositivos en el sistema.
3. Presionar la tecla y arrancar el sistema para entrar en BIOS setup.
4. Seleccionar el menú "SpeedEasy CPU SETUP" para seleccionar la velocidad de la CPU.

Nota: si no selecciona la velocidad de la CPU, el sistema funcionará a la velocidad por defecto.

5. Grabar y salir de BIOS Setup, entonces el sistema arrancará y funcionará como Ud. espera.



Configuración de la CPU en el menu SpeedEasy

Seleccione <CPU Speed SETUP> en el menu principal para entrar en el siguiente menu:




Figure -1. SpeedEasy CPU Setup Menu

Para la placa base SpeedEasy, la BIOS proporciona un juego de valores básicos para seleccionar el tipo de CPU, en lugar de los jumpers. Para hacer que su sistema funcione lo más rápidamente posible, Ud. puede manualmente aumentar el valor de la velocidad de frecuencia en "CPU Speed" en el menu <SpeedEasy CPU SETUP>.



Aviso

Aviso: es recomendable no seleccionar una frecuencia superior para la CPU a la que esta fue diseñada. En caso contrario, no nos hacemos responsables de los posibles daños que esto pueda causar.

Nota: por lo tanto, si su sistema no puede rearrancar de nuevo tras haber variado la frecuencia de trabajo de la CPU por una incorrecta, Ud. puede arrancar manteniendo apretada la tecla mientras conecta su equipo. El sistema arrancará con los valores básicos.