



**Mpower 4 plus
SYSTEM BOARD
MANUAL**

Document Number: 06-00229-01, Ver. A
August 1994
221 Warren Ave., Fremont, CA 94539-7085

Copyright Notices

Micronics Computers, Inc.

The information contained in the Mpower 4 plus system board manual has been carefully checked and is believed to be accurate. Micronics assumes no responsibility for any inaccuracies that may be contained in this document. Micronics makes no commitments to update or to keep the information in this manual at a current level when changes are made to the product.

Micronics reserves the right to make improvements to this document and/or product at any time and without notice.

All Rights Reserved. No part of this document may be photocopied, reproduced, translated, or reduced to any medium or machine form without prior, written consent from Micronics.

COPYRIGHT (C) 1994, Micronics Computers, Inc.
232 E. Warren Ave., Fremont, California 94539-7085

Portions of the Manual

Portions of this manual were copied (with permission) from Phoenix Technologies, Ltd. Copyright 1994. All rights reserved.


Trademarks

IBM is a registered trademark of International Business Machines. Microsoft, Microsoft Word, Windows are registered trademarks of Microsoft Corporation. Intel is a registered trademark of Intel Corporation. UNIX is a registered trademark of AT&T Corporation. Lotus 1-2-3 is a registered trademark of Lotus Development Corp. All other product names mentioned herein are used for identification purposes only and may be the trademarks of their respective companies.

Micronics Quick Installation

We know that many experienced people prefer to read as little of the documentation as possible. If this sounds like you, here's the short form:

1. Ground yourself to prevent damaging static discharge, then remove the Mpower 4 plus from its packaging.
2. Configure and verify the system board's jumper settings. (See Jumper Settings in Chapter 2)
3. Install the CPU and the system memory. (See Chapter 3)
4. Install the system board into the system case and make all of the necessary case connections.
5. Install any peripherals (see Chapter 3). It is best not to put the computer cover on until you have verified the system is working properly.
6. Turn the computer on. The computer goes through a self-test and the following screen appears. If Setup detects any configuration errors, the message "Press <F1> to continue (boot up) or <F2> to run the Setup procedure" will appear. Press the <F2> key and make any necessary configurations.



If the Power-Up screen does not appear, but the DOS prompt does (ie., A:\ or C:\), press the <Ctrl>, <Alt>, and <Esc> keys simultaneously to begin the Setup procedure.

7. Set the time and date. Adjust the BIOS settings to match what is installed in your system. If installing an IDE drive, select the IDE device you wish to configure. Select Auto Config and the BIOS will automatically configure the drive for you. (See Chapter 4)
8. After all configurations have been made, press <Esc> to exit. Then press <F4> to save the configuration and reboot. (See Chapter 4)

Contents

Introduction	1-1
Features	1-2
Setting Up the Mpower 4 plus	2-1
Static Electricity	2-1
Office Environment	2-1
Mpower 4 plus Components	2-2
Jumper Settings	2-3
Installing the Mpower 4 plus, System Memory, CPUs, and Peripherals	3-1
Installation of the Mpower 4 plus	3-2
Tools Required	3-2
Equipment Required	3-2
System Memory	3-3
Memory Configuration	3-3
Installing the SIMMs	3-4
Removing SIMMs	3-4
Installing the Upgrade OverDrive CPU	3-5
Installing Cache Memory	3-6
64K of Level 2 Cache	3-6
128K of Level 2 Cache	3-7
256K of Level 2 Cache	3-8
Installing Video Memory	3-9
Installing a VL-Bus Riser Card	3-10
Installing a VL-Bus Card	3-11
The BIOS Setup Utility	4-1
Configuration	4-1
Initial Boot Up	4-1
Setup	4-2
Running the Setup Procedure	4-2
Setting the CMOS Parameters	4-3
Setting the CMOS Main Screen	4-4

System Time and Date	4-4
Diskette A or B	4-4
Hard Disk 1 or 2 (IDE Drives Only)	4-4
Base Memory and Extended Memory	4-4
Video Card.....	4-4
Keyboard	4-4
HD1 and HD2 Block Modes (IDE Drives Only)	4-5
Beeper Option	4-5
The “Green Section” of the BIOS	4-5
Setting the CMOS Extended Screen	4-6
System BIOS	4-6
Video BIOS	4-6
System Speed	4-7
CPU Type	4-7
System and Setup Menu Passwords	4-7
System Password	4-7
Setup Password	4-7
Internal Cache	4-8
External Cache	4-8
External Cache Mode	4-8
Serial Port 1	4-8
Serial Port 2	4-8
Parallel Port	4-8
On Board Floppy	4-8
On Board IDE.....	4-8
HD1 Speed	4-9
HD2 Speed	4-9
Non-Cacheable Area #1 and #2	4-9
Re-Configuring Your Computer	4-9
Installing Graphics Accelerator Software	5-1
Preparation	5-1
Installation	5-2
Main Menu Options	5-2
System Information	5-3
Quick Setup	5-3
Drivers Installation	5-4
Utilities Installation	5-4
Diagnostics	5-5
Advanced Setup.....	5-5
Troubleshooting	5-7

Installing Video Drivers	6-1
Installation	6-1
De-Installation	6-1
Microsoft Windows 3.1	6-2
De-Installation Procedure	6-2
Installation Procedure	6-2
AutoCAD 386 R10/R11/R12.....	6-3
IBM OS/2 Presentation Manager 2.1	6-4
Installation Procedure	6-4
De-Installation Procedure	6-5
Intergraph MicroStation 4.0	6-6
Microsoft Windows NT	6-6
Installation Procedure	6-6
De-Installation Procedure	6-7
Microsoft Word (for DOS) 5.x, 6.0	6-7
WordPerfect (for DOS) 5.x, 6.0	6-8
WordPerfect Versions 5.0 and 5.1	6-8
WordPerfect Version 6.0	6-8
POST Messages	A-1
Beep Codes	B-1
Hard Disk Drive Types	C-1
Specifications	D-1
Environmental Specifications	D-2
Temperature Range	D-2
Relative Humidity	D-2
Battery Disposal	D-3
FCC Warning Statement	F-1
Glossary	G-1
Limited Warranty	W-1
Non-Warranty Service	W-2

List of Figures

Figure 2-1: Mpower 4 plus Components	2-2
Figure 3-1: Installing a SIMM	3-4
Figure 3-2: Installing a CPU	3-5
Figure 3-3: Installing 64K of Level 2 Cache	3-6
Figure 3-4: Installing 128K of Level 2 Cache	3-7
Figure 3-5: Installing 256K of Level 2 Cache	3-8
Figure 3-6: Installing Video Memory	3-9
Figure 3-7: Installing a VL-Bus Riser Card	3-10
Figure 3-8: Inserting a VESA Local Bus Card	3-11
Figure 4-1: Power-Up Screen	4-2
Figure 4-2: CMOS Main Screen	4-3
Figure 4-3: CMOS Extended Screen	4-6
Figure 4-4: Exit Pop-Up Screen	4-10
Figure 5-1: Main Menu	5-2
Figure 5-2: Monitor Selection Menu	5-4
Figure 5-3: Set Power-Up Configuration Menu	5-6

List of Tables

Table 2-1: Real-Time Clock Settings	2-3
Table 2-2: Video Monitor Display Selection	2-3
Table 2-3: Mouse Configuration Selection	2-3
Table 2-4: Parity Configuration Selection	2-3
Table 2-5: Super I/O Selection	2-4
Table 2-6: BIOS Operation Selection	2-4
Table 2-7: Write-Back Cache Selection	2-5
Table 2-8: CPU Selection	2-5
Table 2-9: Reserved Jumpers	2-6
Table 2-10: Cache Size Selection	2-6
Table 2-11: Parallel Port Selection	2-6
Table 2-12: Video Selection	2-7
Table 2-13: Case and Peripheral Connections	2-7
Table 2-14: DIP Switch 1 Settings	2-8
Table 2-15: DIP Switch 2 Settings	2-8
Table 3-1: Memory Configurations	3-3
Table 5-1: Error Codes and Messages	5-8