

# 6VIA90A

## User's Manual Version 1.1

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Pentium is a trademark of Intel Corporation

AWARD is a registered trademark of Award Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

**Trademarks and/or registered trademarks are the properties of their respective owners.**

---

## Table of Contents

<b>Chapter 1</b>	<b>Introduction .....</b>	<b>1</b>
	How this manual is organized .....	1
	Package checklist .....	2
<b>Chapter 2</b>	<b>Features .....</b>	<b>3</b>
	Features of the mainboard .....	4
<b>Chapter 3</b>	<b>Installation .....</b>	<b>5</b>
	The 6VIA90A Mainboard Layout.....	7
	System Installation Setups .....	8
	Static Electricity Precaution .....	8
	Jumper Settings .....	9
	System Memory (DIMM modules) .....	11
	DIMM Memory Installation .....	12
	CPU Installation .....	14
	Clearance Requirements .....	18
	Fan Exhaust .....	18
	External Connectors .....	19

### Note:

If there is any change in the content please refer to our website. Regarding the BIOS setting & Driver installation, refer the web site please.([www. acorp.com.tw](http://www.acorp.com.tw))