Contents

Chapter 1: Introduction 1
Welcome 1
About the Manual 2
Checklist..... 3
Standard Items ---------- 3
Optional Items ---------- 3
Recommendations..... 3
Features 4

Chapter 2: Installation 7
Quick Installation Table..... 7
Quick Jumper Setting Reference 8
Before You Begin 9
Static Electricity ---------- 9
Choosing a Case ---------- 10
How to Set Jumpers ---------- 10
Preparing the Mainboard 12
Mainboard Guide ---------- 12
I/O Ports Side View ---------- 14
Check the Jumper Settings ---------- 14
Install the Mainboard in the Case---------- 16
Connecting Power, Chassis Fan, and Panel ---------- 17
Install Other Hardware 19
Install the Processor ---------- 19
Installing a Slot1 Processor ---------- 21
Installing a Socket-370 Processor---------- 23
Install the Memory Modules---------- 25
Install a Hard Disk Drive and CD-ROM ---------- 26
Installing a Floppy Diskette Drive---------- 29
Using the Expansion Slots ---------- 30
Add-in Card Options ---------- 32
Install Options and Extension Brackets ---------- 33
Make the External Connections 35

Chapter 3: Setup 36
About the Setup Utility 36
Starting the Setup Utility ---------- 36
How to Flash a New BIOS ---------- 38
Standard CMOS Setup Option 39

BIOS Features Setup Option 40
Chipset Features Option..... 43
Power Management Setup Option 45
PNP/PCI Configuration Option..... 49
Load BIOS Defaults Option..... 50
Load Optimum Settings Option 50
Integrated Peripherals Option 51
Supervisor and User Password Settings 53
IDE HDD Auto Detection Option 54
Save And Exit Setup Option..... 54
Exit Without Saving Option 54

Chapter 4: Software..... 55
About the Software 55
Folders for this Mainboard 55
Running the Support CD-ROM 57
Utility Folder Installation Notes..... 57
CMI8X38 Folder Installation Notes..... 58
Audio Software---------- 58
Modem Driver and Software---------- 59
VIA Folder Installation Notes..... 59
GL520SM Folder Installation Notes..... 60
Mainboard (P6BAT-Me) Installation Notes 60

Appendix 1: Quick Jumper Setting Reference 61

Appendix 2: Glossary 63