

# 2S1P I/O Card-Jumper Setting & Address/IRQ

## Jumper Setting & Address/IRQ Assignment

Jumper No.	Pin No. Closed	Port Name	Address/IRQ	Factory Default
1	1 & 2			OFF
	3 & 4			OFF
	5 & 6	COM2	2F8	ON
	7 & 8	LPT1	378	ON
	9 & 10	COM1	3F8	ON
2	1 & 2	COM1	IRQ3	
	3 & 4	COM2	IRQ4	ON
3	1 & 2	COM2	IRQ3	ON
	3 & 4	COM2	IRQ4	
4	1 & 2	LPT1	IRQ7	ON
	3 & 4	LPT1	IRQ5	

## 2S1P I/O Card Layout

