



## Setting Jumpers

### Jumper Settings

Jumper	Type	Description	Setting (default)
JP1	3-pin	Clear CMOS	1-2: <i>Normal</i> 2-3: Clear CMOS 
JP2	2-pin	BIOS flash protection	<i>Open: Unlock</i> Short: Lock 

**Jumper 1** – This jumper enables you to clear the BIOS. Refer to the following instructions:

1. Turn the system off.
2. Short pins 2 and 3 on JP1.
3. Return the jumper to the normal setting.
4. Turn the system on. The BIOS is returned to the default settings.

**Jumper 2** – This jumper enables you to prevent the BIOS from being updated (flashed). Set the jumper to unlock to update your BIOS. After updating the BIOS, change it to the locked setting. For instructions on updating, the BIOS refer to Chapter 3.