



Setting Jumpers

Jumper Settings

Jumper	Type	Description	Setting (default)
JP1	3-pin	Clear CMOS	1-2: Normal 2-3: Clear 
JP2	2-pin	BIOS flash protection	Short: Disable Open: Enable 

Jumper 1 – enables you to clear the BIOS:

1. Turn the system off.
2. Short pins 1 and 2 on jumper 1.
3. Return the jumper to the normal setting.
4. Turn the system on. The BIOS is returned to the default settings.

Jumper 2 – enables you to prevent the BIOS from being updated (flashed). Short the jumper to disable if you are going to update your BIOS. After updating the BIOS, return it to the enabled setting (open). For instructions on updating the BIOS refer to Chapter 3.