











Jumper Setting for System I/O (Continued)

JCP	Password Clear Select (Default)  Clear password 
J4	Display Type Select  Mono/EGA/VGA (Default)  CGA
JW7	Game Port Select  Disable game port  Enable game port (Default)
JR1	IDE Hard Disk R/W Signals From...  W83758  VT82C496G (Default)
JR2	Same as JR1
JH	Onboard FDC  Disable  Enable (Default)