













Jumper Setting for ISA IDE

JG	Onboard IDE Controller  Disable  Enable (Default)
J5	Local IDE Connector Jumper Select  IDE connector pin28 linked to BALE signal  IDE connector pin28 open (Default)
JP1	ISA IDE Connector Jumper Select  ISA IDE connector pin27 linked to IOCHRDY signal  ISA IDE connector pin27 open (Default)
JP2	ISA IDE Connector Jumper Select  ISA IDE connector pin28 linked to BALE signal  ISA IDE connector pin28 open (Default)

Jumper Setting for VESA Bus

JV1	High Speed Write Select  One wait write  Zero wait write (Default)
JV2	CPU Speed Select  Greater than 33 MHz  Less than or equal to 33 MHz (Default)