	Pin (defintions	of COM-pc	ort cables	for Jamico	on Mainbo	ards.	1
here are t	two types of cables	used for Jamio	con Mainboards (A	AT), known as	Type A & B(=C).			
ere is a lis	st of which mainboa	ard uses which	cable type.					
уре А		MB-KMT5-1; ; MB-KM566A	MB-KMT5-2; M (Rev:1.0)	B-KMT5-V1	MB-KMT5-V2;	MB-KMT5-V3	B; MB-KMT5-	V3+;
-				MD WAT ()	A ND WMEOOT	MB KMEOO		
уре В			5; MB-KMT5-T1; KM643E; MB-KI		1; MB-KM5331 	; MB-KM522V	/; 	
		•						
ere are th	ne lists of the two o	different cable	pin-outs. TYP	PF A				
		Flatcable	Description	SubD9male	SubD25male			
		1	DCD	1	8			
		2	DSR	6	6			
		3	RD RTS	<u>2</u> 7	3 4			
		5	SD	3	2			
		6	CTS	8	5			
		7	DTR	4	20			
		8	RI	9	22			
		9 10	GND N.C.	5 X	7 X			
		10	IV.C.	^	^			
			TYP					
		Flatcable	Description	SubD9male	SubD25male			
		1	DCD	1	8			
		3	RD SD	3	3			
		4	DTR	4	20			
		5	GND	5	7			
		6	DSR	6	6			
		7	RTS	7	4			
		8	CTS	8	5			
		9 10	RI N.C.	9 X	22			
		10	IV.C.		Y			
				^	Х			
	Pin	defintions	of USB-po			n Mainbo	ards.	
here are t	Pin (of USB-po	rt cables	for Jamico	n Mainbo	ards.	
		used for Jamic	on Mainboards, kr	rt cables	for Jamico	n Mainbo	ards.	
ere is a lis	two types of cables	used for Jamic ard uses which	on Mainboards, kr	ert cables	for Jamico	on Mainbo	ards.	
ere is a lis	st of which mainboom MB-KMV5-V1	used for Jamic ard uses which ; MB-KMT5-T	on Mainboards, kr cable type.	nown as Type	for Jamico		ards.	
ere is a lis	st of which mainboom MB-KMV5-V1	used for Jamic ard uses which ; MB-KMT5-T	on Mainboards, kr	nown as Type	for Jamico		ards.	
ype A ype B	st of which mainboom MB-KMV5-V1	used for Jamic ard uses which ; MB-KMT5-T	on Mainboards, kr cable type. 1; MB-KMT6-AI	nown as Type L1 A; MB-KM64	for Jamico		ards.	
ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which ; MB-KMT5-T	on Mainboards, kr cable type. T1; MB-KMT6-AI T3; MB-KM566,	nown as Type L1 A; MB-KM64	for Jamico A & B. 3E; MB-KM643		ards.	
ere is a lis ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which ; MB-KMT5-T 2A; MB-KMT5-	on Mainboards, kr cable type. 1; MB-KMT6-AI	nown as Type L1 A; MB-KM64	for Jamico		ards.	
ere is a lis ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which 1; MB-KMT5-T 2A; MB-KMT5- different cable Pin 1 2	on Mainboards, kr cable type. T1; MB-KMT6-AI T3; MB-KM566, pin-outs. TYP Description +5V USB-	nown as Type L1 A; MB-KM64 PE A Pin 1 2	Description +5V USB-		ards.	
ere is a lis ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which ; MB-KMT5-T A; MB-KMT5- different cable Pin 1 2 3	on Mainboards, kr cable type. 1; MB-KMT6-AI T3; MB-KM566, pin-outs. TYP Description +5V USB- USB+	nown as Type L1 A; MB-KM64 PE A Pin 1 2 3	Description +5V USB- USB+		ards.	
ere is a lis ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which 1; MB-KMT5-T 2A; MB-KMT5- different cable Pin 1 2	on Mainboards, kr cable type. T1; MB-KMT6-AI T3; MB-KM566, pin-outs. TYP Description +5V USB-	nown as Type L1 A; MB-KM64 PE A Pin 1 2	Description +5V USB-		ards.	
ere is a lis ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which ; MB-KMT5-T A; MB-KMT5- different cable Pin 1 2 3	on Mainboards, kr cable type. 1; MB-KMT6-AI T3; MB-KM566, pin-outs. TYP Description +5V USB- USB+	nown as Type L1 A; MB-KM64 PE A Pin 1 2 3 4	Description +5V USB- USB+		ards.	
ere is a lis ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which ; MB-KMT5-T A; MB-KMT5- different cable Pin 1 2 3	on Mainboards, kr cable type. 11; MB-KMT6-AI T3; MB-KM566 pin-outs. TYP Description +5V USB- USB+ GND	nown as Type L1 A; MB-KM64 PE A Pin 1 2 3 4	Description +5V USB- USB+		ards.	
ere is a lis ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which 1; MB-KMT5-T 2A; MB-KMT5- different cable Pin 1 2 3 4 Pin 1	on Mainboards, kr cable type. T1; MB-KMT6-AI T3; MB-KM566 pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB+ GND	nown as Type L1 A; MB-KM64 PE A Pin 1 2 3 4 E B Pin 4	Description USB- USB- USB- GND Description GND		ards.	
ere is a lis ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which ; MB-KMT5-T 2A; MB-KMT5- different cable Pin 1 2 3 4 Pin 1 2	on Mainboards, kr cable type. 1; MB-KMT6-AI T3; MB-KM566. pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB+ GND	nown as Type L1 A; MB-KM64 PE A Pin 1 2 3 4 E B Pin 4 3	Description Seription Seription		ards.	
ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which ; MB-KMT5-T A; MB-KMT5-T different cable Pin 1 2 3 4 Pin 1 2 3 4	on Mainboards, kr cable type. T1; MB-KMT6-AI T3; MB-KM566, pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB+ USB+ USB+ USB- USB- USB- USB-	nown as Type L1 A; MB-KM64 PE A Pin 1 2 3 4 E B Pin 4	Description +5V USB- USB+ GND Description GND USB+ USB- USB+ USB-		ards.	
ype A ype B	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2	used for Jamic ard uses which ; MB-KMT5-T 2A; MB-KMT5- different cable Pin 1 2 3 4 Pin 1 2	on Mainboards, kr cable type. 1; MB-KMT6-AI T3; MB-KM566. pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB+ GND	nown as Type L1 A; MB-KM64 PE A Pin 1 2 3 4 E B Pin 4 3	Description Seription Seription		ards.	
Type A Type B Here are th	MB-KMV5-V2 MB-KMV5-V2 The functional	used for Jamic ard uses which ; MB-KMT5-T A; MB-KMT5- different cable Pin 1 2 3 4 Pin 1 2 3 4 ity of the USB	on Mainboards, kr cable type. 1; MB-KMT6-AI T3; MB-KM566. pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB+ GND TYP OBSCRIPTION OB	nown as Type L1 A; MB-KM64 E A Pin 1 2 3 4 E B Pin 4 3 2 1 the same, only	Description +5V USB- USB- GND Description GND USB+ USB- +5V	-;		
Type A Type B Here are th	MB-KMV5-V2 MB-KMV5-V2 The functional	used for Jamic ard uses which ; MB-KMT5-T A; MB-KMT5- different cable Pin 1 2 3 4 Pin 1 2 3 4 ity of the USB	on Mainboards, kr cable type. 1; MB-KMT6-AI T3; MB-KM566, pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB+ GND	nown as Type L1 A; MB-KM64 E A Pin 1 2 3 4 E B Pin 4 3 2 1 the same, only	Description +5V USB- USB- GND Description GND USB+ USB- +5V	-;		
Igre is a listing a listing in the second se	two types of cables st of which mainbox MB-KMV5-V1 MB-KMV5-V2 ne lists of the two of The functional and therefor y	used for Jamic ard uses which I; MB-KMT5-T PA; MB-KMT5- Gifferent cable Pin 1 2 3 4 Pin 1 2 3 4 ity of the USB ou should use	on Mainboards, kr cable type. T1; MB-KMT6-AI T3; MB-KM566 pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB- USB- USB- USB- USB- USB- USB-	PE A Pin 1 2 3 4 E B Pin 4 3 2 1 Che same, only or universal ca	Description +5V USB- USB+ GND Description GND USB+ USB- +5V the layout of the bles.	e pins are differ		
Type A Type B Here are the	The functional and therefor yeary trouble, under	used for Jamic ard uses which ; MB-KMT5-T A; MB-KMT5- different cable Pin 1 2 3 4 Pin 1 2 3 4 ity of the USB rou should use	on Mainboards, kr cable type. T1; MB-KMT6-AI T3; MB-KM566 pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB- USB- USB- USB- USB- USB- USB-	PE A Pin 1 2 3 4 E B Pin 4 3 2 1 Che same, only or universal ca	Description +5V USB- USB+ GND Description GND USB+ USB- +5V the layout of the bles.	e pins are differ		
lere is a listype A lype B lere are the	The functional and therefor yeary trouble, under	used for Jamic ard uses which I; MB-KMT5-T PA; MB-KMT5-T CA; MB-KMT5-T Different cable Pin 1 2 3 4 Pin 1 2 3 4 ity of the USB rou should use rstanding this CTRONICS B.V.	on Mainboards, kr cable type. T1; MB-KMT6-AI T3; MB-KM566 pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB- USB- USB- USB- USB- USB- USB-	PE A Pin 1 2 3 4 E B Pin 4 3 2 1 Che same, only or universal ca	Description +5V USB- USB+ GND Description GND USB+ USB- +5V the layout of the bles.	e pins are differ		
Type A Type B Here are the	The functional and therefor yeary trouble, under	used for Jamic ard uses which I; MB-KMT5-T PA; MB-KMT5-T CA; MB-KMT5-T Pin 1 2 3 4 Pin 1 2 3 4 ity of the USB ou should use rstanding this CTRONICS B.V. 9-375100	on Mainboards, kr cable type. T1; MB-KMT6-AI T3; MB-KM566 pin-outs. TYP Description +5V USB- USB+ GND TYP Description +5V USB- USB- USB- USB- USB- USB- USB- USB-	PE A Pin 1 2 3 4 E B Pin 4 3 2 1 Che same, only or universal ca	Description +5V USB- USB+ GND Description GND USB+ USB- +5V the layout of the bles.	e pins are differ		