



CD663N

USER'S GUIDE





CD663N **CONTENTS**

Qrium CD663N USER GUIDE CONTENTS



CD663N







.....
↓
CONTENTS
.....

Starting	4
<hr/> How to use this manual / Check Items / System Setting	
1. System Configuration	7
<hr/> Front Configuration / Rear Configuration	
2. Installation	8
<hr/> Plugging Keyboard and Mouse / Plugging the Monitor Plugging the power cord / Plugging the RJ11 Phone line	
3. System Specifications	10
<hr/> System Configuration Table System Main Board Layout	
4. Troubleshooting	25

663N






Starting


Starting

1. How to use this manual

This manual is for anyone who wants to setup and configure the PC. It will help you to use CD663N computer easily. Please read this guide carefully before you install the system.



- For your safety, remember to turn off the system and to disconnect all cords and cables before opening the system chassis.
- To avoid electric shock, do not open the power supply.





2. Check Items

Your box should include CD663N, Keyboard, Mouse, and Power Cord.
Check all the items in your system box.



System




Keyboard



Mouse



Manual




CD-ROM Title




Power Cord



Modem Cable







Starting

3. System Setting


Operate the PC on a Sturdy level surface such as desk or table.




Please do not overload the power socket




Keep the computer away from high temperature and direct sunlight




Please do not place magnetic objects close to the system



Keep distance between the system and the wall




Keep the computer away from excessive moisture and dust




Place the system away from radio or any electronic receivers








1. System Configuration

1. Front Configuration



2. Rear Configuration






2. Installation


2. Installation

1. Plugging Keyboard and Mouse





- USB Keyboard/Mouse connectors are on the rear panel.
- Connect the keyboard cable to one of the USB connectors.
- Connect the mouse cable to the other USB connector.

2. Plugging the Monitor




Connect the monitor to the MONITOR connector colored royal blue.







3. Plugging the Power Cord




CD663N Computer System applies both 110/220 power range with automatic Voltage Switching

4. Plugging the RJ11 Phone Line(Modem Cable)

Locate telephone wall outlet. If a telephone is connected, you may need a telephone splitter cable or connector, Which allows you to connect both modem cable and telephone cable to the outlet. Plug one of the modem Cable end connector into Tel Line Socket on the rear of the computer. Plug the other end of the modem cable connector into the telephone wall outlet.







3. System Specifications

3. System Specifications



1. System Configuration Table


Motherboard	Daewoo CB663FB
Form Factor	FlexATX
Chipset	Intel i810e
CPU TYPE	FC-PGA Packaging, Celeron / Pentium III
RAM (SDRAM)	One 144-pin SODIM SOCKET, MAX 512MB
HDD	3.5" Ultra DMA 33/66 EIDE DRIVE
Video Card	Built-in 3D AGP, UMA with Intel D.V.M Technology
CD-ROM	24X slim type
Sound Card	Built-in (AC Link 97)
Fax/Modem	56K Mini-PCI Type III (combined with Ethernet)
Ethernet Card	10/100Mbps Mini-PCI Type III (with Fax/Modem)
Speaker	built-in stereo
Mouse	USB
KB	USB
USB Ports	Four USB Connectors
SMPS	60watts, AC-DC
BIOS	Phoenix PnP BIOS
Manageability	ACPI 1.0, PCI 2.0, PC 99





2. System Mainboard Layout





4. Troubleshooting


4. Troubleshooting


1. Troubleshooting

Solving General Problems

Problem	Cause	Solution
Computer won't turn on	Computer is not connected to an external power source	Connect to an external power source
	Cables to the external power source are unplugged	Ensure that cables connecting the computer to the external power source are plugged in properly and the wall outlet is active
Blank screen	Monitor is not turned on and the monitor light is not on	Turn on the monitor and check that the monitor light is on
Monitor does not function properly when used with energy saver features	Monitor without energy saver capabilities is being used with energy saver features enabled	Disable monitor energy saver feature
Sound does not come out of the speaker or headphones	Software volume control is turned down	Double click on the speaker icon on the taskbar, then set volume by adjusting the volume slider
System will not boot from CD-ROM	The CD-ROM boot is not enabled through the Computer Setup utility	Run the Computer Setup utility and set the drive priorities
	Non-bootable CD in drive	Try a bootable CD in the drive

- Additional troubleshooting information can be found at **www.datuspc.com** for US customers.





4. Troubleshooting

YOUR PRODUCT KEY FOR MICROSOFT WINDOWS 98
(CERTIFICATE OF AUTHENTICITY, #####-#####-#####-#####-#####)

www.datuspc.com

