


Quick Jumper Setting Reference


JP1: Power Option Jumper

Function	Jumper Position
5V standby (keyboard power on)	Short pins 1-2
Vcc (no keyboard power on)	Short pins 2-3




JP2: Onboard Graphics Enable/Disable Jumper

Function	Jumper Position
Enable onboard graphics	Open pins 1-2
Disable onboard graphics	Close pins 1-2




JP4: Select TV-out Format Jumper

Function	Jumper Position
Select NTSC	Open pins 1-2
Select PAL	Short pins 1-2



JP6: Clear CMOS Memory Jumper

Function	Jumper Position
Normal Operation	Short pins 1-2
Clear CMOS Memory	Short pins 2-3



PANEL1: Connectors for Case Switches and LEDs

Function	Pinout
Power Indicator	+1, +2, 3
Sleep Switch	4, 5
Green Indicator	+7, +8, 9
Key Lock	10, 11
Reset Switch	12, 13
Speaker	+15, 16, 17, 18
Hard Disk Indicator	+20, 21
Power Switch	+22, 23

