

---

## Chapter 3

### AMI BIOS

This chapter tells how to configure the system parameters. To update the BIOS ,refer to section "BIOS Flash Utility".




**Important:** Because the BIOS code is the most often changed part of the mainboard design, the BIOS information contained in this chapter (especially the Chipset Setup parameters) may be a little different compared to the actual BIOS that came with your mainboard.

#### 3.1 Entering the AMI BIOS Setup

BIOS setup utility is a segment of code/routine resides in the BIOS Flash ROM. This routine allows you to configure the system parameters and save them into 128 bytes CMOS area , (normally in the RTC chip or directly in the main chipset). To enter the BIOS Setup, press <Del> during POST (Power-On Self Test). The BIOS Setup Main Menu appears as shown below.


# AMI BIOS



The AMI BIOS is in Windows form. You can use either the keyboard or a mouse to move between the items. To select among the Setup menu groups, use <Tab> to highlight the selected group or simply click on the icon of the selected Setup menu. To select among the options, you can either use the arrow keys to move the highlight bar or simply click on the icon of the desired option. After making your selection, press <Enter> or double-click on the icon to open the selected menu option.


## 3.2 Setup Menu

The screen below shows the Setup menu window. Use the arrow keys to highlight an option.



### 3.2.1 Standard Setup


The following screen appears if you select **Standard** from the Setup options:



This Standard Setup menu allows you to setup basic information of hard disk, data/time and floppy. For hard disk parameters, choose any of following:

- Standard --> Pri Master**
- Standard --> Pri Slave**
- Standard --> Sec Master**
- Standard --> Sec Slave**

These items are setting of onboard IDE primary and secondary channel, each channel supports two IDE devices which are connected as master and slave. Refer to section 2.3 "Connectors" of how to connect them. The example below is for **Pri Master**.



## AMI BIOS

### Standard --> Pri Master --> Type

When move cursor bar to Type and press <Enter> , this menu appears:

Hard Disk Types					
Type	Cyl	Hd	WP	Sec	Size(MB)
Not Installed					
1	306	4	128	17	10
2	615	4	300	17	20
3	615	6	300	17	31
4	940	8	512	17	62
5	940	6	512	17	47

or

Hard Disk Types					
Type	Cyl	Hd	WP	Sec	Size(MB)
43	830	7	512	17	48
44	830	10	65535	17	69
45	917	15	65535	17	114
46	1224	15	65535	17	152
User					
Auto					
CDROM					

#### Type

Not Installed  
1  
2  
...  
46  
User  
Auto  
CDROM

This item lets you set the IDE device type that your system supports. Default is **Auto** to automatically detect the installed HDD or CDROM at POST (Power-On Self Test). Select **CDROM** if you have a CDROM installed in your system. Select type **1~46** if your HDD has parameters listed on the table. Select **User** if your HDD is not on the table and you prefer to enter parameters manually. Set this to **Not Installed** if no HDD connected. Normally, use **Auto** is enough for all kinds of conditions.

## Standard --> Pri Master --> LBA/Large Mode

### LBA/Large

Off  
On

The enhanced IDE feature allows the system to use a hard disk with a capacity of more than 528MB. This is made possible through the Logical Block Address (LBA) mode translation. LBA is now a standard feature of current IDE hard disk on the market, because they are all above 528MB. Note if HDD is formatted with LBA On, it will not be able to boot with LBA Off.

## Standard --> Pri Master --> Block Mode

### Block

Off  
On

This function enhances disk performance depending on the hard disk in use. If enabled, it allows data transfers in block (multiple sectors), and eliminate the interrupt handling time for each sector.

## Standard --> Pri Master --> 32Bit Mode

### 32Bit

Off  
On

Enabling this item improves system performance by using 32-bit instructions for disk access. Although IDE bus is always 16-bit, chipset will convert 32-bit instruction (command) to two 16-bit commands continuously together, and save the time to give second command. Note some old HDDs can not support too close of two 16-bit commands, if you are not sure, set it to **Off**.

## Standard --> Pri Master --> PIO Mode

### PIO

Auto  
0  
1  
2  
3  
4

Setting this item to **Auto** for auto-detecting the speed of hard disk drive. PIO mode represents data transfer rate of HDD, for example mode 0 is 3.3MB/s, mode 1 is 5.2MB/s, mode 2 is 8.3MB/s, mode 3 is 11.1MB/s and mode 4 is 16.6MB/s. In some cases, if your hard disk is unstable, you may manually try the slower mode.



**Caution:** The first IDE drive on each channel is recommended at far end side of cable. Refer to section 2.3 "Connectors" for detail.

## AMI BIOS

---

### Standard --> Date/Time

To set the date and time, highlight **Date/Time** and press <Enter>. The following screen appears:

Date/Time	
Date : Thu, Nov 7, 1996	<input data-bbox="1018 633 1059 678" type="button" value="+"/>
Time : 14:26:09	<input data-bbox="1018 689 1059 734" type="button" value="-"/>

Use the arrow keys to move among the items. Press or click on < +> or <-> to set the current time and date.

### Standard --> Floppy A


### Standard --> Floppy B

<u>Floppy A</u>
Not Installed
360KB 5.25"
1.2MB 5.25"
720KB 3.5"
1.44MB 3.5"
2.88MB 3.5"

Floppy drive type is normally auto-detected, the setting shown left are types supported by this mainboard. Floppy drive B has the same menu as drive A.

### 3.2.2 Advanced Setup

The following items appear if you select the option **Advanced** from the Setup menu:



#### Advanced --> Quick Boot

<b>Quick Boot</b>
Disabled
Enabled

Enable this item if you want to skip some POST (Power-On Self Test) routines during boot-up process. Set this to Disabled to let the system perform all the POST routines and follow the specified bootup sequence.

## AMI BIOS

---

### Advanced --> Power-on Delay

<b>Power-On Delay</b>
Disabled
2
3
...
15

This item lets you set the waiting time before system boot. Some large HDDs need more time for spindle motor to be stabilize and ready for data access. The settings are from 2 to 15 seconds.

### Advanced --> BootUp Sequence

<b>BootUp Sequence</b>
A:,C:,CDROM
A:,CDROM,C:
C:,A:,CDROM
C:,CDROM,A:
CDROM,A:,C:
CDROM,C:,A:

The bootup sequence allows you to specify the system boot search sequence. If you need to boot from CDROM, you may set the CDROM as the first priority. The default is **A:, C:, CDROM**, but after you have installed your operating system, we recommend to use **C:,A:,CDROM**, which prevents accidentally boot virus affected diskette.

### Advanced --> BootUp Num-Lock

<b>BootUp Num-Lock</b>
Off
On

Setting this item to On enables the numeric function of the numeric keypad. Disabling the numeric function allows you to use the cursor control keypad (arrow).

### Advanced --> Floppy Drive Swap

<b>Floppy Drive Swap</b>
Disabled
Enabled

This item allows you to swap floppy drives. For example, if you have two floppy drives (A and B), you can assign the first drive as drive B and the second drive as drive A or vice-versa.

### Advanced --> Floppy Drive Seek

<b>Floppy Drive Seek</b>
Disabled
Enabled

When enabled, the BIOS issues seek command to floppy during POST, to move floppy drive head forward and backward.

## Advanced --> Typematic Rate

### Typematic Rate

Disabled  
15  
20  
30

This item allows you to control the speed of repeated keystrokes. The default is 30 characters/sec.

## Advanced --> System Keyboard

### System Keyboard

Absent  
Present

If there is a keyboard connected to the system, set this item to Present. Otherwise, POST will bypass the keyboard test if select Absent.

## Advanced --> Primary Display

### Primary Display

Absent  
VGA/EGA  
CGA40x25  
CGA80x25  
Mono

This function selects the type of video card in use. The default setting is **VGA/EGA**. Because current PCs are almost all VGA only, this item becomes almost useless.

## Advanced --> Password Check

### Password Check

Setup  
Always

This item lets you set when to check for the password. When set to Always, a password prompt appears every time you turn-on the computer or when you enter Setup. When set to Setup, the password prompt appears when you try to enter Setup.

## Advanced --> Parity Check

### Parity Check

Disabled  
Enabled

Set this item to Enabled if you install SIMMs with parity in your system. Otherwise, set this item to Disabled. Since the DRAM can still operate without enabling the parity scheme for SIMMs with parity, this function is normally set to **Disabled**.

## AMI BIOS

---

### Advanced --> OS/2 Compatible Mode

<b><u>OS/2 Compatible Mode</u></b> Disabled Enabled
---

Enable this item if your system is utilizing an OS/2 operating system and has a memory size of more than 64 MB.

### Advanced --> Internal Cache

<b><u>Internal Cache</u></b> Disabled Enabled
---

This function lets you enable or disable the internal cache (The cache within CPU).

### Advanced --> External Cache

<b><u>External Cache</u></b> Disabled Enabled
---

This function lets you enable or disable the external cache (The PBRAM cache on the mainboard).

### Advanced --> System BIOS Cacheable

<b><u>System BIOS Cacheable</u></b> Disabled Enabled
--

Enabling this item allows you to cache the system BIOS to further enhance system performance.

## AMI BIOS

**Advanced --> C000, 16K Shadow**  
**Advanced --> C400, 16K Shadow**  
**Advanced --> C800, 16K Shadow**  
**Advanced --> CC00, 16K Shadow**  
**Advanced --> D000, 16K Shadow**  
**Advanced --> D400, 16K Shadow**  
**Advanced --> D800, 16K Shadow**  
**Advanced --> DC00, 16K Shadow**

### **C000,16K Shadow**

Disabled  
Enabled  
Cached

These items are for the shadow and cacheable option of ROM code on the expansion cards (including VGA). The shadow means to copy ROM code into faster DRAM and hence improves the execution performance of these ROM code. Cache them will further improve the performance but there are some cards have incompatible problem if cache its ROM code. You need to know the specific addresses of the ROM code, for example, VGA BIOS occupies segment C000 and C400, so that the default of C000 and C400 are Cached. If you do not know this information, enable all the ROM shadow settings. This ensures shadowing of any present ROMs and reduces the available memory.



**Note:** *The F000 and E000 segments are always shadowed because BIOS code occupies these area.*

## AMI BIOS

### 3.2.3 Chipset Setup

The **Chipset** Setup includes settings for the chipset dependent features, especially the features related to system performance.



**Caution:** Make sure you understand the meaning of each setting before you try to change anything. The settings in this section improve system performance but may cause system unstable if the setting are not correct for your system configuration.

Chipset Setup	
430HX Global Features	: Disabled
Memory Hole	: Disabled
8Bit I/O Recovery Time (Sysclk)	: 4
16Bit I/O Recovery Time (Sysclk)	: 1
DRAM Timings	: 60ns
DRAM Refresh Rate	: 66 Mhz
ISA Clock	: PCICLK/4
Turbo Read Leadoff	: Disabled
DRAM Read Burst Timing	: x333
DRAM Write Burst Timing	: x222
Fast RAS to CAS Delay (clocks)	: 3
DRAM Leadoff Timing	: 6/5/3/4
Speculative Leadoff	: Enabled
Turn-Around Insertion	: Disabled
Peer Concurrency	: Disabled
Memory Error Check Mode	: Disabled
PCI 2.1 Compliant	: Disabled
USB Host Controller	: Disabled
USB Legacy Support	: Disabled

#### Chipset --> 430HX Global Features

<b>430HX Global Features</b>
Disabled
Enabled

This option is a global control to enable or disable the 430HX chipset enhancement features. The Turbo default setting enables this item.

## Chipset --> Memory Hole

### Memory Hole

Disabled  
512K-640K  
15M-16M

This option lets you reserve system memory area for special ISA cards. Chipset accesses code/data of these area from the ISA bus directly, normally it is for memory mapped I/O card.

## Chipset --> 8Bit I/O Recovery Time (\$sysclk)

### 8Bit I/O Recovery Time (Sysclk)

Disabled  
8  
1  
2  
3  
4  
5  
6  
7

For some old I/O chips, when there is an I/O command finished, the device needs a specified amount of time (recovery time) before next I/O command can be started. Because of new generation CPU and mainboard chipset, the assertion of I/O command is getting faster, and sometimes shorter than specified I/O recovery time of old I/O devices. This item delays 8-bit I/O command by count of ISA bus clock, if you find any unstable 8-bit I/O card, you may try to extend the I/O recovery time by setting of this item. The BIOS default value is **4 system clocks**. If set to Disabled, the chipset will insert 3.5 system clocks.

## Chipset --> 16Bit I/O Recovery Time (\$sysclk)

### 16Bit I/O Recovery Time (Sysclk)

Disabled  
4  
1  
2  
3

The same as 8-bit I/O recovery time. This item delays 16-bit I/O command by count of ISA bus clock, if you find any unstable 16-bit I/O card, you may try to extend the I/O recovery time by setting of this item. The BIOS default value is **1 system clocks**. If set to Disabled, the chipset will auto insert 3.5 system clocks.

## Chipset --> DRAM Timings

### DRAM Timings

Manual  
60ns  
70ns

The selections for this item are 60ns, 70ns, and Manual. If you select either 60ns or 70ns, the DRAM Timing subitems become non-configurable since BIOS automatically sets the values. Select Manual if you want to specify your own item settings. The BIOS default is **60ns**.

## AMI BIOS

---



**Warning:** The default memory timing setting is 60ns to get the optimal performance. Because the specification limitation of chipset, 70ns SIMM can only be used with CPU external clock 60MHz or below. To use 70ns SIMM with 66MHz CPU external clock may result in unstable system behavior.

### Chipset --> DRAM Refresh Rate

#### DRAM Refresh Rate

50 Mhz  
60 Mhz  
66 Mhz

This option lets you specify the clock frequency at which the chipset refreshes the DRAM to avoid data lost. The setting is normally equal to CPU bus clock (external clock).

### Chipset --> ISA Clock

#### ISA Clock

PCICLK/4  
PCICLK/3

This option specifies the ISA bus clock frequency. The selections are PCI bus clock divide by 4 or PCI clock divide by 3, PCI clock is the half of CPU bus clock, for example, 66Mhz CPU bus clock has 33Mhz PCI bus clock, and the ISA bus clock should be  $33M/4= 8.25Mhz$ , The ISA bus clock must be near 8Mhz.

### Chipset --> Turbo Read Leadoff

#### Turbo Read Leadoff

Disabled  
Enabled

This item is reserved for cacheless configuration only. When enabled, chipset bypasses the first data input of the DRAM data pipeline buffer. Therefore, reduces one clock of DRAM read leadoff timing. The default is **Disabled**.



**Warning:** "Turbo Read Leadoff" can only be enabled for cacheless system or external cache disabled.

**Chipset --> DRAM Read Burst Timing**

**DRAM Read Burst Timing**  
x444  
x333

The Read Burst means to read four continuous memory cycles on four predefined addresses from the DRAM. The default value of 60ns FPM (Fast Page Mode) DRAM is x333 which means the 2nd,3rd and 4th memory cycles are 3 CPU clocks. For EDO DRAM, the chipset will automatically reduce one clock, that is, x444 becomes x333 and x333 becomes x222. The value of x is the timing of first memory cycle and depends on the "DRAM Leadoff Timing" setting

**Chipset --> DRAM Write Burst Timing**

**DRAM Write Burst Timing**  
x444  
x333  
x222

The Write Burst means to write four continuous memory cycles on four predefined addresses to the DRAM. This item sets the DRAM write timing of the 2nd,3rd and 4th memory cycles. There is no difference of EDO and FPM DRAM on the write burst timing. The value of x depends on the "DRAM Leadoff Timing" setting

**Chipset --> Fast RAS to CAS Delay (clocks)**

**Fast RAS to CAS Delay (clocks)**  
3  
2

This option specifies the wait state between the DRAM row address strobe (RAS) and column address strobe (CAS) signals. The default setting is **3 clocks**.

**Chipset --> DRAM Leadoff Timing**

**DRAM Leadoff Timing**  
7/6/3/4  
6/5/3/4  
7/6/4/5  
6/5/4/5

The Leadoff means the timing of first memory cycle in the burst read or write. Actually, this setting includes not only read/write leadoff timing but also the clocks of RAS precharge and width of refresh RAS signal. The four digital represent Read Leadoff/ Write Leadoff/ RAS Precharge/ Refresh RAS Width. For example, default is **6/5/3/4**, which means you have 6xxx DRAM read and 5xxx DRAM write, with 3 clocks RAS precharge and 4 clock refresh RAS width.

## AMI BIOS

---

### Chipset --> Speculative Leadoff

**Speculative  
Leadoff**

Disabled  
Enabled

Enable this item reduce one clock of DRAM read leadoff timing by presenting the DRAM read request before the controller chip decodes the final memory target (i.e., cache, DRAM or PCI). For example, the DRAM read timing of 60ns EDO is 6-2-2-2, Enable this option improve DRAM read timing to 5-2-2-2.

### Chipset --> Turn-Around Insertion

**Turn-Around  
Insertion**

Disabled  
Enabled

Enabling this option allows the chipset to insert one turn-around clock cycle to the memory data bus for back-to-back memory read and write cycles. If you have large loading on the memory data bus, for example, four SIMMs with many DRAM chips on the SIMM, this option provides a safety time for data bus to switch direction.

### Chipset --> Peer Concurrency

**Peer  
Concurrency**

Disabled  
Enabled

Peer Concurrency enables the CPU to run DRAM or cache cycle while PCI master is accessing PCI target (slave), however, the CPU to/from PCI bus will still be blocked. If Disabled, the CPU will always be blocked when PCI master owns the PCI bus. This function is useful if you have heavy loading PCI masters on your system (such as PCI SCSI or Network card).

### Chipset --> Memory Error Check Mode

**Memory Error  
Check Mode**

Disabled  
Parity  
ECC

This item selects the memory error check mode. The parity mode uses 1 parity bit for each byte, each time the memory data is updated, parity bit will be adjusted to have even count "1" for each byte. When next time, if memory is read with old number of "1", the parity error is occurred and this is called single bit error detection. The ECC mode needs 8 ECC bit for 64 bit data, ECC bits are updated and checked by special algorithm, the ECC algorithm has the ability to detect double bit error and automatically correct single bit error.



**Tip:** Because 36 bit SIMM has 4 bit more for parity, the ECC mode can be supported by two traditional parity SIMMs, it is no need to have special ECC SIMM.

## Chipset --> PCI 2.1 Compliant

**PCI 2.1  
Compliant**  
Disabled  
Enabled

This item lets you control the Passive Release or Delayed Transaction function of the PIIX3 chipset (Intel PCI to ISA bridge). Enable it complies with the PCI revision 2.1. Try to enable or disable it, if you have ISA card compatibility problem.

## Chipset --> USB Host Controller

**USB Host  
Controller**  
Disabled  
Enabled

This item lets you enable or disable the USB function in chipset. The mainboard acts as USB host, and you can plug USB devices on the USB connector of back panel. You need USB driver to support USB devices, normally, they are provided by USB device vendors or operating system such as Win95.



**Important:** The USB function shares INTD with PCI slot 4. Therefore, if you enable the USB function, only PCI cards that do not require IRQ, such as VGA, can be installed in slot 4. The PnP BIOS assigns an IRQ to VGA only if the VGA requests for it.

## Chipset --> USB Legacy Support

**USB Legacy  
Support**  
Disabled  
Enabled

This item lets you enable or disable the USB keyboard driver within the onboard BIOS. The keyboard driver simulates legacy keyboard command and let you use USB keyboard during POST or after boot if you don't have USB driver in the operating system.




**Caution:** You can not use both USB driver and USB legacy keyboard at the same time. Disable "USB Legacy Support" if you have USB driver in the operating system.


## AMI BIOS

### 3.2.4 Power Management Setup

To take advantage of the power-management feature, select **Power Mgmt** from the Setup menu. The following items appear:



The states transition of power management is shown below. Note that monitor and HDD can be on or off at Standby and Suspend state, depend on the setting in "Green Monitor Power Down State" and "Hard Disk Power Down Mode":



**Power Mgmt --> Power Management/APM**

**Power Management/APM**  
 Disabled  
 Enabled  
 Instant-On

This item is the global control to enable or disable the advanced power-management function.

**Power Mgmt --> Instant-OnTimeout (Minutes)**

**Instant-On Timeout (Minutes)**  
 Disabled  
 1  
 .....  
 15

This item is configurable only if the Power Management/APM item is set to Instant On. This lets you specify when to resume system power after being in power-saving mode for a certain period of time.

## AMI BIOS

---

### Power Mgmt --> Green Monitor Power Down State

<b><u>Green Monitor Power Down State</u></b>
--

Standby Suspend Off
---------------------------

This function lets you select at which state to power down your monitor. BIOS blanks the screen and power down the monitor by special signal (VSYNC, HSYNC) on the monitor connector. You need DPMS (Display Power Management Standard) monitor to support power down function.

### Power Mgmt --> Display Card Power Down Mode

<b><u>Display Card Power Down State</u></b>
---

Disabled Standby Suspend
--------------------------------

This option allows you to select at which state to power down your system display card. You need display card which supports power down command for this function.

### Power Mgmt --> Hard Disk Power Down Mode

<b><u>Hard Disk Power Down State</u></b>
--

Disabled Standby Suspend
--------------------------------

This option allows you to select at which state to power down your IDE hard disk. The reduction of power consumption is achieved by shutting down the spindle motor of HDD. You need HDD which supports power down command for this function.

### Power Mgmt --> Hard Disk Timeout (Minutes)

<b><u>Hard Disk Timeout (Minute)</u></b>
--

Disabled 1 ..... 15
------------------------------

This option lets you set the time of your IDE hard disk to go into power down state (spindle motor off) when there is no hard disk activities. This item is independent with the power state described above (Standby and Suspend).

**Power Mgmt --> StandbyTimeout (Minutes)**

<b><u>Standby Timeout</u></b> <b><u>(Minute)</u></b>
Disabled
1
.....
15

This item lets you set the time of your system to go into Standby power down state when there is no system activities. In Standby state, CPU clock is slowdown according to the ratio set in "Slow Clock Ratio" below. Any event detected returns the system to full power. The system activity(or event) is detected through monitoring of IRQ signals.

**Power Mgmt --> SuspendTimeout (Minutes)**

<b><u>Suspend Timeout</u></b> <b><u>(Minute)</u></b>
Disabled
1
.....
15

This item lets you set the time (after Standby) to go into Suspend power down state when there is no system activities. System goes to Standby first and then goes to Suspend state. In Suspend state, CPU clock is stopped. Any event detected returns the system to full power. The system activity(or event) is detected through monitoring of IRQ signals.

**Power Mgmt --> Slow Clock Ratio**

<b><u>Slow Clock Ratio</u></b>
1:1
1:2
1:4
1:8
1:16
1:32
1:64
1:128

When the system enters the Standby state, the CPU clock count in a giving time (not frequency) is reduced by the ratio set in this item, actually, the period per CPU clock is not changed. For example, 30ns clock period of 66MHz CPU clock is not changed at Standby state, chipset generates STPCLK (stop clock) signal periodically to prevent CPU for accepting clock from clock generator. For full power on, the CPU can receive 66M count in one second, but if the ratio is set at 1:2, the CPU will only receive 33M clock count in one second at Standby state. This will effectively reduce CPU speed as well as CPU power. This method is also known as Clock Throttling.

## AMI BIOS

---

**Power Mgmt --> IRQ3**(COM2)  
**Power Mgmt --> IRQ4**(COM1)  
**Power Mgmt --> IRQ5**(Network/Sound or Others)  
**Power Mgmt --> IRQ7**(Printer or Others)  
**Power Mgmt --> IRQ8**(RTC)  
**Power Mgmt --> IRQ9**(Video or Others)  
**Power Mgmt --> IRQ10**(SCSI or Others)  
**Power Mgmt --> IRQ11**(SCSI or Others)  
**Power Mgmt --> IRQ12**(PS/2 Mouse or Others)  
**Power Mgmt --> IRQ13**(Floating Point of CPU)  
**Power Mgmt --> IRQ14**(IDE1)  
**Power Mgmt --> IRQ15**(IDE2)

### **IRQ3**

Ignore  
Monitor  
WakeUp  
Both

The system activities are monitored through the specified IRQ signals to determine the transition of power state. Set parameter to **Monitor** allows system to monitor the IRQ and wait for timeout to go into Standby or Suspend state. Set parameter to **WakeUp** allows system to back to full power if the activity associated with this IRQ is detected. **Both** has function of both Monitor and WakeUp.,



**Note:** The system activities listed above are general PC standard, special card may require special IRQ, refer to card manual for correct IRQ setting. You may also refer to Win95 "Device Manager" for which IRQ is assigned to which device.



**Important:** The IRQ8 is fixed for RTC and IRQ13 is fixed for floating point. They are recommended to set at Ignore. If IRQ8 is not Ignore, OS/2 may fail to go into Standby/Suspend, because of the periodically RTC interrupt.

**Important:** Network workstation will periodically receive the polling command from network server, if the IRQ of network card (normally IRQ5 or IRQ3) is not set to Ignore, the system may fail to go into Standby/Suspend

### 3.2.5 PCI/PnP Setup

The PCI/PnP Setup allows you to specify the setting for your PCI devices. The items below appear if you select **PCI/PnP** from the Setup menu.



**Note:** You can press <Ins> to enter the BIOS Setup screen. This procedure resets PnP configuration information and reconfigure PnP resource again, it allows you to solve an IRQ/DMA/Memory resources conflict.

**PCI/PnP Setup**

Plug and Play Aware OS	: No
PCI VGA Palette Snoop	: Disabled
PCI IDE Card	: Auto
PCI IDE Primary IRQ	: Disabled
PCI Slot1 IRQ Priority	: Auto
PCI Slot2 IRQ Priority	: Auto
PCI Slot3 IRQ Priority	: Auto
PCI Slot4 IRQ Priority	: Auto
DMA Channel 0	: PnP
DMA Channel 1	: PnP
DMA Channel 3	: PnP
DMA Channel 5	: PnP
DMA Channel 6	: PnP
DMA Channel 7	: PnP
IRQ3	: PCI/PnP
IRQ4	: PCI/PnP
IRQ5	: PCI/PnP
IRQ7	: PCI/PnP
IRQ9	: PCI/PnP
IRQ10	: PCI/PnP
IRQ11	: PCI/PnP
IRQ14	: PCI/PnP
IRQ15	: PCI/PnP
Reserved Memory Size for ISA	: Disabled
Reserved Memory Base for ISA	: C8000

## AMI BIOS

---

### PCI/PnP --> Plug and Play Aware O/S

**Plug and Play  
Aware O/S**

No  
Yes

Normally the PnP resource is allocated by BIOS during POST (Power-On Self Test). If you are using PnP operating system (such as Windows 95), you may set this item to Yes, which informs BIOS to configure only the resources needed for boot (VGA/IDE or SCSI). The rest of system resources will be allocated by PnP operating system.

### PCI/PnP --> PCI VGA Palette Snoop

**PCI VGA  
Palette Snoop**

Disabled  
Enabled

Enable this item informs the PCI VGA card to be quiet preventing conflict when the palette register is updated (accept data without responding any communication signals). This is only useful for two display cards use the same palette address and plugged on the PCI bus together (such as MPEQ or Video capture), one is set to be quiet and the other is set to act normally.

### PCI/PnP --> PCI IDE Card

**PCI IDE Card**

Auto  
Slot1  
Slot2  
Slot3  
Slot4

Some old PCI IDE add-on cards are not fully PnP compatible. You need to specify the slot you are using for BIOS to configure correct PnP resources. This function allows you to select the PCI slot for any of PCI IDE add-on card present. Set this item to **Auto** to automatically configure the installed PCI IDE card.

### PCI/PnP --> PCI IDE Primary IRQ

### PCI/PnP --> PCI IDE Secondary IRQ

**PCI IDE  
Primary IRQ**

Disabled  
INTA  
INTB  
INTC  
INTD  
Hardwired

These two items are in conjunction with "PCI IDE Card" to decide IRQ routing of the primary or secondary channel of the PCI IDE add-on card (not the onboard IDE). Each PCI slot has 4 PCI interrupts aligned as the table below, you have to specify the slot in "PCI IDE Card" above and choose the PCI interrupt (INTx) according to the interrupt connection on the card. There are also cards support legacy mode only, which is, connect IRQ directly through small extension card on ISA bus, not through PCI interrupt. In such case, select Hardwired.

## AMI BIOS

PCI Slot	Location 1 (pin A6)	Location 2 (pin B7)	Location 3 (pin A7)	Location 3 (pin B8)
Slot 1	INTA	INTB	INTC	INTD
Slot 2	INTB	INTC	INTD	INTA
Slot 3	INTC	INTD	INTA	INTB
Slot 4	INTD	INTA	INTB	INTC
Slot 5 (if any)	INTD	INTA	INTB	INTC

**PCI/PnP --> PCI Slot1 IRQ Priority**

**PCI/PnP --> PCI Slot2 IRQ Priority**

**PCI/PnP --> PCI Slot3 IRQ Priority**

**PCI/PnP --> PCI Slot4 IRQ Priority**

**PCI Slot1 IRQ  
Priority**

Auto  
None  
3  
4  
5  
7  
9  
10  
11  
12

These items let you specify the preferred IRQ priority for each PCI slot. PnP BIOS will assign the IRQ to each slot according to the priority of these settings. Set to **Auto** for PnP BIOS to configure IRQ automatically without any priority preferred. Set to **None** if you does not want PnP BIOS to allocate any IRQ for this slot (such as VGA card). Set to specific IRQ if you prefer this IRQ for this card on this slot.

## AMI BIOS

---

**PCI/PnP --> DMA Channel 0**  
**PCI/PnP --> DMA Channel 1**  
**PCI/PnP --> DMA Channel 3**  
**PCI/PnP --> DMA Channel 5**  
**PCI/PnP --> DMA Channel 6**  
**PCI/PnP --> DMA Channel 7**

<b><u>DMA Channel 0</u></b>
-----------------------------

PnP ISA
------------

If your ISA card is not PnP compatible and needs special DMA channel to support its function, specify the DMA channel as **ISA**, which informs PnP BIOS to reserve this DMA channel for the this legacy ISA card. The default is **PnP**. PCI card has no DMA channel.

**PCI/PnP --> IRQ3(COM2)**  
**PCI/PnP --> IRQ4(COM1)**  
**PCI/PnP --> IRQ5(Network/Sound or Others)**  
**PCI/PnP --> IRQ7(Printer or Others)**  
**PCI/PnP --> IRQ9(Video or Others)**  
**PCI/PnP --> IRQ10(SCSI or Others)**  
**PCI/PnP --> IRQ11(SCSI or Others)**  
**PCI/PnP --> IRQ14(IDE1)**  
**PCI/PnP --> IRQ15(IDE2)**

<b><u>IRQ3</u></b>
--------------------

PCI/PnP ISA
----------------

If your ISA card is not PnP compatible and needs special IRQ to support its function, specify the IRQ as **ISA**, which informs PnP BIOS to reserve this IRQ for the this legacy ISA card. The default is **PCI/PnP**. PCI card are always PnP compatible (except old PCI IDE card).

### **PCI/PnP --> Reserved Memory Size for ISA**

<b><u>Reserved Memory Size for ISA</u></b>
--

Disabled 16K 32K 64K
-------------------------------

If your ISA card is not PnP compatible and needs special memory space to support its function, specify the memory size in this item, which informs PnP BIOS to reserve the memory space for legacy ISA card. The default is **Disabled**.

## PCI/PnP --> Reserved Memory Base for ISA

<b><u>Reserved Memory Base for ISA</u></b>
--


C0000
C4000
C8000
CC000
D0000
D4000
D8000
DC000

This item is in conjunction with "Reserved Memory Size for ISA" to specify memory space of the non-PnP compatible ISA card. This item sets the memory base (start address), the memory size is specified above.

## AMI BIOS

### 3.2.6 Peripheral Setup

Select **Peripheral** from the Setup menu and the following screen appears.



#### Peripheral --> OnBoard FDC

##### OnBoard FDC

Auto  
Disabled  
Enabled

This item enables or disables the onboard floppy drive controller.

#### Peripheral --> OnBoard Serial Port1

#### Peripheral --> OnBoard Serial Port2

##### OnBoard Serial

##### Port1

Auto  
Disabled  
3F8h  
2F8h  
3E8h  
2E8h

These two items allow you to select the address for onboard serial ports. Selecting Disabled deactivates the port.

#### Peripheral --> Serial Port2 Mode

##### Serial Port2

##### Mode

Normal  
HPSIR  
ASKIR

This item is configurable only if the " OnBoard Serial Port2" is enabled. This allows you to specify the mode of serial port2. The available mode selections are:

## AMI BIOS

- **Normal** - Sets serial port 2 to operate in normal mode. This is the default setting.
- **HPSIR** - Select this setting if you have installed Infrared module on the IrDA connector (refer to section 2.3 "Connectors"). This setting allows infrared serial communication at a maximum baud rate of 115K baud.
- **ASKIR** - Select this setting if you have installed Infrared module on the IrDA connector (refer to section 2.3 "Connectors"). This setting allows infrared serial communication at a maximum baud rate of 19.2K baud.

### Peripheral --> OnBoard Parallel Port

<b><u>OnBoard Parallel Port</u></b> Auto Disabled 378h 278h 3BCh
---

This item allows you to select the address for the parallel port. Selecting Disabled deactivates the parallel port.

### Peripheral --> Parallel Port IRQ

<b><u>Parallel Port IRQ</u></b> 5 7
---

This item is configurable only if the "Onboard Parallel Port" is NOT set to Auto. This allows you to set an IRQ for the parallel port function. The default is 7 for first parallel printer port.

### Peripheral --> Parallel Port Mode

<b><u>Parallel Port Mode</u></b> SPP EPP ECP
---

This item specifies the parallel port mode. The mode options are SPP (Standard and Bi-direction Parallel Port), EPP (Enhanced Parallel Port) and ECP (Extended Parallel Port). SPP is the IBM AT and PS/2 compatible mode. EPP enhances the parallel port throughput by directly write/read data to/from parallel port without latch. ECP supports DMA and RLE (Run Length Encoded) compression and decompression.

## AMI BIOS

---

### Peripheral --> OnBoard IDE


#### **OnBoard IDE**

Disabled  
Primary  
Secondary  
Both

This item enables or disables the onboard IDE controller. Select **Primary** to enable primary channel and disable secondary channel. Select **Secondary** to disable primary and enable secondary channel. Select **Both** to enable both of them.


### 3.3 Security Setup

The Security window contains the password and anti-virus features.



#### **Supervisor Password**

The use of password prevents unauthorized use of your computer. If you set a Supervisor password, the system prompts for this password before granting access to Setup or system boot, depending on the Password Check setting in the "Advanced Setup" menu (refer to section 3.2.2). To set a Supervisor password, select **Supervisor** from the Security window. The following screen appears:



Follow these steps to set up a password using the keyboard or mouse:

1. Type/click in a six-character password using letters, numbers, or a combination of both. When you type the characters, they appear as asterisks on the password screen boxes.
2. Press or click on <Enter>.
3. Retype the password when a password confirmation box appears asking you to retype the password.

## User Password

To set a User password, select **User** from the Security window. The screen and procedures are similar as Supervisor password described above.



**Note:** *The Supervisor and User password are currently implemented the same privilege to access the same system information.*

## Anti-Virus

### Anti-Virus

Disabled  
Enabled


The Anti-Virus protection option allows you to enable or disable the virus protection feature. If enabled, BIOS issues warning when boot sector of IDE HDD is going to be modified.

## AMI BIOS

---

### 3.4 Utility Setup

The Utility window lets you change WinBIOS Setup colors and language setting.



#### Color Set

**Color Set**

LCD  
Army  
Pastel  
Sky

The Color Set allows you to select your desired background color for AMI WinBIOS.

#### Language

**Language**

English

The system language currently supported is only English. Therefore, this option is non-configurable and is for display only.

### 3.5 Default Setup

The Default window allows you to select two sets of AMI BIOS default setting (**Optimal** and **Turbo**).



### Original

Actually, Original is not a set of default setting, it is a little like "Undo", choose Original if you change some setting and you don't want to save them.

### Optimal

Select Optimal to load the optimal default value. Optimal is relatively safer than Turbo, It is the setting for general optimal performance. We recommend to use Optimal if you have large memory size and full loading of add-on card, for example, file server using double side 8MB SIMM x4 and SCSI plus Network card occupy many of the PCI and ISA slots. Optimal is not the slowest setting of this mainboard, if you need to verify any unreliable problem, you may set manually in "Advanced Setup" and "Chipset Setup" to get slowest and most save setting.

### Turbo

Turbo default value has better performance than Optimal, it is not the best performance setting of this mainboard but it is setting qualified by AOpen RD and QA department that we think it is reliable if you have limited add-on card with light loading of memory (for example, VGA/Sound and two SIMMs only). If you need best performance, you may set manually in "Chipset Setup" to get proprietary setting, be sure you understand every item in "Chipset Setup". The performance difference of Optimal and Turbo is normally around 3% to 10%, depending on chipset and application.

## 3.6 Exiting Setup

Carefully check your new settings when you have finished configuring the system. If correct, write them down and keep the recorded values in a safe place. If in the future, the battery loses power or the CMOS chip is damaged, you will know what values to enter when you rerun setup.

Press <Esc> and select **Save changes and Exit** to save the changes that you made. Select **Do not save changes and Exit** to leave setup without saving your changes. Select **Continue** if you want to make any more configuration changes.

## AMI BIOS

---

### 3.7 Onboard NCR SCSI BIOS

The NCR 53C810 SCSI BIOS resides in the same flash memory chip as the system BIOS. The onboard NCR SCSI BIOS is used to support NCR 53C810 SCSI control card without the need of BIOS code on the SCSI card.

The NCR SCSI BIOS directly support DOS, Windows 3.1 and OS/2, but you may get better performance by using drivers come from the NCR SCSI card vendor or from operating system (such Windows 95). For detail, refer to the installation manual of your NCR 53C810 SCSI card.

### 3.8 AMI Flash Utility

The AMI Flash Utility allows you to upgrade the system BIOS. To get the AMI flash utility and the upgrade BIOS file, contact your local distributor or visit our homepage at <http://www.aopen.com.tw>. The file name of AMI flash utility is AMIFLASH.EXE, run this program under DOS, follow the instruction on the screen, actually, you need only input the BIOS file name. After programming, reboot your system for the new BIOS to take effect.



**Warning:** Make sure you use AMI Flash Utility version 5.23 or later, the version before 5.23 has bug to program INTEL 12V Flash ROM, and after the programming, the system may fail to reboot.

**Warning:** Be sure you get the correct BIOS file and carefully read the instruction and notice from AOpen homepage. Use incorrect BIOS file on incorrect version of mainboard may damage your system.