

PENTIUM[®]
P5V580 VP3

Notice

The information in this document is subject to change in order to improve reliability, design, or function without prior notice and does not represent a commitment on the part of this company. In no event will we be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or the possibility of such damages.

All trademarks are the property of their respective owners.

CONTENTS

<i>CPU Speed Quick Setup(English)</i> -----	1
<i>CPU Speed Schnell-Installation(Deutsch)</i> -----	3
<i>Fácil Y Veloz Rápida Instalación(Español)</i> -----	5
<i>Facilité de vitesse Initialisation(Francais)</i> -----	7
<i>Setup Della Scheda CPU Speed(Italiano)</i> -----	9
<i>CPU Speed</i> çìÈÙ•2×•Ö,ÄI(ÖÐÎÄ·±Ìå)-----	11
<i>CPU Speed</i> çìÈÙ•2×•Ö,ÄI(ÖÐÎÄ¼òÌå) -----	13
1. Introduction	1-1
1.1 Overview.....	1-1
1.2 Key Features.....	1-1
2. Connector Configuration	2-1
2.1 Power Connector.....	2-1
2.2 Modem Ring on Connector	2-1
2.3 ATX Power Connector	2-1
2.4 Power Switch.....	2-1
2.5 Keyboard Connector	2-2
2.6 Hard Disk LED Connector.....	2-2
2.7 Reset Switch.....	2-2
2.8 Speaker Connector.....	2-2
2.9 Power LED & Keylock.....	2-2
2.10 Green-LED	2-3
2.11 SLEEP.....	2-3
2.12 USB1/USB2 Connector.....	2-3
2.13 FAN Connector.....	2-3
2.14 Wake up on LAN Connector.....	2-3

CONTENTS

2.15 PS/2 Mouse	2-4
2.16 IrDA Connector	2-4
2.17 I/O Port Description.....	2-5
2.18 Clear CMOS.....	2-5
2.19 Memory Configuration	2-6
3. AWARD BIOS Description.....	3-1
3.1 Entering BIOS Setup.....	3-1
3.2 Standard CMOS Setup	3-2
3.3 CPU Speed Setup.....	3-4
3.4 BIOS Features Setup.....	3-5
3.5 Chipset Features Setup	3-7
3.6 Power Management Setup.....	3-9
3.7 PNP/PCI Configuration Setup	3-11
3.8 Load Setup Defaults	3-12
3.9 Integrated Peripherals.....	3-13
3.10 Password Setting.....	3-14
3.11 IDE HDD Auto Detection.....	3-15
3.12 Power-On Boot	3-16
APPENDIX.....	A-1
Appendix A Utility Diskette	A-1
Appendix B Introduce AMD-K5 CPU mark	A-2
Appendix C Introduce AMD-K6 CPU mark	A-3
Appendix D Introduce Cyrix 6x86 CPU mark.....	A-4
Appendix E Introduce Cyrix 6x86MX CPU mark.....	A-5



CPU Speed Quick Setup

Procedures :

1. Insert the CPU correctly.
2. Plug in other configurations and restore the system.
3. Press key and power on the system to enter BIOS Setup.
4. Enter “CPU Speed Setup” menu to set up CPU speed.

Note: If you don't set CPU speed, your system will run at default setting (75MHz for Pentium and AMD CPU, 100MHz for Cyrix etc).

5. Save and exit BIOS Setup, then your system can boot successfully as you expected.

ENGLISH

CPU Speed Type introduction

CPU Speed Setup Menu

Select <CPU Speed Setup> item from the main menu and enter the sub-menu:




Figure - 1 CPU Speed Setup Menu

For *CPU Speed* mainboard, BIOS will provide you a set of basic values for your CPU selection instead of jumper setting. To make your system run as fast as possible, you can manually select CPU speed value in “CPU Speed” item on “CPU Speed Setup” menu screen.

Warning

You'd better not to set CPU frequency higher than its working frequency. Otherwise, we will not be responsible for any damage it causes.

Note: In addition, if your system can not boot up again because of wrong CPU setting, you can hold down the hot-key while power on the system, the system will reboot and run at basic values.



Schneller Überblick über die Einstellungen:

Vorgehensweise:

1. Setzen Sie die CPU richtig ein.
2. Stecken Sie weitere Komponenten ein und vervollständigen Sie das System.
3. Drücken < DEL > oder < ENTF > und schalten Sie das System ein, um in das BIOS-Setup zu gelangen.
4. Wählen Sie das Menü „CPU Speed Setup“, um die CPU-Taktfrequenz einzustellen.

Anmerkung: Wenn Sie die CPU-Taktfrequenz nicht einstellen, wird Ihr System in der Grundeinstellung laufen (75 MHz bei Intel Pentium® und AMD CPUs, 100 Mhz bei Cyrix 6x86 CPUs usw.).

5. Wählen Sie die Option „Save and Exit BIOS Setup“, um die vorgenommen Änderungen abzuspeichern. Anschließend können Sie wie erwartet das System erfolgreich hochfahren.

DEUTSCH

Installation der Mainboards vom Typ „CPU Speed“

Menü für die CPU Speed CPU-Einstellungen

Wählen Sie das Menü <CPU Speed Setup> aus und gehen Sie in das folgende Untermenü:

ROM PCI/ISA BIOS (2A5LEQ19)	
CPU SPEED SETUP	
AWARD SOFTWARE, INC.	
CPU Model : Intel Pentium MMX	Warning: Be sure your selection is right. CPU over speed will be dangerous!
Speed Mode : Standard	
CPU Speed : 233MHz	
CPU Voltage Ctrl : Auto	ESC:Quit ↑↓→←:Select Item
CPU I/O Voltage : 3.3V	F1: Help PU/PD/+/-: Modify
CPU Core Voltage : 2.8V	(Shift) F2: Color

Bild 1 „CPU Speed Setup Menu“

Beim den *CPU Speed*-Mainboard stellt Ihnen das BIOS anstelle von Jumper-Einstellungen eine Auswahl von Grundeinstellungen zur Verfügung. Um Ihr System optimal zu betreiben, können Sie von Hand die Werte für die CPU-Taktfrequenz unter der Option „CPU-Taktfrequenz“ unter der Option „CPU Speed“ im „CPU Speed Setup“ Menü einstellen.

Warnung: Sie sollten die CPU-Taktfrequenz nicht höher als die angegebene Arbeitsgeschwindigkeit einstellen. Anderfalls sehen wir uns für irgendwelche hierdurch hervorgerufene Schäden nicht verantwortlich.

Anmerkung: Falls Ihr System aufgrund einer falschen CPU-Einstellung nicht mehr hochfahren kann, halten Sie beim inschalten des Rechners die Taste < DEL > bzw. < ENTF > gedrückt. Das System wird dann mit den Grundeinstellungen neu gestartet.



Setup Rápido

Procedimiento:

1. Insertar la CPU correctamente.
2. Insertar otros dispositivos en el sistema.
3. Presionar la tecla y arrancar el sistema para entrar en BIOS setup.
4. Seleccionar el menu “CPU Speed Setup” para seleccionar la velocidad de la CPU.

Nota: si no selecciona la velocidad de la CPU, el sistema funcionará a la velocidad por defecto (75 Mhz para Pentium y AMD, 100 MHz para Cyrix 6x86, etc.)

5. Grabar y salir de BIOS Setup, entonces el sistema arrancará y funcionará como Ud. espera.

ESPAÑOL

Introducción a CPU Speed

Configuración de la CPU en el menu CPU Speed

Seleccione <CPU Speed Setup> en el menu principal para entrar en el siguiente menu:




Figure -1 CPU Speed Setup Menu

Para la placa base *CPU Speed*, la BIOS proporciona un juego de valores básicos para seleccionar el tipo de CPU, en lugar de los jumpers. Para hacer que su sistema funcione lo más rápidamente posible, Ud. puede manualmente aumentar el valor de la velocidad de frecuencia en “CPU Speed” en el menu <CPU Speed Setup>.

Aviso: es recomendable no seleccionar una frecuencia superior para la CPU a la que esta fue diseñada. En caso contrario, no nos hacemos responsables de los posibles daños que esto pueda causar.

Nota: por lo tanto, si su sistema no puede rearrancar de nuevo tras haber variado la frecuencia de trabajo de la CPU por una incorrecta, Ud. puede arrancar manteniendo apretada la tecla mientras conecta su equipo. El sistema arrancará con los valores básicos.



Mise en marche rapide

Démarche à suivre:

- 1) Insérer correctement le Processeur.
- 2) Assembler les autres éléments et mettez le système en place.
- 3) Appuyer sur la touche (Efface) et mettre le système en marche afin d'accéder à la configuration du BIOS.
- 4) Accédez au menu “CPU Speed Setup “ pour mettre au point la fréquence du processeur.

Remarque : Si vous ne réglez pas la vitesse du processeur, votre système va fonctionner à la fréquence par défaut, (75Mhz pour les processeurs Pentium d'Intel et d' AMD , 100Mhz pour les processeurs 6X86 de Cyrix etc...)

- 5) Sauvegarder la configuration et sortir du BIOS , alors votre système peut démarrer comme vous le voulez.

FRANÇAIS

CPU Speed

Menu de configuration de processeur de CPU Speed

Sélectionnez <CPU Speed Setup> du menu principal et accédez au sous-menu comme suit :




Figure -1 CPU Speed Setup Menu

Pour les cartes mère *CPU Speed* , le BIOS va vous procurer un ensemble de paramètres de base pour le choix de votre processeur au lieu de placer des cavaliers (Jumpers). Pour faire fonctionner votre système à la plus haute fréquence possible , vous pouvez augmenter manuellement les valeurs de fréquence du processeur dans “CPU Speed” sur l’écran menu “*CPU Speed Setup*”.

Avertissement : Vous avez intérêt à ne pas mettre la fréquence du processeur plus haute que celle indiquée par le manufacturier.Sinon, nous ne pourrions pas être tenu responsables des dégâts que cela peut causer.

Remarque : En plus si votre système ne peut pas redémarrer à cause du mauvais réglage du processeur, vous pouvez appuyer sur la touche clé (ou Efface) pendant que vous remettez le système en marche. Le système va redémarrer et va fonctionner avec les paramètres de base.



Setup Rapido

Procedure:

1. Inserire la CPU correttamente.
2. Inserire gli altri componenti e ricomporre il sistema.
3. Premere il tasto e accendere il sistema per entrare nel setup del Bios.
Nota: Se la velocita` di CPU non viene impostata, il sistema lavorera` alla velocita` di default (75Mhz per CPU Pentium e AMD, 100 Mhz per Cyrix 6 x 86 CPU ecc.).
4. Entrare nel menu “CPU Speed Setup” per impostare la velocita` della CPU.
5. Salvare e uscire dal Setup del Bios. Il sistema si riavviera` alla velocita` voluta.

ITALIANO

Introduzione al Tipo CPU Speed

Menu CPU Speed per l'impostazione della CPU

Selezionare <CPU Speed Setup> dal menu principale ed entrare nel seguente sottomenu:

ROM PCI/ISA BIOS (2A5LEQ19) CPU SPEED SETUP AWARD SOFTWARE, INC.		
CPU Model : Intel Pentium MMX Speed Mode : Standard CPU Speed : 233MHz		Warning: Be sure your selection is right. CPU over speed will be dangerous!
CPU Voltage Ctrl : Auto CPU I/O Voltage : 3.3V CPU Core Voltage : 2.8V		ESC:Quit ↑↓→←:Select Item F1: Help PU/PD/+/-: Modify (Shift) F2: Color

Figura 1: Menu CPU Speed per l'impostazione della CPU

Per una mainboard *CPU Speed*, il BIOS fornisce una serie di valore base per la specifica CPU, invece di dover impostarli via jumpers. Per far lavorare il sistema in modo ottimale, si puo` impostare la velocita` di CPU manualmente, alla voce “CPU Speed” del menu “*CPU Speed Setup*”.

Attenzione: SEGO declina ogni responsabilita` per eventuali danni causati alla CPU da una impostazione della velocita` piu` alta di quanto indicato dal produttore della CPU stessa.

Nota: Se il sistema non completa il boot per impostazioni errate della CPU, riaccendere tenendo premuto il tasto . Il sistema si riavviera` con i valori di base.



¿ìËÙÉèÖÃµÄ^{21/2}Öè

1;¢ÓyÈ·°2×° CPU;£

2;¢°2×°°~ÍµÍ³, ×!4±, ¢°ú;£

3;¢°~ÍÅ ¼ü±³Ö²»¶-£¬ È»áá¢°»ú½øÈë BIOS ÉèÖÃ³ÌÐò;£

4;¢½øÈë “CPU Speed Setup” Ä¢°Å¼ÉèÖÃ CPU ÈÙ¶£;£

×¢Óâ£°È¢¹ûÓÃ»§²»ÉèÖÃCPU ÈÙ¶£¬
ÔòÍµÍ³»áÓÃÔ-Éè¶ÖµÔËÐÐ (Intel ±¼ÌÚ°Í AMD K5 CPU
»áÓÃ75MHz ÔËÐÐ£¬Cryix 6x86 CPU »áÓÃ100MHz ÔËÐÐ);£

5;¢±£`æ¼°ÍÈ³öBIOSÉèÖÃ³ÌÐò£¬È»ááÍµÍ³¾Í¢ÉÛÉè¶µÄÈÙ¶£
Å

È³ÀûÔËÐÐ;£

中文繁體

CPU Speed

CPU Speed CPU ÉèÖÃÄçÂ¼

ÔÚ BIOS ÉèÖÃ³ÌÐòÖ÷ÄçÂ¼ÖÐÑ¡Ôñ <CPU Speed Setup> Ô»Íí£¬½ø ÈëÈçÏÅ×ÓÄçÂ¼£º

ROM PCI/ISA BIOS (2A5LEQ19) CPU SPEED SETUP AWARD SOFTWARE, INC.	
CPU Model : Intel Pentium MMX Speed Mode : Standard CPU Speed : 233MHz	Warning: Be sure your selection is right. CPU over speed will be dangerous!
CPU Voltage Ctrl : Auto CPU I/O Voltage : 3.3V CPU Core Voltage : 2.8V	
	ESC:Quit ↑↓→←:Select Item F1: Help PU/PD/+/-: Modify (Shift) F2: Color

Í¼£-1 CPU Speed CPU ÉèÖÃÄçÂ¼

¶ÓÓÚ CPU Speed Ö÷å£-BIOS Ìº CPUÖÉèÁËÒ»Ì×ù±¾²ÍÉy¶íPÐéÉèÖÃ Èí¶íß;£íÁËÉííµPÖÐÐÓÚCPU±êÉ¶µÄµÅÅ£-ÓÃ»§;ÉOOÓÚ "CPU Speed Setup" ÄçÂ¼ÆÁÄ»ÉÍ×ÔÐÐÐÞ, Ä CPU µÄÉÙ¶É¡£

¾-, æ£°

²»Öæ½«CPUµÄ¹¤×÷ÆµÅÅÉèÓÚ, ß³öÆä±êÉ¶µÄÆµÅÅ£-ñÔòÎÒ Åç¶ÓÓÉË

ÓýÆðµÄËðº, Å², °Ôð;£

×¢Öå£°

Èç¹ûµí³ÓòÍºÓÃ»§ÉèÖÃ 'Ííóµ¼ÖÄÍµÍ³²»ÄÜÔÙÆð¶£-Ôò;ÉÒÔ° 'ÍÅÈÈ¹/º ~~~~ ±£³Ö²»¶£-È»ááçº»ú £- ÍµÍ³»áÒÓÔ¤ÉèµÄ»ù±¾²ÍÉyÆð¶¹/ºÔË ÐÐ;£



¿ìËÙÉèÖÃµÄ^{21/2}Öè

1;¢ÓyÈ·°2×° CPU;£

2;¢°2×°°~ÍµÍ³, ×!4±, ¢°ú;£

3;¢°~ÍÅ ¼ü±£³Ö²»¶-£¬ È»°ó¢°ú½ø Èë BIOS ÈëÖÃ³ÌÐò;£

4;¢½ø Èë “CPU Speed Setup” Ä;¢°¼ ÈëÖÃ CPU ÈÙ¶-£

×¢Óâ£°È¢°ûÓÃ»§²» ÈëÖÃ CPU
ÈÙ¶-£¬ ÓòÍµÍ»áÓÃÔ-Ée¶-ÖµÔËÐÐ (Intel ±¼ÌÚ°Í AMD K5
CPU »áÓÃ75MHz ÔËÐÐ£¬ Cyrix 6x86 CPU »áÓÃ 100MHz
ÔËÐÐ);£

5;¢±£` æ²¢ÍÈ³öBIOS ÈëÖÃ³ÌÐò£¬ È»°óµÍ³¾Í¢ÉÔÚ Èë¶-µÄÈÙ¶-£

中文簡體

CPU Speed CPU ÉèÖÃÄçÂ¼

ÓÚ BIOS ÉèÖÃ³ÌÐòÔ÷ÄçÂ¼ÖÐÑ¡Ôñ <CPU Speed Setup> Ô»Íí£¬½ø ÈëÈçÏÅ×ÓÄçÂ¼£º

ROM PCI/ISA BIOS (2A5LEQ19) CPU SPEED SETUP AWARD SOFTWARE, INC.	
CPU Model : Intel Pentium MMX	Warning: Be sure your selection is right. CPU over speed will be dangerous!
Speed Mode : Standard	
CPU Speed : 233MHz	
CPU Voltage Ctrl : Auto	ESC:Quit ↑↓→←:Select Item
CPU I/O Voltage : 3.3V	F1: Help PU/PD/+/-: Modify
CPU Core Voltage : 2.8V	(Shift) F2: Color

Í¼£-1 CPU Speed CPU ÉèÖÃÄçÂ¼

¶ÓÓÚCPU SpeedÖ÷°å£-BIOS®CPUÖ¤ÉèÁËÒ»Ì×»ù±¾‡Èý¶íPÐéÉèÖÃÆÍ¶íøÍßj£Í¶ÁËÈÍµÍÖÐÐÓÚCPU±éÈ¶µÄÆµÄ£¬ÓÃ»§íÉÓÓÓÚ "CPU Speed Setup" ÄçÂ¼ÆÁÄ»Í×ÔÐÐÐP, Ä CPU µÄÈÙ¶È; £

¾ „æ£"

»Ò¤½«CPUµÄ¹¤×÷ÆµÄÊÉèÓÚ, ß¤Æä±êÈ¶µÄÆµÄÊ£¬·ñÔòÍÒ ÄÇ¶ÓÓÉ È

ÒýÆðµÄËðº, Å²», °Ôð; £

×¢Òâ£"

Èç¹µµÍ³ÒòÍºÓÃ»§ÉèÖÃ íÍóµ¼ÖÄÍµÍ²»ÄÜÔÙÆô¶£¬Ôò; ÉÒÓ° ÍÀÈÈ¹/º ~~~~ ±£³Ö²»¶£¬È»ºó; »ú £-ÍµÍ³»áÒÓÔ¤ÉèµÄ»ù±¾‡ÈýÆô¶¼°ÔË ðÐ.

Chapter 1

Introduction

1.1 Overview

P5V580 VP3 green mainboard provides a highly integrated solution for fully compatible, high performance PC/ATX platforms, and supports Intel Pentium®, Cyrix 6x86, 6x86MX and AMD K5, K6 microprocessors. It features Write-Back Secondary Cache memory for 512KB in size. Flexible main memory size can be installed from 8MB up to 384MB DRAMs, so as to give full play to the advantages of the Pentium , Cyrix 6x86, 6x86MX, idt C6 and AMD K5, K6 CPUs. The mainboard offers a wide range of interface to support integrated on-board IDE and on-board I/O function. The current green function is compliant to ACPI specification and OS Directed Power Management.

1.2 Key Features

- | | |
|--------------------|--|
| CPU | - Supports Intel Pentium 75, 90, 100, 120, 133, 150, 166, 180, 200, 233MHz, Intel Pentium Processor with MMX technology.
- Supports Cyrix 6x86 100MHz (P120 Plus), 110MHz (P133 Plus), 120MHz (P150 Plus), 133MHz (P166 Plus), 150MHz (P200 Plus)*, 175 MHz (P233 plus), Cyrix 6x86L, 6x86MX and idt C6 CPUs
- Supports AMD K5 PR75, PR90, PR100, PR120, PR133, PR166, PR200 and K6 PR166, PR200, PR233, PR266 CPUs
- Switching regulator (2.0~3.5V circuit) on board |
| Chipset | - VIA VP3 chipset |
| Clock Chip | - Supports I ² C clock chip on board |
| Main memory | - Supports 2x72 pin SIMM modules and 2x168 pin DIMM modules
- 64-bit data path for flexible memory size expanded from 8MB up to 384MB DRAMs
- Supports Fast Page mode DRAM and EDO DRAM for SIMM socket |

“*”: The max speed of VIA chipset specification is 66MHz only, so it's not recommended by VIA to set system clock frequency as 75MHz or 83 MHz.

- Supports from 8MB to 128MB 3.3V unbuffered

Introduction

	<p>SDRAM DIMM or 3.3V unbuffered EDO DIMM for DIMM slot</p>
AGP Support	<ul style="list-style-type: none">- AGP V1.0 compliant- Supports SideBand Addressing (SBA) mode- Supports 133 MHz 2X mode for AD and SBA signaling pipeline split-transaction long-burst transfers up to 533MB/sec.
Cache Memory On-board IDE	<ul style="list-style-type: none">- Provides 512KB L2 Pipeline Burst Cache on board- Supports 2 PCI Bus Master IDE ports- Supports PIO mode up to Mode 4 Timing- Supports "Ultra DMA/33" synchronous DMA mode transfers up to 33MBytes/sec- Supports 2 Fast IDE interfaces for up to 4 IDE devices e.g. IDE hard disks and CD ROMs drives
Green function ACPI Ready (requires ATX power supply)	<ul style="list-style-type: none">- Supports 3 green mode: Doze, Standby and Suspend- ACPI (Advanced Configuration and Power Interface) is also implemented on P5V580 VP3 Advanced II. ACPI provide more Energy Saving Features for the future operation system (OS) supporting OS Direct Power Management (OSPM) functionality. With these features implemented in the OS, PCs can be ready around the same time everyday, yet satisfy all the energy saving standards. To fully utilize the benefits of ACPI, an ACPI-supported OS such as in the next release of Windows 9X must be used
Auto Fan Off	<ul style="list-style-type: none">- The CPU fan will power off automatically even in sleep mode. This function reduces both energy consumption and system noise, and is an important feature to implement silent PC system
Dual Function Power Button (requires ATX power supply)	<ul style="list-style-type: none">- The system can be in one of two states, one is Sleep mode and the other is the Soft-Off mode. Pushing the power button for less than 4 seconds places the system into Sleep mode. When the power button is pressed for more than 4 seconds, it enters the Soft-Off mode
Remote Ring On (requires ATX power supply)	<ul style="list-style-type: none">- This allows a computer to be turned on remotely through a modem (internal modem card or external modem), so that any user can access vital information from their computer from anywhere in the world

Wake up on LAN (require ATX power supply)	- Supports wake up on LAN function
On-board I/O	<ul style="list-style-type: none">- 2 x ISA Slots, 3 x PCI Slots and 1 AGP Slot- Use ITE Plug & Play IO chip IT8661- Supports up to two 3.5" or 5.25" floppy drives 360K/720K/1.2M/1.44M/2.88M format- Supports 120MB floppy drive & zip drive- All I/O ports can be enabled or disabled in BIOS- Two high speed 16550 compatible UARTs (COM1/COM2/COM3/COM4 selectable) with 16-byte send/receive FIFOs and support MIDI compliant- One parallel port at I/O address 378H/278H/3BCH with additional bi-direction I/O capability and multi-mode selection (SPP/EPP/ECP) (IEEE 1284 compliant)- Provides protection circuit to prevent damage to the parallel port when a connected printer is powered up or operated at a higher voltage- Supports PS/2 mouse and PS/2 keyboard (optional)- Supports IrDA TX/RX Header- Supports USB (Universal Serial Bus) in specification
BIOS	<ul style="list-style-type: none">- Licensed advanced AWARD BIOS. Supports Flash ROM BIOS, Plug and Play ready, DMI ready. Built-in NCR810 SCSI BIOS
Board size	<ul style="list-style-type: none">- 220mm x 235mm

Introduction

* * This page is intentionally left blank * *


Chapter 2

Connector Configuration

This section lists all connector pin assignment and port description on the mainboard. The situations of the connectors and ports are illustrated in the following figures. Before inserting these connectors, please pay attention to the directions.

2.1 Power Connector (CN6)

PIN NUMBER	FUNCTION
1	POWER GOOD
2	+5V
3	+12V
4	-12V
5	GND
6	GND
7	GND
8	GND
9	-5V
10	+5V
11	+5V
12	+5V



2.2 Modem Ring on Connector (J1)


PIN NUMBER	FUNCTION
1	5VSB
2	INST-ON
3	GND

2.3 ATX Power Connector (CN5)

2.4 Power Switch (POWER)

If standby Power supply or ATX Power supply is used, the Power Switch supports the function as figure in next page.

1. If you want to power up your system, you should turn on the mechanical switch of Standby Power supply first, then push once the button connected to Power Switch connector.



Connector Configuration

2. If you want to power off your system, you needn't to turn off the mechanical switch of Standby Power supply, just push the button connected to Power Switch connector for four seconds or longer.

2.5 Keyboard Connector (CN1)

PIN NUMBER	FUNCTION
1	CLOCK
2	DATA
3	NC
4	GND
5	+5V

2.6 Hard Disk LED Connector (HDLED1)

PIN NUMBER	FUNCTION
1	VCC
2	IDE ACT

2.7 Reset Switch (RESET)

SETTING	FUNCTION
Close once	Reset the system
Open	NORMAL

2.8 Speaker Connector (SPEAKER)

PIN NUMBER	FUNCTION
1	SPKDATA
2	NC
3	GND
4	VCC

2.9 Power LED & Keylock (PWR-LED+KEY-L)

PIN NUMBER	FUNCTION
1	5VSB&VCC
2	GND
3	GND
4	KEYLOCK
5	GND

2.10 Green-LED

PIN NUMBER	FUNCTION
1	GREEN
2	GND

3	GND
---	-----

2.11 SLEEP

PIN NUMBER	FUNCTION
1	SLEEP
2	GND

2.12 USB1/USB2 Connector (USB)


PIN NUMBER	FUNCTION
1	2
3	4
5	6
7	8
9	10

2.13 FAN Connector (FAN1)

PIN NUMBER	FUNCTION
1	GND
2	+12V
3	GND

2.14 Wake up on LAN Connector (J5)

PIN NUMBER	FUNCTION
1	5VSB
2	GND
3	WOL



Connector Configuration

4	NC
5	+5V

Note: If you want to use PS/2 Mouse, please contact your vendor for optional PS/2 Mouse cable.


2.16 IrDA Connector (CN4)

PIN NUMBER	FUNCTION
1	VCC
2	NC
3	IRRX
4	GND
5	IRTX
6	VCC

2.17 I/O Port Description

CONNECTOR	FUNCTION
IDE1 PS/2 Mouse	(Pin 1) Primary IDE Port
IDE2	Secondary IDE Port
FLOPPY	Floppy Drive Port
PRINTER	Parallel Port
UART1	COM1/COM2/COM3/COM4
UART2	COM2/COM3/COM4/COM1

2.18 Clear CMOS



“*”: Represent for default jumper setting.

2.19 Memory Configuration

Note: You must power down the AC supply (110/220V) when you want to clear CMOS, the jumper (JVBAT1) should be set back to normal (open) before you turn on the system.

bank simultaneously.

Total Memory	SIMM1&2	DIMM1	DIMM2
8MB	4MB x 2	----	----
	----	8MB	----
16MB	8MB x 2	----	----
	4MB x 2	8MB	----

Connector Configuration

	----	16MB	----
	----	8MB	8MB
24MB	8MB x 2	----	8MB
32MB	8MB x 2	16MB	----
	16MB x 2	----	----
	----	16MB	16MB
	----	32MB	----
48MB	16MB x 2	----	16MB
	----	32MB	16MB
64MB	16MB x 2	----	32MB
	32MB x 2	----	----
	----	32MB	32MB
72MB	32MB x 2	8MB	----
80MB	32MB x 2	----	16MB
96MB	32MB x 2	16MB	16MB
128MB	32MB x 2	32MB	32MB
128MB	-----	64MB	64MB
256MB	64MB x 2	64MB	64MB

Illustration of Connector on board

Remark :

DRAM and SDRAM modules can be installed in a variety of configurations. Please understand that not all possible combinations of installation are listed here.




Figure 2-1 Illustration of All Connectors on Board

Connector Configuration

* * This page is intentionally left blank *

Chapter 3

AWARD BIOS Description

3.1 Entering BIOS Setup

Power on the computer, when the following message appears briefly at the bottom of the screen during the POST (Power On Self Test), press key or simultaneously press <Ctrl> + <Alt> + <Esc> keys.

Press to enter SETUP

Once you enter Award BIOS CMOS Setup Utility, the Main Menu (Figure 1) will be appeared on the screen. The Main Menu allows you to select from ten setup functions and two exit choices. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.




Figure 3-1 Main Menu

3.2 Standard CMOS Setup

AWARD BIOS Description

Use the arrow keys to highlight the item, then use the < PgUp> or <PgDn> keys to select the value you want in each item.

ROM PCI/ISA BIOS (2A5LEQ19) CMOS SETUP UTILITY AWARD SOFTWARE, INC.								
Date (mm:dd:yy) : Thu, Jul 17 1997								
Time (hh:mm:ss) : 00:00:00								
HARD DISKS								
Primary Master	: Auto	0	0	0	0	0	0	Auto
Primary Slave	: Auto	0	0	0	0	0	0	Auto
Secondary Master	: Auto	0	0	0	0	0	0	Auto
Secondary Slave	: Auto	0	0	0	0	0	0	Auto
Drive A	: 1.44M, 3.5 in.				Base Memory : 640K Extended Memory : 7168K Other Memory : 384K			
Drive B	: None				Total Memory : 8192K			
Video	: EGA/VGA							
Halt On	: All Errors							
ESC : Quit	↑↓→←:Select Item				PU/PD/+/- :Modify			
F1 : Help	(Shift)F2 :Change Color							

Figure 3-2 Standard CMOS Setup Menu

3.2.1 Hard Disk

Primary Master / Primary Slave / Secondary Master / Secondary Slave

The categories identify the types of 2 IDE channels that have been installed in the computer. Type “User” is user-definable. If your hard disk drive type is not matched with drive table or listed in it, you can use Type “User” to define your own drive type manually.

If you select Type “Auto”, BIOS will Auto-Detect the HDD & CD-ROM drive at the POST stage and show the IDE for HDD & CD-ROM drive. If you select Type “User”, related information is asked to be entered into the following items. Enter the information directly from the keyboard and press <Enter>.

If an additional ESDI HDD Controller interface is ESDI, on-chip Primary and/or Secondary has to be disabled. If the controller of HDD interface is SCSI, the type shall be set to “Auto”.

CYLS	number of cylinders	HEAD	number of heads
PRECOMP	write precom	LANDZ	landing zone

SECTOR	number of sectors	MODE	HDD access mode
--------	-------------------	------	-----------------

3.2.2 Video

You have two ways to boot up the system:

- I. When VGA is used as primary and monochrome is used as secondary, the selection of the video type is **“VGA Mode”**.
- II. When monochrome is used as primary and VGA is used as secondary, the selection of the video type is **“Monochrome Mode”**.

EGA/ VGA	Enhanced Graphics Adapter / Video Graphic Array. For EGA, VGA, SEGA, SVGA, or PGA monitor adapters.
CGA 40	Color Graphic Adapter, powering up in 40 column mode.
CGA 80	Color Graphic Adapter, powering up in 80 column mode.
MONO	Monochrome adapter, including high resolution monochrome adapters.

3.2.3 Halt on

The category determines that whether the computer will stop or not if an error is detected during powering up.

No errors	The system boot will not stop for any error that may be detected.
All errors	Whenever the BIOS detects a non-fatal error, the system will stop and you will be prompted.
All, But Keyboard	The system boot will not stop for a keyboard error, but it will stop for all the other errors.
All, But Diskette	The system boot will not stop for a disk error; but it will stop for all the other errors.
All, But Disk/Key	The system boot will not stop for a keyboard or disk error, but it will stop for all the other errors.

3.2.4 Memory

The category is display-only which is determined by POST (Power On Self Test) of the BIOS.

Base Memory	The POST of the BIOS will determine the amount of base (or conventional) memory installed in the system.
Extended Memory	The BIOS determines that how much extended memory is presented during the POST.
Other Memory	This is the memory that can be used for different applications. Most use for this area is Shadow RAM.
Total Memory	Total memory of the system is the sum of the above memory.

3.3 CPU Speed Setup

ROM PCI/ISA BIOS (2A5LEQ19)
CPU SPEED SETUP

AWARD BIOS Description

Warning: System may hang up or your CPU may be damaged if you wrongly set CPU voltage. It is strongly recommended that you should not	
CPU Speed	: 166MHz
CPU Voltage Ctrl	: Auto
CPU I/O Voltage	: 3.3V
CPU Core Voltage	: 2.8V
is right. CPU over speed will be dangerous!	
ESC: Exit ↑↓→← · Selection Item F1: Help PU/PD/+/- : Modify (Shift) F2 : Color	

Figure 3-3 CPU Speed Setup

The following pages tell you the options of each item and describe the meaning of each option.

<u>Item</u>	<u>Option</u>	<u>Description</u>
• CPU Model		BIOS can automatically detect known CPU model, so this item is shown only.
• Speed Model	Standard Jumper Emulation	You should select CPU Speed according to your CPU brand and type. This item is only for the user who understand all the CPU parameter. (Such as CPU voltage, clock frequency and clock multiplier.)
• Bus Clock	50MHz 55MHz 60MHz 66MHz 66+MHz 75MHz 83MHz	
• Multiplier	x1.5,BF1/BF0=1/1 x2,BF1/BF0=1/0 x2.5,BF1/BF0=0/0 x3,BF1/BF0=0/1	Left table is only for Pentium CPU. The other CPU Manufacturers' definitions of BF1/BF0 (or BF2/BF1/BF0) should be referred to your CPU Vendor.
• CPU Speed	75MHz~233MHz P120+~P200+ PR75~PR200 166MHz~266MHz	It is for Intel Pentium CPU. It is for Cyrix CPU. It is for AMD K5 CPU. It is for AMD K6 CPU.
• CPU Voltage Ctrl	Auto Manual	BIOS can automatically set CPU voltage. User can set CPU voltage according to CPU brand and type.

3.4 BIOS Features Setup

ROM PCI/ISA BIOS (2A5LEQ19) BIOS FEATURES SETUP AWARD SOFTWARE, INC.	
Virus Warning	: Disabled
CPU Internal Cache	: Enabled
External Cache	: Enabled
Quick Power On Self Test	: Enabled
Boot Sequence	: A,C, SCSI
Swap Floppy Drive	: Disabled
Boot Up Floppy Seek	: Disabled
Boot Up Numlock Status	: On
Gate A20 Option	: Fast
Typematic Rate Setting	: Disabled
Typematic Rate (Chars/Sec)	: 6
Typematic Delay(Msec)	: 250
Security Option	: Setup
OS Select For DRAM>64MB	: Non-OS2
Report No FDD For WIN95	: Yes
Video BIOS Shadow : Enabled C8000-CBFFF Shadow : Disabled CC000-CFFFF Shadow : Disabled D0000-D3FFF Shadow : Disabled D4000-D7FFF Shadow : Disabled D8000-DBFFF Shadow : Disabled DC000-DFFFF Shadow : Disabled Delay For HDD (Secs) : 0	
ESC: Quit ↑↓→← : Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift) F2: Color F7 : Load Setup Defaults	

Figure 3-4 BIOS Features Setup Menu

The following pages tell you the options of each item and describe the meaning of each option.

<u>Item</u>	<u>Option</u>	<u>Description</u>
• Virus Warning	<i>Enabled</i>	Activates automatically when the system boots up causing a warning message to appear when anything attempts to access the boot sector or hard disk partition table.
	<i>Disabled</i>	No warning message appears when anything attempts to access the boot sector or hard disk partition table. Note: This function is available only for DOS and other OS that do not trap INT13.
• CPU Internal Cache	<i>Enabled</i> <i>Disabled</i>	This item speeds up memory access. However, it depends on CPU/chipset design. The default value is enabled. Enable external cache. Disable external cache.
• External Cache	<i>Enabled</i> <i>Disabled</i>	Enable quick POST. BIOS will shorten or skip some check items during POST to speed up POST after you power on the computer. Normal POST.
• Quick Power On Self Test	<i>Enabled</i>	
• Boot Sequence	<i>Disabled</i> <i>A,C,SCSI... C, CDROM,A</i>	You can choose any search sequence for bootup.

AWARD BIOS Description

• Swap Floppy Drive	<i>Enabled</i>	It will exchange the assignment of A&B floppy drives.
	<i>Disabled</i>	The assignment of A&B floppy drives are normal.
• Boot Up Floppy Seek	<i>Enabled</i>	BIOS searches for floppy disk drive to determine if drive is ready for diskette read/write during booting.
	<i>Disabled</i>	skip drive seeking to speed up system booting.
• Boot Up Numlock Status	<i>On</i>	Keypad is used as number keys.
• Gate A20 Option	<i>Off</i>	Keypad is used as arrow keys.
	<i>Normal</i>	The A20 signal is controlled by keyboard controller or chipset hardware.
	<i>Fast</i>	It is default. The A20 signal is controlled by Port 92 or chipset specific method.
• Typematic Rate Setting	<i>Enabled</i>	Enable typematic rate and typematic delay programming.
	<i>Disabled</i>	Disable typematic rate and typematic delay programming. The system BIOS will use default value of these two items.
• Typematic Rate Chars/Sec)	6-30	Set the speed of the typematic rate (characters per second).
• Typematic Delay (Msec)	250 ~ 1000	Set the time of the typematic delay.
• Security Option	<i>System</i>	The system will not boot and access to Setup will be denied if the correct password is not entered when prompting.
	<i>Setup</i>	The system will boot up, but access to Setup will be denied if the correct password is not entered when prompting.
		Note: To disable security, select Password Setting (refer to page 3-14) at Main Menu and then you will be asked to enter password. Do not type anything and just press <Enter>, it will disable security. Once the security is disabled, the system will boot and you can enter Setup freely.
• OS Select For DRAM>64MB	<i>Non-OS2</i>	If your operating system is not OS/2, please select this item.
	<i>OS2</i>	If system DRAM is more than 64MB and operating system is OS/2, please select this item.
• Report No FDD For WIN95	<i>Yes</i>	Release IRQ6 to WIN95 if no FDD in connection
• Video BIOS Shadow	<i>No</i>	Not release IRQ6 to WIN95
	<i>Enabled</i>	Video BIOS will be copied to RAM. Video Shadow will increase the video speed.
	<i>Disabled</i>	Video shadow is disabled.

<ul style="list-style-type: none"> • C8000-CBFFF Shadow ... DC000~DFFFFF Shadow: • Delay For HDD (Secs) 	<p><i>Enabled</i></p> <p><i>Disabled</i></p> <p><i>0 ~ 15</i></p>	<p>Optional ROM will be copied to RAM by 16K bytes per unit.</p> <p>The shadow function is disabled.</p> <p>Set the predelay time for hard disk to be ready to be accessed by the system.</p>
--	---	---

3.5 Chipset Features Setup

ROM PCI/ISA BIOS (2A5LEQ19) CMOS SETUP UTILITY CHIPSET FEATURES SETUP			
Bank 0/1 DRAM Timing	: 70ns	On Chip	USB : Disabled
Bank 2/3 DRAM Timing	: 70ns		
Bank 4/5 DRAM Timing	: 70ns		
SDRAM Latency length	: 3		
DRAM Read Pipeline	: Enabled		
Sustained 3T Write	: Enabled		
L2 Cache Pipeline	: Enabled		
Read Around write	: Disabled		
Cache Timing	: Fast		
Video BIOS Cacheable	: Enabled	ESC: Quit ↑↓→← : Select Item	
System BIOS Cacheable	: Enabled	F1 : Help PU/PD/+/- : Modify	
Memory Hole At 15Mb Addr	: Disabled	F5 : Old Values (Shift)F2: Color	
AGP Aperture Size (4~256)	: 64M	F7 : Load Setup Defaults	
AGP-2X mode	: Disabled		

Figure 3-5 Chipset Feature Setup

The following pages tell you the options of each item and describe the meaning of each option.

<u>Item</u>	<u>Option</u>	<u>Description</u>
<ul style="list-style-type: none"> • Bank 0/1, 2/3, 4/5 DRAM Timing 	<p><i>60ns</i></p> <p><i>70ns</i></p>	<p>These items are of selected EDO DRAM read/write timing. You must ensure that your DIMMs are as fast as 60ns, otherwise you have to select 70ns.</p>
<ul style="list-style-type: none"> • SDRAM Latency length 	<p><i>3</i></p> <p><i>2</i></p>	<p>Define the CLT timing parameter of SDRAM expressed in 66MHz clocks,</p> <p>Latency Time = 2 clocks</p> <p>Latency Time = 3 clocks</p>
<ul style="list-style-type: none"> • DRAM Read Pipeline • Sustained 3T Write • L2 Cache Pipeline 	<p><i>Enabled</i></p> <p><i>Disabled</i></p> <p><i>Enabled</i></p> <p><i>Disabled</i></p> <p><i>Enabled</i></p>	<p>Enable DRAM Read Pipeline</p> <p>Disable DRAM Read Pipeline</p> <p>Enable Sustained 3T Write</p> <p>Disable Sustained 3T Write</p> <p>Enable L2 Cache Pipeline</p>

AWARD BIOS Description

• Read Around Write	<i>Disabled</i>	Disable L2 Cache Pipeline
• Cache Timing	<i>Enabled</i>	Enable Read Around Write
	<i>Disabled</i>	Disable Read Around Write
	<i>Fast</i>	This item is used to select Cache Read / Write speed, "Fast" is the optimize selection
• Video BIOS Cacheable	<i>Fastest</i>	
• System BIOS Cacheable	<i>Enabled</i>	Besides conventional memory, video BIOS area is also cacheable.
• Memory Hole At 15Mb Addr	<i>Disabled</i>	Video BIOS area is not cacheable.
• AGP Aperture Size (4~256)	<i>Enabled</i>	Beside conventional memory, the system BIOS area is also cacheable.
• AGP-2X mode	<i>Disabled</i>	The system BIOS area is not cacheable.
• On Chip USB	<i>Enabled</i>	Memory Hole at 15-16M is reserved for expanded PCI card.
	<i>Disabled</i>	Do not set this memory hole.
	<i>64M</i>	Set the effective size of the Graphics Aperture to be used in the particular PAC configuration.
	<i>Enabled</i>	Enable this item only when AGP Card supports 2X mode
	<i>Disabled</i>	
	<i>Enabled</i>	This item is used to enable or disable on chip USB controller.
	<i>Disabled</i>	

3.6 Power Management Setup

ROM PCI/ISA BIOS (2A5LEQ19) POWER MANAGEMENT SETUP AWARD SOFTWARE, INC.			
Power Management	: Disabled	Primary INTR	: ON
PC Control by APM	: Yes	IRQ3 (COM2)	: Primary
Video Off Option	: Suspend→Off	IRQ4 (COM2)	: Primary
Video Off Method	: V/H SYNC+Blank	IRQ5 (COM2)	: Primary
Modem Use IRQ	: NA	IRQ6 (COM2)	: Primary

Soft-Off by PWRBTN : Instant-off ** PM Timers **	IRQ7 (COM2) : Primary
HDD Power Down : 10 Min	IRQ8 (COM2) : Primary
Doze Mode : Disabled	IRQ9 (COM2) : Primary
Suspend Mode : Disabled	IRQ10 (COM2) : Primary
** PM Events **	IRQ11 (COM2) : Primary
VGA : OFF	IRQ12 (COM2) : Primary
LPT & COM : LPT/COM	IRQ13 (COM2) : Primary
HDD & FDD : ON	IRQ14 (COM2) : Primary
DMA/master : OFF	IRQ15 (COM2) : Primary
Modem Ring Resume : Disabled	ESC: Quit ↑↓←→ : Select Item
RTC Alarm Resume : Disabled	F1 : Help PU/PD/+/- : Modify
	F5 : Old Values (Shift)F2: Color
	F7 : Load Setup Defaults

Figure 3-6 Power Management Setup Menu

The following pages tell you the options of each item and describe the meanings of each option.

<u>Item</u>	<u>Option</u>	<u>Description</u>
• Power Management	<i>Disabled</i> <i>User Define</i> <i>Min Saving</i>	Global Power Management (PM) will be disabled. Users can configure their own Power Management Timer. Pre - defined timer value are used such that all timers are in their MAX values
	<i>Max Saving</i>	Pre - defined timer value are used such that all timers are in their MIN value
• PC Control by APM	<i>No</i> <i>Yes</i>	System BIOS will ignore APM when Power Management is enabled. System BIOS will wait for APM's prompt before it enter any PM mode e.g. Standby or Suspend.
• Video Off Option	<i>Suspend→Off</i> All modes→ Off	Select “Video off” status.
• Video Off Method	<i>Always On</i> <i>Blank</i> <i>Screen</i>	The system BIOS will only blank off the screen when disabling video.
	<i>V/H SYNC + Blank</i>	In addition to Blank Screen, BIOS will also turn off the V-SYNC & H - SYNC signals from VGA cards to monitor.
	<i>DPMS</i>	This function is enabled only for the VGA card supporting DPMS.
• Modem Use IRQ	<i>N/A</i>	Select IRQ “X” used by modem
• Soft-Off by PWRBTN	<i>IRQ “X”</i> <i>Instant-off</i> <i>Delay 4 secs</i>	The system will power off immediately once the power button is pressed The system will not power off immediately when the power button is pressed

AWARD BIOS Description

• HDD Power Down	<i>Disabled</i> <i>1 ~15 Min</i>	HDD's motor will not be off. Defines the continuous HDD idle time before the HDD entering power saving mode (motor off).
• Doze mode	<i>Disabled</i> <i>1Min ~ 1Hr</i>	The system will never enter Doze mode. Defines the continuous idle time before the system entering Doze mode. If any item defined in "Wake Up Events In Doze & Suspend" is On and activated, the system will be waken up.
• Suspend Mode	<i>Disabled</i> <i>1 Min ~ 1Hr</i>	The system will never enter Suspend mode. Defines the continuous idle time before the system entering Suspend mode. If any item defined in "Wake Up Events In Suspend" is On and activated, the system will be waken up.
• VGA	<i>ON</i> <i>OFF</i>	VGA active reloads global timer VGA active has no influence to global timer
• LPT & COM HDD & FDD DMA/ master	<i>ON</i> <i>OFF</i>	Any operation of the items Reload global timer. The operation of the items have no influence to global timer
• Modem Ring Resume	<i>Enabled</i>	Allow the system to be powered on when a Ring indicator signal comes up to UART1 or UART2 from external modem (to LAN Wake-up Header from LAN adapter or to modem Ring on Header from internal modem card)
• RTC Alarm Resume	<i>Disabled</i> <i>Enabled</i>	Do not allow Ring Power-on. RTC alarm can be used to generate a wake event when the system is in sleeping
• IRQ(3~15),	<i>Disabled</i> <i>Primary</i> <i>Secondary</i>	Do not allow Ring Power-on Reload global timer No influence to global timer, only finish an operation that IRQ "X" requests No influence to global timer

3.7 PNP/PCI Configuration Setup

ROM PCI/ISA BIOS (2A5LEQ19) PNP/PCI CONFIGURATION SETUP AWARD SOFTWARE, INC			
PNP OS Installed	: No	CPU to PCI Write Buffer	: Enabled
Resources Controlled By	: Manual	PCI Dynamic Bursting	: Enabled
Reset Configuration Data	: Disabled	PCI Master 0 WS Write	: Enabled
IRQ-3 assigned to	: Legacy ISA	PCI Delay Transaction	: Enabled
IRQ-4 assigned to	: Legacy ISA	PCI Master Read Prefetch	: Enabled
IRQ-5 assigned to	: PCI/ISA PnP	PCI #2 Access #1 Retry	: Disabled
IRQ-7 assigned to	: Legacy ISA	AGP Master 1 ws Write	: Enabled
IRQ-9 assigned to	: PCI/ISA PnP	AGP Master 1 ws Read	: Disabled

IRQ-10 assigned to	:	PCI/ISA PnP	PCI IRQ Actived By : Level ESC: Quit $\uparrow\downarrow\leftarrow\rightarrow$: Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift)F2: Color F7 : Load Setup Defaults
IRQ-11 assigned to	:	PCI/ISA PnP	
IRQ-12 assigned to	:	PCI/ISA PnP	
IRQ-14 assigned to	:	Legacy ISA	
IRQ-15 assigned to	:	Legacy ISA	
DMA-0 assigned to	:	PCI/ISA PnP	
DMA-1 assigned to	:	PCI/ISA PnP	
DMA-3 assigned to	:	PCI/ISA PnP	
DMA-5 assigned to	:	PCI/ISA PnP	
DMA-6 assigned to	:	PCI/ISA PnP	
DMA-7 assigned to	:	PCI/ISA PnP	

Figure 3-7 PNP/PCI Configuration Setup Menu

The following pages will tell you the options of each item and describe the meaning of each option.

<u>Item</u>	<u>Option</u>	<u>Description</u>
• PNP OS Installed	<i>No</i> <i>Yes</i>	Device resource assigned by BIOS. Device resource assigned by PnP OS. Remark: It is strongly recommended that you choose “Yes” when using PnP OS, i.e. Windows 95.
• Resources Controlled By	<i>Manual</i>	Assigns system resources (IRQ and DMA) manually by user.
	<i>Auto</i>	Assigns system resources (IRQ and DMA) automatically by BIOS.
• Reset Configuration Data	<i>Enabled</i>	The configuration data will be reset to default setting
	<i>Disabled</i>	The configuration data will not be reset
• IRQ-3 ~ IRQ-15 assigned to	<i>Legacy ISA</i>	The specified IRQ-x will be assigned to ISA only.
	<i>PCI/ISA PnP</i>	The specified IRQ-x will be assigned to ISA or PCI.
• DMA-0 ~ DMA-7 assigned to	<i>Legacy ISA</i>	The specified DMA-x will be assigned to ISA only.
	<i>PCI/ISA PnP</i>	The specified DMA-x will be assigned to ISA or PCI.
• CPU to PCI Write Buffer	<i>Enabled</i> <i>Disabled</i>	Enable CPU to PCI Write Buffer Disable CPU to PCI Write Buffer
• PCI Dynamic Bursting	<i>Enabled</i>	Enable PCI Dynamic Bursting
	<i>Disabled</i>	Disable PCI Dynamic Bursting
• PCI Master 0 ws Write	<i>Enabled</i>	Enable PCI Master 0 ws Write Disable PCI Master 0 ws Write

AWARD BIOS Description

• PCI Delay Transaction	<i>Disabled</i>	Enable PCI Delay Transaction
• PCI Master Read	<i>Enabled</i>	Disable PCI Delay Transaction
Prefetch	<i>Disabled</i>	Enable PCI Master Read Prefetch
• PCI #2 Access #1 Retry	<i>Enabled</i>	Disable PCI Master Read Prefetch
• AGP Master 1 ws Write	<i>Disabled</i>	Enable PCI #2 Access #1 Retry
• AGP Master 1 ws Read	<i>Enabled</i>	Disable PCI #2 Access #1 Retry
• PCI IRQ Actived By	<i>Disabled</i> <i>Level</i> <i>Edge</i>	Enable AGP Master 1 ws Write Disable AGP Master 1 ws Write Enable AGP Master 1 ws Read Disable AGP Master 1 ws Read Select PCI IRQ Active mode

3.8 Load Setup Defaults

The Setup Defaults is common and efficient setting.

3.9 Integrated Peripherals

ROM PCI/ISA BIOS (2A5LEQ19) INTEGRATED PERIPHERALS AWARD SOFTWARE, INC.			
On Chip IDE First Channel	: Enabled	Parallel Port Mode	: SPP
On Chip IDE Second Channel	: Enabled		
IDE Prefetch Mode	: Enabled		
IDE HDD Block Mode	: Enabled		
IDE Primary Master PIO	: Auto		
IDE Primary Slave PIO	: Auto		
IDE Secondary Master PIO	: Auto		
IDE Secondary Slave PIO	: Auto		
IDE Primary Master UDMA	: Auto		
IDE Primary Slave UDMA	: Auto		
IDE Secondary Master UDMA	: Auto		
IDE Secondary Slave UDMA	: Auto		

Onboard FDC Controller	: Enabled	
Onboard Serial Port 1	: 3F8/IRQ4	
Onboard Serial Port 2	: 2F8/IRQ3	
IR Address Select	: Disabled	
Onboard Parallel Port	: 378/IRQ7	
		ESC: Quit ↑↓→← : Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift)F2: Color F7 : Load Setup Defaults

Figure 3-8 Integrated Peripherals Menu

The following pages tell you the options of each item and describe the meaning of each option.

<u>Item</u>	<u>Option</u>	<u>Description</u>
• On Chip IDE First / Second Channel	<i>Enabled</i>	Enable on chip IDE First/Second Channel
• IDE Prefetch Mode	<i>Disabled</i>	Disable on chip IDE First/Second Channel
• IDE HDD Block Mode	<i>Enabled</i>	Enable IDE Prefetch Mode
	<i>Disabled</i>	Disable IDE Prefetch Mode
• IDE Primary/Secondary Master/Slave PIO/UDMA	<i>Mode 0 - 4</i>	Allows IDE HDD read/write several sectors one time.
• Onboard FDC Controller	<i>Auto</i>	IDE HDD only reads/writes a sector one time.
	<i>Enabled</i>	Defines the IDE primary/secondary master/slave PIO mode.
	<i>Disabled</i>	The IDE PIO mode is defined according to auto - detect
• Onboard Serial Port 1/2	<i>3F8/IRQ4, 2F8/IRQ3, 3E8/IRQ4, 2E8/IRQ3, Disabled</i>	Onboard floppy disk controller is enabled.
	<i>3F8H</i>	Onboard floppy disk controller is disabled.
• IR Address Select	<i>1.7</i>	Defines onboard serial port address and required interrupt number.
	<i>1.9</i>	
	<i>SPP</i>	
	<i>ECP</i>	
• Onboard Parallel Port	<i>3E8H</i>	Onboard serial port is disabled.
• Parallel Port Mode		This item is used to configure IR Address
		Defines EPP version.
		Select parallel port mode

AWARD BIOS Description

3.10 Password Setting

When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

ENTER PASSWORD

Type the password, up to eight characters, and press <Enter>. The password typed now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable password, just press <Enter> when you are prompted to enter password. A message will confirm the password being disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

PASSWORD DISABLED

If you select “**System**” at “Security Option” of “BIOS Features Setup” Menu, you will be prompted for the password every time the system is rebooted or any time you try to enter “CMOS Setup”.

If you select “**Setup**” at “Security Option” of “BIOS Features Setup” Menu, you will be prompted for the password only when you try to enter “CMOS Setup”.

3.11 IDE HDD Auto Detection

The Enhanced IDE features was included in all Award BIOS. Below is a brief description of this features.

ROM/PCI/ISA BIOS (2A5LEQ19) IDE HDD AUTO DETECTION AWARD SOFTWARE, INC.							
HARD DISKS TYPE SIZE CYLS HEAD PRECOMP LANDZ SECTOR MODE							
Primary Master:							
Select Primary Master Option (N=Skip): N							
OPTION	SIZE	CYLS	HEADS	PRECOMP	LANDZ	SECTORS	MODE
2(Y)	541	525	32	0	1049	67	LBA
1	541	1050	16	65535	1049	63	NORMAL
3	541	525	32	65535	1049	63	LARGE

Note: Some OSes (like SCO-UNIX) must use “NORMAL” for installation

Figure 3-9 IDE HDD Auto Detection Menu

3.11.1 Setup Changes With auto-detection

- BIOS setup will display all possible modes that is supported by the HDD including NORMAL, LBA and LARGE.
- If HDD does not support LBA modes, no “LBA” option will be shown.
- If number of physical cylinders is less than or equal to 1024, “LARGE” option may not be shown.
- Users can select a mode which is appropriate for them.

With Standard CMOS Setup

	CYLS	HEADS	PRECOMP	LAND	SECTOR	MODE
				ZONE		
Drive C:User (516MB)	1120	16	65535	1119	59	Normal
Drive D:User (203MB)	684	16	65535	685	38	-----

When HDD type is in “user” type, the “MODE” option will be opened for user to select their own HDD mode.

3.11.2 HDD Modes

The Award BIOS supports 3 HDD modes: NORMAL, LBA and LARGE, and Auto detect.

NORMAL

Generic access mode in which neither the BIOS nor the IDE controller will make any transformation during accessing. The maximum number of cylinders, heads and sectors for NORMAL mode are 1024,16 and 63.

If user sets his HDD to NORMAL mode, the maximum accessible HDD size will be 528 megabytes even though its physical size may be greater than that.

LBA (Logical Block Addressing) mode

A new HDD accessing method to overcome the 528 Megabyte bottleneck.

The number of cylinders, heads and sectors shown in setup may not be the number physically contained in the HDD.

During HDD accessing, the IDE controller will transform the logical address described by sector, head and cylinder number into its own physical address inside the HDD. The maximum HDD size supported by LBA mode is 8.4 Gigabits.

AWARD BIOS Description

LARGE mode

Some IDE HDDs contain more than 1024 cylinder without LBA support (in some cases, user do not want LBA). The Award BIOS provides another alternative to support these kinds of HDD.

BIOS tricks DOS (or other OS) that the number of cylinders is less than 1024 by dividing it by 2. At the same time, the number of heads is multiplied by 2. A reverse transformation process will be made inside INT13h in order to access the right HDD address.

Auto detect

If using Auto detect, the BIOS will automatically detect IDE hard disk mode and set it to one kind of HDD modes.

3.11.3 Remark

To support LBA or LARGE mode of HDDs, there must be some software involved which are located in Award HDD Service Routine

(INT13h).It maybe fail to access a HDD with LBA (LARGE) mode selected if you are running under an Operating System which replaces the whole INT 13h.

3.12 Power - On Boot

If you have made all the changes to CMOS values and the system can not boot with the CMOS values selected in Setup, restart the system by turning it OFF then ON or press the “RESET” button on the system case. You may also restart the system by simultaneously pressing <Ctrl>, <Alt> and keys.

Appendix A. Utility Diskette

You may use this diskette to update your BIOS when necessary.

For the most update and additional information about BIOS upgrade, please refer to "README" in the "Utility Diskette".

Warning:


- We strongly recommend that you only upgrade BIOS when in trouble.
- Before you update your BIOS, you should look over the "README" file to avoid making mistake.

Appendix

Appendix B.


Introduce AMD-K5 CPU mark:

Operating Voltage:
B=3.45V~3.60V-- >3.5V
C=3.30V~3.465V-- > 3.3V
F=3.135V~3.465V-- > 3.3V
G = x/y
H=2.86V~3.00V/3.30V~3.465V -- > 2.9/3.3
J=2.57V~2.84V/3.30V~3.465V -- > 2.7/3.3
~~K=2.38V~2.65V/3.30V~3.465V -- > 2.5/3.3~~



Appendix C.


Introduce AMD-K6 CPU mark:



Appendix

Appendix D.

Introduce Cyrix 6x86 CPU mark:



Appendix E.

Introduce Cyrix 6x86MX CPU mark:

Name of processor:
6x86 MX

CPU P-Rating:
PR233

Core Voltage: 2.9V

CPU Core Frequency:
75MHz x 2.5



P/N: 430-01012-612

Appendix

Manual P5V580 VP3 Ver 2.1