

	1MB	4MB	16MB	16MB
21MB	1MB	16MB	4MB	
	4MB	1MB	16MB	
	4MB	16MB	1MB	1MB
22MB	4MB	16MB	1MB	
	4MB	4MB	16MB	
24MB	4MB	16MB	4MB	
	4MB	16MB	4MB	4MB
25MB	1MB	16MB	4MB	4MB
28MB	4MB	16MB	4MB	4MB
			16MB	16MB
32MB			32MB	
			16MB	16MB
33MB	1MB	16MB	16MB	
	1MB	1MB	16MB	16MB
34MB	1MB	1MB	16MB	16MB
	4MB	16MB	16MB	
36MB		4MB	16MB	16MB
	4MB	4MB	16MB	16MB
37MB	1MB	4MB	16MB	16MB
	4MB	1MB	16MB	16MB
40MB	4MB	4MB	16MB	16MB
48MB		16MB	16MB	16MB
49MB	1MB	16MB	16MB	16MB
52MB	4MB	16MB	16MB	16MB
		32MB	32MB	
64MB		32MB	32MB	
65MB	1MB	64MB	32MB	
	1MB	32MB	32MB	
66MB	1MB	32MB	1MB	32MB
	32MB	32MB	1MB	1MB
67MB	1MB	32MB	1MB	1MB
	4MB	32MB	32MB	
68MB	4MB	32MB	32MB	
		4MB	32MB	32MB
32MB		32MB	4MB	

Table 3 - I. DRAM Configurations (Continued)

→ NOTE : All memory banks accept double-RAS SIMM.

Installation Instructions

NOTE : Always observe static electricity precautions. See "Handling Precautions" at the start of this manual.

1. Locate the SIMM banks on the mainboard. Determine your desired configuration to be installed.
 2. Swing each SIMM into its upright, locked position. When locking a SIMM in place, push on each end of the SIMM do not push in the middle.




Figure 3-2. Installing a SIMM Module