

Motherboard 4S661QP

Package Contents	3
1. 4S661QP Specifications	4
1.1 Introduction	4
1.2 Specifications and Features	5
CPU Processor	5
Chipset	5
PCI	5
Integrated LAN Controller	5
Universal Serial Bus	5
WOL (Wake On LAN)	5
Award BIOS	6
ATA 100/133 On Board	6
PCI-Based AC 97 Audio Processor	6
VGA On Board	6
AGP 4X/8X On Board	7
1394A– high performance serial bus on board	7
1.3 4S661QP Layout Diagram	8
1.4 CPU and CPU Fan Installation	10
1.4.1. CPU Installation with Socket 478	10
1.4.2. CPU Fan Installation with P4 Fan Base	11
1.5. DDR SDRAM Installation	12
1.6 Connectors & Jumpers Setting	13
1.6.1. Back Panel I/O Connectors	13
1.6.1.1. PS/2 Mouse / Keyboard Connectors	13
1.6.1.2. 3xUSB Ports	13
1.8.1.3. Serial Interface Port: COM1	14
1.6.1.4. Parallel Interface Port	14

- 1.6.1.5. Audio Port Connectors 14
- 1.7.1.6 VGA Connector 14
- 1.7.1.7 1394A Connector 14
- 1.6.2. ATX Main Power Connectors: PW1/PW2 15
- 1.6.3. Floppy Disk Connector: FDD 16
- 1.6.4. Hard Disk Connectors: IDE1/IDE2 16
- 1.6.5. Fan Connectors: FAN1~3 16
- 1.6.6. Audio-In Connectors: CD1/AUX1 17
- 1.6.7. Wake On LAN Connector: WOL 17
- 1.6.8. USB Pin Headers 18
- 1.6.9. 1394A Pin Header 18
- 1.6.10. Front Panel Connectors: PANEL1 19
- 1.6.11. SPDIF Connector: SPDIF1 20
- 1.6.12. IR infrared module: IR1 Connector 20
- 1.6.13. Front Audio Connector: JP1 21
- 1.6.14. CMOS Function Selector: JP4 21
- 2. BIOS Setup 22**
 - 2.1 BIOS Support 22
 - 2.2 Main Menu 25
 - 2.3 Standard CMOS Features 28
 - 2.4 Advanced BIOS Features 32
 - 2.5 Advanced Chipset Features 36
 - 2.6 Integrated Peripherals 40
 - 2.7 Power Management Setup 45
 - 2.8 PnP/PCI Configurations 48
 - 2.9 PC Health Status 51
 - 2.10 Frequency/Voltage Control 52
 - 2.11 Load Fail-Safe Defaults 54
 - 2.12 Load Optimized Defaults 55
 - 2.13 Set Supervisor / User Password 56
 - 2.14 Save & Exit Setup 57

2.15 Exit Without Saving	58
3. Drivers & Utilities	59
3.1 Auto-run Menu	59
3.2 Installing IDE Driver	61
3.3 Installing LAN Driver	62
3.4 Installing Audio Driver	63
3.4.1 Installing 6-channel Driver	63
3.4.2 Verifying 6-channel Driver	64
3.5 Installing USB 2.0 Driver	66
3.6 Installing VGA Driver	68
3.7 Installing AGP Driver	70
Appendix I On Model 4S661QP	72
Motherboard Compatibility Test	72
(1) CPU Compatibility Test	72
(2) Memory Compatibility Test	73
(3) AGP Display Card Compatibility Test	74

Package Contents

- ◆2xUltra ATA IDE Cables
- ◆1x FDD Cable
- ◆Flash Memory with BIOS
- ◆Fully Setup Driver CD with built in utilities.
- ◆User Manual.
- ◆I/O Shielding.

Chapter 1

Specifications

1. 4S661QP Specifications

1.1 Introduction

The 4S6661QP motherboard is an integration of Intel P4 CPUs in Socket-478 packaging and the North Bridge SiS661FX supporting 800/533/400 MHz Front Side Bus.

North Bridge SiS661FX on board also supports DDR 400/333/266/200 DRAMs and the integrated AGP 8X/4X Interface, while the South Bridge SiS963 provides stable supports of ULTRA ATA 133/100, 6-channel Audio playback, LPC Super I/O, USB 2.0/1.1 interface, IEEE1394A interface, PCI interface as well as integrated 10/100Mbit Fast Ethernet LAN Controller.

The resulting architecture will provide an ideal multi-task environment to support operating systems such as MS-DOS, Windows, WindowsNT, Windows ME, Windows 2000, Novell, OS/2, Windows 95/98, Windows 98SE, Windows XP, UNIX, Liunx, SCO UNIX etc. This user-friendly manual is to describe in detail how to install, configure and use this motherboard with drivers and BIOS setup illustrations.

This manual is a general reference of the first release of this motherboard which is subject to update without notice. If any difference is found between this manual and the motherboard you are using, please refer to the Web Site.

1.2 Specifications and Features

CPU Processor

- | Supporting 800/533/400MHz System Interface speed.
- | Single Socket 478 for Intel P4™ 1.5 to 3.2GHz or higher* (Northwood Processor).
- | Supporting Intel Netburst™ Micro-architecture.

* The higher frequency CPU should be compatible with Intel CPU specification and the motherboard latest BIOS version which will be released on the web site.

Chipset

- | SiS661FX North Bridge, supporting 800/533/400MHz FSB and AGP 2.0/3.0 interface
- | SiS963 South Bridge.

PCI

- | Supporting 33MHz PCI Bus speed.
- | 1 x PCI slots on board

Integrated LAN Controller

- | Supporting 10/100Mbit Fast Ethernet LAN
- | Supporting 1xRJ45 Connector

Universal Serial Bus

- | Supporting 3 on-board Universal Serial Bus(USB) Ports and 2 external Universal serial Bus(USB) Ports.
- | Supporting USB 2.0/1.1

WOL (Wake On LAN)

- | Supporting system power-on by LAN Ring-up signal.

Award BIOS

- | Supporting Plug & Play specification which detects the peripheral devices and expansion cards automatically
- | Supporting CD-ROM, SCSI, LAN BOOT, Temperature sensor, LAN, Alarm Bus CLK setup
- | Supporting Desktop Management Interface (DMI) function for recording mainboard specification

ATA 100/133 On Board

- | Supporting four IDE devices with 2 x IDE connectors
- | Supporting PIO Mode 5, Master Mode, high performance hard disk drives
- | Dual -channel Ultra DMA 33/66/100/133 Bus Master Mode
- | Supporting IDE interface with CD-ROM
- | Supporting high capacity hard disk drives
- | Supporting LBA mode

PCI-Based AC 97 Audio Processor

- | AC 97 2.2 compatible Codec, 6-channel Audio interface.
- | 18-bit Stereo Full-Duplex Codec with up to 48 KHz sampling rate
- | 4 Analog Line-level Stereo inputs for connection from Line, CD, Video and AUX
- | 2 Analog Line-level Stereo inputs for speakerphone and PC beep

VGA On Board

- | 1x 15-pin VGA connector on board
- | CRT highest resolution mode: 2048x1536x32@75NI


AGP 4X/8X On Board

- | AGP 66MHz, 1.5V for AGP4X/8X graphic card.
- | AGP 3.5/2.0 compliant
- | Digital LCD/TV-out card supported
- | LCD highest solution mode: 1600x1200x32@60NI
- | TV highest solution mode: 1024x768x32@60NI

1394A-- high performance serial bus on board

- | 1394A Interface on board
- | Compliant with IEEE 1394A-2000 standard for high performance serial bus
- | Supporting 2x1394 ports, 400/200/100 Mbits transfer rates

1.3 4S661QP Layout Diagram



4S661QP Component Layout :


- 1. IDE1: IDE Connector**
- 2. IDE2: IDE Connector**
- 3. FDC1: Floppy Drive Connector**
- 4. FAN1: CPU Fan Connector**
- 5. Thermal Detector**
- 6. P4 CPU Socket 478**
- 7. P4 CPU Fan Base**
- 8. ATX Main Power Connector**
- 9. +12V Power Connector**
- 10. DEBUG1: Connector for Printer ERROR debug**
- 11. Back Panel: Back Panel I/O Connectors (Mouse, Keyboard, COM1, VGA, Printer, 1394A Port, 3xUSB ports, Mic in, Line in, Speaker, RJ45)**
- 12. JP1: Front Audio Pin-header**
- 13. ALC650: 6-channel AC'97 Audio CODEC**
- 14. SPDIF1: SPDIF (S/P Digital Interface Format) Connector**
- 15. AUX1: Audio-in connector for Wave audio input**
- 16. CD1: CD Audio-in connector**
- 17. FAN3: Cooling Fan connector**
- 18. South Bridge SiS963**
- 19. JP4: Jumper for Clear CMOS Select**
- 20. USB2 Header: USB2 Pin-header for 2 external USB ports**
- 21. Panel1: Front Panel connectors**
- 22. JP5: Pin Header supporting 1 external USB Port**
- 23. JP10: Jumper for USB2 Wake-up Select**
- 24. IR2: Connector for Infrared signal transmission/reception.**
- 25. North Bridge SiS661FX**
- 26. FAN2: Cooling Fan connector**
- 27. WOL1: Wake On LAN connector**
- 28. 1394A Header: 1393A Pin-header for 1x external 1394A port**

1.4 CPU and CPU Fan Installation

This motherboard is designed with Socket 478 for Intel P4™ processor.


1.4.1. CPU Installation with Socket 478

1. Pull the lever sideways away from the socket then raise the lever to a 90-degree angle.
2. Locate Pin 1 in the socket. Pin 1 of CPU is marked by the yellow corner or cut edge on the CPU. Match Pin 1 of Socket 478 and Pin 1 of CPU.
3. Pull up the lever of Socket 478 to let the CPU in and press the lever down to lock the CPU.
4. Make sure that Pin 1 of Socket 478 is matching with Pin 1 of CPU.
5. Make sure that all CPU pins are completely in socket before pressing down the socket lever.



1.4.2. CPU Fan Installation with P4 Fan Base

1. P4 CPU Fan is typically designed with 4 latches and mounted with a thick heatsink. Please do not use other type of CPU fan which cannot match the P4 Fan base on board.
2. Install the P4 CPU fan into the Fan base in such a way that the 4 latches of the CPU Fan match with the 4 Supporters of the CPU Fan Base.
3. Press down the latches to lock CPU Fan to the Fan Base.
4. Then connect the Fan Power Cable to one of the Fan connectors on board.
5. Make sure that the Fan Power Cable is correctly connected to Fan Connector.



1.5. DDR SDRAM Installation

This motherboard supports a maximized 2GB DDR SDRAM. It provides two 184-pin unbuffered DDR sockets. It supports 64MB to 1GB DDR memory module.


DDR SDRAM Installation Procedures:

1. The DDR socket has a “Plastic Safety Tab” and the DDR memory module has an asymmetrical notch”, so the DDR memory module can only fit into the slot in one direction.
2. Push the tabs out. Insert the DDR memory modules into the socket at a 90-degree angle then push down the module vertically to fit it into place.
3. The Mounting Holes and plastic tabs should fit over the edge and hold the DDR memory modules in place.

Note: If you want to run FSB 800/533MHz on this Motherboard (with 133MHz CPU), you must use DDR 400/333/266MHz module.

Bank	Memory module
DIMM 1	64MB, 128MB, 256MB, 512MB, 1GB
	184 pin, 2.5V DDR SDRAM
DIMM 2	64MB, 128MB, 256MB, 512MB, 1GB
	184 pin , 2.5V DDR SDRAM
	Total System Memory (Max 2GB)

184-pin DDR Module




Warning: Be sure to turn off system power whenever to insert or remove a Memory Module. Otherwise, the power will damage the module or even the system.

1.6 Connectors & Jumpers Setting

1.6.1. Back Panel I/O Connectors

This motherboard provides the following back panel connectors:



1.6.1.1. PS/2 Mouse / Keyboard Connectors

The motherboard provides a standard PS/2 mouse / Keyboard mini DIN connector for attaching a PS/2 mouse. You can plug a PS/2 mouse / Keyboard directly into this connector.


1.6.1.2. 3xUSB Ports

The motherboard provides a OHCI(Open Host Controller Interface)Universal Serial Bus Roots for attaching USB devices such as a keyboard, mouse and other USB devices. You can plug the USB devices directly into this connector.

1.8.1.3. Serial Interface Port: COM1

The serial interface port is sometimes referred to as an RS-232 port or an asynchronous communication port. Mice, printers, modems and other peripheral devices can be connected to a serial port. The serial port can also be used to connect computer systems together. If you like to transfer the contents of your hard disk to another system, it can be accomplished with serial port.

COM1



1.6.1.4. Parallel Interface Port

Unlike serial ports, parallel interface ports have been standardized and should not present any difficulty interfacing peripherals to your system. Sometimes called a Centronics port, the parallel port is almost exclusively used with printers. The parallel port on your system is a 25-pin, DB 25 connector.

1.6.1.5. Audio Port Connectors

Speaker out is a connector for Speakers or Headphones. Line in is used for external CD player, Tape player, or other audio devices. Mic is a connector for the microphones.

1.7.1.6 VGA Connector

1x 15-pin VGA connector on board, supporting CRT highest resolution mode: 2048x1536x32@75NI

1.7.1.7 1394A Connector

1394A Iconnector on board, compliant with IEEE 1394A-2000 standard for high performance serial bus, supporting 400/200/100 Mbits transfer rates.

1.6.2. ATX Main Power Connectors: PW1/PW2

This connector supports the power button on-board. Using the ATX power supply, functions such as Modem Ring Wake-Up and Soft Power Off are supported on this motherboard. This power connector supports instant power-on functionality, which means that the system will boot up instantly when the power connector is inserted on the board. ATX 4-pin power connector only support +12V voltage.



Pin PW1 Signal		Pin PW1 Signal	
1	GND	2	GND
3	+12V	4	+12V



Pin PW2 Signal		Pin PW2 Signal	
1	3.3V	11	3.3V
2	3.3V	12	-12V
3	GND	13	GND
4	5V	14	PS-ON
5	GND	15	GND
6	5V	16	GND
7	GND	17	GND
8	PW-OK	18	-5V
9	5V _{SB}	19	5V
10	12V	20	5V

Note:

When you set up P4 power supply, both PW1 and PW2 must be connected to power.

Important:

To switch on your power supply, please make sure:

1. Memory Module is properly installed.
2. Power supply setup is OK.


1.6.3. Floppy Disk Connector: FDD

This connector supports the provided floppy drive ribbon cable. After connecting the single end of the cable to the board, connect the two plugs on the other end to the floppy drives.

1.6.4. Hard Disk Connectors: IDE1/IDE2

These connectors are provided with IDE hard disk ribbon cable into the package. After connecting the end of cable with single connector to the mainboard, connect the other two connectors at the other end to your hard disk. If you install two hard disks, you must configure the second drive to Slave mode by setting its jumper settings. BIOS now supports SCSI device or IDE CD-ROM boot up (see "HDD Sequence SCSI/IDE First" & "Boot Sequence" in the BIOS Features Setup of the BIOS SOFTWARE).

1.6.5. Fan Connectors: FAN1~3



FAN1, FAN2 and FAN3 connectors

1.6.6. Audio-In Connectors: CD1/AUX1


CD1 and AUX1 are the connectors for CD-Audio and Wave Input signal. Please connect them to CD-ROM CD-Audio output connector.

Pin	CD1	Definition
1		CD-L
2		GND
3		GND
4		CD-R

Pin	AUX1	Definition
1		WAVL
2		GND
3		GND
4		WAVR


1.6.7. Wake On LAN Connector: WOL

CN2 is a Wake On LAN (WOL) connector for transmitting the Ring signal from a PCI LAN card to wake up system. If you use a PCI LAN card for system networking, you can connect this Wake On LAN connector with the PCI LAN card on board for Wake On LAN function.



1.6.8. USB Pin Headers


USB Pin Headers support external USB ports. Each USB pin header requires a USB cable for expansion of two or one USB ports. This optional USB cable is available from your motherboard dealer or vendor.



1.6.9. 1394A Pin Header

1x 1394A Pin-header on board, compliant with IEEE 1394A-2000 standard for high performance serial bus, supporting 1x1394 A port, 400/200/100 Mbits transfer rates.

1.6.10. Front Panel Connectors: PANEL1



PSSW

The system power is controlled by a momentary switch connected to this lead. Pushing the button once will switch the system ON.

Power LED Lead (PW_LED)

The system power LED lights when the system power is on.

Speaker Connector (SPEAKER)

The speaker (onboard or offboard) provides error beep code information during the Power Self-Test when the computer cannot use the video interface. The speaker is not connected to the audio subsystem and does not receive output from the audio subsystem.

Hard Drive LED Connector (HD_LED)


This connector supplies power to the cabinet IDE activity LED. Read and write activity by devices connected to the Primary or Secondary IDE connectors will cause the LED to light up.

Reset Switch Lead (RST)

The connector can be connected to a reset switch. Press this reset switch to restart system.


1.6.11. SPDIF Connector: SPDIF1

SPDIF1 is designed on board for Digital Audio in/out.



1.6.12. IR infrared module: IR1 Connector


This connector supports the optional wireless transmission and reception infrared module. You must configure the setting through the BIOS setup to use the IR function.



1.6.13. Front Audio Connector: JP1


JP1 provides connection to the Front Audio connectors of the Front Audio Panel.

To use this Front Audio Connector, please remove the jumper caps on it and connect it to the Front Audio Panel.



Remove the jumper caps to connect this connector to the Front Audio Panel


- Pin 1 Mic In
- Pin 3 VREFOUT
- Pin 5 FR-IN
- Pin 7 (NC)
- Pin 9 FL-IN
- Pin 2 Aud GND
- Pin 4 Aud Vdd
- Pin 6 FR-OUT
- Pin 8 (Key)
- Pin 10 FL-OUT



Remove the jumper caps to connect this connector to the Front Audio Panel

1.6.14. CMOS Function Selector: JP4

When you have problem with booting system, you may clear CMOS to restore the optimum default BIOS data.



Pin JP4	Function
1-2 closed	Normal (Default)
2-3 closed	Clear CMOS

1. Remove the Jumper cap of Jp5 from 1-2.
 2. After 1 or two seconds, set Jp5 to 2-3 closed with the jumper cap.
 3. After 1 or two seconds, restore the Jp5 to 1-2 closed.
- Now, the CMOS RAM has restored to the optimum default setting.

Chapter 2

BIOS Setup

2. BIOS Setup

2.1 BIOS Support

This chapter discusses the Award BIOS Setup program built in the ROM BIOS. The Setup program allows the user to modify the basic system configuration. The modification is then stored in battery-backed RAM so that it can retain the setup information after the power is turned off. The Award BIOS installed in your computer system ROM (Read Only Memory) is a custom version of an industry standard BIOS. The BIOS provides critical low-level support for standard devices such as disk drives and serial and parallel ports. This chapter is intended for guiding you through the process of configuring your system BIOS.

Plug and Play Support

This AWARD BIOS supports the Plug and Play Version 1.0A specification. ESCD(Extended System Configuration Data) write is also supported.

EPA Green PC Support

This AWARD BIOS supports Version 1.03 of the EPA Green PC specification.

PCI Bus Support

This AWARD BIOS also supports Version 2.1 of the Intel PCI (Peripheral Component Interconnect) local bus specification.

APM Support

This AWARD BIOS supports Version 1.1&1.2 of the Advanced Power Management(APM) specification. Power management features are implemented via the System Management Interrupt(SMI). Sleep and Suspend power management modes are supported. Power to the hard disk drives and video monitors can be managed by this AWARD BIOS.

DRAM Support

DDR SDRAMs (Double Data Rate SDRAM) are supported.

CPU Support

This AWARD BIOS supports the Intel P4 Processor.

Setup Menu

In general, you use the arrow keys to highlight items of the Main BIOS Setup Menu, press <Enter>to select, use the <PgUp>and <PgDn>keys to change entries, press<F1>for help and press <Esc> to quit The following table provides more detail about how to navigate in the Setup program by using the keyboard.

Note:

(BIOS version 1.0 is for reference only. If there is a change in BIOS version, please use the actual version on the BIOS.)

Keystroke	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left(menu bar)
Right arrow	Move to the item on the right(menu bar)
Esc	Main Menu: Quit without saving changes Submenus: Exit Current page to the next higher level menu
Move Enter	Move to item you desired
PgUp key	Increase the numeric value or make changes
PgDn key	Decrease the numeric value or make changes
+Key	Increase the numeric value or make changes
-Key	Decrease the numeric value or make changes
Esc Key	Main menu-Quit and not save changes into CMOS Status Page Setup Menu and option Page Setup Menu-Exit Current page and return to Main Menu
F1 Key	General help on Setup navigation keys.
F5 Key	Load previous values from CMOS
F6 Key	Load the fail-safe defaults from BIOS default table
F7 Key	Load the optimized defaults
F10 Key	Save all the CMOS changes and exit

Standard CMOS Features

This setup page includes all the items in standard compatible BIOS.

Advanced BIOS Features

This setup page includes all the items of the BIOS special enhanced features.

Advanced Chipset Features

This setup page includes all the items of the Chipset special enhanced features.

Integrated Peripherals

This selection page includes all the items of the IDE hard drive and Programmed Input/Output features.

Power Management Setup

This setup page includes all the items of the power management features.

PnP/PCI Configurations

This setup page includes the user defined or default IRQ Setting.

PC Health Status

This page shows the hardware Monitor information of the system.

Frequency/Voltage Control

This setup page controls the CPU's clock and frequency ratio.

Load Fail-safe Defaults

Use this menu to load the BIOS default values for the minimal/stable performance for your system to operate.

Load Optimized Defaults

These settings are for configuring a workable computer when something is wrong. If you cannot boot the computer successfully, select the BIOS Setup options and try to diagnose the problem after the computer boots. These settings do not provide optional performance.

Set Supervisor/User Password

Change, set, or, disable password. It allows you to limit access to the system and Setup, or just to Setup.

Save & Exit Setup

Save CMOS value changes to CMOS and exit setup.

Exit Without Saving

Abandon all CMOS value changes and exit setup.

2.3 Standard CMOS Features

This main option in the Standard CMOS Setup Menu is divided into 10 fields or items. Each field provides one or more setup choices. Use the arrow keys to highlight the field and then use the <PgUp> or <PgDn> keys to select the value or choice.

Phoenix - AwardBIOS CMOS Setup Utility Standard CMOS Features

Date(mm:dd:yy)	Tue,Jun 6 2002	Item Help
Time (hh:mm:ss)	11:26:10	
IDE Primary Master	None	Menu Level
IDE Primary Slave		Change the day, month,year and century.
IDE Secondary Master		
IDE Secondary Master	None	
Drive A	1.44M,3.5 in	
Drive B	None	
Floppy 3	Disabled	
Video	EGA/VGA	
Halt On	All,But Keyboard	
Base Memory	640K	
Extended Memory	65472K	
Total	1024K	

←→↑↓: Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

Main Menu Selections

Item	Options	Description
Date (mm : dd :yy)	Month Day Year	Set the system,date. Note that the 'Day' automatically changes when you set the data.
Time (hh : mm : SS)	Hour Minute Second	Select the hour, minute and second of the time.
IDE Primary Master	Options are in its sub menu.	Press<Enter> to enter sub menu.
IDE Primary/ Slave	Options are in its sub menu.	Press<Enter> to enter sub menu.
IDE Second- ary Master	Options are in its sub menu.	Press<Enter> to enter sub menu.
IDE Second- ary Slave	Options are in its sub menu.	Press<Enter> to enter sub menu
Drive A Drive B	None 360K,5.25in, 1.2M,5.25in 720K,3.5M 1.44M,3.5in 2.88M,3.5in	Select the type of floppy disk drive installed in your system.
Floppy 3 Mode Support	Disabled Driver A Driver B Both	Disable or support the 3rd floppy mode in Drive A, or Drive B or both.
Video	EGA/VGA CGA 40 CGA 80 MONO	Select the default video device.

Item	Options	Description
Halt On	All Errors No Errors All, but Keyboard All, but Diskette All, but Disk/Key	Select the situation in which you want the BIOS to stop the POST process and notify.
Base Memory	(640K)	The amount of conventional memory detected during boot up.
Extended Memory	(65472K)	The amount of conventional memory detected during boot up.
Total Memory	(1024K)	The total memory available in system.

IDE Primary(Master/Slave)/Secondary(Master/Slave)

Press Enter on these items to show the following sub-menu:

Primary Master/Secondary

IDE HDD Auto-Detection	Press Enter Item Help	
IDE Primary Master	Auto	Menu Level
Access Mode	Auto	
Capacity	13022MB	
Cylinder	25232	
Head	16	
Precomp	0	
Landing Zone	25231	
Sector	61	

IDE HDD Auto-Detection

Press Enter on this item to let BIOS auto-detect your Hard Disk and show all the Primary Hard Disk Parameters (Capacity, Cylinder, Head, Precomp, Landing Zone, Sector) on the menu.

IDE Primary(Master/Slave)/Secondary(Master/Slave)

This item allows you to detect the Hard Disk in 3 ways.

The Choices: Auto: BIOS Auto-detect HDD;
None: No Hard Disk detected;
Manual: Manually detect HDD

Access Mode

This item allows you to select the Access mode to the Hard Disk..

The Choices:

CHS: Select the Cylinder, Head, Sector addressing mode to access Hard Disk;

LBA: Select the Logical Block Addressing mode to access Hard Disk.

Large: Select Large Mode to access Hard Disk;

Auto: Allow BIOS to auto-access Hard Disk;

Capacity

Showing the capacity of Hard Disk in MB.

Cylinder

Showing the number of cylinder in the Hard Disk.

Head

Showing the number of heads in the Hard Disk.

Precomp

The number of Pre-compensation.

Landing Zone

Number of Landing zone in the Hard Disk.

Sector

The number of Sector in the Hard Disk.

2.4 Advanced BIOS Features

Phoenix - AwardBIOS CMOS Setup Utility Advanced BIOS Features

Virus Warning	Disabled	Item Help
CPU L1 & L2 Cache	Enabled	
Quick Power On Self Test	Enabled	
First Boot Device	Floppy	
Second Boot Device	HDD-0	
Third Boot Device	LS-120	
Boot Other Device	Enabled	
Swap Floppy Drive	Disabled	
Boot Up Floppy Seek	Disabled	
Boot Up NumLock Status	On	
Gate A20 Option	Fast	
Typematic Rate Setting	Disabled	
X Typematic Rate (Chars/Sec)	6	
X Typematic Delay (Msec)	250	
Security Option	Setup	
APIC Mode	Disabled	
x MPS Version Control For OS	1.4	
OS Select For DRAM >64MB	Non-OS2	
HDD S.M.A.R.T. Capability	Disabled	
Report No HDD for Win95	No	
Video BIOS Shadow	Enabled	
EPA / (H/W Monitor) Show	H/W Monitor	

←→↑↓: Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

Virus Warning

This option allows you to choose the VIRUS Warning feature for IDE Hard Disk boot sector protection. If this function is enabled and someone attempts to write data into this area, BIOS will show a warning message on screen and alarm beep.

The Choices:

Disabled(default), Enabled.

CPU L1 & L2 Cache

These fields allow you to Enable or Disable the CPU's L1 (Internal) / L2 (External) cache to provide better performance.

The choices:

Enabled (default); Disabled

Quick Power On Self Test

This category speeds up Power on self-Test (POST) after you power up the computer. If it is set to Enabled, BIOS will shorten or skip some check items during POST.

The choices:

Enabled (default); Disabled

First/Secondary/Third Boot Device

This BIOS attempts to load the operating system from the devices in the sequence selected in these items.

The Choices:

Floppy (default), LS120, HDD-0, SCSI, CDROM, HDD-1, HDD-2, HDD-3, ZIP100, LAN, USB-FDD, USB-Zip, USB-CDROM, USB-HDD, Disabled.

Boot Other Device

Allows user to set booting from other devices.

The Choices:

Enabled (default), Disabled.

Swap Floppy Drive

If the system has two floppy drives, you can swap the logical drive name assignments.

The Choices:

Disabled (default), Enabled.

Boot Up Floppy Seek

If enabled, this item allows BIOS to test floppy drives to determine whether they have 40 or 80 tracks.

The Choices:

Disabled (default), Enabled.

Boot Up NumLock Status

Select power on state for Numlock..

The Choices

On (default): Numpad is number keys;

Off: Numpad is arrow keys;

Gate A20 Option

Select if chipset or keyboard controller should control Gate A20.

The choices:

Normal: A pin in the keyboard controller controls Gate A20.

Fast (default): Lets chipset control Gate A20.

Typematic Rate Setting

Allows user to adjust the key stroke repeat rate.

The choices:

Enabled: Enabled this option to adjust the keystroke repeat rate; Disabled (default): Disabled.

Typematic Rate (Char/Sec)

Range between 6(**default**) and 30 characters per second. This option controls the speed of repeating keystrokes.

Typematic Delay (Msec)

This option sets the time interval for displaying the first and the second characters.

The Choices: 250(default), 500, 750, 1000.

Security Option

This category allows you to determine whether to use password access the system and Setup, or just Setup.

The choices:

System: To access system and BIOS Setup with correct password.

Setup (default): To access BIOS Setup with correct password.

APICMode

Allows user to disable/enable the APIC mode
The Choices: Disabled; Enabled

x MPS Version Control For OS

If APIC mode is enabled, this item allows user to select the MPS Version Control For OS.
The choices: 1.4; 1.1

OS Select For DRAM >64MB

Select the operating system that is running with greater than 64MB of RAM on the system.
The Choices: Non-OS2(default), OS2.

HDDS.M.A.R.T.Capability

Allows user to choose the Self-monitoring Analysis and Reporting Technology for Hard Disk Drive.
The choices: Disabled(default); Enabled

Report No FDD for Win 95

Use this item to report no FDD for Win 95.
The choices: No; Yes

Video BIOS Shadow

Use this item to enable/disable the Video BIOS Shadow function
The choices: Enabled; Disabled

EPA/(H/W Monitor) Show

Use this item to enable/disable the Environmental Protection Association (EPA)/ Hardware Monitor) logo on initiating screen..
The choices: H/W Monitor; EPA Logo

2.5 Advanced Chipset Features

This section allows you to configure the system based features of the installed chipset. This chipset manages bus speeds and access to system memory resources, such as DRAM and external cache. It also coordinates communications of the PCI bus and AGP interface.

Phoenix - AwardBIOS CMOS Setup Utility Advanced Chipset Features

		Item Help
▶ DRAM Clock/Timing Control	Press Enter	
Performance Mode	Disabled	
DRAM Timing Control	By SPD	
x DRAM CAS Latency	2.5T	
x RAS Active Time(tRAS)	6T	
x RAS Precharge Time (tRP)	3T	
x RAS to CAS Delay (tRCD)	3T	
▶ AGP & P2P Bridge Control	Press Enter	
AGP Aperture Size	64MB	
Graphic Window WR Combin	Disabled	
AGP Fast Write Support	Enabled	
AGP Data Rate	Auto	
▶ OnChip AGP Control	Press Enter	
Dual Display Support	Disabled	
VGA Share Memory Size	32 MB	
Hot Key Support	Disabled	
OSD Support	Disabled	
Display logo while POST	Disabled	
Display Device Setting	Disabled	
x Display Device	CRT1	
x TV Device SElect	None	
LCD Setting	Disabled	
x LCD Display Type	Full Screen	
x LCD Panel Resolution	1024 x 768	
TV Setting	Disabled	
x TV Display Mode	NTSV	
x TV Display Type	Under Scan	
x YPbPr Mode	525i	
System BIOS Cacheable	Enabled	
Video RAM Cacheable	Enabled	
Memory Hole at 15M-16M	Disabled	

←→↑↓: Move Enter>Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

► **DRAM Clock/Timing Control:** Press <Enter> to reveal the following submenu.

Performance Mode

The Choices: Enabled; Disabled

DRAM Timing Control

Use this item to select the DRAM Clock/Timing mode.

The Choices:

By SPD: DRAM Timing is by Serial Presence Detect (SPD) which is located on the memory module itself.

Manual: DRAM Timing is set manually with the options following this item below.

X DRAM CAS Latency

This item is to set CAS (Column Access Stroke) Latency time.

The Choices: 2T; 2.5T; 3T

X RAS Active Time (tRAS)

This item is to set Active to Precharge Delay cycle.

The Choices: 4T; 5T; 6T; 7T; 8T; 9T

X RAS Precharge Time (tRP)

This item is to set the RAS (Row Access Stroke) Precharge cycle.

The Choices: 2T; 3T; 4T; 5T

X RAS to CAS Delay (tRCD)

This item is to set the RAS to CAS (Column Access Stroke) Delay cycle.

The Choices: 2T; 3T; 4T; 5T

▶ **AGP & P2P Bridge Control:** Press <Enter> to reveal the following submenu.

AGP Aperture Size

Select the size of the Accelerated Graphic Port(AGP) aperture . The aperture is a portion of the PCI memory address range dedicated for graphics memory address space. Host cycle that hit the aperture range are forwarded to the AGP without any translation.

The Choices: 128MB; 64MB(default);,32MB; 16MB; 8MB; 4MB; 256MB

Graphic Window WR Combin

Use this item to enable/disable the Graphic Window Write Combin function.

The choices: Enabled; Disabled

AGP Fast Write Support

The Choices: Enabled; Disabled

AGP Data Rate

The Choices: Auto; 1.x; 2x; 4x; 8x

►**OnChip AGP Control:** Press <Enter> to reveal following submenu.

Dual Display Support

The Choice: Disabled; Enabled

VGA Share Memory Size

The Choice: 16 MB; 32 MB; 64 MB; 128 MB

Hot Key Support

The Choice: Disabled; Enabled

OSD Support

The Choice: Disabled; Enabled

Display Logo While POST

The Choice: Disabled; Enabled

Display Device Setting

The Choice: Disabled; Enabled

While enabled, it provides two options.

x Display Device

The Choice: CRT1; CRT1+LCD; CRT1+TV; CRT1+CRT2

x TV Device Select

The Choice: None; Composite TV; S-video TV; SCART;
Hi-vision TV; YPbPr

LCD Setting

The Choice: Disabled; Enabled

While enabled, it provides two options.

x LCD Display Type

The Choice: Full Screen; Center Screen

x LCD Panel Resolution

The Choice: 1024x768; 1280x1024; 1400x1050; 1688x806;
1600x1200;1408x806;

TV Setting

The Choice: Disabled; Enabled

While enabled, it provides 3 options.

x TV Display Mode

The Choice: NTSC; NTSC-J; PAL; PAL-M; PAL-N

x TV Display Type

The Choice: Under Scan; Over Scan

YPbPr Mode

The Choice: 525i; 525p; 750p; 1080i

System BIOS Cacheable

The Choices: Disabled; Enabled

Video RAM Cacheable

The Choices: Disabled; Enabled

Memory Hole At 15-16M

The Choices: Disabled; Enabled.

2.6 Integrated Peripherals

Phoenix - AwardBIOS CMOS Setup Utility Integrated Peripherals

<ul style="list-style-type: none"> ▶ SiS OnChip IDE Device Press Enter Internal PCI/IDE Both IDEPrimary Master PIO Auto IDE Primary Slave PIO Auto IDE Secondary Master PIO Auto IDESecondary Slave PIO Auto Primary Master Ultra DMA Auto Primary Slave Ultra DMA Auto Secondary Master Ultra DMA Auto Secondary Slave Ultra DMA Auto IDE Burst Mode Enabled 	Item Help
<ul style="list-style-type: none"> ▶ SiS OnChip PCI Device Press Enter SiS USB Controller Enabled USB Ports Number 6 Ports USB 2.0 Controller Enabled USB Keyboard Support Enabled USB Mouse Support Enabled SiS AC97 Audio Enabled SiS 10/100M Ethernet Enabled SiS 1394 Controller Enabled 	
<ul style="list-style-type: none"> ▶ Onboard Super IO Device Press Enter Onboard HDC Controller Enabled Onboard Serial Port 1 3F8/IRQ4 Onboard Serial Port 2 2F8/IRQ3 UART Mode Select Normal x UR2 Duplex Mode Half Onboard Parallel Port 378/IRQ7 Parallel Port Mode ECP ECP Mode Use DMA 3 Game Port Address 201 MIDI Port Address 330 MIDI Port IRQ 10 	
<ul style="list-style-type: none"> IDE HDD Block Mode Enabled Init Display First PCI Slot 	

←→↑↓: Move Enter>Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
 F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

SiS On-Chip IDE Device: Press Enter to configure the following submenu:

Internal PCI/IDE

Use this item to choose the ePCI/IDE mode.

The choices: Both; Disabled; Primary; Secondary

IDE Primary Master/Slave PIO

Auto (default):BIOS will automatically detect the IDE HDD Accessing mode.

Mode 0~4: Manually set the IDE Accessing mode.

IDE Secondary Master/Slave PIO

Auto (default):BIOS will automatically detect the IDE HDD Accessing mode.

Mode 0~4: Manually set the IDE Accessing mode.

Primary Master/Slave Ultra DMA

Auto (default):BIOS will automatically enable Ultra DMA mode of the IDE HDD Accessing .

Disabled: UDMA mode is disabled

Secondary Master/Slave Ultra DMA

Auto (default):BIOS will automatically enable the Ultra DMA mode of the IDE HDD Accessing mode.

Disabled: Ultra DMA disabled.

IDE Burst Mode

Use this item to enable/disable the IDE Burst mode.

SiS On-Chip PCI Device: Press Enter to configure the following submenu:

SiS USB Controller

Use this item to enable or disable the USB Controller.

The Choices: Enabled (default); Disabled

USB Ports Number

Use this item to select the USB ports supported

The Choices: 6 Ports; 5 ports; 4 ports; 3 ports

USB 2.0 Controller

If USB Controller is enabled, use this item to enable or disable USB 2.0 controller.

The Choices: Enabled (default); Disabled

USB Keyboard/Mouse Support

Use this item to enable or disable the USB Keyboard / Mouse support.

The Choices: Enabled; Disabled

SiS AC97 Audio

Use this item to enable/disable the AC97 Audio/ SW Modem function.

The Choices: Enabled; Disabled

SiS 10/100 METHERNET

Use this item to enable or disable the 10/100 Ethernet controller.

The Choices: Enabled; Disabled

SiS 1394 Controller

Use this item to enable or disable the 1394 Controller.

The Choices: Enabled; Disabled

Onboard Super IO Device: Press Enter to configure the following submenu:

Onboard FDC Controller

The choices: Enabled (default) Disabled

Onboard Serial Port 1/2

Select an address and corresponding interrupt for the first and second serial ports.

The Choices: Auto; 3F8/IRQ4; 2F8/IRQ3; 3E8/IRQ4; 2E8/IRQ3; Disabled.

UART Mode Select

This item allows you to select which Infra Red(IR) function of the onboard I/O chip you wish to use.

The Choices: Normal(default), IrDA, SCR, ASKIR.

UR2 Duplex Mode

This item allows you to select which Infra Red(IR) function of the onboard I/O chip you wish to use.

The Choices: Half (default), Full.

Onboard Parallel Port

This item allows you to select the onboard parallel port and IRQ.

The Choices: 378/IRQ7; 278/IRQ5; 3BC/IRQ7; Disabled

Parallel Port Mode

The choices are for Parallel Port Mode select:

The choices: SPP; EPP; ECP; ECP+EPP

ECP Mode Use DMA

The Choices: 3(default), 1.

Game Port Address

The choices are for setting Game Port Address:

201 (default); 209; Disabled

MIDI Port Address

The choices are for setting MIDI Port Address:

300; 330 (default); Disabled.

MIDI Port IRQ

The choices are for setting MIDI Port IRQ:

10 (default); 5

IDE HDD Block Mode

If your IDE HDD supports block mode select, enabled is for automatic detection of the optimal number of block read/write per sector the drive can support..

The Choices: Enabled(default); Disabled

Init Display First

Use this item to enable or disable the onboard USB controller.

The Choices: PCI Slot(default); AGP

2.7 Power Management Setup

Phoenix - AwardBIOS CMOS Setup Utility

Power Management Setup

ACPI Function	Enabled	Item Help
ACPI Suspend Type	S1(POS)	
Power Management	User Define	
Suspend Mode	Disabled	
HDD Off After	Disabled	
Video Off Option	Suspend --> Off	
Video Off Method	V/H Sync+Blank	
Modem Use IRQ	3	
Soft-off by PWRBTN	Instant Off	
PWRON After PWR-Fail	Always Off	
▶ PM Wake Up Events	Press Enter	
Power On by PS/2KB	Hot Key	
Power On by PS2MS	Disabled	
Power On By USB	Disabled	
Power On By PME	Disabled	
Power On by WOL	Disabled	
Power On By Modem Ring	Disabled	
RTC Alarm Resume	Disabled	
X Month Alarm	NA	
X Date (of Month) Alarm	0	
X Time(hh:mm:ss) Alarm	0 : 0 : 0	

←→↑↓: Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
 F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

ACPI Function

Use this item to enable/disable the ACPI function.

The choices: Stop Grant(default); Power On Suspend

ACPI Suspend Type

The choices are for setting the ACPI Suspend Type.

S1(Power On Suspend)(default); S3(Suspend To RAM); S1&S3

Power Management

The choices are for setting the Power management mode:

User Define (default); Min Saving; Max Saving.

Suspend Mode

Use this item to set the Suspend time.

The choices: Disabled(default); 1~60 min.

HDD Off After

Use this item to set the HDD Off After time.

The choices: Disabled; 1~15 min..

Video Off Option

The choices are for setting the Video Off option:

Suspend --> Off; Susp, Stby --> Off; All Modes --> Off;

Always On

Video Off Method

The choices are for determining the manner in which the monitor is blanked.

The choices:

V/H SYNC+Blank (default): Turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.

Blank Screen: Writes blanks to the video buffer.

DPMS Supported: Initial display power management signaling.

Modem Use IRQ

This determines the IRQ, which can be applied in Modem use.

The choices: 4;5; 7; 9; 10; 11; Auto (default)

Soft-off by PWRBTN

Use this item to set the Soft-off by power button mode.

The choices: Instant Off; Delay 4 Sec.

PWRON After PWR-Fail

Use this item to set the Power On After Power Fail mode.
The Choices: Always Off; Always On; Keep Pre-state

▷ PM Wake Up Events: Press <Enter> to configure the following:**Power On By PS/2KB**

Use this item to enable/disable the Power On by PS/2 Keyboard function.

Power On By PS/2 MS

Use this item to enable/disable the Power On by PS/2 Mouse.

Power On By USB

Use this item to enable/disable the Power On by USB function..

Power On By PME

Use this item to enable/disable the Power On by PME function

Power On By WOL

Use this item to enable/disable the Power On by WOL function

Power On By Modem Ring

Use this item to enable/disable the Power On by Modem Ring signal.

RTC Alarm Resume

Use this item to enable/disable the RTC Alarm Resume function.

x Month Alarm

Use this item to set the Month Alarm (if RTC alarm Resume is enabled).

Choices:NA; 1~12 (Choose the month)

x Date of Month Alarm

Choose the date (from 1 to 31) alarm

x Time (hh:mm:ss) Alarm

Choose the time (hour:minute:second) alarm

2.8 PnP/PCI Configurations

This section describes configuration of the PCI bus system. PCI or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself when communicating with the components on board. This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.

Phoenix - AwardBIOS CMOS Setup Utility PnP/PCI Configurations

Reset Configuration Data	Disabled	Item Help
Resources Controlled By x IRQ Resources	Auto(ESCD) Press Enter	
PCI/VGA Palette Snoop	Disabled	

←→↑↓: Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

Reset Configuration Data

The system BIOS supports the PnP feature so the system needs to record which resource is assigned and proceeds to get rid of resource conflict. Every peripheral device has a node, which is called ESCD (Extended System Configuration Data). This node records which resources are assigned to it. If Disabled (Default) is chosen, the system ESCD will update only when the new configuration varies from the last one. If Enabled is chosen, the system is forced to update ESCDs and then is automatically reset to the “Disabled” mode.

Resources Controlled By

By Choosing “Auto”(default), the system BIOS will detect the system resources and automatically assign the relative IRQ and DMA channel for each peripheral. By choosing “Manual”, the user will need to assign IRQ & DMA for add-on cards. Be sure that no IRQ/DMA and I/O port conflict exists.

IRQ Resources :

Press Enter to configure the following Submenus

IRQ Resources

IRQ-3 assigned to	: PCI Device	Item Help
IRQ-4 assigned to	: PCI Device	
IRQ-5 assigned to	: PCI Device	
IRQ-7 assigned to	: PCI Device	
IRQ-9 assigned to	: PCI Device	
IRQ-10 assigned to	: PCI Device	
IRQ-11 assigned to	: PCI Device	
IRQ-12 assigned to	: PCI Device	
IRQ-14 assigned to	: PCI Device	
IRQ-15 assigned to	: PCI Device	

IRQ Resources

When resources are controlled manually, assign each system interrupt a type, depending on the type of device using the interrupt.

PCI/VGA Palette Snoop

Choose Disabled or Enabled. Some graphic controllers which are not VGA compatible take the output from a VGA controller and map it to their display as a way to provide boot information and VGA compatibility.

However, the color information coming from the VGA controller is drawn from the palette table inside the VGA controller to generate the proper colors, and the graphic controller needs to know what is in the palette of the VGA controller. To do this, the non-VGA graphic controller watches for the write access to the VGA palette and registers the snoop data. In PCI based systems, the Write Access to the palette will not show up on the ISA bus if the PCI VGA controller responds to the Write.

In this case, the PCI VGA controller should not respond to the Write, it should only snoop the data and permit the access to be forwarded to the ISA bus. The non-VGA ISA graphic controller can then snoop the data on the ISA bus. Unless you have the above situation, you should disable this option.

The choices: Disabled (default); Enabled

2.9 PC Health Status

Phoenix - AwardBIOS CMOS Setup Utility

PC Health Status

	Item Help
Vcore	
Vcc 3.3V	
Vcc 5.0V	
Vcc 12.0V	
Vsb 5.0V	
Voltage Battery	
CPU Temperature	
System Temperature	
Fan 1 Speed	
Fan 2 Speed	
Fan 3 Speed	

←→↑↓: Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

This menu shows the current status of the system, CPU and CPU Fan. No value in this menu can be changed manually.

Vcore /+3.3V/+5V/12V/5Vsb

These items show the respective voltage running on board.

Voltage Battery

These items show the battery voltage used on board.

CPU/System Temp

This item shows the current System/CPU temperature.

FAN1/2/3 Speed

This item shows the fan speed running on board.

2.10 Frequency/Voltage Control

Phoenix - AwardBIOS CMOS Setup Utility Frequency/Voltage Control

CPU Clock Ratio	10 X	Item Help
Auto Detect DIMM/PCI CLK	Enabled	
Spread Spectrum	+/- 0.25%	
CPU Clock	100	
CPU:DRAM Frequency Ratio	SPD	
DRAM Frequency	133 MHz	
CPU0 Skew Adjust	Disabled	
CPU1 Skew Adjust	Disabled	
DRAM Skew Adjust	Disabled	
AGP Skew Adjust	Disabled	
PCI0 Skew Adjust	Disabled	
PCI1 Skew Adjust	Disabled	
ZClk Skew Adjust	Disabled	

←→↑↓: Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

CPU Clock Ratio

Use this item to set CPU Clock Ratio.

The Choices: 8X ~50X in 1X stepping

AutoDetectDIMM/PCICLK

This item allows you to enable/disable auto detect DIMM/PCI CLOCK.

The Choices: Disabled; Enabled (default)

Spread Spectrum

This function is designed for the EMI test only.

The Choices: Disabled; +/- 0.25; +/- 0.35; +/- 0.45; -0.5

CPU Frequency

Use this item to set CPU Clock .

The Choices: 100~232 MHz in 1MHz stepping

CPU:DRAM Frequency Ratio

Use this item to set the CPU:DRAM Frequency Ratio.

The choices: SPD; 1:1;3:4;3:5;1:2;

xDRAM Frequency

This item will show the DRAM Frequency with the CPU:DRAM frequency Ratio.

CPU0/1 Skew Adjust

This item allows you to enable/disable the CPU0/1 signal distance adjust.

The Choices: Disabled; Enabled

DRAM Skew Adjust

This item allows you to enable/disable the DRAM signal distance adjust.

The Choices: Disabled; Enabled

AGP Skew Adjust

This item allows you to enable/disable the AGP signal distance adjust.

The Choices: Disabled; Enabled

PCI0/1 Skew Adjust

This item allows you to enable/disable the PCI0/1 signal distance adjust.


The Choices: Disabled; Enabled

ZClk Skew Adjust

This item allows you to enable/disable the ZClk signal distance adjust.

The Choices: Disabled; Enabled

2.13 Set Supervisor / User Password



When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

Enter Password (for Supervisor/User)


Type a password, up to eight characters, and press <Enter>. The password you type now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <ESC> to abort the selection and not enter a password. To disable the password, just press <Enter> when you are prompted to enter a password. A message will confirm that you wish to disable the password. Once the password is disabled, the system will boot without asking user to enter a password.

Password for System or BIOS Setup

If you select “System” at the Security Option of BIOS Features Setup Menu, you will be prompted for the password every time when the system is rebooted, or any time when you try to enter Setup. If you select “Setup” at the Security Option of BIOS Features Setup Menu, you will be prompted only when you try to enter Setup.

2.15 Exit Without Saving

Phoenix - AwardBIOS CMOS Setup Utility



Typing “Y” will quit the Setup Utility without saving to RTC CMOS RAM.

Typing “N” will return to the Setup Utility.

Chapter 3

Drivers & Utilities

3. Drivers & Utilities

There are motherboard drivers and utilities included in the disc attached in this motherboard package. You don't have to install all of them for booting your system. But after you have finished the hardware installation, you have to install an operation system (such as windows XP) before you are able to install any drivers or utilities.

Note: Please be aware of the different Procedures for installing drivers for Windows 98/ME/XP/2000 .

3.1 Auto-run Menu

You can use the auto-run menu in the driver CD attached in the motherboard package. Then choose the utility or driver and select model name. The autorun starting screen looks like below:

(1) The SiS Auto-run CD Main Menu



(2) SiS DriverSetup Main Menu: Point to the "Driver" button with the mouse for SiS Drivers Setup.



(3) Click to the "Driver" button and the Drivers Setup List will appear as below:



3.2 Installing IDE Driver


Mouse-click on the "IDE Driver" item on the main menu to install the IDE drivers, and the InstallShield Wizard will start to run instantly.



(1)
Click "IDE Driver" item
to continue.



(2)
Click "Next" to
continue.



(3)
Click "Next" button to
continue.




(4)
Click "Finish" button
and restart system to put
the IDE driver into effect.

3.3 Installing LAN Driver


Mouse click the "LAN Driver" item to install the built in LAN driver. The InstallShield Wizard will start to run instantly.



(1)
Click on the "LAN Driver"
item to start LAN driver
setup.



(2)
Click "Next" button to
continue.



(3)
In a few seconds, Setup
completes. Click "Finish"
button to restart system and
complete setup.


3.4 Installing Audio Driver

Mouse click the "Audio Driver" item on the Main Menu to set up the Audio driver. The InstallShield Wizard will start to run instantly.


3.4.1 Installing 6-channel Driver



(1)
Click "Audio Driver" bar to continue.




(2)
Click "Next" button to continue.




(3)
In a few seconds, setup completes. Click the "Finish" button to restart system and complete setup.

3.4.2 Verifying 6-channel Driver

(1) Click the Audio Manager "Sound Effect" on the Start Screen.



(2)
Click "Speaker Configuration" button to configure the Audio connectors on mainboard.



(3)
 Follow the instructions on the screen to configure the Audio connectors on board.



(4)
 Click "Speaker Test" button to test the 6-channel speakers.

3.5 Installing USB 2.0 Driver


Mouse click the "USB2.0" item to install the SiS USB 2.0 driver. The InstallShield Wizard will start to run instantly.



(1)
Click the "USB 2.0" item to install USB 2.0 driver. "



(2)
Click the "Yes" button to continue.



(2)
Click "Accept" button to agrto the License Agreement and continue

(4) In a few seconds, Setup completes. Click "Yes" button to resatart system and complete setup.




3.6 Installing VGA Driver




(1)
Select the "SiS VGA Driver" item to continue.



(2)
Select the operating system running in your PC.



(3)
Instantly, the "InstallWizard" is exposed on screen and will guide you through the whole VGA driver setup.



(4)
Next screen will show
that installation of
Xminator II will go on.




(5)
When the "Setup
Complete" screen
appears, click to the
"Tick" icon button to
finish setup.

3.7 Installing AGP Driver


If an external AGP card is used, user should install the "Acceleration Graphic Driver" instead of the "VGA Driver".



(1)
Click "Acceleration Graphic Driver" item to continue.



(2)
Click "Next" button to continue.



(3)
Click "Next" button to
continue.



(4)
Click "Finish" button to
restart system so as to
put the just installed
driver into effect.

Appendix I On Model 4S661QP

Motherboard Compatibility Test

(1) CPU Compatibility Test

System Configuration	Workstation - 1	Workstation - 2	Workstation - 3	Workstation - 4					
Memory	HYNIX PC-266								
	CHINA 256MB*2								
Display Card	HYSDV28822AT-H								
	ON BOARD								
Hard Drive	QUANTUM 20G AS2000DAT								
CD-ROM	LEMEL 50X 493-3450								
Power Supply	ENLIGHT HPC-340-101(110W)								
Nucleus	Model	CLK	Voltage	Bus Speed	CPU S.P.E.C	Stepping	RESET 10 Time	PW On/Off 10 Time	CC WS 2002 Test
HYPERTRONIC	3.20	800	1.5V		QWN2ES		PASS	PASS	36.1
HYPERTRONIC	3.00	800	1.525V		SL6WK		PASS	PASS	34.8
HYPERTRONIC	2.80	800	1.5V		SL6WJ		PASS	PASS	34.7
HYPERTRONIC	2.60	800	1.5V				PASS	PASS	32.7
HYPERTRONIC	2.40	800	1.5V		SL6WF		PASS	PASS	31.2
HYPERTRONIC	3.060	533	1.5V		SL6S5	C1	PASS	PASS	34.9
HYPERTRONIC	2.660	533	1.5V				PASS	PASS	32.1
NORTHWOOD	2.80	533	1.5V				PASS	PASS	33.7
NORTHWOOD	2.660	533	1.5V		SL6SK	C1	PASS	PASS	32.3
NORTHWOOD	2.530	533	1.5V			C01	PASS	PASS	32.9
NORTHWOOD	2.480	533	1.5V		QM16ES		PASS	PASS	31
NORTHWOOD	2.260	533	1.5V		SL683		PASS	PASS	30.8
NORTHWOOD	2.60	400	1.5V				PASS	PASS	32.8
NORTHWOOD	2.40	400	1.5V		SL67R	B0	PASS	PASS	27.1
NORTHWOOD	2.0A0	400	1.5V		SL5VR	B0	PASS	PASS	28.8
NORTHWOOD	1.8A0	400	1.5V		SL680		PASS	PASS	26.4
NORTHWOOD	1.6A0	400	1.5V		SL668	B0	PASS	PASS	25.1
CELERON	2.60	400	1.5V		QYDQES		PASS	PASS	24
CELERON	2.40	400	1.5V		QWV8ES		PASS	PASS	23
CELERON	2.30	400	1.5V		SL672		PASS	PASS	22.9
CELERON	2.20	400	1.5V		QWV2ES		PASS	PASS	22.3
CELERON	2.10	400	1.5V		QVY6ES		PASS	PASS	22
CELERON	2.00	400	1.5V		QPF7ES		PASS	PASS	18.5
CELERON	1.80	400	1.75V		SL6A2		PASS	PASS	21.3
CELERON	1.70	400	1.75V		SL68C		PASS	PASS	17.6
WILLAMETTE	2.00	400	1.75V		SL5TL	D0	PASS	PASS	26
WILLAMETTE	1.90	400	1.75V		SL5YG	D0	PASS	PASS	25.4
WILLAMETTE	1.80	400	1.75V		SL5UK	D0	PASS	PASS	24.3
WILLAMETTE	1.70	400	1.75V		SL5N9	C1	PASS	PASS	23.7
WILLAMETTE	1.50	400	1.75V		SL5N8		PASS	PASS	22.2

Appendices

(2) Memory Compatibility Test

System Configuration	Workstation - 1	Workstation - 2	Workstation - 3
Processor	HYPER THREADING 3.06G/533	NORTHWOOD 2.66G/533	NORTHWOOD 2.8G/533
	ELSA	ON BOARD	ON BOARD
Display Card	GLDVIAC 921		
	SEAGATE 20G ST320414A	QUANTUM 20G AS20000AT	QUANTUM 20G AS200000AT
Hard Drive	ACER 52X 652P-073	CREATIVE 52X CD5233E	CREATIVE 52X CD5233E
	CHANNEL WELL CWT-300ATX12(110V)	SHARK HPS 300-101(110V)	SHARK HPS 300-101(110V)

Module Vendor	IC_Vender	IC_Serial Numbers	CAPACITY	SIDE	DRAM CLK	Location	
1	Adata	ADATA	ADD8608A8A-4.5B	256M	S	450	DIMM 1,2
1	Adata	ADATA	ADD8608A8A-5B	256M	S	400	DIMM 1,2
2	Adata	WINBOND	W942508CH-5	256M	S	400	DIMM 1,2
2	Adata	SAMSUNG	K4H560838D-TCC	256M	S	400	DIMM 1,2
1	Adata	HYNIX	HY5DU56822BT-D43	256M	S	400	DIMM 1,2
3	Kingmax	KINGMAX	KDL684T4AA-50	256M	D	400	DIMM 1,2
2	Adata	WINBOND	W942508BH-5	512M	D	400	DIMM 1,2
4	Adata	SAMSUNG	K4H560838D-TCC4	512M	D	400	DIMM 1,2
3	TwinMos	WINBOND	W942508AH-6	512M	D	333	DIMM 1,2
1	Retail	NANYA	NT5DS16M8AT-7K	512M	D	266	DIMM 1,2
2	Weblink	ELKIR	N2DS12880AT-75B	256M	D	266	DIMM 1,2
2	Apacer	INFINEON	HYB25D256800AT-7	256M	D	266	DIMM 1,2
1	PMI	PMI	PM4D328V5	256M	S	400	DIMM 1,2
1	KINGSTON	KINGSTON	D3208DLT1-5	512M	D	400	DIMM 1,2
1	KINGSTON	HYNIX	HY5DV56822BT-D43	256M	S	400	DIMM 1,2
1	Adata	ADATA	ADD8608A8A-4.5B	256M	S	450	DIMM 1
1	Adata	ADATA	ADD8608A8A-5B	256M	S	400	DIMM 1
2	Adata	WINBOND	W942508CH-5	256M	S	400	DIMM 1
2	Adata	SAMSUNG	K4H560838D-TCC	256M	S	400	DIMM 1
1	Adata	HYNIX	HY5DU56822BT-D43	256M	S	400	DIMM 1
3	Kingmax	KINGMAX	KDL684T4AA-50	256M	D	400	DIMM 1
2	Adata	WINBOND	W942508BH-5	512M	D	400	DIMM 1
4	Adata	SAMSUNG	K4H560838D-TCC4	512M	D	400	DIMM 1
3	Transcend	SAMSUNG	K4H560838C-TCB3	512M	D	333	DIMM 1
3	TwinMos	WINBOND	W942508AH-6	512M	D	333	DIMM 1
1	Retail	NANYA	NT5DS16M8AT-7K	512M	D	266	DIMM 1
2	Weblink	ELKIR	N2DS12880AT-75B	256M	D	266	DIMM 1
2	Apacer	INFINEON	HYB25D256800AT-7	256M	D	266	DIMM 1
1	PMI	PMI	PM4D328V5	256M	S	400	DIMM 1
1	GEIL	GEIL	G216L646D2T05NK3	512M	D	400	DIMM 1
1	Kingmax	KINGMAX	KDL388P4EA-50	512M	D	400	DIMM 1
1	KINGSTON	KINGSTON	D3208DLT1-5	512M	D	400	DIMM 1
1	KINGSTON	HYNIX	HY5DV56822BT-D43	256M	S	400	DIMM 1

Module Vendor	IC_Vender	IC_Serial Numbers	CAPACITY	SIDE	DRAM CLK	Location	Memtest 1.04	WS 2001 Business	
1	Adata	ADATA	ADD8608A8A-4.5B	256M	S	450	DIMM 2	PASS	26.4
1	Adata	ADATA	ADD8608A8A-5B	256M	S	400	DIMM 2	PASS	28.1
2	Adata	WINBOND	W942508CH-5	256M	S	400	DIMM 2	PASS	20.4
2	Adata	SAMSUNG	K4H560838D-TCC	256M	S	400	DIMM 2	PASS	19.2
1	Adata	HYNIX	HY5DU56822BT-D43	256M	S	400	DIMM 2	PASS	27.6
3	Kingmax	KINGMAX	KDL684T4AA-50	256M	D	400	DIMM 2	PASS	26.3
2	Adata	WINBOND	W942508BH-5	512M	D	400	DIMM 2	PASS	22.4
4	Adata	SAMSUNG	K4H560838D-TCC4	512M	D	400	DIMM 2	PASS	22.1
3	Transcend	SAMSUNG	K4H560838C-TCB3	512M	D	333	DIMM 2	PASS	22.6
3	TwinMos	WINBOND	W942508AH-6	512M	D	333	DIMM 2	PASS	25.2
1	Retail	NANYA	NT5DS16M8AT-7K	512M	D	266	DIMM 2	PASS	25.9
2	Weblink	ELKIR	N2DS12880AT-75B	256M	D	266	DIMM 2	PASS	19.2
2	Apacer	INFINEON	HYB25D256800AT-7	256M	D	266	DIMM 2	PASS	18.6
1	PMI	PMI	PM4D328V5	256M	S	400	DIMM 2	PASS	28.3
1	GEIL	GEIL	G216L646D2T05NK3	512M	D	400	DIMM 2	PASS	30
1	Kingmax	KINGMAX	KDL388P4EA-50	512M	D	400	DIMM 2	PASS	30.9
1	KINGSTON	KINGSTON	D3208DLT1-5	512M	D	400	DIMM 2	PASS	30.8
1	KINGSTON	HYNIX	HY5DV56822BT-D43	256M	S	400	DIMM 2	PASS	24.8

Appendices

(3) AGP Display Card Compatibility Test

System Configuration	WIN 2000&XP	WIN98SE	Workstation - 3	Workstation - 4			
Processor	NORTHWOOD	NORTHWOOD					
	2.4G400	2.8G533					
Memory	HYNIX PC-266	NANYA PC-266					
	CHINA 256MB*2	RETAIL 512MB					
Hard Drive	HY5DV28822AT-H	NT5DS18M8AT-7K					
	QUANTUM 20G	QUANTUM 30G					
CD-ROM	AS20000AT	AS30000AT					
	LEMEL 50X	CREATIVE 52X					
Power Supply	LCD-50AV	CD5233E					
	ENLIGHT	SHARK TECH NOLOGY					
	HPC-300-101(110V)	HPS300-101(110V)					
Win98 SE 1024 x 768 x 32 bit							
AGP Model	Vendor	AGP Mode	Driver Version	EDMARK 2001E Search Mode	Quake III Demo 001		
					frames	seconds	fps
RADEON 9700	ATI	8X	4.13.01.9069	12631	1346	9.4	143.1
GF4 Ti4200	WINFAST	8X	4.14.10.4403	7556	1346	14.6	92.1
GF4 MX440	WINFAST	8X	4.14.10.4403	5512	1346	14.2	94.9
RADEON 64M	ATI	4X	4.13.01.9069	3187	1346	18.0	74.6
Ti500	WINFAST	4X	4.14.10.4403	6843	1346	14.9	90.4
Win98 SE 800 x 600 x 16 bit							
AGP Model	Vendor	AGP Mode	Driver Version	EDMARK 2001E Search Mode	Quake III Demo 001		
					frames	seconds	fps
RADEON 9100	ATI	4X	6.14.10.6390	8994	1346	6.9	196.2
Ti4200	PROLINK	8X	4.14.10.4345	8505	1346	12.8	105.1
V7100 PRO	ASUS	4X	4.14.10.3082	4604	1346	16.3	82.8
GF2 MX200	WINFAST	4X	4.14.10.3082	2931	1346	24.6	54.6
GF2 MX400	WINFAST	4X	4.14.10.3082	4380	1346	17.0	79.1
Win 2000 1024 x 768 x 32 bit							
AGP Model	Vendor	AGP Mode	Driver Version	EDMARK 2001E Search Mode	Quake III Demo 001		
					frames	seconds	fps
VOODOO 4500	3DFX	4X	5.1.0.2600	1685	1346	33.6	40.0
9550	MARTOX	4X	5.86.32.0	1328	1346	41.0	32.8
GV-GF 1280	GIGABYTE	4X	6.14.10.3082	2270	1346	21.0	63.9
GF3 AGP 64M	WINFAST	4X	6.14.10.3082	7022	1346	6.9	193.8
XABRE 200 64M	ACORP	8X	6.14.10.3110	4119	1346	15.4	87.5
Win 2000 800 x 600 x 16 bit							
AGP Model	Vendor	AGP Mode	Driver Version	EDMARK 2001E Search Mode	Quake III Demo 001		
					frames	seconds	fps
GA-GF 2560	GIGABYTE	4X	6.14.10.3082	3346	1346	12.0	112.1
GF3 AGP 64M	TRIPLEX	4X	6.14.10.3082	4040	1346	9.3	144.7
GF4 MX440	PROLINK	4X	6.14.10.4345	6926	1346	6.4	211.6
GF2 MX440	INNO3D	4X	6.14.10.2832	3750	1346	10.2	131.6
XABRE 400 128M	ACORP	8X	6.14.10.3110	8054	1346	6.5	206.4
Win XP 1024 x 768 x 32 bit							
AGP Model	Vendor	AGP Mode	Driver Version	EDMARK 2001E Search Mode	Quake III Demo 001		
					frames	seconds	fps
RADEON 9700	ATI	8X	6.13.10.6200	12311	1346	6.1	221.2
RADEON 8500LE	ATI	4X	6.13.10.6153	8599	1346	22.4	60.1
GF4 MX440	ACORP	8X	6.14.10.4109	6396	1346	7.4	180.9
GF3 921 DVI	ELSA	4X	6.14.10.4109	8590	1346	6.6	203.3
XABRE 400 64M	ACORP	8X	6.14.10.3110	5623	1346	10.8	124.4
Win XP 800 x 600 x 16 bit							
AGP Model	Vendor	AGP Mode	Driver Version	EDMARK 2001E Search Mode	Quake III Demo 001		
					frames	seconds	fps
GF2 GTS ULTRA 64M	CREATIVE	4X	6.14.10.3082	6653	1346	6.1	220.3
Ti4600	WINFAST	4X	6.14.10.4345	12106	1346	6.0	223.3
XABRE 600 64M	ACORP	8X	6.14.10.3110	8593	1346	6.6	203.8
Ti4200	WINFAST	8X	6.14.10.4403	11648	1346	5.9	226.4
XABRE PRO 64M	TRIPLEX	8X	6.14.10.3010	8407	1346	6.6	204.7